

PCB:

136x180mm Fr4 double layer 2oz, 8mil clearance

Case (zs-8247)

(optional: color of the case: black)

Vendor Ningbo Sunyoung Enclosure Co.,Ltd Address: Room802,TianHong Building ,No 555 ,RenheRoad ,Cultural Business Zone,Cixi ,Ningbo

China 315300

Tel: +86-574-63086395 Fax: ++86-574-63086395

Mobile:+8615157753600

Skype :+8615157753600 Whats App :+

8615157753600

Wechat: cjh15157753600

E-mail: sales2@robustcasing.com

www.robustcasing.com

https://robustcase.en.alibaba.com/










Plate drill/mill guid

Front Platte



Backe Platte






Engraving/Labeling

Front




Back





Assembly


Panel Front:



On the Front Panel two IEC connectors have to be added. Left one is the male C14 and the left connector is Female C13.

Panel Back:


4 Fuse holder (20x5mm) have to be mounted on the BackPanel




!ALL cabels must have a shrinking tube




When the pcb got assembled, a few wires must be added.




P1, P2 -> 2.5mm^2 (P1 needs to be connected to IEC C14 and P2 needs to be connected to IEC C13) !ALL cabels must have a shrinking tube











P10 -> 2.5mm^2 (to Fuse 1)



P9 -> 1.5mm^2


- 1 -> Fuse2
- 2 -> Fuse3
- 3 -> Fuse2
- 4 -> Fuse3
- 5 -> Fuse 4
- 6 -> Fuse 4



!ALL cabels must have a shrinking tube



The pcb shall be placed as shown in the following picture



Finish

And in the End the fuses shall be put in like:

- Fuse1, 230VAC ~15A AC
- Fuse2, 24VDC ~4A **DC**
- Fuse3, 24VDC ~4A **DC**
- Fuse4, 24VDC ~10A DC