Multicycle operations



E. Sanchez, M. Sonza Reorda Politecnico di Torino

Dipartimento di Automatica e Informatica (DAUIN)

Torino - Italy

This work is licensed under the Creative Commons (CC BY-SA) License. To view a copy of this license, visit http://creativecommons.org/licenses/by-sa/3.0/




FLOATING-POINT OPERATIONS

- Floating point units perform more complex operations than integer ones.
- Therefore, in order to force them to perform their job in a single clock cycle, the designer should
 - either use a very slow clock, or
 - make these units very complex.
- As a popular alternative, floating point units generally require more than one clock cycle to complete.
- The EX stage is composed of different functional units, which may require as many clock cycles, as the instruction requires.

Integer Pipeline



Extension for FP



Latency and Initiation Interval

Latency

 It is the number of cycles that should last between an instruction that produces a result and an instruction that uses the same result.


Initiation interval

 It is the number of cycles that must elapse between issuing two operations of the same type to the same unit.


Example

Functional Unit	Latency	Initiation Interval
Integer ALU	0	1
Data Memory	1	1
FP add	3	1
FP/integer multiply	6	1
FP/integer divide	24	25

Pipelined FP units




Pipelined FP units



Hazards

Due to the different structure of the EX stage, hazards may become more frequent.

Example



Structural hazards

- Structural hazards can occur:
 - because of the unpipelined divide unit, when several instructions could need it at the same time
 - because the instructions have varying running times, when the number of register writes required in a cycle is larger than 1.

Contemporary register writes

					Clo	ock cycle r	number				\wedge
Instruction	1	2	3	4	5	6	7	8	9	10	11
MUL.D F0,F4,F6	IF	ID	M1	M2	M3	M4	M5	M6	M7	MEM	WB
• • •		IF	ID	EX	MEM	WB					
•••			IF	ID	EX	MEM	WB				
ADD.D F2,F4,F6				IF	ID	A1	A2	A3	A4	MEM	WB
• • •					IF	ID	EX	MEM	WB		
• • •						IF	ID	EX	MEM	WB	
L.D F2,0(R2)							IF	ID	EX	MEM	WB

Solutions

- Adding other write ports (normally too expensive)
- Forcing a structural hazard:
 - instructions are stalled in the ID stage, or
 - instructions are stalled before entering the MEM or WB stage.

More frequent data hazards

Because of longer latency of operations, stalls for data hazards may stall the pipeline for longer periods.

5									Cloc	k cyc	le nun	nber						
Instru	ıction	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
L.D	F4,0(R2)	IF	ID	EX	MEM	WB												
MUL.D	F0,F4,F6		IF	ID	stall	M1	M2	M3	M4	M5	M6	M7	MEM	WB				
ADD.D	F2,F0,F8			IF	stall	ID	stall	stall	stall	stall	stall	stall	A1	A2	A3	A4	MEM	WB
S.D	F2,0(R2)					IF	stall	stall	stall	stall	stall	stall	ID	EX	stall	stall	stall	MEM

More frequent data hazards

Because of longer latency of for data hazards may stall the longer periods.

Read After Write (RAW) hazard

S									Cloc	k cyc	le nui	nb	1	\land				
Instru	ıction	1	2	3	4	5	6	7	8	9	10	11	1	13	$\sqrt{\int}$	15	16	17
L.D	F4,0(R2)	IF	ID	EX	MEM	WB												
MUL.D	F0,F4,F6		IF	ID	stall	M1	M2	M3	M4	M5	M6	M7	MEM	WB				
ADD.D	F2,F0,F8			IF	stall	ID	stall	stall	stall	stall	stall	stall	A1	A2	A3	A4	MEM	WB
S.D	F2,0(R2)					IF	stall	stall	stall	stall	stall	stall	ID	EX	stall	stall	stall	MEM

New data hazards

Instructions no longer reach WB in order: therefore, new kinds of data hazards are now possible.

<u>Example</u>		Clock cycle number										
Instruction	1	2	3	4	5	6	7	8	9	10	11	
MUL.D F0,F4,F6	IF	ID	M1	M2	M3	M4	M5	M6	M7	MEM	WB	
•••		IF	ID	EX	MEM	WB						
•••			IF	ID	EX	MEM	WB					
ADD.D F2,F4,F6				IF	ID	A1	A2	A3	A4	MEM	WB	
•••					IF	ID	EX	MEM	WB			
•••						IF	ID	EX	MEM	WB		
L.D F2,0(R2)							IF	ID	EX	MEM	WB	

New data hazards

Instructions no longer read therefore, new kinds of data possible.

L.D could write in F2 before ADD.D

<u>Example</u>					Clo	ock cycle	number		\	7 L	
Instruction	1	2	3	4	5	6	7	8	9	\	11
MUL.D F0,F4,F6	IF	ID	M1	M2	M3	M4	M5	M6	M7	M	WB
•••		IF	ID	EX	MEM	WB					
•••			IF	ID	EX	MEM	WB				
ADD.D F2,F4,F6				IF	ID	A1	A2	A3	A4	MEM	WB
•••					IF	ID	EX	MEM	WB		
•••						IF	ID	EX	MEM	WB	
L.D F2,0(R2)							IF	ID	EX	MEM	WB

New data hazards

Instructions no longer reach therefore, new kinds of data possible.

Write After Write (WAW) hazard

<u>Example</u>					Clo	ock cycle		\wedge		\	
Instruction	1	2	3	4	5	6	7	8	9	10	11
MUL.D F0,F4,F6	IF	ID	M1	M2	M3	M4	M5	M6	M7	MEM	WB
•••		IF	ID	EX	MEM	WB					
•••			IF	ID	EX	MEM	WB				
ADD.D F2,F4,F6				IF	ID	A1	A2	A3	A4	MEM	WB
•••					IF	ID	EX	MEM	WB		
•••						IF	ID	EX	MEM	WB	
L.D F2,0(R2)							IF	ID	EX	MEM	WB

Solution

- Before issuing an instruction to the EX stage, check whether it is going to write on the same register of an instruction still in the EX stage.
- In this case, stall the new instruction.

Summary

- If hazard detection is always performed in the ID stage, three checks have to be performed:
 - structural hazards (involving the divide unit and the write port)
 - RAW data hazards: check whether some source register is listed among the destination registers of pending instructions, and whether this register will not be available at the right moment
 - WAW data hazards: check whether the instruction currently in ID has the same destination register of any instruction in A1,...,A4, D, M1, ..., M7.

Imprecise exceptions

- Guaranteeing precise exceptions is more complex with multiple cycle architectures.
- Example

DIV.D F0, F2, F4

ADD.D F10, F10, F8

SUB.D F12, F12, F14


Instructions ADD.D and SUB.D complete before DIV.D (out-of-order completion). If an exception arises during SUB.D, an imprecise exception occurs.


Solutions


- Accepting imprecise exceptions
- Providing a fast, but imprecise operating mode, and a slow, but precise one (only one FP instruction is executed at a time)
- Buffering the results of each instruction until all the previously issued instructions have been completed
- Forcing the FP units to early determine whether an instruction can cause an exception, and issuing further instructions only when the previous ones are guaranteed not to cause an exception.


THE MIPS R4000 PIPELINE


- The MIPS R-4000 processor is a 64-bit microprocessor introduced in 1991, whose instruction set is similar to the MIPS64 one.
- The R-4000 uses a deeper pipeline (8 stages) to account for slower cache access and higher clock frequency:
 - memory accesses are decomposed in several stages.
- Long pipelines sometimes take the name of superpipelines.





















The 8-stage pipe


Both instruction and data memory accesses are pipelined: a new instruction can start on every clock cycle.



Characteristics


- More forwarding is required
- Increased load delay slot (2 cycles)
- Increased branch delay slot (3 cycles).


Load delay slot



The data is available at the end of DS. Activating the forwarding logic, it is passed to the ADDD instruction. CC7 CC8 CC9 CC 10 CC 11 Data memory Reg LD_{R1} Instruction memory Reg LOAD DELAY SLOT Data memory Reg Instruction 1 Instruction memory Reg Data memory Reg Reg Instruction 2 Instruction memory Data memory Reg ADDD R2, R1 Instruction memory Reg

Branch delay slot





FP pipeline

- The FP unit is composed of three functional units: divider, multiplier, adder
- the FP unit can be thought as composed of 8 different stages:

stage	functional unit	description
A	adder	Mantissa ADD stage
D	divider	divide
• E	multiplier	exception test
M	multiplier	multiplier I
N	multiplier	multiplier II
R	adder	rounding
• S	adder	operand shift
• U		unpack numbers


FP operations


FP instruction	Latency	Initiation interval	Pipe stages
Add, subtract	4	3	U, S + A, A + R, R + S
Multiply	8	4	U, E + M, M, M, M, N, N + A, R
Divide	36	35	$U, A, R, D^{27}, D + A, D + R, D + A, D + R, A, R$
Square root	112	111	U, E, (A+R) ¹⁰⁸ , A, R
Negate	2	1	U, S
Absolute value	2	1	U, S
FP compare	3	2	U, A, R

Latency is reduced by 1 if the destination is a store instruction.

FP instruction	Latency	Initiation interval	Pipe stages
Add, subtract	4	3	U, S + A, A + R, R + S
Multiply	8	4	U, E + M, M, M, M, N, N + A, R
Divide	36	35	$U, A, R, D^{27}, D + A, D + R, D + A, D + R, A, R$
Square root	112	111	U, E, (A+R) ¹⁰⁸ , A, R
Negate	2	1	U, S
Absolute value	2	1	U, S
FP compare	3	2	U, A, R

Performance





For FP programs FP result stalls are the most important contributors to total CPI. Base Load stalls Branch stalls FP result stalls 3.00 FP structural stalls 2.50 2.00 Pipeline CPI 1.50 1.00 0.50 compressednicht eat hydro2d ndiid9 su2cot SPEC92 benchmark

Total CPI varies between 1.2 and 2.8, depending on the program. Base Load stalls Branch stalls FP result stalls 3.00 FP structural stalls 2.50 2.00 Pipeline CPI 1.50 1.00 0.50 compress education ear nydro2d ndiido su2cor SPEC92 benchmark