# USBSID-Player manual

Author: LouD - generated on 2026-10-25

# Table of Contents

Disclaimer . . . 2
What!? . . . 2
Firmwares with embedded USBSID-Player . . . 2
Usage . . . 2
  Keyboard controls of the usplayer CLI . . . 2
Drivers . . . 3
  Linux Udev rules . . . 3
  Windows driver . . . 4
Development . . . 4
License . . . 4
  Software License ~ GNUv2 . . . 4
  Configtool Software License ~ EPLv2 . . . 4
  USBSID-Pico v1.5 PCB Hardware License ~ CC BY-NC-ND 4.0 . . . 5
  USBSID-Pico v1.3 PCB Hardware License ~ CC BY-SA 4.0 . . . 5
  USBSID-Pico v1.0 PCB Hardware License ~ CC BY-SA 4.0 . . . 5
  USBSID-Volume-daughterboard v1.0 PCB Hardware License ~ CC BY-SA 4.0 . . . 5

# Disclaimer

I do this stuff in my free time for my enjoyment. Since I like to share my joy in creating this with everyone I try my best to provide a working PCB and Firmware. I am in no way an electronics engineer and can give ***no guarantees*** that this stuff does not break or damage your hardware, computer, phone, or whatever you try to hook it up to. Be sure to take great care when inserting any real MOS SID chips into the board. While everything has been tested with real chips, this is in no way a guarantee that nothing could go wrong. Use of this board and firmware at your own risk! I am in no way responsible for your damaged hardware. That being said, have fun!

# What!?

Yes you read that right, USBSID-Player is embedded on USBSID-Pico and allows you to play PSID, RSID, PRG or P00 chiptunes without the need of an emulator on your computer!

# Firmwares with embedded USBSID-Player

Starting with firmware version v0.6.0-BETA firmwares have an embedded emulator that can play PSID and RSID tunes and PSID64 PRG/P00 files.
From v0.8.1 and later these files are for example `usbsidpico-v1.0_em.uf2`, `usbsidpico2-v1.3-rgb_em.uf2` or `usbsidpico2-v1.5_em.uf2`
This USBSID-Player is in active development and some tunes might not work or play at all, let me know if you come across any!
**NOTE!** Highly demanding cycle-exact SID tunes (e.g. some digi/sample tunes) may not play at full speed on Pico1 or Pico1_w boards (RP2040). Use a Pico2 or Pico2_w (rp2350) board for these tunes.
**WARNING!** Whenever the USBSID-Player is compiled into the firmware the Pico MCU is overclocked to 250MHz. Passive cooling *might/could* be needed.
Cynthcart also runs through the embedded USBSID-Player ~ see the `USBSID-Pico-Cynthcart-manual` file for more information.

# Usage

To play SID tunes and run PRG/P00 PSID64 files *on* USBSID-Pico you will need the `send_sid` tool that is available in the `tools.zip` starting with firmware release v0.6.0-BETA and up, the help menu is self explanatory.
Firmware release v0.7.0 and up supports the send sid mode on the USBSID-Pico config website and on Deepsid!
Multi-subtune PSID/RSID files are supported, you can switch to the following or previous subtune while a tune is playing.

## Keyboard controls of the usplayer CLI

While a tune plays, the `usplayer` command line player reads single key presses without Enter. Keys are lowercase, up and down arrows are ignored.
On Linux and macOS the keys are active when stdin is a terminal. With stdin on a pipe or script the

keys are off, the player prints `press ctrl-c to stop` and ctrl-c stops it. On Windows the keys are on and read from the console.
At start with keys on the player prints the list of keys. The arrow keys work the same as `n` and `p`. A bare Esc quits.

| Key | Action |
|---|---|
| space | Pause or resume. The chip is silenced while paused and restored from the register file on resume, the time display freezes |
| n or right arrow | Go to the following subtune. Wraps from the last subtune to the first. Does nothing on a tune with one song. |
| p or left arrow | Previous subtune. Wraps from the first subtune to the last. Does nothing on a tune with one song. |
| r | Restart the current song from its start. Unlike n and p it also works on a tune with a single song. |
| f | Toggle fast forward. This is a seek without pacing, writes are discarded and the chip is silent while it runs. Press again to stop seeking, the chip is caught up from the register file and pacing resumes from that point. The status line shows `>> seeking`. USBSID cannot play faster than the tune timing. |
| 1, 2, 3 | Toggle mute of voice 1, 2 or 3 on the selected SID chip. The selected chip is SID 1 at start. |
| c | Cycle the selected SID chip for the 1, 2 and 3 keys, wraps from the last chip to SID 1. Needs more than one SID |
| s | Stop playback and exit. |
| q or Esc | Quit, same effect as s. |
| ctrl-c | Quit, same effect as s (SIGTERM does the same) |

# Drivers

## Linux Udev rules


In the examples/udev directory you can find the udev rules that are used on Linux.
This purely an example file that you can use and change to your own needs. Steps required for this to work

```
# Check if you are in the plugdev group with the groups command
groups
# If not, add yourself to the plugdev group, then log out and in
sudo usermod -aG plugdev $USER
# Copy the udev ules file to the correct directory
sudo cp 69-usbsid-permissions.rules /etc/udev/rules.d
# Now reload the udev rules
udevadm control --reload-rules && udevadm trigger
# Not working? Try reloading the service
```

```
sudo systemctl restart udev
```

## Windows driver

Use Zadig to install the correct driver. Replace the driver for `USBSID-Pico Data` with WinUSB.




# Development

More information about USBSID-Player is available on the github repo

# License

## Software License ~ GNUv2


All code written by me in this repository is licensed under the terms of the GNU General Public License as published by the Free Software Foundation, version 2. Any code in this repository that is not written by me automatically falls under the licensing conditions by the authors of said code as mentioned in the source code header. For for more information about this license please read the LICENSE document in the root of the USBSID-Pico repository.

## Configtool Software License ~ EPLv2

This program and the accompanying materials are made available under the terms of the Eclipse Public License 2.0 which is available at eclipse.org.
SPDX-License-Identifier: EPL-2.0

# USBSID-Pico v1.5 PCB Hardware License ~ CC BY-NC-ND 4.0

USBSID-Pico v1.5 PCB © 2026 by LouD is licensed under
Creative Commons Attribution-NonCommercial-NoDerivatives 4.0 International



# USBSID-Pico v1.3 PCB Hardware License ~ CC BY-SA 4.0

USBSID-Pico v1.3 PCB © 2025-2026 by LouD is licensed under
Creative Commons Attribution-ShareAlike 4.0 International



# USBSID-Pico v1.0 PCB Hardware License ~ CC BY-SA 4.0

USBSID-Pico v1.0 PCB © 2024-2026 by LouD is licensed under
Creative Commons Attribution-ShareAlike 4.0 International



# USBSID-Volume-daughterboard v1.0 PCB Hardware License ~ CC BY-SA 4.0

Volume-daughterboard v1.0 PCB © 2026 by LouD is licensed under
Creative Commons Attribution-ShareAlike 4.0 International



Author: LouD - generated on 2026-10-25