All-Sky Software Design flow chart Additional classes: (types) INDI set exposure (number) = File I/O = activemq INDI set frame type (switch '4') INDI get ccd info (number) Stomp Activemq INDI data handler (Blob) Listener Broker (remote) class Camera-Controlling Disk **FITS** Script Init Host (imports all handler Class (remote) common classes) Minimal Config-UI Scheduler Input (remote) class json