31	30 25	5 24 21	20	19	15 14 12	2 11 8	7	6 0	
f	unct7	rs	2	rs1	funct3	rd	l	opcode	Tipo R
imm[11:0]			rs1	funct3	rd	l	opcode	Tipo I	
imm[11:5]		rs	2	rs1 funct3		imm[4:0]		opcode	Tipo S
imm[12]	imm[10:5]	rs	2	rs1	funct3	imm[4:1]	imm[11]	opcode	Tipo B
imm[31:12]							rd		Tipo U
				•					_
imm[20]	imm[1	0:1]	imm[11]	imm	[19:12]	rd	l	opcode	Tipo J

Função	Opcode	Funct3	Funct7	<b>ALUControl</b>	ALUOp
ADD	"0110011"	"000"	"0000000"	"0010"	"10"
SUB	"0110011"	"000"	"0100000"	"0110"	"10"
AND	"0110011"	"111"	"0000000"	"0000"	"10"
OR	"0110011"	"110"	"0000000"	"0001"	"10"
ADDI	"0010011"	"000"	///////////////////////////////////////	"0010"	?
LW	"0000011"	"010"	///////////////////////////////////////	"0010"	"00"
SW	"0100011"	"010"	///////////////////////////////////////	"0010"	"00"
BEQ	"1100011"	"000"	///////////////////////////////////////	"0110"	"01"
BNE	"1100011"	"001"	///////////////////////////////////////	"0110"	"01"

