## Manage your modem's settings in the interface of the Home Hub 3000 and 4000, and the Giga Hub



## How to find and change your Bell Wi-Fi password

How to configure the primary Wi-Fi network on my modem	+
How to set or change the administrator password on my modem	+
How to configure the guest Wi-Fi network on my modem	+
How to set up password recovery on my modem	<b>(+)</b>
How to determine which devices consume the most usage with my modem	+
How to perform a speed test from my modem	

This speed test provides speeds for both download (to your modem) and upload (to the Internet). It temporary disables all local network activity so that the results reflect more closely the speeds you're subscribed to.

- 1. Open your web browser and visit **bell.ca/mymodem** or **192.168.2.1**.
- 2. Click Speed test.
- 3. If prompted, enter the administrator password
  - Unless you've changed it, the password is the serial number located on the sticker on the back of the modem.
- 4. Select Block all local network activity to temporarily disable network activity that could impact the results.
- 5. Click Start test.
- 6. A warning will appear that Internet, home phone and TV services (including shows being recorded) may be disrupted during the speed test. Click **Continue** if you wish to do so. Note: This will disable Fibe Internet for the duration of the test.
- 7. Wait for the speed test to be completed.