

PRODUCT DESCRIPTION

OffShore is a single-component, waterborne clear wood coating based on an aliphatic polyurethane dispersion (PUD) built on a German-grade raw material system. Aliphatic chemistry is what lets the film live in sunlight: it does not yellow and does not embrittle under UV the way conventional clear coatings do. Straight from the can — no hardener, no mixing, no thinning — it is applied by brush, roller or spray onto sanded bare wood, where it forms a tough, low-odour transparent film that deepens the timber's tone the way wood looks when wet, while keeping every grain line visible. Suitable for interior joinery and furniture as well as exterior woodwork, with film thickness (number of coats) as the single durability lever.

KEY DATA

Chemistry	One-component aliphatic waterborne polyurethane dispersion (PUD) — German-grade raw material system
Supplied form	Ready-to-use liquid — no hardener, no mixing; never thin with water
Sheen options	Clear (semi-gloss / satin) · Matt — same film, the difference is light reflection only
Application	Brush, roller or spray onto bare wood sanded to grit 240–320 along the grain
Coats	2 coats minimum · exterior or hard-use work 3–4 coats — durability scales with film thickness
Coverage	1 kg » approx. 5 m ² at 2 coats (2.5 kg » 12.5 m ² · 5 kg » 25 m ²)
Touch dry	30–60 minutes
Recoat	2–4 hours · sand lightly with grit 320–400 between coats to cut raised grain
Light use	After 24 hours
Full cure	7 days
Immersion	Film passed 7-day continuous water immersion (film test only — coated timber is NOT rated for immersion or standing water)
Conditions	Apply and store at 5–35 °C
Tool cleaning	Plain water, before the coating dries
Packaging	1 kg · 2.5 kg · 5 kg

NOTE ON VALUES

Coverage varies with timber species and surface porosity — open-grained and weathered wood draws the first coat in far faster than dense, close-grained timber. Figures in this document are typical guidance only and are not a specification.

APPLICATION NOTES

- Sand bare wood to grit 240–320 along the grain and remove all dust. Old lacquer, shellac or oil finishes must be stripped back to bare timber first — the coating needs direct contact with the wood.
- Stir gently before use. Do not shake — shaking folds air into the liquid and the bubbles carry into the film.
- Expect the first coat to raise the wood grain: once dry, the surface feels rougher than it did. Sand lightly with grit 320–400, dust off, then apply the next coat. This step decides whether the finished surface is smooth or rough.
- The coated timber turns darker and richer, the way wood looks when the surface is wet. To preview the final colour before committing, put a drop of water on the sanded wood — the colour you see while it is wet is the colour you will get.
- Fill chips, nail holes and splits and sand flat before coating — a clear film follows the shape of whatever is underneath it and hides nothing.
- Never thin with water. Waterborne does not mean water may be added: dilution thins the film and reduces adhesion.
- Exterior work: apply 3–4 coats. Fully exposed timber will still need recoating on a maintenance cycle — the film fades gradually as it ages rather than yellowing.
- Not recommended for timber floors with daily foot traffic, for surfaces where water ponds or stands, or for any submerged application — the wood itself, not the film, is the limiting factor.

HEALTH & SAFETY

Waterborne and low odour: the coating can be applied in occupied interior spaces with normal ventilation, and the room can be used as soon as the work is finished. Avoid eye contact; rinse splashes with plenty of water. Wash hands after use. Keep the liquid away from children and animals. Fully dried film is inert.

STORAGE

Store in the original tightly sealed container in a dry place at 5–35 °C away from direct sunlight and heat. Reseal immediately after use. Protect from frost. Use within the shelf life printed on the packaging.