

Perfect Wireless Experience 完美无线体验

FIBOCOM L610 AT Commands_FOTA

Version: V1.0.0 Date: 2019-11-29





Applicability Type

No.	Туре	Note
1	L610	NA





Copyright

Copyright ©2019 Fibocom Wireless Inc . All rights reserved.

Without the prior written permission of the copyright holder, any company or individual is prohibited to excerpt, copy any part of or the entire document, or transmit the document in any form.

Attention

The document is subject to update from time to time owing to the product version upgrade or other reasons. Unless otherwise specified, the document only serves as the user guide. All the statements, information and suggestions contained in the document do not constitute any explicit or implicit guarantee.

Trademark



The trademark is registered and owned by Fibocom Wireless Inc.

Versions

Version	Author	Assessor	Approver	Update Date	Description
V1.0.0	Robin	Long Zhongyou	Long Zhongyou	2019-11-29	Initial version



Contents

1 FOTA Command				
	1.1	FOTA Upgrade Command	5	
	1.2	+GTOTA, FOTA Upgrade	5	
	1	.2.1 Description	5	
	1	.2.2 Syntax	£	
	1	.2.3 Attributes	<i>6</i>	
	1	2.4 Defined Values	6	



1 FOTA Command

1.1 FOTA Upgrade Command

This section describes the FOTA features. Modem's firmware can be upgraded from the Remote Server by the FOTA process.



Notes:

- The speed of 2G network is slow, it may fail to upgrade when using 2G network. So we
 recommend to fix the network to the highest-level that the module can support when using
 this command to upgrade firmware.
- Since ring call may interrupts the upgrade process, so this function must be disabled by
 using command [AT+GTSET="CALLBREAK",1] before performing the FOTA process.
 Besides, command [AT+GTSET="GPRSFIRST",1] should be using if the product supports
 it.

1.2 +GTOTA, FOTA Upgrade

1.2.1 Description

This command is used to start FOTA upgrade process. The firmware data can be downloaded over FTP or HTTP protocol.

Note that it needs to use the +MIPCALL command to active a PDP before starting FOTA upgrade process

1.2.2 Syntax

Command	Possible response(s)	
+GTOTA= <type>,<"url">[,</type>	OK	
<"filename">,<"username">		
,<"password">]	or:	
	+CME ERROR: <err></err>	
	Note: During the firmware downloading, the module will report the following	
	unsolicited report indicating the downloading status:	
	GTOTA DOWNLOAD START	



Command	Possible response(s)	
	GTOTA DOWNLOADING: <percent>%</percent>	
	GTOTA DOWNLOAD COMPLETE	
	GTOTA DOWNLOAD FAILED	
+GTOTA=?	+GTOTA: <type>,<"url">[,<"filename">,<"username">,<"password">]</type>	
	ОК	

1.2.3 Attributes

Pin Restricted	Persistent	Sync Mode	Effect Immediately	Time of duration
Yes	No	Yes	Yes	< 1s

1.2.4 Defined Values

<type> integer type and range 0-1; Default value is 0.

- 0 FOTA upgrade through HTTP
- 1 FOTA upgrade through FTP
- <"url"> string type; Address of HTTP or FTP server. The maximum length is 255 bytes.
- <"filename"> string type; The file name of OTA package. The maximum length is 255 bytes.
- <"username"> string type; User name for FTP server. The maximum length is 255 bytes.
- <"password"> string type; FTP password for <"username">. The maximum length is 255 bytes.



Note:

- 1. When <type> is 0, parameters <"filename">, <"username">, and <"password"> can't be used. When <type> is 1, parameters <"filename">, <"username">, and <"filename"> must be given.
- When using HTTP, the file name and path of the OTA package must be included in <"URL">.
 When using FTP, <"URL"> is just the address of FTP server, while filename is given by parameter <"filename">.
- 3. The file path may also be included to <"filename"> when needed.