





Please make sure to avoid any wires coming up above the PCB but have a clean surface so all short circuits are avoided. The same avoidance of short circuits is to be done with the bottom of the PCB. Finally, cover the PCB with shrink-wrap