

MuonCollider BIB analysis: user manual

How to run the package, where everything lives, and what comes out. Luciano Ristori, October 2026.

Master copy: `~/code/MuonCollider/docs/user_manual.pdf` (git; source docs/src/user_manual/user_manual.tex).

The copy `_START_HERE_user_manual.pdf` in the Analysis folder is refreshed from it automatically by `./run_all` and `./run_scan`: do not edit the copy; change the source and rebuild (see `README.txt` next to it).

The 30-second version. Everything is run from *one* folder, in a Terminal:

```
cd ~/Dropbox/Documents/MuonColliderSimulation/Analysis
```

In that folder you edit plain-text settings files (names starting with `__`), then type one command:

- `./run_all` — applies smearing and cuts to the BIB and signal files and makes the highlights plots and PDF, with the BIB rejection, signal efficiencies *and the expected number of fake tracks* for your cuts and resolutions (Sections 3 and 4).
- `./run_scan` — scans the timing or pointing-angle resolution, re-deriving the cuts at each point (Section 5).

Every run is archived, with a copy of the settings it used, in `runs/`. The newest results are always the files whose names start with `_` in the Analysis folder. Nothing you do there can damage the code.

1 Where everything lives

There are two places: the **code**, under git, and the **simulation folder** in Dropbox, which holds the data, the settings and all results.

1.1 The simulation folder (Dropbox) — where you work

```
~/Dropbox/Documents/MuonColliderSimulation/
|-- Data/                input ROOT n-tuples (BIB plus/minus/ipp, combined BIB, signal)
|-- Geometry/            detector geometry XML files (MuSIC, Vertex, IT, OT)
'-- Analysis/            <-- THE WORKING FOLDER: cd here, edit, run
    |-- __input_files_config.txt  which files in Data/ and Geometry/ to use
    |-- __cuts_config.txt        cuts per subsystem, track definition
    |-- __smearing_config.txt    detector resolutions (position, time, angle)
    |-- __scan_config.txt        what ./run_scan scans
    |-- run_all, run_scan        the two commands (tiny launchers)
    |-- _START_HERE_user_manual.pdf  this manual (auto-refreshed copy)
    |-- _highlights_<date>_<time>.pdf  PDF of the latest ./run_all
    |-- _highlights/            its key plots (PNG) and the same PDF
    |-- _scan_time_<date>_<time>.pdf  PDF of the latest time scan
    |-- _scan_angle_<date>_<time>.pdf  PDF of the latest angle scan
    |-- latest_run.txt          which run the step* folders show, + its summary
    |-- step1... step4...       all plots/tables of the latest successful ./run_all
    |-- runs/                  ARCHIVE: one folder per run or scan (see Sec. 6)
    '-- claude_scratch/        scratch files from work with Claude; ignore
```

1.2 The code (git) — normally you don't touch it

```
~/code/MuonCollider/          git, github.com/LucianoRistori/MuonCollider
|-- README.md                 detailed reference: n-tuple format, every step, definitions
|-- docs/user_manual.pdf      this manual (source in docs/src/user_manual/)
|-- docs/efficiency_pt_infinity.pdf  note: how efficiencies for pT -> inf are obtained
|-- run_all_steps.sh          what ./run_all does (checks, steps 1-4, archiving)
|-- run_scan.sh               what ./run_scan does
|-- bib_common.py             shared library: reading, smearing, cuts, efficiencies
|-- make_basic_plots.py, incidence_angle_plots.py, time_of_flight_plots.py,
|   signal_overlay_*.py, apply_cuts.py, track_efficiency.py, nl_cut_plots.py
|                             the analysis steps 1-4
|-- fake_rate.py              expected number of fake tracks (Sec. 4)
|-- resolution_scan.py        the resolution scans (Sec. 5)
|-- make_highlights_pdf.py    builds the highlights PDF of a run
|-- check_configs.py, cuts_table.py, input_files.py  read and check the settings
|-- templates/                pristine copies of the four settings files
|-- fake_rate_framework/      analytic fake-track framework of the paper (Sec. 13-14)
'-- resolution_scans/         original scripts and results of paper Sec. 15-16
```

The launchers `run_all` and `run_scan` in the Analysis folder just find the code in `~/code/MuonCollider` and run it on the folder they are in. If you move the code, run with `MUONCOLLIDER_CODE=/new/path` `./run_all`.

2 The four settings files

All four are commented plain text: open them in any editor and read the comments, which explain every line. A summary:

<code>__input_files_config.txt</code>	[data]: the BIB files <code>bib_plus</code> , <code>bib_minus</code> , <code>bib_ipp</code> (optional), the combined BIB file <code>bib_combined</code> , and the signal muon-gun sample; [geometry]: the four XML files. <i>Names only</i> : files are looked up in <code>Data/</code> and <code>Geometry/</code> . The combined file is (re)built automatically when it is missing or does not match <code>plus + minus + ipp</code> .
<code>__cuts_config.txt</code>	[cuts]: a table, one row per subsystem (VXD/IT/OT, barrel and endcap), with the three cuts <i>time</i> ($ t_{\text{corrected}} $, ns), <i>z0</i> ($ z_0 $, mm) and <i>pT</i> (minimum p_T , GeV/c), or <i>off</i> ; then three <i>zoom</i> columns that only set the range of the zoomed N-1 plots. [track]: a muon is “found” if at least <code>min_hits_found</code> of its hits pass (<code>exclude_vertex_hits</code> : VXD hits not counted). [signal]: <code>muon_hits_only</code> .
<code>__smearing_config.txt</code>	Gaussian resolutions applied to the (exact) simulated hits: [position] <code>sigma_u_mm</code> , <code>sigma_v_mm</code> ; [time] <code>sigma_t_ns</code> ; [angle_u], [angle_v] <code>sigma_deg</code> (pointing angle). Each section has <code>enabled = true/false</code> . [general] <code>seed</code> fixes the random numbers.
<code>__scan_config.txt</code>	Only for <code>./run_scan</code> : parameter (time or angle), containment (% of signal hits each re-derived cut keeps) and <code>grid</code> (the values to scan).

Both commands check the files before running anything (typos, unknown settings, non-numbers, missing input files) and stop with a message saying what to fix. If a settings file is missing, a fresh copy is made from `templates/` and you are asked to check it. Editing a file while a run is going has no effect on that run: the files are copied at the start.

3 Case 1 — highlights plots for some data files

1. New data? Copy the ROOT files into `Data/` and put their names in `__input_files_config.txt`. (Same data as last time: skip this.)
2. Set the cuts in `__cuts_config.txt` and the resolutions in `__smearing_config.txt`.
3. Run:

```
cd ~/Dropbox/Documents/MuonColliderSimulation/Analysis
./run_all          # step 4 only: everything the PDF needs  (~1 1/4 min)
./run_all --full   # steps 1-4: all plots of the analysis  (~6 min)
```

4. Look at `_highlights_<date>_<time>.pdf` in the Analysis folder.

What the steps are. Step 1: hit maps and densities of the BIB (plus, minus, combined). Step 2: incidence angles and time-of-flight of BIB and signal. Step 3: BIB and signal overlaid (z_0 , p_T , corrected time). Step 4: the cuts — BIB rejection and signal hit efficiency per subsystem, track-finding efficiency vs. p_T , N-1 plots, expected fake tracks.

What comes out. The PDF has a title page with the settings and the main results (BIB rejection factor

and signal hit efficiency for $p_T \rightarrow \infty$ per subsystem, track-finding efficiency, expected fake tracks), the cuts per subsystem, and the key plots with captions quoting that run's numbers. The same results are in `summary.txt` of the run (also at the bottom of `latest_run.txt`). The `step*` folders and `_highlights/` show the latest *successful* run; a failed run never replaces them. To compare all past runs: `cat runs/*/summary.txt`.

4 Case 2 — fake-track rate for given cuts and resolutions

This is the same command as Case 1: set `__cuts_config.txt` and `__smearing_config.txt`, then `./run_all`. The expected number of fake tracks is reported

- on the title page of the highlights PDF (“Expected fake tracks”),
- in `summary.txt` and `latest_run.txt` (last line),
- in `step4_cuts/fake_rate.csv`, with the BIB hits after the cuts in each of the six layers used.

What the number is. $E[\text{\#fakes}]$ is the expected number of fake tracks in the 6-layer IT + OT barrel “tower” of the fake-rate framework (paper, Sections 14–16):

$$E[\text{\#fakes}] = P_{\text{true}} \prod_{i=1}^6 n_i, \quad n_i = \frac{\text{BIB hits after the cuts in layer } i}{\text{area of layer } i} \times W_i^2,$$

where W_i^2 are the plane areas of the projective tower (1 m² outermost plane) and P_{true} is the fake probability calibrated in `fake_rate_framework/real_tower_calibration.py`, for three track models: exact helix (the one quoted), conservative quadratic, and straight line ($B = 0$). Values well below 1 mean fakes are negligible.

Two things to remember. (1) It uses only the IT and OT barrel layers; the calibration assumes the current geometry (a warning is printed if the layer areas change). (2) There are two track-finding efficiencies. `./run_all` reports the *whole-tracker* one (all muons; found if at least `min_hits_found` of their hits pass, VXD hits not counted). `./run_scan` reports it too, and next to it the *barrel-tower* one, defined on the same six layers as $E[\text{\#fakes}]$ (muons with no IT/OT endcap hit; found if at least `min_hits_found` of their 6 barrel hits pass). They are different quantities: compare like with like.

5 Case 3 — resolution scans

1. Edit `__scan_config.txt`:

```
parameter    = time                # or: angle
containment  = 98                   # % of signal hits kept by each re-derived cut
grid         = log 0.010 1.0 10    # time: 10 ps - 1 ns, 10 points
# angle:     grid = linear 0 5 11   (0 - 5 deg in 0.5 deg steps)
# any:       grid = list 0.02 0.05 0.1
```

2. Check `__smearing_config.txt` (all the resolutions that are *not* scanned) and the p_T cut in `__cuts_config.txt`.
3. Run `./run_scan` (about 15–25 s) and open `_scan_time_<date>_<time>.pdf` (or `_scan_angle_...`).

What a scan does at each value. The scanned resolution is applied to the hits of *all* subsystems (for angle, equally to u and v); every other resolution is taken from `__smearing_config.txt`; the p_T cut from `__cuts_config.txt` is kept fixed. The z_0 and time cuts of every subsystem are then *re-derived* so that each keeps containment % of the signal hits: z_0 first (on the hits passing p_T), then time (on those passing p_T and z_0). In a time scan z_0 does not depend on the timing, so it is derived once. The z_0 and time values written in `__cuts_config.txt` are *not* used. The scan reports $E[\text{\#fakes}]$ and the track-finding efficiency for $p_T \rightarrow \infty$, both on the barrel tower, and also the whole-tracker efficiency exactly as `./run_all` defines it (Section 4).

What comes out (in `runs/<date>_<time>_scan_<time|angle>/`): a PDF with a settings page, a results table, and three plots ($E[\text{\#fakes}]$, the two efficiencies, and the derived cuts of all six subsystems vs. the resolution); `scan_results.csv` with every number. With the settings above (98%) a scan reproduces the paper’s Sections 15 and 16 exactly.

Tip: `grid = list <value>` gives a single point: the efficiency and $E[\text{\#fakes}]$ for one resolution with containment-derived cuts, to compare with the fixed cuts of Case 2.

6 The archive: runs/

Every run gets its own folder, named by the date and time it started:

2026-10-07_161638	a full <code>./run_all --full</code> run
2026-10-07_161638_pdf	a default <code>./run_all</code> (step 4 only)
<code>.._scan_time, .._scan_angle</code>	a <code>./run_scan</code>
<code>.._FAILED, .._INTERRUPTED</code>	did not complete — see its <code>run_log.txt</code>

When a run finishes (or fails), all the files in its folder are made **read-only**, so the archive can’t be changed by accident; the folder itself can still be deleted. The copies in the `step*` folders and `_highlights/` stay editable.

Each holds the settings files exactly as used, `run_log.txt` (everything printed), `code_version.txt` (git commit of the code, input files with sizes and dates), and the results (`summary.txt`, `step` folders, `_highlights/`; or the scan’s CSV, plots and PDF). To repeat an old run, copy its settings files back into the Analysis folder and run again. The copies are read-only too: `chmod u+w __*_config.txt` makes them editable (each run also does this for you). To edit a file inside a run on purpose: `chmod u+w runs/<run>/<file>`. To rebuild the PDF of an old run: `python3 ~/code/MuonCollider/make_highlights_pdf.py runs/<run>`. Old run folders can be deleted freely; Dropbox keeps a version history.

7 If something goes wrong

- **“ERROR: ... fix the settings file(s)”** — nothing was run; the message lists each problem and the file it is in.
- **Python is missing packages** — the message gives the command, e.g. `python3 -m pip install uproot awkward`. Needed: `numpy`, `uproot`, `awkward`, `matplotlib`.
- **A run ends in `_FAILED`** — open its `run_log.txt`; the step that failed is at the end. Your `step*`

folders and `_highlights/` still show the last good run.

- `./run_all`: **Permission denied** — the launcher lost its executable flag (e.g. after a copy):
`chmod +x run_all run_scan`.
- **Help on the commands** — `./run_all --help`, `./run_scan --help`.
- **A full run under a time limit** can be split: `./run_all --full --steps 1,2`, then `./run_all --run <run> --steps 3,4`.

8 Where to read more

- `README.md` in the code folder: the n-tuple format, each analysis step and its plots, how every quantity is defined and quoted.
- `docs/efficiency_pt_infinity.pdf`: the efficiencies for $p_T \rightarrow \infty$ (the fit of $\epsilon_\infty + c/p_T^2$).
- The paper draft and the project notes (milestones, decisions) are in the Claude project “Muon Collider Tracking”.
- `fake_rate_framework/` and `resolution_scans/`: the scripts behind the paper’s Sections 13–16.
- Changing the code: commit with git in `~/code/MuonCollider` and `git push` to GitHub; each run records the commit it used.