



Kinematics

Prof. Darius Burschka

Technische Universität München
Institut für Informatik
Machine Vision and Perception Group (I6)





1. Usually, variables written in uppercase represent vectors or matrices. Lowercase variables are scalars.
2. Leading subscripts and superscripts identify which coordinate system a quantity is written in. For example, ${}^A P$ represents a position vector written in coordinate system $\{A\}$, and ${}^B R$ is a rotation matrix³ that specifies the relationship between coordinate systems $\{A\}$ and $\{B\}$.
3. Trailing superscripts are used (as widely accepted) for indicating the inverse or transpose of a matrix (e.g., R^{-1} , R^T).
4. Trailing subscripts are not subject to any strict convention but may indicate a vector component (e.g., x , y , or z) or may be used as a description—as in P_{bolt} , the position of a bolt.
5. We will use many trigonometric functions. Our notation for the cosine of an angle θ_1 may take any of the following forms: $\cos \theta_1 = c \theta_1 = c_1$.

书16页

Relation between **joints** (q_i) and the **pose (position/orientation)** of some point (e.g.: frame $\{n\}$)

指代某个点的姿态编号编号

如该处是0, 运动完成一次之后为1

- Primary Workspace (*reachable*): WS_1

Positions that can be reached with at least one orientation



Each point can be reached
(orientation “does not matter”)

主要工作范围：该机械臂在至少一种情况下才能完成。

也就是图中的半圆

- Out of WS_1 there is no solution to the problem
- For all $\mathbf{p} \in WS_1$ (using a proper orientation), there is at least one solution

- Secondary Workspace (*dexterous*): WS_2

Positions can be reached with any orientation





Reach every poing with all
possible orientations

- For all $\mathbf{p} \in WS_2$ there is (at least) one solution for every orientation

- Relation between WS_1 y WS_2 :

$$WS_2 \subseteq WS_1$$

Example: R-R Robot





- Workspace ($l_1 > l_2$):

$$WS = \{\mathbf{p} \in \mathbb{R}^2 : |l_1 - l_2| \leq \|\mathbf{p}\| \leq l_1 + l_2\}$$

with $q_1 \in [0, 2\pi]$, $q_2 \in [0, 2\pi]$

Degrees of Freedom N – number of independent motion parameters of a body in space





Pose of an object in space $\overset{\circ}{P} \rightarrow \overset{n}{P}$



通过该公式， P 点可以在借助任意坐标系表达，这对于有摄像头的机械臂更容易进行距离测量

$$\overset{A}{P} = \overset{A}{R} \cdot \overset{B}{P} + \overset{A}{T}$$

- $q = (\text{position, orientation}) = (x, y, z, ???)$

- Parametrization of orientations by matrix:

$q = (r_{11}, r_{12}, \dots, r_{33}, r_{33})$ where $r_{11}, r_{12}, \dots, r_{33}$ are the elements of rotation matrix

$$R = \begin{pmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{pmatrix}$$

V_1, V_2 $V_1^T \cdot V_2 = ||V_1|| \cdot ||V_2|| \cdot \cos\alpha$


with

- $r_{1i}^2 + r_{2i}^2 + r_{3i}^2 = 1$ for all i , 为什么不能选择9个元素，因为他们是互相关的

- $r_{1i}r_{1j} + r_{2i}r_{2j} + r_{3i}r_{3j} = 0$ for all $i \neq j$, 每一列与其他列都是正交的 \Rightarrow 正交矩阵

- $\det(R) = +1$ 总距离是一样的，只是改变了角度

- Parametrization of orientations by Euler angles: (ϕ, θ, ψ)



$${}^1 \vec{P} = \begin{pmatrix} {}^1 \hat{x}_1^\top & {}^1 \hat{p} \end{pmatrix} = \begin{pmatrix} x \\ y \end{pmatrix}$$

$${}^2 \vec{P} = \begin{pmatrix} {}^2 \hat{x}_2^\top & {}^2 \hat{p} \end{pmatrix}$$

$$\text{eq: } {}^1 \hat{x}_1 = \begin{pmatrix} 1 \\ 0 \end{pmatrix}, {}^1 \hat{x}_2 = \begin{pmatrix} c\alpha \\ s\alpha \end{pmatrix}$$


$${}^1 \hat{y}_1 = \begin{pmatrix} 0 \\ 1 \end{pmatrix}, {}^1 \hat{y}_2 = \begin{pmatrix} -s\alpha \\ c\alpha \end{pmatrix}$$

~

$$\tilde{R} = \begin{pmatrix} c\alpha & -s\alpha \\ s\alpha & c\alpha \end{pmatrix} \xrightarrow{3D} \begin{pmatrix} c\alpha & -s\alpha & 0 \\ s\alpha & c\alpha & 0 \\ 0 & 0 & 1 \end{pmatrix} = \tilde{R}_z(\alpha)$$

$$\begin{pmatrix} c\beta & 0 & s\beta \\ 0 & 1 & 0 \\ -s\beta & 0 & c\beta \end{pmatrix} = \tilde{R}_x(\beta)$$

$$\begin{pmatrix} 1 & 0 & 0 \\ 0 & c\gamma & -s\gamma \\ 0 & s\gamma & c\gamma \end{pmatrix} = \tilde{R}_z(\gamma)$$



$$\begin{aligned} & \text{Given } P_1 = P_2 = r \\ & P_1 (r \cos \theta, r \sin \theta) \\ & P_2 (r \cos(\alpha + \theta), r \sin(\alpha + \theta)) \\ & \quad \downarrow \\ & r [\sin \alpha \cdot \cos \theta + \cos \alpha \cdot \sin \theta] \\ & = x_1 \cdot \sin \alpha + y_1 \cdot \cos \alpha \\ & = x_1 \cdot \cos \alpha - y_1 \cdot \sin \alpha \end{aligned}$$

$$x_2 = x_1 \cdot \cos \alpha - y_1 \cdot \sin \alpha$$

$$y_2 = x_1 \cdot \sin \alpha + y_1 \cdot \cos \alpha$$

$$\Rightarrow {}^2\vec{p} = \begin{pmatrix} \cos \alpha & -\sin \alpha \\ \sin \alpha & \cos \alpha \end{pmatrix} \cdot {}^1\vec{p}$$

$${}^3\vec{p} \Rightarrow R = \begin{pmatrix} \cos \alpha & -\sin \alpha & 0 \\ \sin \alpha & \cos \alpha & 0 \\ 0 & 0 & 1 \end{pmatrix}$$

Example of a singularity in Euler representation

为什么R是从后到前

$${}^A_B R_{XYZ}(\gamma, \beta, \alpha) = R_Z(\alpha)R_Y(\beta)R_X(\gamma)$$

$$= \begin{bmatrix} c\alpha & -s\alpha & 0 \\ s\alpha & c\alpha & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} c\beta & 0 & s\beta \\ 0 & 1 & 0 \\ -s\beta & 0 & c\beta \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 \\ 0 & c\gamma & -s\gamma \\ 0 & s\gamma & c\gamma \end{bmatrix},$$

$${}^3\vec{\rho} = {}^2\hat{R} \left({}^1\hat{R} \left({}^0\vec{\rho} \right) \right)$$

$$\begin{aligned} {}^A_B R_{XYZ}(\gamma, \beta, \alpha) &= \begin{bmatrix} c\alpha c\beta & c\alpha s\beta s\gamma - s\alpha c\gamma & c\alpha s\beta c\gamma + s\alpha s\gamma \\ s\alpha c\beta & s\alpha s\beta s\gamma + c\alpha c\gamma & s\alpha s\beta c\gamma - c\alpha s\gamma \\ -s\beta & c\beta s\gamma & c\beta c\gamma \end{bmatrix} \\ &= \sqrt{c^2\alpha^2 c^2\beta + s^2\alpha^2 c^2\beta} = \sqrt{c^2\beta (c^2\alpha + s^2\alpha)} = {}^1\rho \sqrt{c^2\alpha + s^2\alpha} = {}^1\rho \end{aligned}$$


$$= {}^1\beta$$

$$\beta = \text{Atan2}(-r_{31}, \sqrt{r_{11}^2 + r_{21}^2}), \quad \frac{{}^1\rho}{c\beta} = \tan \beta \quad \beta = 90.0^\circ,$$


$$\alpha = \text{Atan2}(r_{21}/c\beta, r_{11}/c\beta), \quad \frac{s\alpha}{c\alpha} = \tan \alpha \quad \alpha = 0.0.$$

$$\gamma = \text{Atan2}(r_{32}/c\beta, r_{33}/c\beta), \quad \frac{s\gamma}{c\gamma} = \tan \gamma \quad \gamma = \text{Atan2}(r_{12}, r_{22}),$$

$$\text{ATAN2}(a, b) = \begin{cases} \arctan\left(\frac{a}{b}\right) & \text{falls } b > 0 \\ \frac{\pi}{2} & \text{falls } b = 0, a > 0 \\ \text{undefiniert} & \text{falls } b = 0, a = 0 \\ -\frac{\pi}{2} & \text{falls } b = 0, a < 0 \\ \arctan\left(\frac{a}{b}\right) + \pi & \text{falls } b < 0 \end{cases}$$



Proper Euler angles			
$X_1Z_2X_3 = \begin{bmatrix} c_2 & -c_3s_2 & s_2s_3 \\ c_1s_2 & c_1c_2c_3 - s_1s_3 & -c_3s_1 - c_1c_2s_3 \\ s_1s_2 & c_1s_3 + c_2c_3s_1 & c_1c_3 - c_2s_1s_3 \end{bmatrix}$			
$X_1Y_2X_3 = \begin{bmatrix} c_2 & s_2s_3 & c_3s_2 \\ s_1s_2 & c_1c_3 - c_2s_1s_3 & -c_1s_3 - c_2c_3s_1 \\ -c_1s_2 & c_3s_1 + c_1c_2s_3 & c_1c_2c_3 - s_1s_3 \end{bmatrix}$			
$Y_1X_2Y_3 = \begin{bmatrix} c_1c_3 - c_2s_1s_3 & s_1s_2 & c_1s_3 + c_2c_3s_1 \\ s_2s_3 & c_2 & -c_3s_2 \\ -c_3s_1 - c_1c_2s_3 & c_1s_2 & c_1c_2c_3 - s_1s_3 \end{bmatrix}$			
$Y_1Z_2Y_3 = \begin{bmatrix} c_1c_2c_3 - s_1s_3 & -c_1s_2 & c_3s_1 + c_1c_2s_3 \\ c_3s_2 & c_2 & s_2s_3 \\ -c_1s_3 - c_2c_3s_1 & s_1s_2 & c_1c_3 - c_2s_1s_3 \end{bmatrix}$			
$Z_1Y_2Z_3 = \begin{bmatrix} c_1c_2c_3 - s_1s_3 & -c_3s_1 - c_1c_2s_3 & c_1s_2 \\ c_1s_3 + c_2c_3s_1 & c_1c_3 - c_2s_1s_3 & s_1s_2 \\ -c_3s_2 & s_2s_3 & c_2 \end{bmatrix}$			
$Z_1X_2Z_3 = \begin{bmatrix} c_1c_3 - c_2s_1s_3 & -c_1s_3 - \underline{c_2c_3s_1} & s_1s_2 \\ c_3s_1 + c_1c_2s_3 & c_1c_2c_3 - s_1s_3 & -c_1s_2 \\ s_2s_3 & c_3s_2 & c_2 \end{bmatrix}$			




$$\text{空间矩阵 } V_A = \{x_A, y_A, z_A\}^\top \quad V_B = \{x_B, y_B, z_B\}^\top$$

$$\Rightarrow V_B = R \cdot V_A.$$

$$\therefore x_A = \{1, 0, 0\}^\top \quad y_A = \{0, 1, 0\}^\top \quad z_A = \{0, 0, 1\}^\top$$

$$\Rightarrow \hat{x}_B = R \cdot \begin{pmatrix} 1 \\ 0 \\ 0 \end{pmatrix} \quad \hat{y}_B = R \cdot \begin{pmatrix} 0 \\ 1 \\ 0 \end{pmatrix} \quad \hat{z}_B = R \cdot \begin{pmatrix} 0 \\ 0 \\ 1 \end{pmatrix}$$

$$\Rightarrow R = \{\hat{x}_B, \hat{y}_B, \hat{z}_B\}$$




$$A \cdot B = \|A\| \cdot \|B\| \cdot \cos \theta$$

且 $\|B\|=1$ 时
A-B 那为 A 在 B 上的投影

We denote the unit vectors giving the principal directions of coordinate system $\{B\}$ as ${}^A\hat{x}_B$, ${}^A\hat{y}_B$, and ${}^A\hat{z}_B$. When written in terms of coordinate system $\{A\}$, they are called ${}^A\hat{x}_B$, ${}^A\hat{y}_B$, and ${}^A\hat{z}_B$. It will be convenient if we stack these three unit vectors together as the columns of a 3×3 matrix, in the order ${}^A\hat{x}_B$, ${}^A\hat{y}_B$, ${}^A\hat{z}_B$. We will call this matrix a **rotation matrix**, and, because this particular rotation matrix describes $\{B\}$ relative to $\{A\}$, we name it with the notation A_R (the choice of leading sub- and superscripts in the definition of rotation matrices will become clear in following sections):

$${}^A_R = [{}^A\hat{x}_B \ {}^A\hat{y}_B \ {}^A\hat{z}_B] = \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix}. \quad (2.2)$$



$$\Rightarrow \text{易得 } {}^A\hat{x}_B = \begin{bmatrix} \vec{x}_B \cdot \vec{x}_A \\ \vec{x}_B \cdot \vec{y}_A \\ \vec{x}_B \cdot \vec{z}_A \end{bmatrix}$$

$${}^A_R = \begin{bmatrix} {}^A\hat{x}_B & {}^A\hat{y}_B & {}^A\hat{z}_B \end{bmatrix}$$

$$= \begin{bmatrix} \vec{x}_B \cdot \vec{x}_A & \vec{y}_B \cdot \vec{x}_A & \vec{z}_B \cdot \vec{x}_A \\ \vec{x}_B \cdot \vec{y}_A & \vec{y}_B \cdot \vec{y}_A & \vec{z}_B \cdot \vec{y}_A \\ \vec{x}_B \cdot \vec{z}_A & \vec{y}_B \cdot \vec{z}_A & \vec{z}_B \cdot \vec{z}_A \end{bmatrix}$$

$$\Rightarrow {}^B\vec{x}_A^T = \begin{bmatrix} \vec{x}_A \cdot \vec{x}_B \\ \vec{x}_A \cdot \vec{y}_B \\ \vec{x}_A \cdot \vec{z}_B \end{bmatrix}$$

$$= \begin{bmatrix} {}^B\vec{x}_A^T \\ {}^B\vec{y}_A^T \\ {}^B\vec{z}_A^T \end{bmatrix} = \begin{bmatrix} {}^B\vec{x}_A & {}^B\vec{y}_A & {}^B\vec{z}_A \end{bmatrix} = {}^B_R^T$$

$$\therefore {}^A_R = {}^B_R^T = {}^B_R^{-1} \quad \#p22$$

$${}^1\vec{R}^{-1} \left({}^1\vec{p} - {}^1\vec{T} \right) = \underbrace{{}^0\vec{R}^{-1} {}^1\vec{R}}_{{}^0\vec{R}} \cdot {}^0\vec{p}$$

$${}^0\vec{p} = {}^0\vec{R} \left({}^1\vec{p} - {}^1\vec{T} \right) = \begin{pmatrix} \vec{I} \\ {}^1\vec{R} \end{pmatrix}$$


$$\hat{{}^0\vec{R}} = \begin{pmatrix} {}^0\vec{x} & {}^0\vec{y} & {}^0\vec{z} \\ {}^1\vec{x} & {}^1\vec{y} & {}^1\vec{z} \\ {}^2\vec{x} & {}^2\vec{y} & {}^2\vec{z} \end{pmatrix}$$

$$\therefore R = \begin{pmatrix} c\alpha & s\alpha & 0 \\ -s\alpha & c\alpha & 0 \\ 0 & 0 & 1 \end{pmatrix} \Rightarrow \begin{pmatrix} c\alpha & -s\alpha & 0 \\ s\alpha & c\alpha & 0 \\ 0 & 0 & 1 \end{pmatrix}$$

$$\therefore \hat{{}^0\vec{R}}^{-1} = \begin{pmatrix} {}^0\vec{x} & {}^0\vec{y} & {}^0\vec{z} \end{pmatrix} \text{ 在什么投影系下的矩阵}$$

$$\Rightarrow {}^1\vec{R}^{-1} = {}^0\vec{R}^T = {}^0\vec{R}$$

$$\Rightarrow {}^0\vec{p} = {}^1\vec{R}^{-1} {}^1\vec{p} + \left(-{}^1\vec{R}^T \cdot {}^1\vec{T} \right)$$



Let's start from a geometric view point. Imagine a coordinate with a vector \vec{X} where \vec{k} is the unit vector representing the axis of rotation. Let the vector \vec{x} be the result of rotating \vec{X} by an angle θ about \vec{k} . You can imagine a circle created by \vec{X} and \vec{x} with the axis of rotation going through its center (see Figure 1).




Figure 1: Axis and angle of rotation

$$\text{Hence } \vec{x} = (\vec{X} \cdot \vec{k})\vec{k} + (\vec{X} - (\vec{X} \cdot \vec{k})\vec{k})\cos\theta + (\vec{k} \times \vec{X})\sin\theta$$

(Also a good exercise to prove that $\vec{k} \times \vec{X}$ is perpendicular to $\vec{X} - (\vec{X} \cdot \vec{k})\vec{k}$)

Let define a skew symmetric matrix K such that $K = J(\vec{k})$. This means

$$K = \begin{bmatrix} 0 & -k_3 & k_2 \\ k_3 & 0 & -k_1 \\ -k_2 & k_1 & 0 \end{bmatrix} \text{ and we know that } K\vec{v} = \vec{k} \times \vec{v}$$

$$\begin{aligned}
 &= \begin{pmatrix} k_x \\ k_y \\ k_z \end{pmatrix} \times \begin{pmatrix} x \\ y \\ z \end{pmatrix} \\
 &= \begin{pmatrix} k_y z - k_z y \\ k_z x - k_x z \\ k_x y - k_y x \end{pmatrix} = \begin{pmatrix} 0 & -k_3 & k_2 \\ k_3 & 0 & -k_1 \\ -k_2 & k_1 & 0 \end{pmatrix} \begin{pmatrix} x \\ y \\ z \end{pmatrix} \\
 &\quad \vec{k} \quad \vec{x} \quad \vec{k} \quad \vec{x}
 \end{aligned}$$

Now we can write \vec{x} as

$$\begin{aligned}\vec{x} &= \vec{X} - \vec{X} + (\vec{X} \bullet \vec{k})\vec{k} + (\vec{X} - (\vec{X} \bullet \vec{k})\vec{k}) \cos \theta + (K\vec{X}) \sin \theta \\ &= \vec{X} - (\vec{X} - (\vec{X} \bullet \vec{k})\vec{k}) + (\vec{X} - (\vec{X} \bullet \vec{k})\vec{k}) \cos \theta + (K\vec{X}) \sin \theta \\ &= \vec{X} - (1 - \cos \theta)(\vec{X} - (\vec{X} \bullet \vec{k})\vec{k}) + (K\vec{X}) \sin \theta\end{aligned}\tag{2}$$

There exists an identity that $a \times (a \times b) = (a \bullet a)b - (a \bullet b)a$. You can also try to prove this for exercise as well. Now we can rewrite $(\vec{X} - (\vec{X} \bullet \vec{k})\vec{k})$ using this identity as

$$(\vec{X} - (\vec{X} \bullet \vec{k})\vec{k}) = (\vec{k} \bullet \vec{k})\vec{X} - (\vec{X} \bullet \vec{k})\vec{k} = \vec{k} \times (\vec{X} \times \vec{k}) = -\vec{k} \times (\vec{k} \times \vec{X})\tag{3}$$

Note here that $(\vec{k} \bullet \vec{k})$ is just 1, so this doesn't change anything. Then rewrite the result using the property of the skew symmetric matrix K , we get

$$-\vec{k} \times (\vec{k} \times \vec{X}) = -\vec{k} \times K\vec{X} = -(K(K\vec{X})) = -K^2 \vec{X} \quad (4)$$

Substitute (4) in (2), we get

$$\begin{aligned}\vec{x} &= \vec{X} - (1 - \cos \theta)(K^2 \vec{X}) + (K\vec{X}) \sin \theta \\ &= (I + (1 - \cos \theta)K^2 + \sin \theta K)\vec{X}\end{aligned}$$

Since $\vec{x} = R\vec{X}$, therefore, the rotation matrix is described by

$$R = (I + (1 - \cos \theta)K^2 + \sin \theta K)$$

$$q = (x, y, z, \alpha, \beta, \gamma) \in \text{Euler}$$

$$q = (x, y, z, \vec{F}, \theta) \quad (5)$$

$$\begin{aligned}\vec{r} &= \vec{k} \cdot \vec{\theta} \\ \vec{k} &= \frac{\vec{r}}{\|\vec{r}\|} = \vec{\theta}\end{aligned} \quad (6)$$

Rodrigues formula.

Now we can use this formula to find back \vec{k} and θ . Knowing that $R^T(\vec{k}, \theta) = R(\vec{k}, -\theta)$ applying Rodrigues formula for both sides, we will get

$$\boxed{\begin{aligned}R - R^T &= 2 \sin \theta K \\ K &= \frac{R - R^T}{2 \sin \theta}\end{aligned}}$$

$$\begin{pmatrix} a & b & c \\ d & e & f \\ g & h & I \end{pmatrix} - \begin{pmatrix} q & d & g \\ s & e & h \\ t & f & I \end{pmatrix} = \begin{pmatrix} 0 & -e & -f \\ e & 0 & -d \\ f & d & 0 \end{pmatrix} \quad (7)$$

Hence, $\vec{k} = \frac{1}{2 \sin \theta} \text{vect}(K)$ and θ can be determined by solving $2 \sin \theta = \|\text{vect}(R - R^T)\|$

Note: Problems arise when θ is small since the axis of rotation is ill-defined and that (\vec{k}, θ) and $(-\vec{k}, -\theta)$ result in the same orientation.


- Parametrization of orientations by **unit quaternion**:

quaternion: $u = (u_1, u_2, u_3, u_4)$ with $u_1^2 + u_2^2 + u_3^2 + u_4^2 = 1.$

- Note $(u_1, u_2, u_3, u_4) =$

$(\cos \theta/2, n_x \sin \theta/2, n_y \sin \theta/2, n_z \sin \theta/2)$ with $n_x^2 + n_y^2 + n_z^2 = 1.$

$$\mathbf{n} = (n_x, n_y, n_z)$$



- Compare with representation of orientation in 2-D:


$$(u_1, u_2) = (\cos \theta, \sin \theta)$$

- Advantage of unit quaternion representation
 - Compact 没有那么多限制
 - No singularity 可逆 行列式非0
 - Naturally reflect the topology of the space of orientations
- Number of dofs = 6
- Topology: $\mathbb{R}^3 \times \text{SO}(3)$

理解一个点的运动，就能理解整个物体
的运动

- The **configuration** of a moving object is a specification of the position of **every** point on the object.


- Usually a configuration is expressed as a vector of position & orientation parameters: $q = (q_1, q_2, \dots, q_n)$




- The **configuration space** C is the set of all possible configurations.
 - A configuration is a point in C .




Where can we put $\bullet q_B$?



An obstacle in the robot's workspace




Torus
(wraps horizontally and vertically)




An obstacle in the robot's workspace

Where do we put ?




Torus
(wraps horizontally and vertically)



B


How do we get from A to B ?



An obstacle in the robot's workspace

The C-space representation
of this obstacle...

- The **dimension of a configuration space** is the **minimum** number of parameters needed to specify the configuration of the object completely.
- It is also called the **number of degrees of freedom** (dofs) of a moving object.




- 3-parameter specification: $q = (x, y, \theta)$ with $\theta \in [0, 2\pi)$.
 - 3-D configuration space


- 4-parameter specification: $q = (x, y, u, v)$ with $u^2 + v^2 = 1$. Note $u = \cos\theta$ and $v = \sin\theta$. u和v是相关的
- dim of configuration space = ???
 - Does the dimension of the configuration space (number of dofs) depend on the parametrization?
- Topology: a 3-D cylinder $C = \mathbb{R}^2 \times S^1$




- Does the topology depend on the parametrization?




revolving joint



linear joint




rotational joint



twisting joint


- Example: ABB's IRB 120 robot



It is used to evaluate the robot for a specific application



What are this arm's forward kinematics?




(How does its position
depend on its joint angles?)


$$\vec{r} = f(\vec{\theta})$$



What are this arm's forward kinematics?



Find (x, y) in terms of α and β ...




$$\begin{aligned} \vec{x} = & \left(\begin{array}{c} \cos(\theta_1) \cdot l_1 \\ \sin(\theta_1) \cdot l_1 \end{array} \right) \\ + & \left(\begin{array}{c} \cos(\theta_1 + \theta_2) \cdot l_2 \\ \sin(\theta_1 + \theta_2) \cdot l_2 \end{array} \right) \end{aligned}$$

Keeping it “simple”

$$c_\alpha = \cos(\alpha), s_\alpha = \sin(\alpha)$$

$$c_\beta = \cos(\beta), s_\beta = \sin(\beta)$$

$$c_+ = \cos(\alpha + \beta), s_+ = \sin(\alpha + \beta)$$



$$\begin{pmatrix} x \\ y \end{pmatrix} = \begin{pmatrix} L_1 c_\alpha \\ L_1 s_\alpha \end{pmatrix} + \begin{pmatrix} L_2 c_+ \\ L_2 s_+ \end{pmatrix} \text{ Position}$$

Keeping it “simple”

$$c_\alpha = \cos(\alpha), \quad s_\alpha = \sin(\alpha)$$

$$c_\beta = \cos(\beta), \quad s_\beta = \sin(\beta)$$

$$c_+ = \cos(\alpha+\beta), \quad s_+ = \sin(\alpha+\beta)$$

In general, a point in n-D space transforms by

$$\mathbf{P}' = \text{rotate}(\text{point}) + \text{translate}(\text{point})$$

In 2-D space, this can be written as a matrix equation:

$$\begin{pmatrix} x' \\ y' \end{pmatrix} = \begin{pmatrix} \cos(\theta) & -\sin(\theta) \\ \sin(\theta) & \cos(\theta) \end{pmatrix} \begin{pmatrix} x \\ y \end{pmatrix} + \begin{pmatrix} tx \\ ty \end{pmatrix}$$

In 3-D space (or n-D), this can generalized as a matrix equation:

$$\mathbf{p}' = \mathbf{R} \mathbf{p} + \mathbf{T} \quad \text{or} \quad \mathbf{p} = \mathbf{R}^t (\mathbf{p}' - \mathbf{T})$$

$$\mathbf{p}' = \begin{bmatrix} n \\ n-1 \\ \vdots \\ 1 \end{bmatrix} \mathbf{R} \cdot \begin{bmatrix} n \\ n-1 \\ \vdots \\ 1 \end{bmatrix} \mathbf{p} + \dots$$

向量计算过于复杂，因此将引入矩阵计算

Now, using the idea of homogeneous transforms,
we can write:

$$p' = \begin{pmatrix} R & T \\ 0 & 0 & 0 & 1 \end{pmatrix} p$$

The group of rigid body rotations $\text{SO}(3) \times \mathfrak{R}(3)$ is denoted $\text{SE}(3)$ (for special Euclidean group)

What does the inverse transformation look like?

$$p' = \begin{pmatrix} R & T \\ 0 & 0 & 0 & 1 \end{pmatrix} p$$

$$P_H = \begin{pmatrix} R & \begin{pmatrix} T_x \\ T_y \\ T_z \end{pmatrix} \\ 0 & \begin{pmatrix} 1 \\ 1 \\ 1 \end{pmatrix} \end{pmatrix} \begin{pmatrix} P_x \\ P_y \\ P_z \\ 1 \end{pmatrix}$$

$$\overset{3}{\vec{P}_H} = \overset{3}{\vec{T}} \cdot \overset{2}{\vec{T}} \cdot \overset{1}{\vec{T}} \cdot \overset{0}{\vec{P}_H}$$

$\overset{3}{\vec{T}}$

$$\overset{3}{\vec{T}}^{-1} = \overset{3}{\vec{T}} = \begin{pmatrix} \overset{3}{\vec{R}} & \begin{pmatrix} -\overset{3}{\vec{R}} \cdot \overset{3}{\vec{T}} \end{pmatrix} \\ 0 & 1 \end{pmatrix}$$

Cartesian


$$\vec{p} = \begin{pmatrix} x \\ y \\ z \end{pmatrix}$$

homogeneous

$$P_H = \begin{pmatrix} x \\ y \\ z \\ 1 \end{pmatrix}$$

$$\vec{v} = \begin{pmatrix} v_x \\ v_y \\ v_z \\ 1 \end{pmatrix}$$


$$\vec{p}(t) = \vec{f}(t) - \begin{pmatrix} f_x \\ f_y \\ f_z \\ f_d \\ f_m \\ f_a \end{pmatrix} \Rightarrow \vec{o} = \begin{pmatrix} f_x(t) \\ f_y(t) \\ f_z(t) \\ f_d(t) \\ f_m(t) \\ f_a(t) \end{pmatrix}$$



z-axis along the axis of motion
 x-axis perpendicular on the two consecutive motion axes
 y in a direction defined by a right hand system


沿着运动轴的Z轴 右手螺旋，正向随旋转方向
 X轴垂直于两个连续的运动轴 两轴间的最短距离
 y在右手系统定义的方向上

- ① Find z_i
- ② Define x_i



两轴间角度


i	a_{i-1}	d_{i-1}	d_i	θ_i
-----	-----------	-----------	-------	------------



对于平行组件， d_i 是变量， θ_i 是定值
 而对于转动组件， d_i 是定值， θ_i 是变量

3D position
3D orientation } → 6D

$${}^{i-1}P = R_z(\theta) \cdot T_z(d) T_x(a) R_x(\alpha) {}^iP$$



1. Translation along z_i
2. Rotation around z_i
3. Translation along to the origin of the next frame
4. Rotation between the coordinate frames

$$\left\{ \begin{array}{l} \xrightarrow{\text{z}} \\ \xrightarrow{\text{z}} \end{array} \right. \tilde{T}_z(\theta_i) \tilde{T}_z(d_i) \tilde{T}_{x_{i-1}}(d_{i-1})$$

DH rules

$${}^{i-1}A_i = T(0, 0, d_i) \cdot R(z, \theta_i) \cdot T(a_i, 0, 0) \cdot R(x, \alpha_i)$$

modified DH rules : ${}^{i-1}P = T_x R_x R_z T_z {}^iP$



$${}^{i-1}A_i = \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & d_i \\ 0 & 0 & 0 & 1 \end{pmatrix} \cdot \begin{pmatrix} C\theta_i & -S\theta_i & 0 & 0 \\ S\theta_i & C\theta_i & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \cdot \begin{pmatrix} 1 & 0 & 0 & a_i \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \cdot \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & C\alpha_i & -S\alpha_i & 0 \\ 0 & S\alpha_i & C\alpha_i & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

.. results in

$${}^{i-1}\mathbf{A}_i = \begin{pmatrix} C\theta_i & -C\alpha_i \cdot S\theta_i & S\alpha_i \cdot S\theta_i & a_i \cdot C\theta_i \\ S\theta_i & C\alpha_i \cdot C\theta_i & -S\alpha_i \cdot C\theta_i & a_i \cdot S\theta_i \\ 0 & S\alpha_i & C\alpha_i & d_i \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

... the inverse direction can be calculated to

$${}^{i-1}\mathbf{A}_i^{-1} = {}^i\mathbf{A}_{i-1} = \begin{pmatrix} C\theta_i & S\theta_i & 0 & -a_i \\ -C\alpha_i \cdot S\theta_i & C\alpha_i \cdot C\theta_i & -S\alpha_i & -d_i \cdot S\alpha_i \\ S\alpha_i \cdot S\theta_i & -S\alpha_i \cdot C\theta_i & C\alpha_i & -d_i \cdot C\alpha_i \\ 0 & 0 & 0 & 1 \end{pmatrix}$$



i	α_i	a_i	d_i	θ_i -Bereich
1	-90	0	0	$-160^\circ \dots + 160^\circ$
2	0	450mm	0	$-227.5^\circ \dots + 47.5^\circ$
3	90	0	0	$-52.5^\circ \dots + 232.5^\circ$
4	-90	0	450mm	$-270^\circ \dots + 270^\circ$
5	90	0	0	$-105^\circ \dots + 120^\circ$
6	0	0	85mm	$-270^\circ \dots + 270^\circ$

$${}^0A_6 = {}^0A_1 \cdot {}^1A_2 \cdot {}^2A_3 \cdot {}^3A_4 \cdot {}^4A_5 \cdot {}^5A_6$$

$${}^0A_3 = {}^0A_1 \cdot {}^1A_2 \cdot {}^2A_3 = \begin{pmatrix} \cos \theta_1 \cdot \cos(\theta_2 + \theta_3) & -\sin \theta_1 & \cos \theta_1 \cdot \cos(\theta_2 + \theta_3) & a_2 \cdot \cos \theta_1 \cdot \cos \theta_2 \\ \sin \theta_1 \cdot \cos(\theta_2 + \theta_3) & \cos \theta_1 & \sin \theta_1 \cdot \sin(\theta_2 + \theta_3) & a_2 \cdot \sin \theta_1 \cdot \cos \theta_2 \\ -\sin(\theta_2 + \theta_3) & 0 & \cos(\theta_2 + \theta_3) & -a_2 \sin \theta_2 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

- Given joint variables

$$\boldsymbol{q} = (q_1, q_2, \dots, q_n)$$

- End-effector position & orientation

$$\boldsymbol{Y} = (x, y, z, \phi, \theta, \psi)$$

Homogeneous matrix T_0^n

- specifies the location of the i th coordinate frame w.r.t. the base coordinate system
- chain product of successive coordinate transformation matrices of T_{i-1}^i

$$T_0^n = T_0^1 T_1^2 \dots T_{n-1}^n$$

Orientation matrix


$$= \begin{bmatrix} R_0^n & P_0^n \\ 0 & 1 \end{bmatrix} = \begin{bmatrix} n & s & a & P_0^n \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Position vector

Yaw-Pitch-Roll representation for orientation

$$T_0^n = \begin{bmatrix} C\phi C\vartheta & C\phi S\theta S\psi - S\phi C\psi & C\phi S\theta C\psi + S\phi S\psi & p_x \\ S\phi C\theta & S\phi S\theta S\psi + C\phi C\psi & S\phi S\theta C\psi - C\phi S\psi & p_y \\ -S\theta & C\theta S\psi & C\theta C\psi & p_z \\ 0 & 0 & 0 & 1 \end{bmatrix}$$


$$T_0^n = \begin{bmatrix} n_x & s_x & a_x & p_x \\ n_y & s_y & a_y & p_y \\ n_z & s_z & a_z & p_z \\ 0 & 0 & 0 & 1 \end{bmatrix} \quad \begin{aligned} \theta &= \sin^{-1}(-n_z) \\ \psi &= \cos^{-1}\left(\frac{a_z}{\cos\theta}\right) \\ \phi &= \cos^{-1}\left(\frac{n_x}{\cos\theta}\right) \end{aligned}$$



1. Number the joints
2. Establish base frame
3. Establish joint axis Z_i
4. Locate origin,
 $X_i = +(Z_{i-1} \times Z_i) / \|Z_{i-1} \times Z_i\|$
 $Y_i = +(Z_i \times X_i) / \|Z_i \times X_i\|$
OR
(intersect. of Z_i & Z_{i-1}) OR (intersect of common normal & Z_i)
5. Establish X_i, Y_i

PUMA

260



J	θ_i	α_i	a_i	d_i
1	θ_1	-90	0	13
2	θ_2	0	8	0
3	θ_3	90	0	
4	θ_4	-90	0	8
5	θ_5	90	0	0
6	θ_6	0	0	t

 θ_i α_i a_i d_i