

Fuxi-H3 User's manual

FOR GAM

Trouble shooting

If the microphone doesn't work, please fol everything is all set.

Plug the detachable microphone into the microphone sound.



2. In the Windows system, you can also adjust the defau settings to ensure that both the front and rear panels can

E 19 2.4G transr

Earplugs Specification

Product weight: 186.6g

Speaker: Φ40mm Impedance: 17±15%Ω Sensitivity: 106±3dB Frequency response: 20Hz to 20kHz Microphone: Ø6.0×2.7mm Microphone sensitivity: -42±3dB Wireless distance: 10m Plug: 2.4GHz+Wireless+ Type-C Audio cable+3.5mm Audio cable Lithium battery: 600mAh 3.7V 2.4G working hours: 23 hours Wireless working hours: 26 hours Charging time: about 3H Charging method: (Type-C) USB 5V Size: 86*180*195mm

2.4G transmitter indicator

Power Switch Volume +

Wireless mode

- 1) Turn on the headphone, double-click the power button switch prompt:"wireless mode". When the headphone enter the pairing is "power on";
- 2) This headphone is compatible with most of smart phones and
- 3) Turn on your phone and enter wireless mode. Then search "F 4) Click "Fuxi-H3" to pair. After pairing is successful, the voice p always on. (If the device have been paired before, the headp

wireless mode.) **Key Function**

Answering incoming calls



Tip: As some mobile phones answer calls through their own rec phone instructions and set them on your mobile phone.

End current call
Short press the power button to end the current call.

Refuse to answer the phone When there is an incoming call, press the power button for 1.5 s

- Play music

 1) Play/Pause: short press the power button.

 2) Previous song: Double-click "Volume-"to previous song.

 3) Next song: Double-click "Volume+"for the next song.

 4) Volume+: Short/long press "Volume+"to increase the volume 5) Volume-: Short/long press "Volume-"to decrease the volume 5)