

433 MHz vysílač + přijímač



Dvojice těchto modulů umožní komunikaci vývojových kitů až na vzdálenost 200 m. Dosah je ovlivněn několika faktory, jako např. komunikační frekvence, napájecí napětí vysílače, použitá anténa (obsahuje pad/prokov pro připájení antény), prostředí atp. Lze použít se všemi vývojovými kity Arduino/Genuino a spoustou dalších (např. Raspberry PI).




🔁 2. SPECIFIKACE PŘIJÍMACÍHO MODULU


Typ přijímače	XY-MK-5V	Komunikační frekvence (MHz)	315 nebo 433,92
Provozní napětí	5 VDC	Citlivost (50 Ω)	-100 dBm
Provozní proud	< 6 mA	Přenos. rychlost (@ 315 MHz, -95 dBm)	< 9,6 Kb/s
Rozměry (mm)	30 x 14	Max. dosah modulů	20–200 m

3. SPECIFIKACE VYSÍLACÍHO MODULU

Typ vysílače	XY-FST	Komunikační frekvence (MHz)	315 nebo 433,92
Provozní napětí	3-12 VDC	Vysílací výkon (@ 315 MHz, 12 V)	25 mW
Provozní proud	9-40 mA	Přenos. rychlost (@ 315 MHz, -95 dBm)	< 9,6 Kb/s
Šířka pásma	2 MHz	Rozměry (mm)	19 x 19



Vysílač		Přijímač	
Pin	Popis	Pin	Popis
1	ATAD (vysílaná data)	1	GND
2	VCC, napájení 3–12 VDC	2, 3	DATA (přijatá data)
3	GND	4	VCC, napájení 5 VDC



5. Ukázka programu

Tato ukázka předpokládá použití dvou vývojových kitů, kde v jednom je zapojený přijímač a ve druhém vysílač dle obrázku výše.

Zdroj: http://arduinobasics.blogspot.cz/2014/06/433-mhz-rf-module-with-arduino-tutorial.html

```
RF Blink - Transmit sketch
    Written by ScottC 17 Jun 2014
Arduino IDE version 1.0.5
    Website: http://arduinobasics.blogspot.com
    Transmitter: FS1000A/XY-FST
    Description: A simple sketch used to test RF transmission.
#define rfTransmitPin 4 //RF Transmitter pin = digital pin 4
#define ledPin 13
                    //Onboard LED = digital pin 13
void setup() {
  pinMode(rfTransmitPin, OUTPUT);
  pinMode(ledPin, OUTPUT);
void loop(){
  for(int i=4000; i>5; i=i-(i/3)){
    digitalWrite(rfTransmitPin, HIGH);
                                            //Transmit a HIGH signal
    digitalWrite(ledPin, HIGH);
                                            //{\hbox{\tt Turn}} \ \hbox{\tt the LED on}
                                            //Wait for 1 second
    delay(2000);
    digitalWrite(rfTransmitPin,LOW);
                                           //Transmit a LOW signal
    digitalWrite(ledPin, LOW);
                                           //Turn the LED off
                                          //Variable delay
    delay(i);
 RF Blink - Receiver sketch
    Written by ScottC 17 Jun 2014
    Arduino IDE version 1.0.5
    Website: http://arduinobasics.blogspot.com
    Receiver: XY-MK-5V
    Description: A simple sketch used to test RF transmission/receiver.
#define rfReceivePin A0 //RF Receiver pin = Analog pin 0
#define ledPin 13
                         //Onboard LED = digital pin 13
unsigned int data = 0; // variable used to store received data
const unsigned int upperThreshold = 70;  //upper threshold value
const unsigned int lowerThreshold = 50;  //lower threshold value
void setup(){
 pinMode(ledPin, OUTPUT);
  Serial.begin(9600);
void loop(){
 if (data>upperThreshold) {
    digitalWrite(ledPin, LOW); //If a LOW signal is received, turn LED OFF
    Serial.println(data);
  if (data<lowerThreshold) {</pre>
    digitalWrite(ledPin, HIGH); //If a HIGH signal is received, turn LED ON
    Serial.println(data);
}
```