

$$I) R = \frac{\rho L}{A} \quad V = LA \quad \Delta V =$$

$$\frac{\Delta R}{R} = \frac{\rho \left(\frac{L'}{A'} \right) - \rho \left(\frac{L_0}{A_0} \right)}{\frac{\rho L_0}{A_0}} = \frac{\frac{L'}{A'} - \frac{L_0}{A_0}}{\frac{L_0}{A_0}}$$

Because $A_0 L_0 \approx L' A'$

$$A' \approx \frac{A_0 L_0}{L'}$$

$$\frac{\frac{L'}{A'} - \frac{L_0}{A_0}}{\frac{L_0}{A_0}} = \frac{L'^2 - L_0^2}{A_0 L_0} \cdot \frac{A_0}{L_0}$$

$$\frac{L'^2 - L_0^2}{L_0^2} \rightarrow L' = \sqrt{L^2 + 2\Delta L + 2\Delta L L_0}$$

$$\frac{L'^2 + 2\Delta L L_0 - L_0^2}{L_0^2} = \frac{\Delta R}{R}$$

$$\frac{\Delta L^2 + 2\Delta L L_0}{L_0^2} = \frac{\Delta R}{R}$$

$$\frac{\Delta L^2}{L_0^2} + \frac{2\Delta L}{L_0} = \frac{\Delta R}{R}$$

$\Delta L \ll L$

Because ΔL is very small ($\frac{\Delta L^2}{L_0^2}$) is even smaller, we can ignore it

$$\frac{2\Delta L}{L_0} \approx \frac{\Delta R}{R}$$

b) There are a couple of ways to do this the one that sticks out to me the most would be pairing this with a resistor so that there is an RC circuit and because there is an RC there is a τ , which is solved for using the charging/discharging:

Eqn 5. Once τ is known

$$C \text{ is also known. } V(t) = V_0(1 - e^{-t/\tau})$$

If you know the current going through the system and the time it takes to charge the voltage a threshold amount.

$$I = C \frac{dV}{dt} \rightarrow C = \frac{I \cdot t}{\Delta V}$$

$$\frac{dC}{dt} = \frac{\partial C}{\partial V}$$

You can also find the capacitance.