

## **EVAP PURGE CONTROL SOLENOID VALVE**

- EVAP purge control solenoid valve is a solenoid valve that consists of valve, solenoid coil and solenoid spring.
- The EVAP purge control solenoid valve opens/closes the fuel vapor passage. The ECM controls the ground circuit of the solenoid valve.



## **SYSTEM DIAGRAM**



ECM connector (Wire side)

