


ELECTRICAL SYSTEM

PAIR CONTROL SOLENOID VALVE

- · PAIR control solenoid valve is a solenoid valve that consists of valve, solenoid coil and solenoid spring.
- The PAIR control solenoid valve is controlled by the ECM, and the fresh air passage is opened/closed according to running condition.



SYSTEM DIAGRAM

1 PAIR control solenoid valve connector (Wire side)

(2) ECM connector (Wire side)

PAIR control solenoid valve connector (Solenoid valve side)

