Probabilistic Robotics*

Probabilistic Motion Models

Mohan Sridharan


University of Birmingham, UK m.sridharan@bham.ac.uk


^{*}Revised original slides that accompany the book by Thrun, Burgard and Fox.

Robot Motion


Robot motion is inherently uncertain.

• How can we model this uncertainty?





Dynamic Bayesian Network for Controls, States, and Sensations




Probabilistic Motion Models

• To implement the Bayes Filter, we need the transition model $p(x \mid x', u)$.

• The term $p(x \mid x', u)$ is the posterior probability that action u carries the robot from x' to x.

• In this chapter we consider how $p(x \mid x', u)$ can be modeled based on the motion equations.

Coordinate Systems



- In general the configuration of a robot can be described by six parameters.
- Three-dimensional Cartesian coordinates plus three Euler angles pitch, roll, and tilt.
- We will consider robots operating on a planar surface.
- State space of such systems is 3D (x,y,θ) .

Typical Motion Models

- Two types of motion models are typically considered:
 - Odometry-based
 - Velocity-based (dead reckoning)
- Odometry-based models are used when systems are equipped with wheel encoders.
- Velocity-based models have to be applied when no wheel encoders are given.
- They calculate the new pose based on the velocities and the time elapsed.

Example Wheel Encoders

These modules require +5V and GND to power them, and provide a 0 to 5V output. They provide +5V output when they "see" white, and a 0V output when they "see" black.







These disks are manufactured out of high quality laminated color plastic to offer a very crisp black to white transition. This enables a wheel encoder sensor to easily see the transitions.


Dead Reckoning


Term derived from "deduced reckoning."

 Mathematical procedure for determining the present location of a vehicle.


 Calculate the current pose of the vehicle based on its velocities and the time elapsed.

Reasons for Motion Errors






and many more ...



different wheel diameters



Odometry Model

- Robot moves from $\overline{x}_{t-1} = \langle \overline{x}, \overline{y}, \overline{\theta} \rangle$ to $\overline{x}_t = \langle \overline{x}', \overline{y}', \overline{\theta}' \rangle$ (internal coordinates).
- Compute exact odometry parameters: $\langle \delta_{rot1}, \delta_{rot2}, \delta_{trans} \rangle$

$$\delta_{trans} = \sqrt{(\overline{x}' - \overline{x})^2 + (\overline{y}' - \overline{y})^2}$$

$$\delta_{rot1} = \operatorname{atan2}(\overline{y}' - \overline{y}, \overline{x}' - \overline{x}) - \overline{\theta}$$

$$\delta_{rot2} = \overline{\theta}' - \overline{\theta} - \delta_{rot1}$$

$$\delta_{rot2}$$

$$\delta_{rot1}$$

$$\delta_{rot1}$$

The atan2 Function

 Extends the inverse tangent and correctly copes with the signs of x and y.

$$\operatorname{atan2}(y,x) \ = \ \begin{cases} \operatorname{atan}(y/x) & \text{if } x > 0 \\ \operatorname{sign}(y) \left(\pi - \operatorname{atan}(|y/x|)\right) & \text{if } x < 0 \\ 0 & \text{if } x = y = 0 \\ \operatorname{sign}(y) \pi/2 & \text{if } x = 0, y \neq 0 \end{cases}$$


Noise Model for Odometry

 Computed motion is given by the true motion corrupted with noise.

$$\begin{split} \hat{\delta}_{rot1} &= \delta_{rot1} + \varepsilon_{\alpha_1 \, \delta^2_{rot1} + \alpha_2 \, \delta^2_{trans}} \\ \hat{\delta}_{trans} &= \delta_{trans} + \varepsilon_{\alpha_3 \, \delta^2_{trans} + \alpha_4 \, \delta^2_{rot1} + \alpha_4 \, \delta^2_{rot2}} \\ \hat{\delta}_{rot2} &= \delta_{rot2} + \varepsilon_{\alpha_1 \, \delta^2_{rot2} + \alpha_2 \, \delta^2_{trans}} \end{split}$$


Typical Distributions for Probabilistic Motion Models

Normal distribution



$$\varepsilon_{\sigma^2}(x) = \frac{1}{\sqrt{2\pi\sigma^2}} e^{-\frac{1}{2}\frac{x^2}{\sigma^2}}$$

Triangular distribution



$$\varepsilon_{\sigma^2}(x) = \begin{cases} 0 \text{ if } |x| > \sqrt{6\sigma^2} \\ \frac{\sqrt{6\sigma^2 - |x|}}{6\sigma^2} \end{cases}$$

Calculating the Probability of argument 'a'

- For a normal distribution:
 - 1. Algorithm **prob_normal_distribution** (a,b^2) :

2. return
$$\frac{1}{\sqrt{2\pi b^2}} \exp\left\{-\frac{1}{2}\frac{a^2}{b^2}\right\}$$

- For a triangular distribution:
 - 1. Algorithm **prob_triangular_distribution**(a,b^2):

2. **return**
$$\max \left\{ 0, \frac{1}{\sqrt{6} \ b} - \frac{|a|}{6 \ b^2} \right\}$$

Algorithm to compute $p(x_t|u_t, x_{t-1})$

Compute odometry parameters from u_t in internal coordinates.

• Compute displacement based on desired transition from $x_{t-1} = \langle x \ y \ \theta \rangle$ to $x_t = \langle x' \ y' \ \theta' \rangle$

 Compute probability of desired state transition by matching measured odometry with desired displacement.

Calculating the Posterior Given x_{+} , x_{+-1} , and u_{+}

Algorithm motion_model_odometry(x₊, u₊, x₊₋₁)

2.
$$\delta_{trans} = \sqrt{(\overline{x}' - \overline{x})^2 + (\overline{y}' - \overline{y})^2}$$

3.
$$\delta_{rot1} = \operatorname{atan2}(\overline{y}' - \overline{y}, \overline{x}' - \overline{x}) - \overline{\theta}$$

4.
$$\delta_{rot2} = \overline{\theta}' - \overline{\theta} - \delta_{rot1}$$

5.
$$\hat{\delta}_{trans} = \sqrt{(x-x')^2 + (y-y')^2}$$

6.
$$\hat{\delta}_{rot1} = \operatorname{atan2}(y'-y, x'-x) - \theta$$

7.
$$\hat{\delta}_{rot2} = \theta' - \theta - \hat{\delta}_{rot1}$$

8.
$$p_1 = \text{prob}(\delta_{trans} - \hat{\delta}_{trans}, \alpha_3 \hat{\delta}^2_{trans} + \alpha_4 \hat{\delta}^2_{rot1} + \alpha_4 \hat{\delta}^2_{rot2})$$
 probability of state

9.
$$p_2 = \operatorname{prob}(\delta_{rot1} - \hat{\delta}_{rot1}, \alpha_1 \hat{\delta}^2_{rot1} + \alpha_2 \hat{\delta}^2_{trans})$$

10.
$$p_3 = \operatorname{prob}(\delta_{rot2} - \hat{\delta}_{rot2}, \alpha_1 \hat{\delta}^2_{rot2} + \alpha_2 \hat{\delta}^2_{trans})$$


return $p_1 \cdot p_2 \cdot p_3$ 11.

displacement based on state transition (X_{t}, X_{t-1})


$$\binom{2}{rot2}$$
probability of state

Application


- Repeated application of the sensor model for short movements.
- Typical banana-shaped distributions obtained for 2D projection of 3D posterior.



Sample-based Density Representation



Sample-based Density Representation



How to Sample from Normal or Triangular Distributions?


- Sampling from a normal distribution
 - 1. Algorithm **sample_normal_distribution**(b^2):

2. return
$$\frac{1}{2} \sum_{i=1}^{12} rand(-b, b)$$

- Sampling from a triangular distribution
 - 1. Algorithm sample_triangular_distribution(b^2):


2. return
$$\frac{\sqrt{6}}{2} \left[\operatorname{rand}(-b, b) + \operatorname{rand}(-b, b) \right]$$

Normally Distributed Samples




10⁶ samples


For Triangular Distribution




samples



10⁵



 10^4



10⁶ samples

Rejection Sampling


Sampling from arbitrary distributions:

```
1. Algorithm sample_distribution(f,b^2):
2. repeat
3. x = \text{rand}(-b, b)
4. y = \text{rand}(0, \max\{f(x) \mid x \in (-b, b)\})
5. until y \leq f(x)
6. return x
```

Example

Sampling from:

$$f(x) = \begin{cases} abs(x) & x \in [-1; 1] \\ 0 & otherwise \end{cases}$$



Algorithm to sample from $p(x_t|u_{t'}x_{t-1})$

• Compute odometry parameters $\langle \delta_{rot1}, \delta_{rot2}, \delta_{trans}
angle$

 Compute noisy odometry parameters as odometry parameters + sample from noise distribution:

$$\left\langle \hat{\delta}_{rot1}, \hat{\delta}_{rot2}, \hat{\delta}_{trans} \right
angle$$

 Compute new sample pose as previous sample pose + noisy displacement.

Sample Odometry Motion Model

Algorithm **sample_motion_model_odometry**(u_t , x_{t-1}):

$$u_{t} = \langle \delta_{rot1}, \delta_{rot2}, \delta_{trans} \rangle, x_{t-1} = \langle x, y, \theta \rangle$$

1.
$$\hat{\delta}_{rot1} = \delta_{rot1} - \text{sample}(\alpha_1 \delta^2_{rot1} + \alpha_2 \delta^2_{trans})$$

2.
$$\hat{\delta}_{trans} = \delta_{trans} - \text{sample}(\alpha_3 \delta^2_{trans} + \alpha_4 \delta^2_{rot1} + \alpha_4 \delta^2_{rot2})$$

3.
$$\hat{\delta}_{rot2} = \delta_{rot2} - \text{sample}(\alpha_1 \delta^2_{rot2} + \alpha_2 \delta^2_{trans})$$

4.
$$x' = x + \hat{\delta}_{trans} \cos(\theta + \hat{\delta}_{rot1})$$


5.
$$y' = y + \hat{\delta}_{trans} \sin(\theta + \hat{\delta}_{rot1})$$

6.
$$\theta' = \theta + \hat{\delta}_{rot1} + \hat{\delta}_{rot2}$$


7. Return
$$x_t = \langle x', y', \theta' \rangle^T$$

sample_normal_distribution


Sampling from Motion Model



Examples (Odometry-Based)



Velocity-Based Model



Exact Motion Model

- Control as translational and rotational velocities: $u_t = \begin{bmatrix} v_t \\ \omega_t \end{bmatrix}$
- Take as input the initial pose: $x_{t-1} = \langle x \ y \ \theta \rangle$ control signal u_t and successor pose: $x_t = \langle x' \ y' \ \theta' \rangle$
- Compute probability: $p(x_t | u_t, x_{t-1})$
- Velocity measurements are true values + added noise.
- Derive in noise free case; motion on a circle with: $r = \frac{v}{\omega}$
- Velocities fixed in the time interval of one step.

Equation for the Velocity Model

 Derivation of exact motion (using basic trigonometry) in Section 5.3.3.

Also see derivation for real motion.

Compute probability of specific state transitions.

 Can also estimate current state given previous state and control signal.

Probability for Velocity Model: $p(x_t|x_{t-1}, u_t)$

Algorithm motion_model_velocity (x_t, u_t, x_{t-1})

$$\mu = \frac{1}{2} \frac{(x-x')\cos\theta + (y-y')\sin\theta}{(y-y')\cos\theta - (x-x')\sin\theta}$$

$$x^* = \frac{x+x'}{2} + \mu(y-y'), \quad y^* = \frac{y+y'}{2} + \mu(x-x')$$

$$r^* = \sqrt{(x-x^*)^2 - (y-y^*)^2}$$

$$\Delta\theta = \operatorname{atan2}(y'-y^*, x'-x^*) - \operatorname{atan2}(y-y^*, x-x^*)$$

$$\hat{\upsilon} = \frac{\Delta\theta}{\Delta t} r^*, \quad \hat{\omega} = \frac{\Delta\theta}{\Delta t}, \quad \hat{\gamma} = \frac{\theta'-\theta}{\Delta t} - \hat{\omega}$$

$$\operatorname{return} \quad \operatorname{prob}(\upsilon - \hat{\upsilon}, \alpha_1\upsilon^2 + \alpha_2\omega^2).\operatorname{prob}(\omega - \hat{\omega}, \alpha_3\upsilon^2 + \alpha_4\omega^2).$$

$$\operatorname{prob}(\hat{\gamma}, \alpha_5\upsilon^2 + \alpha_6\omega^2)$$

Sampling from Velocity Model to obtain x_t

Algorithm sample_motion_model_velocity (u_t, x_{t-1})

$$\hat{\upsilon} = \upsilon + \mathbf{sample}(\alpha_1 \upsilon^2 + \alpha_2 \omega^2)$$

$$\hat{\omega} = \omega + \mathbf{sample}(\alpha_3 \upsilon^2 + \alpha_4 \omega^2)$$

$$\hat{\gamma} = \mathbf{sample}(\alpha_5 \upsilon^2 + \alpha_6 \omega^2)$$


$$x' = x - \frac{\hat{\upsilon}}{\hat{\omega}} \sin \theta + \frac{\hat{\upsilon}}{\hat{\omega}} \sin(\theta + \hat{\omega} \Delta t)$$

$$y' = y - \frac{\hat{\upsilon}}{\hat{\omega}} \cos \theta - \frac{\hat{\upsilon}}{\hat{\omega}} \cos(\theta + \hat{\omega} \Delta t)$$


$$\theta' = \theta + \hat{\omega} \Delta t + \hat{\gamma} \Delta t$$

$$\text{return} \quad x_t = (x', y', \theta')^T$$

Examples (velocity based)



Map-Consistent Motion Model



Approximation $p(x|u,x',m) = \eta \ p(x|m) \ p(x|u,x')$

Optional tasks...

- Derive motion model equations:
 - Without noise (exact motion).
 - With noise (real motion).
 - Section 5.3.3, PR.
 - Section 5.4.3, PR.

Summary

- Discussed motion models for odometry-based and velocity-based systems.
- Discussed ways to calculate posterior probability: p(x|x', u).
- Described how to sample from p(x|x', u).
- Typically calculations are done in fixed time intervals Δt .
- In practice, parameters of the models have to be learned.
- Discussed an extended motion model that takes the map into account.