
## f2V - MODULO FRECUENCIA A TENSION rev2b- 14-07-2009

## **R.OLIVA/L&R ING**

MOUNTED ON R28T DIN BOARD



Placa no compilada/linkeada con PCB pero identica notacion a "ftoV(II)\_R28T.pcbdoc"
Utilizar Ctrl-H - Select Copper para verificar rev 2022 / Can use +5V direct, reducing R1 value to 0