LGS Control Table (Updated on 26/08/25) (Draft)											
Field	Data Size	Function Code	Modbus Address	Data Name	Access	Initial Value	Range	Unit	Applications Compatibility		
									Bangkok, Pattaya Ban Pong, Ratchburi		
Device Information	2 byte	Holding Registers	0	Device Type	R	-	-	-		_	
			1	Firmware Version	R	-	-	-			
			2	Serial Number	R	-	-	-			
			3	Baud Rate	R/WF	9600	-	bps			
ă		Τ	4	Modbus Slave ID	R/WF	247	1-246	-			
			500	Factory Reset	R/WF	0	0-1				
ntrol	1 bit	Coils	501	Write data (WF type) to EEPROM	R/WF	0	0-1				
Device Control			502	-	-	-	-	-			
			503	-	-	-	-	-			
			504	-	-	-	-	-			
	2 byte	Holding Registers	110	LED 1 Brightness	R/WF	20	0-100	-			
			111	LED 1 Red Value	R/WF	255	0-255	-			
			112	LED 1 Green Value	R/WF	0	0-255	-			
Light Configuration			113	LED 1 Blue Value	R/WF	0	0-255	-			
			120	LED 2 Brightness	R/WF	20	0-100	-			
			121	LED 2 Red Value	R/WF	0	0-255	-			
			122	LED 2 Green Value	R/WF	255	0-255	-			
			123	LED 2 Blue Value	R/WF	0	0-255	-			
			130	LED 3 Brightness	R/WF	20	0-100	-			
			131	LED 3 Red Value	R/WF	0	0-255	-			
			132	LED 3 Green Value	R/WF	0	0-255	-			
			133	LED 3 Blue Value	R/WF	255	0-255	-			
			140	LED 4 Brightness	R/WF	20	0-100	-			
			141	LED 4 Red Value	R/WF	255	0-255	-			
			142	LED 4 Green Value	R/WF	255	0-255	-			
			143	LED 4 Blue Value	R/WF	0	0-255	-			

2 byte	Holding Registers	150	LED 5 Brightness	R/WF	20	0-100	-
		151	LED 5 Red Value	R/WF	0	0-255	-
		152	LED 5 Green Value	R/WF	255	0-255	-
		153	LED 5 Blue Value	R/WF	255	0-255	-
		160	LED 6 Brightness	R/WF	20	0-100	-
		161	LED 6 Red Value	R/WF	255	0-255	-
		162	LED 6 Green Value	R/WF	0	0-255	-
		163	LED 6 Blue Value	R/WF	255	0-255	-
		170	LED 7 Brightness	R/WF	20	0-100	-
		171	LED 7 Red Value	R/WF	255	0-255	-
		172	LED 7 Green Value	R/WF	165	0-255	-
		173	LED 7 Blue Value	R/WF	0	0-255	-
		180	LED 8 Brightness	R/WF	20	0-100	-
		181	LED 8 Red Value	R/WF	255	0-255	-
		182	LED 8 Green Value	R/WF	255	0-255	-
		183	LED 8 Blue Value	R/WF	255	0-255	-
1 bit	Coils	1001	LED 1 Enable	R/WR	0	0-1	-
		1002	LED 2 Enable	R/WR	0	0-1	-
		1003	LED 3 Enable	R/WR	0	0-1	-
		1004	LED 4 Enable	R/WR	0	0-1	-
		1005	LED 5 Enable	R/WR	0	0-1	-
		1006	LED 6 Enable	R/WR	0	0-1	-
		1007	LED 7 Enable	R/WR	0	0-1	-
		1008	LED 8 Enable	R/WR	0	0-1	-
			151 152 153 160 161 162 163 170 171 172 173 180 181 182 183 1001 1002 1003 1004 1005 1006 1007	151 LED 5 Red Value 152	151	151 LED 5 Red Value R/WF 0	151