Namo	Port/IO	ши	Port/IO	Name	Logond	Nama	Port/IO	UЭ		Port/IO	Namo
Name	POIVIO	H1			Legend	Name	POIVIO	H2	_	POIVIO	Name
GPIO0		1 2		GPIO1	PRI	SGPI00		1	2		SGPI01
GPIO2		3 4		GPIO3	SEC	SGPIO2		3			SGPIO3
TR	RADIO_TR		RADIO_RR	RR	SHARE	SGPIO4		5	6		SGPIO5
GPIO4		7 8		GPIO5	AUX	SGPIO6		7			PDM 1 (12V)
GPIO5		9 10		GPIO7	PWR	GND		9	10		PDM 2 (12V)
GPIO8		11 12		GPIO9	NC	PDM 3 (BAT)			12		PDM 4 (BAT)
GPIO10		13 14		GPIO11		PDM 5 (5V)		13	14		GND
GPIO12		15 16		GPIO13		PDM 6 (5V)		15	16		PDM 7 (5V)
RADIO_RX	RADIO_RX	17 18	RADIO_TX	RADIO_TX		GND		17	18		PDM 8 (3v3)
I2C2_SDA		19 20		I2C2_SCL		PDM 9 (3v3)		19	20		PDM 10 (3v3)
SYS_SPI_SCK		21 22		SYS_SPI_MISC		GND		21	22		GND
SYS_SPI_MOS	I	23 24		SYS_SPI_NSS		12V		23	24		12V
~FAULT		25 26		VREF0		5V_SYS	5V	25	26	5V	5V_SYS
SENSE		27 28		VREF1		VCC_SYS	3V	27	28	3V	VCC_SYS
~RESET	SYS_RESET	<mark>29</mark> 30		VREF2		DGND	GND	29	30	GND	DGND
OFF_VCC		31 32		5V_USB		AGND		31	32	GND	DGND
MHX_CRAP	SGPIO9	33 34	SGPIO10	MHX_CRAP		RESERVED		33	34		RESERVED
MHX_CRAP	SGPIO11	35 36	SGPIO12	MHX_CRAP		PCM_IN		35	36		PCM_IN
MHX_CRAP	SGPIO13	<mark>37</mark> 38		MHX_CRAP		RESERVED		37	38		RESERVED
MHX_CRAP		39 40		MHX_CRAP		RESERVED		39	40		RESERVED
SYS_SDA	SYS_SDA	<mark>41</mark> 42		VBACKUP		IDIODE_OUT		41	42		IDIODE_OUT
SYS_SCL	SYS_SCL	<mark>43</mark> 44		RSVD0		IDIODE_OUT		43	44		IDIODE_OUT
RSVD1		45 46		RSVD2		VBATT		45	46		VBATT
USER0	~BUFEN_PRI	47 48	~BUFEN_SEC	USER1		GND	GND	47	48	GND	GND
USER2	I2C2_SDA	49 50	SGPIO7	USER3		USER9	SPI2_NSS	49	50	SPI2_SCK	USER10
USER4	I2C2_SCL	51 52	SGPIO8	USER5		USER11	SPI2_MISO	51	52	SPI2_MOSI	USER12