

INSTRUCTOR WORKBOOK

SRV02 Base Unit Experiment For Matlab®/Simulink® Users

Standardized for ABET Evaluation Criteria

Developed by: Jacob Apkarian, Ph.D., Quanser Michel Lévis, M.A.Sc., Quanser Hakan Gurocak, Ph.D., Washington State University SRV02 educational solutions are powered by: MATLAB SIMULINK Course material complies with:

CAPTIVATE. MOTIVATE. GRADUATE.

© 2011 Quanser Inc., All rights reserved.

Quanser Inc. 119 Spy Court Markham, Ontario L3R 5H6 Canada info@quanser.com Phone: 1-905-940-3575

Fax: 1-905-940-3576

Printed in Markham, Ontario.

For more information on the solutions Quanser Inc. offers, please visit the web site at: http://www.quanser.com

This document and the software described in it are provided subject to a license agreement. Neither the software nor this document may be used or copied except as specified under the terms of that license agreement. All rights are reserved and no part may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Quanser Inc.

ACKNOWLEDGEMENTS

Quanser, Inc. would like to thank Dr. Hakan Gurocak, Washington State University Vancouver, USA, for rewriting this manual to include embedded outcomes assessment.

CONTENTS

Prefa	ace		1
1	SRV02	2 Modeling	1
	1.1	Background	2
		1.1.1 Modeling Using First-Principles	2
		1.1.2 Modeling Using Experiments	8
	1.2	Pre-Lab Questions	3
	1.3	Lab Experiments	13
		1.3.1 Frequency Response Experiment	13
		1.3.2 Bump Test Experiment	17
		1.3.3 Model Validation Experiment	19
		1.3.4 Results	22
	1.4	System Requirements	23
		1.4.1 Overview of Files	23
		1.4.2 Configuring the SRV02 and the Lab Files	24
	1.5	Lab Report	26
		1.5.1 Template for Content	26
	4.0	1.5.2 Tips for Report Format	27
	1.6	Scoring Sheet for Pre-Lab Questions	28
	1.7	Scoring Sheet for Lab Report (Modeling)	29
2	SRV02	2 Position Control	31
	2.1	Background	32
		2.1.1 Desired Position Control Response	32
		2.1.2 PV Controller Design	35
		2.1.3 PIV Controller	36
	2.2	Pre-Lab Questions	38
	2.3	Lab Experiments	42
		2.3.1 Step Response Using PV Controller	42
		2.3.2 Ramp Response Using PV Controller	48
		2.3.3 Ramp Response with No Steady-State Error	52
		2.3.4 Results	57
	2.4	System Requirements	58
		2.4.1 Overview of Files	58
		2.4.2 Setup for Position Control Simulations	59
		2.4.3 Setup for Position Control Implementation	60
	2.5	Lab Report	61
		2.5.1 Template for Content (Step Response Experiment)	62
		2.5.2 Template for Content (Ramp Response with PV)	63
		2.5.3 Template for Content (Ramp Response with No Steady-State Error)	64
		2.5.4 Tips for Report Format	65
	2.6	Scoring Sheet for Pre-Lab Questions	66
	2.7	Scoring Sheet for Lab Report (STEP)	67
	2.8	Scoring Sheet for Lab Report (RAMP PV)	68
	2.9	Scoring Sheet for Lab Report (Ramp Response with No Steady-State Error)	69



3		2 Speed Control	/1			
	3.1	Background	72			
		3.1.1 Desired Response	72			
		3.1.2 PI Control Design	73			
		3.1.3 Lead Control Design	75			
		3.1.4 Sensor Noise	80			
	3.2	Pre-Lab Questions	81			
	3.3	Lab Experiments	83			
		3.3.1 Step Response with PI Control	83			
		3.3.2 Step Response with LEAD Control	89			
	0.4	3.3.3 Results	93			
	3.4	System Requirements	94			
		3.4.1 Overview of Files	94			
		3.4.2 Setup for Speed Control Simulation	95			
		3.4.3 Setup for Speed Control Implementation	96			
	3.5	Lab Report	97			
		3.5.1 Template for Content (PI Control Experiments)	98			
		3.5.2 Template for Content (Lead Control Experiments)	99			
	0.0	3.5.3 Tips for Report Format	100			
	3.6	Scoring Sheet for Pre-Lab Questions	101			
	3.7	Scoring Sheet for Lab Report (PI)	102			
	3.8	Scoring Sheet for Lab Report (LEAD)	103			
Α		SRV02 QUARC Integration				
	A.1	Applying Voltage to SRV02				
		Motor	106			
		A.1.1 Making the Simulink Model	106			
		A.1.2 Compiling the Model	108			
		A.1.3 Running QUARC Code	109			
	A.2	Reading Position using				
		Potentiometer	111			
		A.2.1 Reading the Potentiometer Voltage	111			
		A.2.2 Measuring Position	112			
	A.3	Measuring Speed using				
		Tachometer	115			
	A.4	Measuring Position using				
		Encoder	117			
	A.5	Saving Data	119			
В	SRV0	2 Instructor's Guide	121			
	B.1	Pre-lab Questions and				
		Lab Experiments	122			
		B.1.1 How to use the pre-lab questions	122			
		B.1.2 How to use the laboratory experiments	122			
	B.2	Assessment for ABET				
		Accreditation	123			
		B.2.1 Assessment in your course	123			
		B.2.2 How to score the pre-lab questions	124			
		B.2.3 How to score the lab reports	124			
		B.2.4 Assessment of the outcomes for the course	126			
		B.2.5 Assessment workbook	128			
	B.3	Rubrics	129			

PREFACE

Every laboratory chapter in this manual is organized into four sections.

Background section provides all the necessary theoretical background for the experiments. Students should read this section first to prepare for the Pre-Lab questions and for the actual lab experiments.

Pre-Lab Questions section is not meant to be a comprehensive list of questions to examine understanding of the entire background material. Rather, it provides targetted questions for preliminary calculations that need to be done prior to the lab experiments. All or some of the questions in the Pre-Lab section can be assigned to the students as homework. One possibility is to assign them as a homework one week prior to the actual lab session and ask the students to bring their assignment to the lab session.

Lab Experiments section provides step-by-step instructions to conduct the lab experiments and to record the collected data.

System Requirements section describes all the details of how to configure the hardware and software to conduct the experiments. It is assumed that the hardware and software configuration have been completed by the instructor or the teaching assistant *prior* to the lab sessions. However, if the instructor chooses to, the students can also configure the systems by following the instructions given in this section.

Assessment of ABET outcomes is incorporated into this manual as shown by indicators such as A-1, A-2 . These indicators correspond to specific performance criteria for an outcome. Details of the targetted ABET outcomes, a list of performance criteria for each outcome, scoring rubrics and instructions on how to use them in assessment can be found in the *SRV02 Instructor's Guide*, Appendix B, in this manual.

If the instructor chooses to assign the Pre-Lab questions as homework, then the outcome targetted by these questions can be assessed using the student work. The outcomes targetted by the lab experiments can be assessed from the lab reports submitted by the students. These reports should follow the specific template for content given at the end of each laboratory chapter. This will provide a basis to assess the outcomes easily.



LABORATORY 1

SRV02 MODELING

The objective of this experiment is to find a transfer function that describes the rotary motion of the SRV02 load shaft. The dynamic model is derived analytically from classical mechanics principles and using experimental methods.

Topics Covered

- Deriving the dynamics equation and transfer function for the SRV02 servo plant using the first-principles.
- Obtaining the SRV02 transfer function using a frequency response experiment.
- Obtaining the SRV02 transfer function using a bump test.
- Tuning the obtained transfer function and validating it with the actual system response.

Prerequisites

In order to successfully carry out this laboratory, the user should be familiar with the following:

- Data acquisition device (e.g. Q2-USB), the power amplifier (e.g. VoltPAQ-X1), and the main components of the SRV02 (e.g. actuator, sensors), as described in References [2], [4], and [6], respectively.
- Wiring and operating procedure of the SRV02 plant with the amplifier and data-aquisition (DAQ) device, as discussed in Reference [6].
- Transfer function fundamentals, e.g. obtaining a transfer function from a differential equation.
- Laboratory described in Appendix A to get familiar with using QUARC® with the SRV02.

Completion Time

The approximate times to complete each section is summarized in Table 1.1.

Section	Time (min)
Pre-lab (Section 1.2)	75 min
In-lab: Frequency Response (Section 1.3.1)	60 min
In-lab: Bump Test (Section 1.3.2)	30 min
In-lab: Model Validaton (Section 1.3.3)	45 min

Table 1.1: Approximate Time to Complete Modeling Lab



1.1 Background

The angular speed of the SRV02 load shaft with respect to the input motor voltage can be described by the following first-order transfer function

$$\frac{\Omega_l(s)}{V_m(s)} = \frac{K}{(\tau s + 1)} \tag{1.1.1}$$

where $\Omega_l(s)$ is the Laplace transform of the load shaft speed $\omega_l(t)$, $V_m(s)$ is the Laplace transform of motor input voltage $v_m(t)$, K is the steady-state gain, τ is the time constant, and s is the Laplace operator.

The SRV02 transfer function model is derived analytically in Section 1.1.1 and its K and τ parameters are evaluated. These are known as the nominal model parameter values. The model parameters can also be found experimentally. Sections 1.1.2.1 and 1.1.2.2 describe how to use the frequency response and bump-test methods to find K and τ . These methods are useful when the dynamics of a system are not known, for example in a more complex system. After the lab experiments, the experimental model parameters are compared with the nominal values.

1.1.1 Modeling Using First-Principles

1.1.1.1 Electrical Equations

The DC motor armature circuit schematic and gear train is illustrated in Figure 1.1. As specified in [6], recall that R_m is the motor resistance, L_m is the inductance, and k_m is the back-emf constant.




Figure 1.1: SRV02 DC motor armature circuit and gear train

The back-emf (electromotive) voltage $e_b(t)$ depends on the speed of the motor shaft, ω_m , and the back-emf constant of the motor, k_m . It opposes the current flow. The back emf voltage is given by:

$$e_b(t) = k_m \omega_m(t) \tag{1.1.2}$$

Using Kirchoff's Voltage Law, we can write the following equation:

$$V_m(t) - R_m I_m(t) - L_m \frac{dI_m(t)}{dt} - k_m \omega_m(t) = 0$$
 (1.1.3)

Since the motor inductance L_m is much less than its resistance, it can be ignored. Then, the equation becomes

$$V_m(t) - R_m I_m(t) - k_m \omega_m(t) = 0 {(1.1.4)}$$

Solving for $I_m(t)$, the motor current can be found as:

$$I_m(t) = \frac{V_m(t) - k_m \omega_m(t)}{R_m} \tag{1.1.5}$$

1.1.1.2 Mechanical Equations

In this section the equation of motion describing the speed of the load shaft, ω_l , with respect to the applied motor torque, τ_m , is developed.

Since the SRV02 is a one degree-of-freedom rotary system, Newton's Second Law of Motion can be written as:

$$J \cdot \alpha = \tau \tag{1.1.6}$$

where J is the moment of inertia of the body (about its center of mass), α is the angular acceleration of the system, and τ is the sum of the torques being applied to the body. As illustrated in Figure 1.1, the SRV02 gear train along with the viscous friction acting on the motor shaft, B_m , and the load shaft B_l are considered. The load equation of motion is

$$J_l \frac{d\omega_l(t)}{dt} + B_l \omega_l(t) = \tau_l(t)$$
(1.1.7)

where J_l is the moment of inertia of the load and τ_l is the total torque applied on the load. The load inertia includes the inertia from the gear train and from any external loads attached, e.g. disc or bar. The motor shaft equation is expressed as:

$$J_m \frac{d\omega_m(t)}{dt} + B_m \omega_m(t) + \tau_{ml}(t) = \tau_m(t)$$
(1.1.8)

where J_m is the motor shaft moment of inertia and τ_{ml} is the resulting torque acting on the motor shaft from the load torque. The torque at the load shaft from an applied motor torque can be written as:

$$\tau_l(t) = \eta_a K_a \tau_{ml}(t) \tag{1.1.9}$$

where K_g is the gear ratio and η_g is the gearbox efficiency. The planetary gearbox that is directly mounted on the SRV02 motor (see [6] for more details) is represented by the N_1 and N_2 gears in Figure 1.1 and has a gear ratio of

$$K_{gi} = \frac{N_2}{N_1} \tag{1.1.10}$$

This is the *internal* gear box ratio. The motor gear N_3 and the load gear N_4 are directly meshed together and are visible from the outside. These gears comprise the *external* gear box which has an associated gear ratio of

$$K_{ge} = \frac{N_4}{N_3} \tag{1.1.11}$$

The gear ratio of the SRV02 gear train is then given by:

$$K_q = K_{qe}K_{qi} \tag{1.1.12}$$

Thus, the torque seen at the motor shaft through the gears can be expressed as:

$$\tau_{ml}(t) = \frac{\tau_l(t)}{\eta_q K_q} \tag{1.1.13}$$

Intuitively, the motor shaft must rotate K_q times for the output shaft to rotate one revolution.

$$\theta_m(t) = K_a \theta_l(t) \tag{1.1.14}$$



We can find the relationship between the angular speed of the motor shaft, ω_m , and the angular speed of the load shaft, ω_l by taking the time derivative:

$$\omega_m(t) = K_q \omega_l(t) \tag{1.1.15}$$

To find the differential equation that describes the motion of the load shaft with respect to an applied motor torque substitute (1.1.13), (1.1.15) and (1.1.7) into (1.1.8) to get the following:

$$J_m K_g \frac{d\omega_l(t)}{dt} + B_m K_g \omega_l(t) + \frac{J_l(\frac{d\omega_l(t)}{dt}) + B_l \omega_l(t)}{\eta_g K_g} = \tau_m(t)$$
(1.1.16)

Collecting the coefficients in terms of the load shaft velocity and acceleration gives

$$(\eta_g K_g^2 J_m + J_l) \frac{d\omega_l(t)}{dt} + (\eta_g K_g^2 B_m + B_l)\omega_l(t) = \eta_g K_g \tau_m(t)$$
(1.1.17)

Defining the following terms:

$$J_{eq} = \eta_g K_g^2 J_m + J_l {(1.1.18)}$$

$$B_{eq} = \eta_g K_q^2 B_m + B_l {(1.1.19)}$$

simplifies the equation as:

$$J_{eq}\frac{d\omega_l(t)}{dt} + B_{eq}\omega_l(t) = \eta_g K_g \tau_m(t)$$
(1.1.20)

1.1.1.3 Combining the Electrical and Mechanical Equations

In this section the electrical equation derived in Section 1.1.1.1 and the mechanical equation found in Section 1.1.1.2 are brought together to get an expression that represents the load shaft speed in terms of the applied motor voltage.

The motor torque is proportional to the voltage applied and is described as

$$\tau_m(t) = \eta_m k_t I_m(t) \tag{1.1.21}$$

where k_t is the current-torque constant (N.m/A), η_m is the motor efficiency, and I_m is the armature current. See [6] for more details on the SRV02 motor specifications.

We can express the motor torque with respect to the input voltage $V_m(t)$ and load shaft speed $\omega_l(t)$ by substituting the motor armature current given by equation 1.1.5 in Section 1.1.1.1, into the current-torque relationship given in equation 1.1.21:

$$\tau_{m}(t) = \frac{\eta_{m} k_{t} \left(V_{m}(t) - k_{m} \omega_{m}(t) \right)}{R_{m}}$$
(1.1.22)

To express this in terms of V_m and ω_l , insert the motor-load shaft speed equation 1.1.15, into 1.1.21 to get:

$$\tau_m(t) = \frac{\eta_m k_t \left(V_m(t) - k_m K_g \omega_l(t) \right)}{R_{--}}$$
(1.1.23)

If we substitute (1.1.23) into (1.1.20), we get:

$$J_{eq}\left(\frac{d}{dt}w_l(t)\right) + B_{eq}w_l(t) = \frac{\eta_g K_g \eta_m k_t \left(V_m(t) - k_m K_g \omega_l(t)\right)}{R_m}$$
(1.1.24)

After collecting the terms, the equation becomes

$$\left(\frac{d}{dt}w_l(t)\right)J_{eq} + \left(\frac{k_m\eta_g K_g^2\eta_m k_t}{R_m} + B_{eq}\right)\omega_l(t) = \frac{\eta_g K_g\eta_m k_t V_m(t)}{R_m} \tag{1.1.25}$$

This equation can be re-written as:

$$\left(\frac{d}{dt}w_l(t)\right)J_{eq} + B_{eq,v}\omega_l(t) = A_m V_m(t)$$
(1.1.26)

where the equivalent damping term is given by:

$$B_{eq,v} = \frac{\eta_g K_g^2 \eta_m k_t k_m + B_{eq} R_m}{R_m}$$
 (1.1.27)

and the actuator gain equals

$$A_m = \frac{\eta_g K_g \eta_m k_t}{R_m} \tag{1.1.28}$$

1.1.2 Modeling Using Experiments

In Section 1.1.1 you learned how the system model can be derived from the first-principles. A linear model of a system can also be determined purely experimentally. The main idea is to experimentally observe how a system reacts to different inputs and change structure and parameters of a model until a reasonable fit is obtained. The inputs can be chosen in many different ways and there are a large variety of methods. In Sections 1.1.2.1 and 1.1.2.2, two methods of modeling the SRV02 are outlined: (1) frequency response and, (2) bump test.

1.1.2.1 Frequency Response

In Figure 1.2, the response of a typical first-order time-invariant system to a sine wave input is shown. As it can be seen from the figure, the input signal (u) is a sine wave with a fixed amplitude and frequency. The resulting output (y) is also a sinusoid with the *same* frequency but with a different amplitude. By varying the frequency of the input sine wave and observing the resulting outputs, a Bode plot of the system can be obtained as shown in Figure 1.3.




Figure 1.2: Typical frequency response

The Bode plot can then be used to find the steady-state gain, i.e. the DC gain, and the time constant of the system. The cuttoff frequency, ω_c , shown in Figure 1.3 is defined as the frequency where the gain is 3 dB less than the maximum gain (i.e. the DC gain). When working in the linear non-decibel range, the 3 dB frequency is defined as the frequency where the gain is $\frac{1}{\sqrt{2}}$, or about 0.707, of the maximum gain. The cutoff frequency is also known as the bandwidth of the system which represents how fast the system responds to a given input.






Figure 1.3: Magnitude Bode plot

The magnitude of the frequency response of the SRV02 plant transfer function given in equation 1.1.1 is defined as:

$$|G_{wl,v}(w)| = \left| \frac{\Omega_l(\omega j)}{V_m(\omega j)} \right|$$
 (1.1.29)

where ω is the frequency of the motor input voltage signal V_m . We know that the transfer function of the system has the generic first-order system form given in Equation 1.1.1. By substituting $s=j\,w$ in this equation, we can find the frequency response of the system as:

$$\frac{\Omega_l(\omega j)}{V_m(\omega j)} = \frac{K}{\tau \omega j + 1} \tag{1.1.30}$$

Then, the magnitude of it equals

$$|G_{wl,v}(\omega)| = \frac{K}{\sqrt{1 + \tau^2 \,\omega^2}}$$
 (1.1.31)

Let's call the frequency response model parameters $K_{e,f}$ and $\tau_{e,f}$ to differentiate them from the nominal model parameters, K and τ , used previously. The steady-state gain or the DC gain (i.e. gain at zero frequency) of the model is:

$$K_{e,f} = |G_{wl,v}(0)| (1.1.32)$$

1.1.2.2 Bump Test

The bump test is a simple test based on the step response of a stable system. A step input is given to the system and its response is recorded. As an example, consider a system given by the following transfer function:

$$\frac{Y(s)}{U(s)} = \frac{K}{\tau s + 1}$$
 (1.1.33)

The step response shown in Figure 1.4 is generated using this transfer function with K=5 rad/V.s and $\tau=0.05$ s.

The step input begins at time t_0 . The input signal has a minimum value of u_{min} and a maximum value of u_{max} . The resulting output signal is initially at y_0 . Once the step is applied, the output tries to follow it and eventually settles at its steady-state value y_{ss} . From the output and input signals, the steady-state gain is

$$K = \frac{\Delta y}{\Delta u} \tag{1.1.34}$$




Figure 1.4: Input and output signal used in the bump test method

where $\Delta y = y_{ss} - y_0$ and $\Delta u = u_{max} - u_{min}$. In order to find the model time constant, τ , we can first calculate where the output is supposed to be at the time constant from:

$$y(t_1) = 0.632y_{ss} + y_0 ag{1.1.35}$$

Then, we can read the time t_1 that corresponds to $y(t_1)$ from the response data in Figure 1.4. From the figure we can see that the time t_1 is equal to:

$$t_1 = t_0 + \tau \tag{1.1.36}$$

From this, the model time constant can be found as:

$$\tau = t_1 - t_0 \tag{1.1.37}$$

Going back to the SRV02 system, a step input voltage with a time delay t_0 can be expressed as follows in the Laplace domain:

$$V_m(s) = \frac{A_v e^{(-s t_0)}}{s} \tag{1.1.38}$$

where A_v is the amplitude of the step and t_0 is the step time (i.e. the delay). If we substitute this input into the system transfer function given in Equation (1.1.1), we get:

$$\Omega_l(s) = \frac{KA_v \, e^{(-s \, t_0)}}{(\tau \, s + 1) \, s} \tag{1.1.39}$$

We can then find the SRV02 load speed step response, $w_l(t)$, by taking inverse Laplace of this equation. Here we need to be careful with the time delay t_0 and note that the initial condition is $\omega_l(0^-) = \omega_l(t_0)$.

$$\omega_l(t) = K A_v \left(1 - e^{\left(-\frac{t - t_0}{\tau} \right)} \right) + \omega_l(t_0)$$
 (1.1.40)



1.2 Pre-Lab Questions

Before you start the lab experiments given in Section 1.3, you should study the background materials provided in Section 1.1 and work through the questions in this Section.

1. A-1, A-2 In Section 1.1.1.3 we obtained an equation (1.1.26) that described the dynamic behavior of the load shaft speed as a function of the motor input voltage. Starting from this equation, find the transfer function $\frac{\Omega_l(s)}{V_{trn}(s)}$.

Answer 1.2.1

Outcome Solution

A-1 Taking the Laplace transform of the equations and assuming $\omega_l(0^-)=0$

gives

$$J_{eq}s\Omega_l(s) + B_{eq,v}\Omega_l(s) = A_m V_m(s)$$
(Ans.1.2.1)

A-2 Solving for $\Omega_l(s)/V_m(s)$ gives the plant transfer function

$$\frac{\Omega_l(s)}{V_m(s)} = \frac{A_m}{J_{eq}s + B_{eq},v} \tag{Ans.1.2.2} \label{eq:local_local_problem}$$

2. A-1, A-2 Express the steady-state gain (K) and the time constant (τ) of the process model (Equation (1.1.1)) in terms of the J_{eq} , $B_{eq,v}$, and A_m parameters.

Answer 1.2.2

Outcome Solution

A-1 We need to match the coefficients of the transfer function found in (Ans.1.2.2) to the coefficients of the transfer function in equation 1.1.1.

A-2 The time constant parameter is

$$\tau = \frac{J_{eq}}{B_{eq,v}} \tag{Ans.1.2.3}$$

and the steady-state gain is

$$K = \frac{A_m}{B_{eq,v}} \tag{Ans.1.2.4}$$

3. A-2 Calculate the $B_{eq,v}$ and A_m model parameters using the system specifications given in [6]. The parameters are to be calculated based on an SRV02-ET in the high-gear configuration.

Outcome Solution

A-2

The $B_{eq,v}$ viscous damping expression is given in Equation 1.1.27. All the parameters are defined in Reference [6] including the experimentally determined equivalent viscous damping parameter $B_{eq}=0.015N\,m\,s/rad$ (in the high-gear configuration). Substituting all the specifications into 1.1.27 gives

$$B_{eq,v} = 0.0844 \text{N m s / rad}$$
 (Ans.1.2.5)

Evaluating the actuator gain expression in 1.1.28 with the SRV02 parameters gives

$$A_m = 0.129 \text{ N m/V}$$
 (Ans.1.2.6)

4. A-2 Calculate the moment of inertia about the motor shaft. Note that $J_m = J_{tach} + J_{m,rotor}$ where J_{tach} and $J_{m,rotor}$ are the moment of inertia of the tachometer and the rotor of the SRV02 DC motor, respectively. Use the specifications given in [6].

Answer 1.2.4

Outcome Solution

A-2 The moment of inertia about the motor shaft equals

$$J_m = J_{tach} + J_{m,rotor} (Ans.1.2.7)$$

Evaluating the above expression with the parameters outlined in [6] gives

$$J_m = 4.606251061 \times 10^{-7} \text{ kg m}^2$$
 (Ans.1.2.8)

5. A-2 The load attached to the motor shaft includes a 24-tooth gear, two 72-tooth gears, and a single 120-tooth gear along with any other external load that is attached to the load shaft. Thus, for the gear moment of inertia J_g and the external load moment of inertia $J_{l,ext}$, the load inertia is $J_l = J_g + J_{l,ext}$. Using the specifications given in [6] find the total moment of inertia J_g from the gears . **Hint:** Use the definition of moment of inertia for a disc $J_{disc} = \frac{mr^2}{2}$.



Outcome Solution

A-2 The formula to calculate the moment of inertia of a disc is

$$J_{disc} = \frac{mr^2}{2} \tag{Ans.1.2.9}$$

where m is the mass and r is the radius. Assuming the gears are discs and using the parameters given in Reference [6], the moment of inertia of the 24-tooth, 72-tooth, and 120-tooth gears are

$$J_{24} = 1.01 \times 10^{-7} \text{ kg m}^2$$
 (Ans.1.2.10)

$$J_{72} = 5.44 \times 10^{-6} \text{ kg m}^2$$
 (Ans.1.2.11)

and

$$J_{120} = 4.18 \times 10^{-5} \text{ kg m}^2$$
 (Ans.1.2.12)

The total moment of inertia from the gears is

$$J_g = J_{24} + 2J_{72} + J_{120}$$
 (Ans.1.2.13)

which equals

$$J_a = 5.28 \times 10^{-5} \text{ kg m}^2$$
 (Ans.1.2.14)

6. A-2 Assuming the disc load is attached to the load shaft, calculate the inertia of the disc load, $J_{ext,l}$, and the total load moment of inertia, J_l .

Answer 1.2.6

Outcome Solution

A-2 Using the formula in Ans.1.2.9 with the m_b and r_b disc load parameters found in Reference [6], the external load moment of inertia equals

$$J_{l.ext} = 5.00 \times 10^{-5} \text{ kg m}^2$$
 (Ans.1.2.15)

Using $J_l = J_q + J_{l,ext}$, the total load moment of inertia is

$$J_l = 1.03 \times 10^{-4} \text{ kg m}^2$$
 (Ans.1.2.16)

7. A-2 Evaluate the equivalent moment of inertia J_{eq} .

Answer 1.2.7

Outcome Solution

A-2 Using Equation 1.1.18 with the gear train and motor specifications listed in Reference [6] and the load inertia found in 1.2.6, the equivalent moment of inertia acting on the SRV02 motor shaft is

$$J_{eq} = 0.00213 \text{ kg m}^2.$$
 (Ans.1.2.17)

8. A-2 Calculate the steady-state model gain K and time constant τ . These are the *nominal model parameters* and will be used to compare with parameters that are later found experimentally.

Answer 1.2.8

Outcome Solution

A-2 Using equations Ans.1.2.3 and Ans.1.2.4 with the $B_{eq,v}$, A_m , and J_{eq} parameters found in equations Ans.1.2.5, Ans.1.2.6, and Ans.1.2.17, the steady-state gain is

$$K = 1.53 \text{ rad/(V s)}$$
 (Ans.1.2.18)

and the model time constant is

$$\tau = 0.0253 \, \text{s}$$
 (Ans.1.2.19)

9. A-1, A-2 Referring to Section 1.1.2.1, find the expression representing the time constant τ of the frequency response model given in Equation 1.1.31. Begin by evaluating the magnitude of the transfer function at the cutoff frequency ω_c .

Answer 1.2.9

Outcome Solution

A-1 By definition, the DC gain drops 3 dB (or $\frac{1}{\sqrt{2}}$) at this frequency. Therefore,

$$|G_{wl,v}(w_c)| = \frac{1}{2} |G_{wk,v}(0)| \sqrt{2}$$
 (Ans.1.2.20)

A-2 Applying this to the SRV02 frequency response magnitude in 1.1.31 above gives:

$$\frac{1}{2} |G_{wl,v}(0)| \sqrt{2} = \frac{G_{wl,v}(0)}{\sqrt{1 + \tau_{e,f}^2 \,\omega_c^2}}$$
 (Ans.1.2.21)

We can then solve for the time constant as:

$$\tau_{e,f} = \frac{1}{|\omega_c|} \tag{Ans.1.2.22}$$

10. A-2, A-3 Referring to Section 1.1.2.2, find the steady-state gain of the step response and compare it with Equation 1.1.34. **Hint:** The the steady-state value of the load shaft speed can be defined as $\omega_{l,ss} = \lim_{t \to \infty} \omega_l(t)$.

Outcome Solution

A-2 Using the definition of the steady-state value of the load shaft

$$\omega_{l,ss} = \lim_{t \to \infty} \omega_l(t) \tag{Ans.1.2.23}$$

The limit of the servo step response given in (1.1.40) is

$$\omega_{l,ss} = K A_v + \omega_l(t_0)$$
 (Ans.1.2.24)

and the steady-state gain is

$$K = \frac{\omega_{l,ss} - \omega_l(t_0)}{A_v}$$
 (Ans.1.2.25)

A-3 This is consistent with the $\Delta y/\Delta u$ relationship in Equation 1.1.34.

11. A-2, A-3 Evaluate the step response given in equation 1.1.40 at $t=t_0+\tau$ and compare it with Equation 1.1.34.

Answer 1.2.11

Outcome Solution

A-2 Substituting $t = t_0 + \tau$ in equation 1.1.40 gives the load shaft rate

$$\omega_l(t_0 + \tau) = K A_v \left(1 - e^{-1}\right) + \omega_l(t_0)$$
 (Ans.1.2.26)

A-3 This is consistent with the $y(t_1)$ expression in equation 1.1.34.

1.3 Lab Experiments

The main goal of this laboratory is to find a transfer function (model) that describes the rotary motion of the SRV02 load shaft as a function of the input voltage. We can obtain this transfer function experimentally using one of the following two methods:

- · Frequency response, or
- · Bump test

In this laboratory, first you will conduct two experiments exploring how these methods can be applied to a real system. Then, you will conduct a third experiment to fine tune the parameters of the transfer functions you obtained and to validate them.

Experimental Setup

The q_srv02_mdl Simulink diagram shown in Figure 1.5 will be used to conduct the experiments. The SRV02-ET subsystem contains QUARC® blocks that interface with the DC motor and sensors of the SRV02 system as discussed in Reference [4]. The SRV02 Model uses a *Transfer Fcn* block from the Simulink® library to simulate the SRV02 system. Thus, both the measured and simulated load shaft speed can be monitored simultaneously given an input voltage.




Figure 1.5: q srv02 mdl Simulink diagram used to model SRV02.

IMPORTANT: Before you can conduct these experiments, you need to make sure that the lab files are configured according to your SRV02 setup. If they have not been configured already, then you need to go to Section 1.4.2 to configure the lab files first.

1.3.1 Frequency Response Experiment

As explained in 1.1.2.1 earlier, the frequency response of a linear system can be obtained by providing a sine wave input signal to it and recording the resulting output sine wave from it. In this experiment, the input signal is the motor voltage and the output is the motor speed.



In this method, we keep the amplitude of the input sine wave constant but vary its frequency. At each frequency setting, we record the amplitude of the output sine wave. The ratio of the output and input amplitudes at a given frequency can then be used to create a Bode magnitude plot. Then, the transfer function for the system can be extracted from this Bode plot.

1.3.1.1 Steady-state gain

First, we need to find the steady-state gain of the system. This requires running the system with a constant input voltage. To create a 2*V* constant input voltage follow these steps:

1. In the Simulink® diagram, double-click on the Signal Generator block and ensure the following parameters are set:

Wave form: sineAmplitude: 1.0Frequency: 0.0Units: Hertz

- 2. Set the Amplitude (V) slider gain to 0.
- 3. Set the Offset (V) block to 2.0 V.
- 4. Open the load shaft speed scope, w_l (rad/s), and the motor input voltage scope, V_m (V).
- 5. Click on QUARC | Build to compile the Simulink diagram.
- 6. Select QUARC | Start to run the controller. The SRV02 unit should begin rotating in one direction. The scopes should be reading something similar to Figures 1.6 and 1.7. Note that in the w_I (rad/s) scope, the yellow trace is the measured speed while the purple trace is the simulated speed (generated by the SRV02 Model block).




Figure 1.6: Constant input motor voltage.




Figure 1.7: Load shaft speed response to a constant input.

7. B-5 Measure the speed of the load shaft and enter the measurement in Table 1.2 below under the f = 0 Hz row.

The measurement can be done directly from the scope. Alternatively, you can use $Matlab^{@}$ commands to find the maximum load speed using the saved wl variable. When the controller is stopped, the $w_{-}l$ (rad/s) scope saves the last 5 seconds of response data to the $Matlab^{@}$ workspace in the wl parameter. It has the following structure: wl(:,1) is the time vector, wl(:,2) is the measured speed, and wl(:,3) is the simulated speed.

8. B-7 Calculate the steady-state gain both in linear and decibel (dB) units as explained in 1.1.2.1. Enter the resulting numerical value in the f = 0 Hz row of Table 1.2. Also, enter its non-decibel value in Table 1.3 in Section 1.3.4.

Outcome Solution

B-7

The frequency response magnitude is found from the collected data using Equation 1.1.29. In terms of the frequency in Hertz, i.e. $\omega=0$, the relationship is

$$|G_{wl,v}(0)| = \left|\frac{\Omega_l(0)}{V_m(\omega\,j)}\right| \tag{Ans.1.3.1}$$

As shown in Table 1.2, at f = 0 Hz the maximum load speed measured is $\Omega_l(2\pi)=3.31\,rad/s$ and the voltage is $V_m(0)=2.0\,V$. The gain is therefore

$$|G_{wl,v}(0)| = 1.66 \text{ rad/(V s)}$$
 (Ans.1.3.2)

Using the expression

$$|G_{wl,v}(0)|_d B = 20 Log 10 (1.66)$$
 (Ans.1.3.3)

the gain in dB is

$$|G_{wl,v}(0)|_d B = 4.40 \text{ dB}$$
 (Ans.1.3.4)

This is the steady-state gain of the system.

1.3.1.2 Gain at varying frequencies

In this part of the experiment, we will send an input sine wave at a certain frequency to the system and record the amplitude of the output signal. We will then increment the frequency and repeat the same observation.

To create the input sine wave:

- 1. Set the Offset (V) block to 0 V.
- 2. Set the Amplitude (V) slider gain to 2.0 V.
- 3. The SRV02 unit should begin rotating smoothly back and forth and the scopes should be reading a response similar to Figures 1.8 and 1.9.




Figure 1.8: Input motor voltage scope.




Figure 1.9: Load shaft speed sine wave response.

- 4. Measure the maximum positive speed of the load shaft at f = 1.0 Hz input and enter it in Table 1.2 below.

 As before, this measurement can be done directly from the scope or, preferably, you can use Matlab[®] commands to find the maximum load speed using the saved *wl* variable.
- 5. Calculate the gain of the system (in both linear and dB units) and enter the results in Table 1.2.



- 6. Now increase the frequency to f = 2.0 Hz by adjusting the frequency parameter in the *Signal Generator* block. Measure the maximum load speed and calculate the gain. Repeat this step for each of the frequency settings in Table 1.2.
- 7. B-5, K-2 Using the Matlab® plot command and the data collected in Table 1.2, generate a Bode magnitude plot. Make sure the amplitude and frequency scales are in decibels. When making the Bode plot, ignore the f = 0 Hz entry as the logarithm of 0 is not defined.

Outcome Solution

- B-5 If the experimental procedure was followed correctly, the data markers in the following figure should be correct.
- K-2 The sample_freq_rsp.m script contains the collected data in Table 1.2 and generates the corresponding magnitude Bode plot shown in Figure 1.10.




Figure 1.10: Sample Bode plot after performing frequency response laboratory.

8. K-1 Calculate the time constant $\tau_{e,f}$ using the obtained Bode plot by finding the cutoff frequency. Label the Bode plot with the -3 dB gain and the cutoff frequency. Enter the resulting time constant in Table 1.3. **Hint:** Use the *ginput* command to obtain values from the Matlab[®] figure.

Outcome Solution

K-1 As illustrated in Figure 1.10, the -3 dB gain is

$$|G_{wl,v}(\omega_c)|_{dB} = 1.36 \text{ dB}$$
 (Ans.1.3.5)

and the corresponding cutoff frequency is

$$f_c = 7.04 \text{ Hz}$$
 (Ans.1.3.6)

or

$$\omega_c = 44.3 \text{ rad/s}$$
 (Ans.1.3.7)

Using Equation Ans.1.2.22, the time constant is

$$\tau_{e,f} = 0.0226 \text{ s}$$
 (Ans.1.3.8)

- 9. Click the Stop button on the Simulink®diagram toolbar (or select QUARC | Stop from the menu) to stop the experiment.
- 10. Turn off the power to the amplifier if no more experiments will be performed on the SRV02 in this session.

f (Hz)	Amplitude (V)	Maximum Load	Gain: G(ω)	Gain: $ G(\omega) $
		Speed (rad/s)	(rad/s/V)	(rad/s/V, dB)
0.0	2.0	3.31	1.66	4.37
1.0	2.0	3.25	1.62	4.22
2.0	2.0	3.14	1.57	3.91
3.0	2.0	2.96	1.48	3.40
4.0	2.0	2.77	1.39	2.83
5.0	2.0	2.59	1.29	2.24
6.0	2.0	2.45	1.22	1.75
7.0	2.0	2.34	1.17	1.38
8.0	2.0	2.22	1.11	0.89

Table 1.2: Collected frequency response data.

1.3.2 Bump Test Experiment

In this method, a step input is given to the SRV02 and the corresponding load shaft response is recorded. Using the saved response, the model parameters can then be found as discussed in Section 1.1.2.2.

To create the step input:

- 1. Double-click on the Signal Generator block and ensure the following parameters are set:
 - · Wave form: square
 - Amplitude: 1.0
 - Frequency: 0.4
 - Units: Hertz
- 2. Set the Amplitude (V) slider gain to 1.5 V.
- 3. Set the Offset (V) block to 2.0 V.



- 4. Open the load shaft speed scope, w_l (rad/s), and the motor input voltage cope, V_m (V).
- 5. Click on QUARC | Build to compile the Simulink diagram.
- 6. Select QUARC | Start to run the controller. The gears on the SRV02 should be rotating in the same direction and alternating between low and high speeds. The response in the scopes should be similar to Figures 1.11 and 1.12.




Figure 1.11: Square input motor voltage.




Figure 1.12: Load shaft speed step response.

7. B-5, K-2 Plot the response in Matlab[®]. Recall that the maximum load speed is saved in the Matlab[®] workspace under the *wl* variable.

Answer 1.3.4

Outcome Solution

B-5 If the experimental procedure was followed correctly, the magnitudes and shapes of the signals shown in Figure 1.13 below should be correct.

K-2 See the sample_bumptest.m Matlab®script. It loads sample measured data and plots the response as shown here.




Figure 1.13: Sample SRV02 step response.

8. K-1 Find the steady-state gain using the measured step response and enter it in Table 1.3. *Hint:* Use the Matlab[®] ginput command to measure points off the plot.

Outcome

Solution

K-1

See the sample_bumptest.m Matlab®script for more details on calculating the steady-state gain automatically. From Figure 1.13, the measured initial and steady-state load shaft speeds are

$$\omega_l(t_0) = 0.530 \text{ rad/s}$$
 (Ans.1.3.9)

and

$$\omega_{l,ss} = 5.92 \text{ rad/s}$$
 (Ans.1.3.10)

and the input voltage amplitude is

$$A_v = 3.0 \text{ V}$$
 (Ans.1.3.11)

Using Equation Ans.1.2.25 with the collected data above, the resulting steady-state gain is:

$$K = 1.79 \text{ rad/(V s)}$$
 (Ans.1.3.12)

9. K-1 Find the time constant from the obtained response and enter the result in Table 1.3.

Answer 1.3.6

Outcome

Solution

K-1

See the sample_bumptest.m Matlab® script for more details on the method used to calculate the time constant from a saved response. In order to find time of the first decay $t_1=t_0+\tau$, the corresponding speed measurement defined in Equation Ans.1.2.26 must be found. From Figure 1.13, the time at the shaft speed

$$\omega_l(t_0 + \tau) = 3.92 \text{ rad/s}$$
 (Ans.1.3.13)

is

$$t_1 = 6.273 \text{ s}$$
 (Ans.1.3.14)

The step start time is

$$t_0 = 6.250 \text{ s}$$
 (Ans.1.3.15)

Given the step start time t_0 and decay time t_1 with Equation 1.1.37, the time constant is:

$$\tau = 0.023 \text{ s}$$
 (Ans.1.3.16)

- 10. Click the Stop button on the Simulink®diagram toolbar (or select QUARC | Stop from the menu) to stop the experiment.
- 11. Turn off the power to the amplifier if no more experiments will be performed on the SRV02 in this session.

1.3.3 Model Validation Experiment

In this experiment, you will adjust the model parameters you found in the previous experiments to tune the transfer function. Our goal is to match the simulated system response with the parameters you found as closely as possible to the response of the actual system.

To create a step input:



1. Double-click on the Signal Generator block and ensure the following parameters are set:

· Wave form: square

Amplitude: 1.0Frequency: 0.4

· Units: Hertz

- 2. Set the Amplitude (V) slider gain to 1.0 V.
- 3. Set the Offset (V) block to 1.5 V.
- 4. Open the load shaft speed scope, w 1 (rad/s), and the motor input voltage scope, V m (V).
- 5. Click on QUARC | Build to compile the Simulink® diagram.
- 6. Select QUARC | Start to run the controller. The gears on the SRV02 should be rotating in the same direction and alternating between low and high speeds and the scopes should be as shown in figures 1.14 and 1.15. Recall that the yellow trace is the measured load shaft rate and the purple trace is the simulated trace. By default, the steady-state gain and the time constant of the transfer function used in simulation are set to: $K = 1 \ rad/s/V$ and $\tau = 0.1s$. These model parameters do not accurately represent the system.




Figure 1.14: Input square voltage.




Figure 1.15: Speed step response. Simulation done with default model parameters: K=1 and $\tau=0.1$.

- 7. Enter the command K = 1.25 in the Matlab[®] Command Window.
- 8. Update the parameters used by the Transfer Function block in the simulation by selecting the Edit | Update Diagram item in the q_srv02_mdl Simulink®diagram and observe how the simulation changes.
- 9. Enter the command tau = 0.2 in the Matlab[®] Command Window.
- 10. Update the simulation again by selecting the Edit | Update Diagram and observe how the simulation changes.
- 11. B-9 Vary the gain and time constant model parameters. How do the gain and the time constant affect the system response?

Answer 1.3.7

B-9

Outcome Solution

The steady-state of the simulated speed increases as K is increased. When the time constant, τ , is increased, the peak time of the response increases. That is, it takes longer for the speed to reach its steady-state from the point when the step is engaged.

- 12. Enter the nominal values, K and τ , that were found in Section 1.2 in the Matlab® Command Window. Update the parameters and examine how well the simulated response matches the measured one.
- 13. B-5 If the calculations were done properly, then the model should represent the actual system quite well. However, there are always some differences between each servo unit and, as a result, the model can always be tuned to match the system better. Try varying the model parameters until the simulated trace matches the measured response better. Enter these tuned values under the Model Validation section of Table 1.3.
- 14. B-9 Provide two reasons why the nominal model does not represent the SRV02 with better accuracy.

Outcome Solution

B-9 Here are a few reasons:

- Inductance not taken into account. Using a second-order model to represent the SRV02 would be more accurate.
- Because the SRV02 specifications vary, e.g. back-emf has a rated variance of 12%, the model parameters that are calculated from these specifications will have an inherit variance.
- Equivalent viscous damping parameter was derived experimentally for one SRV02 unit. The viscous friction in each SRV02 is slightly different.
- · Coulomb friction different in each SRV02.

15. K-2 Create a Matlab® figure that shows the measured and simulated response of each method (the nominal model, the frequency response model, and the bumptest model). Enter the nominal values, K and τ , in the Matlab® Command Window, update the parameters, and examine the response. Repeat for the frequency response parameters $K_{e,f}$ and $\tau_{e,f}$ along with the bump test variables $K_{e,b}$ and $\tau_{e,b}$.




Figure 1.16: Model comparison

Answer 1.3.9



16. B-9 Explain how well the nominal model, the frequency response model, and the bumptest model represent the SRV02 system.

Answer 1.3.10

Outcome Solution

B-9 The nominal and frequency response model parameters both represent the SRV02 well. The frequency response model represents the steady-state system slightly better while the transient is represented more accurately with the nominal method. The parameters derived using the bump test method do not represent the SRV02 as well as the other models. As shown in the bottom plot of Figure 1.16, the simulated steady-state value is higher then the measured speed.

- 17. Click the Stop button on the Simulink®diagram toolbar (or select QUARC | Stop from the menu) to stop the experiment.
- 18. Turn off the power to the amplifier if no more experiments will be performed on the SRV02 in this session.

1.3.4 Results

B-6 Fill out Table 1.3 below, with your results.

From Section	Description	Symbol	Value	Unit
1.2	Nominal Values			
	Open-Loop Steady-State Gain	K	1.53	rad/(V.s)
	Open-Loop Time Constant	au	0.0254	s
1.3.1.1	Frequency Response Exp.			
	Open-Loop Steady-State Gain	$K_{e,f}$	1.65	rad/(V.s)
	Open-Loop Time Constant	$ au_{e,f}$	0.0226	s
1.3.2	Bump Test Exp.			
	Open-Loop Steady-State Gain	$K_{e,b}$	1.80	rad/(V.s)
	Open-Loop Time Constant	$ au_{e,b}$	0.023	s
1.3.3	Model Validation			
	Open-Loop Steady-State Gain	$K_{e,v}$	1.60	rad/(V.s)
	Open-Loop Time Constant	$\mid au_{e,v} \mid$	0.0254	s

Table 1.3: Summary of results for the SRV02 Modeling laboratory.

1.4 System Requirements

Before you begin this laboratory make sure:

- QUARC® is installed on your PC, as described in Reference [1].
- You have a QUARC compatible data-aquisition (DAQ) card installed in your PC. For a listing of compliant DAQ cards, see Reference [5].
- SRV02 and amplifier are connected to your DAQ board as described Reference [6].

1.4.1 Overview of Files

Table 1.4: Files supplied with the SRV02 Modeling laboratory.

File Name	Description
01 - SRV02 Modeling - Student	This laboratory guide contains pre-lab and in-lab exer-
Manual.pdf	cises demonstrating how to model the Quanser SRV02
	rotary plant. The in-lab exercises are explained using the
	QUARC software.
setup_srv02_exp01_mdl.m	The main Matlab®script that sets the SRV02 motor and
	sensor parameters. Run this file only to setup the lab-
	oratory.
config_srv02.m	Returns the configuration-based SRV02 model specifica-
	tions Rm, kt, km, Kg, eta_g, Beq, Jeq, and eta_m, the sen-
	sor calibration constants <i>K_POT, K_ENC</i> , and <i>K_TACH</i> ,
	and the amplifier limits VMAX_AMP and IMAX_AMP.
calc_conversion_constants.m	Returns various conversions factors.
q_srv02_mdl.mdl	Simulink® file that implements the open-loop controller for
	the SRV02 system using QUARC.
01 - SRV02 Modeling - Instructor	Same as the student version except with solutions.
Manual.pdf	
srv02_exp01_modeling.mws	Maple® worksheet used to derive the transfer function
	model involved in the experiment. Waterloo Maple® 9, or
	a later release, is required to open, modify, and execute
	this file.
srv02_exp01_modeling.html	HTML presentation of the Maple® Worksheet. It allows
	users to view the content of the Maple® file without having
	Maple® 9 installed. No modifications to the equations can
	be performed when in this format.
/0	entinged on the poyt page)

(Continued on the next page)



File Name	Description
d_model_param.m	Calculates the SRV02 model parameters K and tau based on the device specifications <i>Rm</i> , <i>kt</i> , <i>km</i> , <i>Kg</i> , <i>eta_g</i> , <i>Beq</i> , <i>Jeq</i> , and <i>eta_m</i> .
sample_freq_rsp.m	Generates Bode plot and finds model parameters based on measured data.
sample_bumptest.m	Finds the model parameters given an input step voltage and the corresponding measured load speed response. Users can use the saved responses contained in the MAT files sample_mdl_data_wl.mat and sample_mdl_data_vm.mat, or perform the experiment again and use the response currently saved in the Matlab®workspace.
sample_model_validation.m	Generates a Matlab [®] figure that plots the response from the nominal, frequency response, and bumptest models using the MAT files described below.
data_mdl_val_nom.mat	Sample step load speed response using nominal model.
data_mdl_val_freqrsp.mat	Sample step load speed response using frequency response model.
data_mdl_val_bumptest.mat	Sample step load speed response using bumptest model.
data_bumptest_wl.mat	Bumptest data file: sample load speed step response used by sample_bumptest.m script.
data_bumptest_Vm.mat	Bumptest data file: sample input voltage used by sample_bumptest.m script.

1.4.2 Configuring the SRVO2 and the Lab Files

Before beginning the lab exercises the SRV02 device, the q_srv02_mdl Simulink® diagram, and the setup_srv02_exp02.m script must be configured.

Follow these steps to get the system ready for this lab:

- 1. Set up the SRV02 in the high-gear configuration and with the disc load as described in Reference [5].
- 2. Load the Matlab® software.
- 3. Browse through the Current Directory window in Matlab® and find the folder that contains the SRV02 modeling files, e.g. q_srv02_mdl.mdl.
- 4. Double-click on the q_srv02 mdl.mdl file to open the Simulink®diagram shown in Figure 1.5.
- 5. **Configure DAQ:** Double-click on the HIL Initialize block in the Simulink® diagram and ensure it is configured for the DAQ device that is installed in your system. For instance, the block shown in Figure 1.5 is setup for the Quanser Q8 hardware-in-the-loop board. See [1] for more information on configuring the HIL Initialize block.
- 6. **Configure Sensor**: The speed of the load shaft can be measured using various sensors. Set the *Spd Src* Source block in q_srv02_mdl, as shown in Figure 1.5, as follows:
 - 1 to use tachometer
 - · 2 to use the encoder
- 7. It is recommended that the tachometer sensor be used to perform this laboratory. However, for users who do not have a tachometer with their servo, e.g. SRV02 or SRV02-E options, they may choose to use the encoder with a high-pass filter to get a velocity measurement.
- 8. Go to the *Current Directory* window and double-click on the setup_srv02_exp01_mdl.m file to open the setup script for the q_srv02_mdl Simulink®model.

9. Configure setup script: The beginning of the setup script is shown below. Ensure the script is setup to match the configuration of your actual SRV02 device. For example, the script given below is setup for an SRV02-ET plant in the high-gear configuration mounted with a disc load and it is actuated using the Quanser VoltPAQ device with a motor cable gain of 1. See [6] for more information on SRV02 plant options and corresponding accessories.

Instructors: Set MODELING_TYPE = 'AUTO' to load the model parameter matching the SRV02 system. Students will have this set to 'MANUAL', which generates default modeling parameters that do not match the system.

```
%% SRV02 Configuration
% External Gear Configuration: set to 'HIGH' or 'LOW'
EXT GEAR CONFIG = 'HIGH';
% Encoder Type: set to 'E' or 'EHR'
ENCODER TYPE = 'E';
% Is SRV02 equipped with Tachometer? (i.e. option T): set to 'YES' or 'NO'
TACH_OPTION = 'YES';
% Type of Load: set to 'NONE', 'DISC', or 'BAR'
LOAD TYPE = 'DISC';
% Amplifier Gain: set VoltPAQ amplifier gain to 1
K AMP = 1;
\% Power Amplifier Type: set to 'VoltPAQ', 'UPM_1503', 'UPM_2405', or 'Q3'
AMP_TYPE = 'VoltPAQ';
% Digital-to-Analog Maximum Voltage (V)
VMAX DAC = 10;
%% Lab Configuration
% Type of Controller: set it to 'AUTO', 'MANUAL'
MODELING_TYPE = 'AUTO';
% MODELING_TYPE = 'MANUAL';
```

10. Run the script by selecting the Debug | Run item from the menu bar or clicking on the *Run* button in the tool bar. The messages shown below should be generated in the Matlab®Command Window. These are default model parameters and do not accurately represent the SRV02 system.

```
Calculated SRV02 model parameter:
   K = 1 rad/s/V
   tau = 0.1 s
```



1.5 Lab Report

When you prepare your lab report, you can follow the outline given in Section 1.5.1 to build the *content* of your report. Also, in Section 1.5.2 you can find some basic tips for the *format* of your report.

1.5.1 Template for Content

I. PROCEDURE

I.1. Frequency Response Experiment

- 1. Briefly describe the main goal of this experiment and the procedure.
 - Briefly describe the experimental procedure (Section 1.3.1.1), Steady-state gain
 - Briefly describe the experimental procedure (Section 1.3.1.2), Gain at varying frequencies

I.2. Bump Test Experiment

1. Briefly describe the main goal of this experiment and the experimental procedure (Section 1.3.2).

I.3. Model Validation Experiment

1. Briefly describe the main goal of this experiment and the experimental procedure (Section 1.3.3).

II. RESULTS

Do not interpret or analyze the data in this section. Just provide the results.

- 1. Bode plot from step 7 in Section 1.3.1.2, Gain at varying frequencies.
- 2. Response plot from step 7 in Section 1.3.2, Bump Test Experiment.
- 3. Response plot from step 15 in Section 1.3.3, Model Validation Experiment.
- 4. Provide data collected in this laboratory (from Table 1.2).

III. ANALYSIS

Provide details of your calculations (methods used) for analysis for each of the following:

III.1. Frequency Response Experiment

- 1. Step 8 in Section 1.3.1.1, Steady-state gain.
- 2. Step 8 in Section 1.3.1.2, Gain at varying frequencies.

III.2. Bump Test Experiment

1. Steps 8 and 9 in Section 1.3.2.

IV. CONCLUSIONS

Interpret your results to arrive at logical conclusions.

1. Steps 11, 14, and 16 in Section 1.3.3.

1.5.2 Tips for Report Format

PROFESSIONAL APPEARANCE

- Has cover page with all necessary details (title, course, student name(s), etc.)
- Each of the required sections is completed (Procedure, Results, Analysis and Conclusions).
- Typed.
- · All grammar/spelling correct.
- · Report layout is neat.
- · Does not exceed specified maximum page limit, if any.
- · Pages are numbered.
- · Equations are consecutively numbered.
- Figures are numbered, axes have labels, each figure has a descriptive caption.
- Tables are numbered, they include labels, each table has a descriptive caption.
- Data are presented in a useful format (graphs, numerical, table, charts, diagrams).
- No hand drawn sketches/diagrams.
- · References are cited using correct format.



1.6 Scoring Sheet for Pre-Lab Questions

Student Name:

Question ¹	A-1	A-2	A-3
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
Total			

¹This scoring sheet is for the Pre-Lab questions in Section 1.2

1.7 Scoring Sheet for Lab Report (Modeling)

Student Name:

	CONTENT FORMAT					MAT		
Item ¹	K-1	K-2	B-5	B-6	B-7	B-9	GS-1	GS-2
I. PROC	I. PROCEDURE							
I.1. Freq	I.1. Frequency Response Experiment							
1								
I.2. Bum	p Test Exp	eriment						
1								
I.3. Mode	el Validatio	n Experim	nent					
1								
II. RESU	LTS							
1								
2								
3								
4								
III. ANAI	YSIS							
III.1. Fre	quency Re	esponse E	xperiment					
1								
2								
III.2. Bur	III.2. Bump Test Experiment							
1								
IV. CONCLUSIONS								
1								
Total								

¹This scoring sheet corresponds to the report template in Section 1.5.1.



LABORATORY 2

SRV02 POSITION CONTROL

The objective of this laboratory is to develop feedback systems that control the position of the rotary servo load shaft. Using the proportional-integral-derivative (PID) family, controllers are designed to meet a set of specifications.

Topics Covered

- Design of a proportional-velocity (PV) controller for position control of the servo load shaft to meet certain time-domain requirements.
- · Actuator saturation.
- · Design of a proportional-velocity-integral (PIV) controller to track a ramp reference signal.
- Simulation of the PV and PIV controllers using the developed model of the plant to ensure the specifications are met without any actuator saturation.
- Implementation of the controllers on the Quanser SRV02 device to evaluate their performance.

Prerequisites

In order to successfully carry out this laboratory, the user should be familiar with the following:

- Data acquisition device (e.g. Q2-USB), the power amplifier (e.g. VoltPAQ-X1), and the main components of the SRV02 (e.g. actuator, sensors), as described in References [2], [4], and [6], respectively.
- Wiring and operating procedure of the SRV02 plant with the amplifier and data-aquisition (DAQ) device, as discussed in Reference [6].
- Transfer function fundamentals, e.g. obtaining a transfer function from a differential equation.
- Laboratory described in Appendix A to get familiar with using QUARC® with the SRV02.

Completion Time

The approximate times to complete each section is summarized in Table 2.1.

Section	Time (min)
Pre-lab (Section 1.2)	45 min
In-lab: PV Step Response (Section 2.3.1)	45 min
In-lab: PV Ramp Response (Section 2.3.2)	60 min
In-lab: PIV Ramp Response (Section 2.3.3)	120 min

Table 2.1: Approximate Time to Complete Position Control Lab



2.1 Background

2.1.1 Desired Position Control Response

The block diagram shown in Figure 2.1 is a general unity feedback system with compensator (controller) C(s) and a transfer function representing the plant, P(s). The measured output, Y(s), is supposed to track the reference signal R(s) and the tracking has to match to certain desired specifications.




Figure 2.1: Unity feedback system.

The output of this system can be written as:

$$Y(s) = C(s) P(s) (R(s) - Y(s))$$
(2.1.1)

By solving for Y(s), we can find the closed-loop transfer function:

$$\frac{Y(s)}{R(s)} = \frac{C(s) P(s)}{1 + C(s) P(s)}$$
(2.1.2)

Recall in Laboratory: SRV02 Modelling Section 1, the SRV02 voltage-to-speed transfer function was derived. To find the voltage-to-position transfer function, we can put an integrator (1/s) in series with the speed transfer function (effectively integrating the speed output to get position). Then, the resulting open-loop voltage-to-load gear position transfer function becomes:

$$P(s) = \frac{K}{s(\tau s + 1)} \tag{2.1.3}$$

As you can see from this equation, the plant is a second order system. In fact, when a second order system is placed in series with a proportional compensator in the feedback loop as in Figure 2.1, the resulting closed-loop transfer function can be expressed as:

$$\frac{Y(s)}{R(s)} = \frac{\omega_n^2}{s^2 + 2\zeta \,\omega_n \, s + \omega_n^2} \tag{2.1.4}$$

where ω_n is the natural frequency and ζ is the damping ratio. This is called the *standard second-order* transfer function. Its response proporeties depend on the values of ω_n and ζ .

2.1.1.1 Peak Time and Overshoot

Consider a second-order system as shown in Equation 2.1.4 subjected to a step input given by

$$R(s) = \frac{R_0}{s} {(2.1.5)}$$

with a step amplitude of $R_0=1.5$. The system response to this input is shown in Figure 2.2, where the red trace is the response (output), y(t), and the blue trace is the step input r(t). The maximum value of the response is denoted by the variable y_{max} and it occurs at a time t_{max} . For a response similar to Figure 2.2, the percent overshoot is found using

$$PO = \frac{100 (y_{max} - R_0)}{R_0}$$
 (2.1.6)




Figure 2.2: Standard second-order step response.

From the initial step time, t_0 , the time it takes for the response to reach its maximum value is

$$t_p = t_{max} - t_0 (2.1.7)$$

This is called the *peak time* of the system.

In a second-order system, the amount of overshoot depends solely on the damping ratio parameter and it can be calculated using the equation

$$PO = 100 e^{\left(-\frac{\pi \zeta}{\sqrt{1-\zeta^2}}\right)} \tag{2.1.8}$$

The peak time depends on both the damping ratio and natural frequency of the system and it can be derived as:

$$t_p = \frac{\pi}{\omega_n \sqrt{1 - \zeta^2}} \tag{2.1.9}$$

Generally speaking, the damping ratio affects the shape of the response while the natural frequency affects the speed of the response.

2.1.1.2 Steady State Error

Steady-state error is illustrated in the ramp response given in Figure 2.3 and is denoted by the variable e_{ss} . It is the difference between the reference input and output signals after the system response has settled. Thus, for a time t when the system is in steady-state, the steady-state error equals

$$e_{ss} = r_{ss}(t) - y_{ss}(t)$$
 (2.1.10)

where $r_{ss}(t)$ is the value of the steady-state input and $y_{ss}(t)$ is the steady-state value of the output.

We can find the error transfer function E(s) in Figure 2.1 in terms of the reference R(s), the plant P(s), and the compensator C(s). The Laplace transform of the error is

$$E(s) = R(s) - Y(s)$$
 (2.1.11)

Solving for Y(s) from equation 2.1.3 and substituting it in equation 2.1.11 yields

$$E(s) = \frac{R(s)}{1 + C(s) P(s)}$$
 (2.1.12)






Figure 2.3: Steady-state error in ramp response.

We can find the the steady-state error of this system using the final-value theorem:

$$e_{ss} = \lim_{s \to 0} s E(s) \tag{2.1.13}$$

In this equation, we need to substitute the transfer function for E(s) from 2.1.12. The E(s) transfer function requires, R(s), C(s) and P(s). For simplicity, let C(s)=1 as a compensator. The P(s) and R(s) were given by equations 2.1.3 and 2.1.5, respectively. Then, the error becomes:

$$E(s) = \frac{R_0}{s \left(1 + \frac{K}{s (\tau s + 1)}\right)}$$
 (2.1.14)

Applying the final-value theorem gives

$$e_{ss} = R_0 \left(\lim_{s \to 0} \frac{(\tau \, s + 1) \, s}{\tau \, s^2 + s + K} \right) \tag{2.1.15}$$

When evaluated, the resulting steady-state error due to a step response is

$$e_{ss} = 0$$
 (2.1.16)

Based on this zero steady-state error for a step input, we can conclude that the SRV02 is a *Type 1* system.

2.1.1.3 SRV02 Position Control Specifications

The desired time-domain specifications for controlling the position of the SRV02 load shaft are:

$$e_{ss} = 0$$
 (2.1.17)

$$t_p = 0.20 \text{ s}$$
 (2.1.18)

and

$$PO = 5.0 \%$$
 (2.1.19)

Thus, when tracking the load shaft reference, the transient response should have a peak time less than or equal to 0.20 seconds, an overshoot less than or equal to 5 %, and the steady-state response should have no error.

2.1.2 PV Controller Design

2.1.2.1 Closed Loop Transfer Function

The proportional-velocity (PV) compensator to control the position of the SRV02 has the following structure

$$V_m(t) = k_p \left(\theta_d(t) - \theta_l(t)\right) - k_v \left(\frac{d}{dt} \theta_l(t)\right)$$
(2.1.20)

where k_p is the proportional control gain, k_v is the velocity control gain, $\theta_d(t)$ is the setpoint or reference load shaft angle, $\theta_l(t)$ is the measured load shaft angle, and $V_m(t)$ is the SRV02 motor input voltage. The block diagram of the PV control is given in Figure 2.4. We need to find the closed-loop transfer function $\Theta_l(s)/\Theta_d(s)$ for the closed-loop




Figure 2.4: Block diagram of SRV02 PV position control.

position control of the SRV02. Taking the Laplace transform of equation 2.1.20 gives

$$V_m(s) = k_p \left(\Theta_d(s) - \Theta_l(s)\right) - k_v s \Theta_l(s)$$
(2.1.21)

From the Plant block in Figure 2.4 and equation 2.1.3, we can write

$$\frac{\Theta_l(s)}{V_m(s)} = \frac{K}{s(\tau s + 1)} \tag{2.1.22}$$

Substituting equation 2.1.21 into 2.1.22 and solving for $\Theta_l(s)/\Theta_d(s)$ gives the SRV02 position closed-loop transfer function as:

$$\frac{\Theta_l(s)}{\Theta_d(s)} = \frac{K k_p}{\tau s^2 + (1 + K k_v) s + K k_p}$$
 (2.1.23)

2.1.2.2 Controller Gain Limits

In control design, a factor to be considered is saturation. This is a nonlinear element and is represented by a saturation block as shown in Figure 2.5. In a system like the SRV02, the computer calculates a numeric control voltage value. This value is then converted into a voltage, $V_{dac}(t)$, by the digital-to-analog converter of the data-acquisition device in the computer. The voltage is then amplified by a power amplifier by a factor of K_a . If the amplified voltage, $V_{amp}(t)$, is greater than the maximum output voltage of the amplifier or the input voltage limits of the motor (whichever is smaller), then it is saturated (limited) at V_{max} . Therefore, the input voltage $V_m(t)$ is the effective voltage being applied to the SRV02 motor. The limitations of the actuator must be taken into account when designing a controller. For instance, the voltage entering the SRV02 motor should never exceed

$$V_{max} = 10.0 \text{ V}$$
 (2.1.24)






Figure 2.5: Actuator saturation.

2.1.2.3 Ramp Steady State Error Using PV Control

From our previous steady-state analysis, we found that the closed-loop SRV02 system is a Type 1 system. In this section, we will investigate the steady-state error due to a *ramp* input when using PV controller.

Given the following ramp setpoint (input)

$$R(s) = \frac{R_0}{s^2} {(2.1.25)}$$

we can find the error transfer function by substituting the SRV02 closed-loop transfer function in equation 2.1.23 into the formula given in 2.1.11. Using the variables of the SRV02, this formula can be rewritten as $E(s) = \Theta_d(s) - \Theta_l(s)$. After rearranging the terms we find:

$$E(s) = \frac{\Theta_d(s) \, s \, (\tau \, s + 1 + K \, k_v)}{\tau \, s^2 + s + K \, k_p + K \, k_v \, s}$$
(2.1.26)

Substituting the input ramp transfer function 2.1.25 into the $\Theta_d(s)$ variable gives

$$E(s) = \frac{R_0 (\tau s + 1 + K k_v)}{s (\tau s^2 + s + K k_p + K k_v s)}$$
(2.1.27)

2.1.3 PIV Controller

Adding an integral control can help eliminate any steady-state error. We will add an integral signal (middle branch in Figure 2.6) to have a proportional-integral-velocity (PIV) algorithm to control the position of the SRV02. The motor voltage will be generated by the PIV according to:

$$V_m(t) = k_p \left(\theta_d(d) - \theta_l(t)\right) + k_i \int \left(\theta_d(t) - \theta_l(t)\right) dt - k_v \left(\frac{d}{dt} \theta_l(t)\right)$$
(2.1.28)

where k_i is the integral gain. We need to find the closed-loop transfer function $\Theta_l(s)/\Theta_d(s)$ for the closed-loop position control of the SRV02. Taking the Laplace transform of equation 2.1.28 gives

$$V_m(s) = \left(k_p + \frac{k_i}{s}\right) \left(\Theta_d(s) - \Theta_l(s)\right) - k_v s \Theta_l(s)$$
(2.1.29)

From the Plant block in Figure 2.6 and equation 2.1.3, we can write

$$\frac{\Theta_l(s)}{V_m(s)} = \frac{K}{(\tau s + 1) s} \tag{2.1.30}$$

Substituting equation 2.1.29 into 2.1.30 and solving for $\Theta_l(s)/\Theta_d(s)$ gives the SRV02 position closed-loop transfer function as:

$$\frac{\Theta_l(s)}{\Theta_d(s)} = \frac{K (k_p \, s + k_i)}{s^3 \, \tau + (1 + K \, k_v) \, s^2 + K \, k_p \, s + K \, k_i} \tag{2.1.31}$$




Figure 2.6: Block diagram of PIV SRV02 position control.

2.1.3.1 Ramp Steady-State Error using PIV Controller

To find the steady-state error of the SRV02 for a ramp input under the control of the PIV substitute the closed-loop transfer function from equation 2.1.31 into equation 2.1.11

$$E(s) = \frac{\Theta_d(s) \, s^2 \, (\tau \, s + 1 + K \, k_v)}{s^3 \, \tau + s^2 + K \, k_v \, s + K \, k_i + K \, k_v \, s^2}$$
(2.1.32)

Then, substituting the reference ramp transfer function 2.1.25 into the $\Theta_d(s)$ variable gives

$$E(s) = \frac{R_0 (\tau s + 1 + K k_v)}{s^3 \tau + s^2 + K k_v s + K k_i + K k_v s^2}$$
(2.1.33)

2.1.3.2 Integral Gain Design

It takes a certain amount of time for the output response to track the ramp reference with zero steady-state error. This is called the *settling time* and it is determined by the value used for the integral gain.

In steady-state, the ramp response error is constant. Therefore, to design an integral gain the velocity compensation (the V signal) can be neglected. Thus, we have a PI controller left as:

$$V_m(t) = k_p \left(\theta_d(t) - \theta_l(t)\right) + k_i \int \left(\theta_d(t) - \theta_l(t)\right) dt$$
(2.1.34)

When in steady-state, the expression can be simplified to

$$V_m(t) = k_p e_{ss} + k_i \int_0^{t_i} e_{ss} dt$$
 (2.1.35)

where the variable t_i is the integration time.



2.2 Pre-Lab Questions

Before you start the lab experiments given in Section 2.3, you should study the background materials provided in Section 2.1 and work through the questions in this Section.

1. A-2 Calculate the maximum overshoot of the response (in radians) given a step setpoint of 45 degrees and the overshoot specification given in Section 2.1.1.3.

Hint: By substituting $y_{max} = \theta(t_p)$ and step setpoint $R_0 = \theta_d(t)$ into equation 2.1.6, we can obtain $\theta(t_p) = \theta_d(t) \left(1 + \frac{PO}{100}\right)$. Recall that the desired response specifications include 5% overshoot.

Answer 2.2.1

Outcome Solution

A-2 Substituting a step reference of $\theta_d(t)=0.785$ rad and PO=5 % into this equation gives the maximum overshoot as $\theta(t_p)=0.823$ rad.

2. A-1, A-2 The SRV02 closed-loop transfer function was derived in equation 2.1.23 in Section 2.1.2.1. Find the control gains k_p and k_v in terms of ω_n and ζ . Hint: Remember the standard second order system equation.

Answer 2.2.2

Outcome Solution

A-1 The characteristic equation of the SRV02 closed-loop transfer function in 2.1.7 is

$$\tau s^2 + (1 + K k_v) s + K k_p$$
 (Ans.2.2.1)

and can be re-structured into the form

$$s^2 + \frac{(1 + K k_v) s}{\tau} + \frac{K k_p}{\tau}$$
 (Ans.2.2.2)

Equating this with the standard second order system equation gives the expressions

$$\frac{K k_p}{\tau} = \omega_n^2 \tag{Ans.2.2.3}$$

and

$$\frac{1+Kk_v}{\tau} = 2\zeta\,\omega_n\tag{Ans.2.2.4}$$

A-2 Solve for k_p and k_v to obtain the control gains equations

$$k_p = \frac{\omega_n^2 \, \tau}{K} \tag{Ans.2.2.5}$$

and the velocity gain is

$$k_v = \frac{2\zeta\omega_n\tau - 1}{K}$$
 (Ans.2.2.6)

3. A-2 Calculate the minimum damping ratio and natural frequency required to meet the specifications given in Section 2.1.1.3.

Outcome Solution

> A-2 Substitute the percent overshoot specifications given in 2.1.19 into

Equation 2.1.8 to get the required damping ratio

$$\zeta = 0.690$$
 (Ans.2.2.7)

Using this result and the desired peak time, given in 2.1.18, with Equation 2.1.9 gives the minimum natural frequency needed

$$\omega_n = 21.7 \text{ rad/s}$$
 (Ans.2.2.8)

4. A-2 Based on the nominal SRV02 model parameters, K and τ , found in Laboratory 1: SRV02 Modeling, calculate the control gains needed to satisfy the time-domain response requirements given in Section 2.1.1.3.

Answer 2.2.4

Outcome Solution

> Using the model parameters A-2

$$K = 1.53 \text{ rad/(V s)}$$
 (Ans.2.2.9)

and

$$\tau = 0.0254 \text{ s}$$
 (Ans.2.2.10)

as well as the desired natural frequency found in Ans. 2.2.8 with Equation Ans.2.2.5, generates the proportional control gain

$$k_p = 7.82 \text{ V/rad}$$
 (Ans.2.2.11)

Similarly, the velocity control gain is obtained by substituting the model parameters given above with the minimum damping ratio specification, in Ans.2.2.7, into Equation Ans.2.2.6

$$k_v = -0.157 \,\text{V s/rad}$$
 (Ans.2.2.12)

Thus, when these gains are used with the PV controller, the position response of the load gear on an SRV02 with a disc load will satisfy the specifications listed in 2.1.1.3.

5. A-1, A-2, A-3 In the PV controlled system, for a reference step of $\pi/4$ (i.e. 45 degree step) starting from $\Theta_l(t)=0$ position, calculate the *maximum* proportional gain that would lead to providing the maximum voltage to the motor. Ignore the velocity control ($k_v = 0$). Can the desired specifications be obtained based on this maximum available gain and what you calculated in guestion 4?



Outcome Solution

A-1 The maximum proportional gain leads to providing the maximum voltage to the motor. Therefore, the PV control in 3.1.15 becomes

$$10.0 = \frac{1}{4} k_p \pi$$
 (Ans.2.2.13)

A-2 after substituting the maximum SRV02 input voltage 2.1.24 for $V_m(t)$, the reference step of $\pi/4$, and $k_v=0$ (to ignore the velocity control). Thus, the maximum proportional gain before saturating the SRV02 motor is

$$k_{p,max} = 12.7 \left\lceil \frac{V}{rad} \right\rceil$$
 (Ans.2.2.14)

A-3 The proportional gain designed in Ans.2.2.11 is below $k_{p,max}$, therefore the desired specifications, can still be obtained.

6. A-1, A-2 For the PV controlled closed-loop system, find the steady-state error and evaluate it numerically given a ramp with a slope of $R_0 = 3.36$ rad/s. Use the control gains found in question 4.

Answer 2.2.6

Outcome Solution

A-1 Applying the final-value theorem to the error transfer function yields the expression

$$e_{ss} = \lim_{s \to 0} \frac{R_0 (\tau s + 1 + K k_v)}{\tau s^2 + s + K k_p + K k_v s}$$
 (Ans.2.2.15)

A-2 When evaluated, the resulting steady-state error is

$$e_{ss} = \frac{R_0 \ (1 + K \ k_v)}{K \ k_p}$$
 (Ans.2.2.16)

The steady-state error is a constant, which is as expected since the closed-loop SRV02 position system is Type 1. Evaluating the expression with the reference slope of 3.36 rad/s, the model gain parameter K=1.53, the proportional and velocity gains $k_p=7.82$ and $k_v=0.157$, gives the steady-state error

$$e_{ss} = 0.214 \ [rad]$$
 (Ans.2.2.17)

7. A-2 What should be the integral gain k_i so that when the SRV02 is supplied with the maximum voltage of $V_{max}=10\,V$ it can eliminate the steady-state error calculated in question 6 in 1 second? **Hint:** Start from equation 2.1.35 and use $t_i=1$, $V_m(t)=10$, the k_p you found in question 4 and e_{ss} found in question 6. Remember that e_{ss} is constant.

Outcome Solution

A-2 Since e_{ss} is constant, evaluating the integral in Equation 2.1.35 yields

$$V_m(t) = k_p e_{ss} + k_i t_i e_{ss}$$
 (Ans.2.2.18)

Then, the integral gain is

$$k_i = rac{V_m(t) - k_p \, e_{ss}}{t_i \, e_{ss}}$$
 (Ans.2.2.19)

By substituting $t_i=1.0sec$, the maximum SRV02 voltage $V_m(t)=10V$, $k_p=7.82$ and the PV control steady-state error $e_{ss}=0.214$ we find

$$k_i = 38.9 \text{ V/(rad s)}$$
 (Ans.2.2.20)



2.3 Lab Experiments

The main goal of this laboratory is to explore position control of the SRV02 load shaft using PV and PIV controllers.

In this laboratory, you will conduct three experiments:

- 1. Step response with PV controller,
- 2. Ramp response with PV controller, and
- 3. Ramp response with no steady-state error.

You will need to design the third experiment yourself. In each experiment, you will first simulate the closed-loop response of the system. Then, you will implement the controller using the SRV02 hardware and software to compare the real response to the simulated one.

2.3.1 Step Response Using PV Controller

2.3.1.1 Simulation

First, you will simulate the closed-loop response of the SRV02 with a PV controller to step input. Our goals are to confirm that the desired reponse specifications in an ideal situation are satisfied and to verify that the motor is not saturated. Then, you will explore the effect of using a high-pass filter, instead of a direct derivative, to create the velocity signal V in the controller.

Experimental Setup

The s_srv02_pos Simulink® diagram shown in Figure 2.7 will be used to simulate the closed-loop position control response with the PV and PIV controllers. The SRV02 Model uses a *Transfer Fcn* block from the Simulink® library. The PIV Control subsystem contains the PIV controller detailed in Section 2.1.3. When the integral gain is set to zero, it essentially becomes a PV controller.




Figure 2.7: Simulink model used to simulate the SRV02 closed-loop position response.

IMPORTANT: Before you can conduct these experiments, you need to make sure that the lab files are configured according to your SRV02 setup. If they have not been configured already, then you need to go to Section 2.4.2 to configure the lab files first.

Closed-loop Response with the PV Controller

- 1. Enter the proportional and velocity control gains found in Pre-Lab question 4 in Matlab® as kp and kv.
- 2. To generate a step reference, ensure the SRV02 Signal Generator is set to the following:
 - Signal type = square
 - Amplitude = 1
 - Frequency = 0.4 Hz
- 3. In the Simulink® diagram, set the *Amplitude (rad)* gain block to $\pi/8(rad)$ to generate a step with an amplitude of 45 degrees (i.e., square wave goes between $\pm \pi/8$ which results in a step amplitude of $\pi/4$).
- 4. Inside the PIV Control subsystem, set the Manual Switch to the upward position so the Derivative block is used.
- 5. Open the load shaft position scope, theta_I (rad), and the motor input voltage scope, Vm (V).
- 6. B-5 Start the simulation. By default, the simulation runs for 5 seconds. The scopes should be displaying responses similar to figures 2.8 and 2.9 Note that in the *theta_I* (rad) scope, the yellow trace is the setpoint position while the purple trace is the simulated position (generated by the *SRV02 Model* block). This simulation is called the *Ideal PV* response as it uses the PV compensator with the derivative block.




Figure 2.8: Ideal PV position response.




Figure 2.9: Ideal PV motor input voltage.

7. K-3 Generate a Matlab® figure showing the *Ideal PV* position response and the ideal input voltage. After each simulation run, each scope automatically saves their response to a variable in the Matlab® workspace. That is, the *theta_I* (rad) scope saves its response to the variable called data_pos and the *Vm* (*V*) scope saves its data to the *data_vm* variable. The *data_pos* variable has the following structure: *data_pos*(:,1) is the time vector, *data_pos*(:,2) is the setpoint, and *data_pos*(:,3) is the simulated angle. For the *data_vm* variable, *data_vm*(:,1) is the time and *data_vm*(:,2) is the simulated input voltage.

Answer 2.3.1

K-3

Outcome Solution

The closed-loop position response with the straight derivative, i.e. the ideal response, is shown in Figure 2.10. This is generated using the <code>sample_meas_tp_os.m</code> script. To use this script, do the following:

- (a) Execute the setup_srv02_exp02_pos.m script with CON-TROL TYPE = 'AUTO PV'.
- (b) Run the s srv02 pos Simulink®model.
- (c) Run the sample meas tp os.m script.

8. K-1, B-9 Measure the steady-state error, the percent overshoot and the peak time of the simulated response. Does the response satisfy the specifications given in Section 2.1.1.3? **Hint:** Use the Matlab[®] *ginput* command to take measurements off the figure.






Figure 2.10: Ideal closed-loop PV position response.

Outcome Solution

K-1 Directly from the response shown in Figure 2.10, it is clear that the steady-state error is zero, thus

$$e_{ss} = 0$$
 (Ans.2.3.1)

Using Equation 2.1.7, the peak time of the response in Figure 2.10 is

$$t_p = 0.20 \text{ s}$$
 (Ans.2.3.2)

Similarly, the percent overshoot is calculated using Equation 2.1.6 as

$$PO = 5.0 \%$$
 (Ans.2.3.3)

B-9 The response with the PV controller matches the specifications in Section 2.1.1.3 while maintaining a motor input voltage less than 10 V, i.e. the motor is not saturated. To find the peak time and percent overshoot of a response saved in *data_pos* automatically, run the *sam_ple_meas_tp_os.m* script after running *s_srv02_pos*.

Using a High-pass Filter Instead of Direct Derivative

- 9. When implementing a controller on actual hardware, it is generally not advised to take the direct derivative of a measured signal. Any noise or spikes in the signal becomes amplified and gets multiplied by a gain and fed into the motor which may lead to damage. To remove any high-frequency noise components in the velocity signal, a low-pass filter is placed in series with the derivative, i.e. taking the high-pass filter of the measured signal. However, as with a controller, the filter must also be tuned properly. In addition, the filter has some adverse affects. Go in the PIV Control block and set the Manual Switch block to the down position to enable the high-pass filter.
- 10. B-5 Start the simulation. The response in the scopes should still be similar to figures 2.8 and 2.9. This simulation is called the *Filtered PV* response as it uses the PV controller with the high-pass filter block.
- 11. K-3 Generate a Matlab® figure showing the *Filtered PV* position and input voltage responses.

Outcome Solution

K-3 The Filtered PV step response is illustrated in Figure 2.11. This is generated by executing the *sample_meas_tp_os.m* script after running the *s srv02 pos* simulation.




Figure 2.11: Filtered closed-loop PV position response.

12. K-1, B-9 Measure the steady-state error, peak time, and percent overshoot. Are the specifications still satisfied without saturating the actuator? Recall that the peak time and percent overshoot should not exceed the values given in Section 2.1.1.3. Discuss the changes from the ideal response. **Hint:** The different in the response is minor. Make sure you use *ginput* to take precise measurements.

Answer 2.3.4

Outcome Solution

K-1 As with the ideal response, the steady-state error of the filtered response in Figure 2.11 is

$$e_{ss} = 0$$
 (Ans.2.3.4)

and the peak time is

$$t_p = 0.20 \text{ s}$$
 (Ans.2.3.5)

Thus, the PV Filtered response satisfies the error and peak time specifications given in Section 2.1.1.3.

The percent overshoot of the response shown in Figure 2.11 is

$$PO = 5.76 \%$$
 (Ans.2.3.6)

B-9 This exceeds the 5 % overshoot requirement and, as a result, not all the specifications are satisfied. To find the peak time and percentage overshoot of a response saved in *data_pos* automatically, run the *sam_ple_meas_tp_os.m* script after running *s_srv02_pos*.



2.3.1.2 Implementing Step Response using PV Controller

In this experiment, we will control the angular position of the SRV02 load shaft, i.e. the disc load, using the PV controller. Measurements will then be taken to ensure that the specifications are satisfied.

Experimental Setup

The *q_srv02_pos* Simulink[®] diagram shown in Figure 2.12 is used to implement the position control experiments. The *SRV02-ET* subsystem contains QUARC blocks that interface with the DC motor and sensors of the SRV02 system, as discussed in Section A. The *PIV Control* subsystem implements the PIV controller detailed in Section 2.1.3, except a high-pass filter is used to obtain the velocity signal (as opposed to taking the direct derivative).




Figure 2.12: Simulink model used with QUARC to run the PV and PIV position controllers on the SRV02.

IMPORTANT: Before you can conduct these experiments, you need to make sure that the lab files are configured according to your SRV02 setup. If they have not been configured already, then you need to go to Section 2.4.3 to configure the lab files first.

- 1. Run the setup_srv02_exp02_pos.m script.
- Enter the proportional and velocity control gains found in Pre-Lab question 4.
- 3. Set Signal Type in the SRV02 Signal Generator to square to generate a step reference.
- 4. Set the *Amplitude (rad)* gain block to $\pi/8$ to generate a step with an amplitude of 45 degrees.
- 5. Open the load shaft position scope, theta I (rad), and the motor input voltage scope, Vm (V).
- 6. Click on QUARC | Build to compile the Simulink® diagram.
- 7. Select QUARC | Start to begin running the controller. The scopes should display responses similar to figures 2.13 and 2.14 Note that in the theta_I (rad) scope, the yellow trace is the setpoint position while the purple trace is the measured position.
- 8. B-5, K-3 When a suitable response is obtained, click on the Stop button in the Simulink® diagram toolbar (or select QUARC | Stop from the menu) to stop running the code. Generate a Matlab® figure showing the PV position response and its input voltage.
 - As in the s_srv02_pos Simulink diagram, when the controller is stopped each scope automatically saves their response to a variable in the Matlab[®] workspace. Thus the theta_I (rad) scope saves its response to the data_pos variable and the Vm (V) scope saves its data to the data_vm variable.




Figure 2.13: Measured PV step response.




Figure 2.14: PV control input voltage.

Outcome Solution

- B-5 If the experimental procedure is followed correctly, the measured SRV02 closed-loop position step response with the PV controller should be similar to Figure 2.15.
- K-3 To generate this response, execute the sample_meas_tp_os.m script with the saved MAT files data_step_rsp_theta.mat and data_step_rsp_Vm.mat. Alternatively, to generate a Matlab[®] figure from a new experimental run do the following:
 - (a) Execute the setup_srv02_exp02_pos.m script with CON-TROL_TYPE = 'AUTO_PV'
 - (b) Run the *q_srv02_pos* Simulink®model until a response fills the scopes.
 - (c) Stop QUARC®.
 - (d) Execute the sample_meas_tp_os.m script.




Figure 2.15: Measured SRV02 step response using PV.





9. K-1, B-9 Measure the steady-state error, the percent overshoot, and the peak time of the SRV02 load gear. Does the response satisfy the specifications given in Section 2.1.1.3?

Answer 2.3.6

Outcome Solution

K-1 The steady-state error measured in Figure 2.15 at 1.1 second after the peak time is

$$e_{ss} = 0.0138 \text{ rad}$$
 (Ans.2.3.7)

Thus, there is an error of about 0.79 degrees. The peak time and percent overshoot of the response shown in Figure 2.15, using Equation 2.1.7 and Equation 2.1.6, are

$$t_p = 0.147 \,\mathrm{s}$$
 (Ans.2.3.8)

and

$$PO = 4.88 \%$$
 (Ans.2.3.9)

B-9 The actual measured SRV02 response does not quite satisfy the specifications given in Section 2.1.1.3 because the steady-state error is not zero. However, without saturating the servo motor the peak time does not exceed 0.20 seconds and the percent overshoot is below or equal to 5 %. Thus, the peak time and overshoot specifications are satisfied. The system, generally speaking, is more damped than predicted which leads to a lower overshoot. The constant steady-state error obtained along with the lower overshoot is due to un-modeled effects, notably friction. To find the steady-state error, peak time and percent overshoot of a response saved in data_pos automatically, run the sample_meas_tp_os.m script after running q_srv02_pos or using the responses saved in the MAT files data_step_rsp_theta.mat and data_step_rsp_Vm.mat.

- 10. Click the Stop button on the Simulink® diagram toolbar (or select QUARC | Stop from the menu) to stop the experiment.
- 11. Turn off the power to the amplifier if no more experiments will be performed on the SRV02 in this session.

2.3.2 Ramp Response Using PV Controller

2.3.2.1 Simulation

In this simulation, the goal is to verify that the system with the PV controller can meet the zero steady-state error specification without saturating the motor.

As in the Step Response experiment in Section 2.3.1, in this experiment you need to use the s_srv02_pos Simulink® diagram shown in Figure 2.7 in Section 2.3.1.1 again.

- 1. Enter the proportional and velocity control gains found in Pre-Lab question 4.
- 2. Set the SRV02 Signal Generator parameters to the following to generate a triangular reference (which corresponds to a ramp input):
 - Signal Type = triangle
 - Amplitude = 1
 - Frequency = 0.8 Hz

3. Setting the frequency to 0.8 Hz will generate an increasing and decreasing ramp signal with the same slope used in the Pre-Lab question 6. The slope is calculated from the *Triangular Waveform* amplitude, *Amp*, and frequency, *f*, using the expression.

$$R_0 = 4 \, Amp \, f \tag{2.3.36}$$

- 4. In the Simulink[®] diagram, set the *Amplitude (rad)* gain block to $\pi/3$.
- 5. Inside the PIV Control subsystem, set the Manual Switch to the down position so that the High-Pass Filter block is used.
- 6. Open the load shaft position scope, theta_I (rad), and the motor input voltage scope, Vm (V).
- 7. B-5 Start the simulation. The scopes should display responses similar to figures 2.16 and 2.17.




Figure 2.16: Ramp response using PV.




Figure 2.17: Input voltage of ramp tracking using PV.

8. K-3 Generate a Matlab[®] figure showing the *Ramp PV* position response and its corresponding input voltage trace.

Answer 2.3.7

Outcome Solution

K-3

The closed-loop ramp response when using the PV control is shown in Figure 2.18. This is generated using the *sample_meas_ess.m* script. To use this script, do the following:

- (a) Execute the setup_srv02_exp02_pos.m script with CON-TROL_TYPE = 'AUTO_PV'
- (b) Run the s srv02 pos Simulink model.
- (c) Run the sample meas ess.m script.

9. K-1 Measure the steady-state error. Compare the simulation measurement with the steady-state error calculated in Pre-Lab question 6.




Figure 2.18: Ramp response using PV.

Outcome Solution

K-1 The error between the reference and the simulated response after running for 1.1 second is

$$e_{ss} = -0.213 \text{ rad}$$
 (Ans.2.3.10)

Its magnitude (or absolute value) is very close to the steady-state error predicted earlier in Ans.2.2.17. To find the steady-state error of a ramp response saved in *data_pos* automatically, run the *sam_ple_meas_ess.m* script after running *s_srv02_pos*. It outputs the expected steady-state error when using the PV control, as found in the pre-lab, and the the error measured from the saved response.

2.3.2.2 Implementing Ramp Response Using PV

In this experiment, we will control the angular position of the SRV02 load shaft, i.e. the disc load, using a PV controller. The goal is to examine how well the system can track a triangular (ramp) position input. Measurements will then be taken to ensure that the specifications are satisfied.

As in the Step Response experiment in Section 2.3.1, in this experiment you also need to use the q_srv02_pos Simulink®diagram shown in Figure 2.12 to implement the position control experiments.

- 1. Run the setup_srv02_exp02_pos.m script.
- 2. Enter the proportional and velocity control gains found in Pre-Lab question 4.
- 3. Set the *SRV02 Signal Generator* parameters to the following to generate a triangular reference (i.e., ramp reference):
 - Signal Type = triangle
 - Amplitude = 1
 - Frequency = 0.8 Hz
- 4. In the Simulink[®] diagra, set the *Amplitude (rad)* gain block to $\pi/3$.

- 5. Open the load shaft position scope, theta_I (rad), and the motor input voltage scope, Vm (V).
- 6. Click on QUARC | Build to compile the Simulink® diagram.
- 7. Select QUARC | Start to run the controller. The scopes should display responses similar to figures 2.19 and 2.20.




Figure 2.19: Measured SRV02 PV ramp response.




Figure 2.20: Input voltage of PV ramp response.

8. B-5, K-3 Generate a Matlab[®] figure showing the *Ramp PV* position response and its corresponding input voltage trace.

Answer 2.3.9

Outcome Solution

- B-5 If the experimental procedure is followed correctly, the measured SRV02 closed-loop position ramp response when using the PV control should be similar to Figure 2.21.
- K-3 To generate this response, execute the sample_meas_ess_os.m script with the saved MAT files data_step_rsp_pv_theta.mat and data_step_rsp_pv_Vm.mat. Alternatively, to generate a Matlab®figure from a new experimental run do the following:
 - (a) Execute the setup_srv02_exp02_pos.m script with CONTROL TYPE = 'AUTO PV'
 - (b) Run the *q_srv02_pos* Simulink®model until a response fills the scopes.
 - (c) Stop QUARC®.
 - (d) Execute the sample meas ess .m script.

9. K-1, B-9 Measure the steady-state error and compare it with the steady-state error calculated in Pre-Lab question 6.




Figure 2.21: Measured SRV02 ramp response using PV.

Outcome Solution

K-1 The error between the reference and the measured response taken at the 1.0 second mark is

 $e_{ss} = 0.189 \text{ rad}$ (Ans.2.3.11)

B-9 This is slightly less than the steady-state error calculated earlier in Ans.2.2.17.

To find the steady-state error of a ramp response saved in data_pos automatically, run the sample_meas_ess.m script using the saved response in the MAT files data_step_rsp_pv_theta.mat and data_step_rsp_pv_Vm.mat or after running q_srv02_pos.

2.3.3 Ramp Response with No Steady-State Error

Design an experiment to see if the steady-state error can be eliminated when tracking a ramp input. First simulate the response, then implement it using the SRV02 system.

1. B-1 How can the PV controller be modified to eliminate the steady-state error in the ramp response? State your hypothesis and describe the anticipated cause-and-effect leading to the expected result. **Hint:** Look through Section 2.

Answer 2.3.11

Outcome Solution

B-1 Hypothesis: Adding an integral control will eliminate the steady-state error. Because, the integrator will accumulate the error over time causing the input voltage to the motor to increase to make up for the additional voltage needed to eliminate the steady-state error.

2. B-2 List the independent and dependent variables of your proposed controller. Explain their relationship.

Outcome Solution

B-2 Refering to the controller in Figure 2.6, the dependent variable is $V_m(s)$ and the independent variables are $k_p,\,k_v,\,k_i,\,\theta_d(s)$ and $\theta_l(s)$.

3. B-3 Your proposed control, like the PV compensator, are model-based controllers. This means that the control gains generated are based on mathematical representation of the system. Given this, list the assumptions you are making in this control design. State the reasons for your assumptions.

Answer 2.3.13

Outcome Solution

B-3 We assume that the friction in the system is negligable because it is a well-designed system. Also, noise in the measured signals is neglected since its magnitude is very small compared to the magnitude of the measured signals.

4. B-4 Give a brief, general overview of the steps involved in your experimental procedure for two cases: (1) Simulation, and (2) Implementation.

Answer 2.3.14

Outcome Solution

B-4 Simulation case:

- (a) Enter the integral gain computed in Pre-Lab question 7 into Matlab® (Simulink diagram given in Figure 2.7).
- (b) Start the simulation. The *Ramp PIV* response in the scopes should be similar to figures 2.22 and 2.23.

Implementation case:

- (a) Enter the integral gain computed in Pre-Lab question 7 into Matlab® (Simulink diagram given in Figure 2.12.
- (b) Start the QUARC controller. The *Ramp PIV* response in the scopes should be similar to figures 2.24 and 2.25.




Figure 2.22: PIV ramp response.




Figure 2.23: Input voltage using PIV control.

5. K-3 For each case, generate a Matlab®figure showing the position response of the system and its corresponding input voltage.






Figure 2.24: Measured SRV02 PIV ramp response.




Figure 2.25: Input voltage from PIV ramp control.

Outcome Solution

- K-3 **Simulation case:** After setting the integral gain in Ans.2.3.3 in Matlab[®], the *PIV Ramp* response will be as shown in Figure 2.26. This plot can be generated by:
 - (a) Executing the setup_srv02_exp02_pos.m script with CON-TROL TYPE = 'AUTO PV'
 - (b) Running the s_srv02_pos Simulink model.
 - (c) Running the sample_meas_ess.m script.
- K-3 Implementation case: generate To this response, run sample meas ess.m script using the saved response in the MAT files data step rsp piv theta.mat data step rsp piv Vm.mat. To generate a response after running q srv02 pos, follow these steps:
 - (a) Execute the setup_srv02_exp02_pos.m script with CON-TROL_TYPE = 'AUTO_PIV'
 - (b) Run the *q srv02 pos* Simulink®model.
 - (c) Stop QUARC®when a response fills the scopes.
 - (d) Run the sample_meas_ess.m script.

6. K-1 In each case, measure the steady-state error.




Figure 2.26: Ramp response using PIV control.




Figure 2.27: Measured SRV02 closed-loop ramp response using PIV.

Outcome Solution

K-1 **Simulation case:** The steady-state PIV error measured from the response in Figure 2.26 is

$$e_{ss} = -0.0125 [rad]$$
 (Ans.2.3.12)

and the input voltage is always below 10.0 V. This value is reasonably close to 0.00 rad. Therefore, the specification is satisfied.

To measure the steady-state error saved in *data_pos* automatically, run the *sample_meas_ess.m* script after running *s_srv02_pos*.

K-1 **Implementation case:** The steady-state PIV error measured from the response in Figure 2.27 at the 1.0 second mark is

$$e_{ss} = -0.0343 \text{ rad}$$
 (Ans.2.3.13)





7. B-9 For each case comment on whether the steady-state specification given in Section 2.1.1.3 was satisfied without saturating the actuator.

Answer 2.3.17

Outcome Solution

B-9 **Both cases:** Given that the servo motor is not saturated and the obtained error is reasonably close to 0.00 rad, the specification are satisfied in both cases.

- 8. Click the Stop button on the Simulink®diagram toolbar (or select QUARC | Stop from the menu) to stop the experiment.
- 9. Turn off the power to the amplifier if no more experiments will be performed on the SRV02 in this session.

2.3.4 Results

B-6 Fill out Table 2.2 below with your answers to the Pre-Lab questions and your results from the lab experiments.

Section / Ques-	Description	Symbol	Value	Unit
tion				
Question 4	Pre-Lab: Model Parameters			
	Open-Loop Steady-State Gain	K	1.53	rad/(V.s)
	Open-Loop Time Constant	au	0.0254	S
Question 4	Pre-Lab: PV Gain Design			
	Proportional gain	k_p	7.82	V/rad
	Velocity gain	k_v	-0.157	V.s/rad
Question 5	Pre-Lab: Control Gain Limits			
	Maximum proportional gain	$k_{p,max}$	12.7	V/rad
Question 6	Pre-Lab: Ramp Steady-State Error			
	Steady-state error using PV	e_{ss}	0.214	rad
Question 7	Pre-Lab: Integral Gain Design			
	Integral gain	k_i	38.9	V/(rad.s)
2.3.1.1	Step Response Simulation			
	Peak time	t_p	0.20	S
	Percent overshoot	PO	5.0	%
	Steady-state error	e_{ss}	0.00	rad
2.3.1.1	Filtered Step Response Using PV			
	Peak time	t_p	0.20	S
	Percent overshoot	PO	5.76	%
	Steady-state error	e_{ss}	0.00	rad
2.3.1.2	Step Response Implementation			
	Peak time	t_p	0.147	S
	Percent overshoot	PO	4.88	%
	Steady-state error	e_{ss}	0.0138	rad
2.3.2.1	Ramp Response Simulation with PV			
	Steady-state error	e_{ss}	-0.213	rad
2.3.2.2	Ramp Response Implementation with			
	PV			
	Steady-state error	e_{ss}	0.189	rad
2.3.3	Ramp Response Simulation with no			
	steady-state error			
	Steady-state error	e_{ss}	-0.0125	rad
2.3.3	Ramp Response Implementation with			
	no steady-state error			
	Steady-state error	e_{ss}	-0.0343	rad

Table 2.2: Summary of results for the SRV02 Position Control laboratory.



2.4 System Requirements

Before you begin this laboratory make sure:

- QUARC® is installed on your PC, as described in Reference [1].
- You have a QUARC compatible data-aquisition (DAQ) card installed in your PC. For a listing of compliant DAQ cards, see Reference [5].
- SRV02 and amplifier are connected to your DAQ board as described Reference [6].

2.4.1 Overview of Files

Table 2.3: Files supplied with the SRV02 Position Control laboratory.

File Name	Description
02 - SRV02 Position Control - Student Manual.pdf	This laboratory guide contains pre-lab questions and lab experiments demonstrating how to design and implement a position controller on the Quanser SRV02 rotary plant using QUARC.
setup_srv02_exp02_pos.m	The main Matlab®script that sets the SRV02 motor and sensor parameters as well as its configuration-dependent model parameters. Run this file only to setup the laboratory.
config_srv02.m	Returns the configuration-based SRV02 model specifications <i>Rm, kt, km, Kg, eta_g, Beq, Jeq,</i> and <i>eta_m,</i> the sensor calibration constants K_POT, K_ENC, and K_TACH, and the amplifier limits VMAX_AMP and IMAX_AMP.
d_model_param.m	Calculates the SRV02 model parameters K and tau based on the device specifications Rm, kt, km, Kg, eta_g, Beq, Jeq, and eta_m.
calc_conversion_constants.m	Returns various conversions factors.
s_srv02_pos.mdl	Simulink file that simulates a closed-loop PIV controller for the SRV02 system.
q_srv02_pos.mdl	Simulink file that implements a closed-loop PIV position controller on the SRV02 system using QUARC [®] .
02 - SRV02 Position Control - Instructor Manual.pdf	Same as the student version except with solutions.
srv02_exp02_position_control.mws	Maple worksheet used to design the position controller for the experiment. Waterloo Maple 9, or a later release, is required to open, modify, and execute this file.

(Continued on the next page)

File Name	Description
srv02_exp02_position_control.html	HTML presentation of the Maple Worksheet. It allows users to view the content of the Maple file without having Maple 9 installed. No modifications to the equations can be performed when in this format.
d_pv_design.m	Matlab [®] script file that calculates the control gains <i>kp</i> and <i>kv</i> based on the model parameters K and tau as well as the peak time an overshoot specifications <i>tp</i> and <i>PO</i> .
d_e_ss_ramp_pv.m	Matlab [®] script that computes the ramp steady-state error based on the PV control gains, the ramp slope <i>R0</i> , and model DC gain <i>K</i> .
d_i_design.m	Matlab®script file that calculates the integral control gain ki based on the maximum control voltage, the proportional gain kp, the desired ramp steady-state error e_ss, and the integral time ti.
sample_meas_tp_os.m	Finds the peak time and overshoot of a step response stored in the variables data_pos and data_vm in the Matlab®workspace. Users can also use the saved responses contained in the MAT files sample_step_rsp_theta.mat and sample_step_rsp_vm.mat.
sample_meas_ess.m	Finds the steady-state error of a ramp response stored in the variables data_pos and data_vm in the Matlab®workspace. Users can also use the saved responses contained in the MAT files sample_ramp_rsp_theta.mat and sample_ramp_rsp_vm.mat.
data_step_rsp_theta.mat	Sample measured closed-loop PV step response - load gear position.
data_step_rsp_vm.mat	Sample measured closed-loop PV step response - servo input voltage.
data_ramp_rsp_pv_theta.mat	Sample measured closed-loop PV ramp response - load gear position.
data_ramp_rsp_pv_Vm.mat	Sample measured closed-loop PV ramp response - servo input voltage.
data_ramp_rsp_piv_theta.mat	Sample measured closed-loop PIV ramp response - load gear position.
data_ramp_rsp_piv_Vm.mat	Sample measured closed-loop PIV ramp response - servo input voltage.

2.4.2 Setup for Position Control Simulations

Follow these steps to configure the lab properly:

- 1. Load the Matlab® software.
- 2. Browse through the Current Directory window in Matlab® and find the folder that contains the SRV02 position controller files, e.g. *q_srv02_pos.mdl*.
- 3. Double-click on the s_srv02 pos.mdl file to open the Simulink®diagram shown in Figure 2.7.
- 4. Double-click on the *setup_srv02_exp02_spd.m* file to open the setup script for the position control Simulink models.
- Configure setup script: The controllers will be run on an SRV02 in the high-gear configuration with the disc load. In order to simulate the SRV02 properly, make sure the script is setup to match this configuration, i.e. the EXT_GEAR_CONFIG should be set to 'HIGH' and the LOAD_TYPE should be set to 'DISC'. Also, ensure the



ENCODER_TYPE, TACH_OPTION, K_CABLE, AMP_TYPE, and VMAX_DAC parameters are set according to the SRV02 system that is to be used in the laboratory.

Instructors: Set CONTROL_TYPE = 'AUTO_PV' to load the PV gains meeting the specifications or CONTROL_TYPE = 'AUTO_PIV' to load the PIV gains satisfying the specifications. Students will have this set to 'MANUAL', which will not generate the correct control gains.

6. Run the script by selecting the Debug | Run item from the menu bar or clicking on the Run button in the tool bar. The messages shown below, should be generated in the Matlab[®] Command Window. The model parameters and specifications are loaded but the PIV gains are all set to zero - they need to be changed.

```
SRV02 model parameters:
    K = 1.53 rad/s/V
    tau = 0.0254 s
Specifications:
    tp = 0.2 s
    P0 = 5 %
Calculated PV control gains:
    kp = 0 V/rad
    kv = 0 V.s/rad
Integral control gain for triangle tracking:
    ki = 0 V/rad/s
```

2.4.3 Setup for Position Control Implementation

Before beginning the lab experiments on the SRV02 device, the q_srv02_pos Simulink® diagram and the setup_srv02_exp02_pos script must be configured.

Follow these steps to get the system ready for this lab:

- 1. Setup the SRV02 in the high-gear configuration and with the disc load as described in Reference [6].
- 2. Load the Matlab®software.
- 3. Browse through the *Current Directory* window in Matlab[®] and find the folder that contains the SRV02 position control files, e.g. *q_srv02_pos.mdl*.
- 4. Double-click on the *q_srv02_pos.mdl* file to open the Position Control Simulink® diagram shown in Figure 2.7.
- Configure DAQ: Double-click on the HIL Initialize block in the SRV02-ET subsystem (which is located inside the SRV02-ET Position subsystem) and ensure it is configured for the DAQ device that is installed in your system. See Section A for more information on configuring the HIL Initialize block.
- 6. **Configure Sensor:** The position of the load shaft can be measured using various sensors. Set the Pos Src Source block in q srv02 pos, as shown in Figure 2.7, as follows:
 - 1 to use the potentiometer
 - · 2 to use to the encoder

Note that when using the potentiometer, there will be a discontinuity.

7. Configure setup script: Set the parameters in the setup_srv02_exp02_pos.m script according to your system setup. See Section 2.4.2 for more details.

2.5 Lab Report

This laboratory contains three experiments, namely,

- 1. step response,
- 2. ramp response with PV controller, and
- 3. ramp response with no steady-state error.

When you are writing your lab report, follow the outline corresponding to the experiment you conducted to build the *content* of your report. Also, in Section 2.5.4 you can find some basic tips for the *format* of your report.



2.5.1 Template for Content (Step Response Experiment)

I. PROCEDURE

- 1. Closed-loop response with the PV controller
 - Briefly describe the main goal of the simulation.
 - Briefly describe the simulation procedure (Section 2.3.1.1)
- 2. Step response with PV controller using high-pass filter
 - Briefly describe the main goal of this simulation.
 - Briefly describe the simulation procedure (Section 2.3.1.1)
- 3. Implementing Step Response using PV Controller
 - Briefly describe the main goal of this experiment.
 - Briefly describe the experimental procedure (Section 2.3.1.2)

II. RESULTS

Do not interpret or analyze the data in this section. Just provide the results.

- 1. Response plot from step 7 in Section 2.3.1.1, Simulated step response
- 2. Response plot from step 11 in Section 2.3.1.1, Filtered PV response
- 3. Response plot from step 8 in Section 2.3.1.2, Step response of implemented PV controller
- 4. Provide applicable data collected in this laboratory (from Table 2.2).

III. ANALYSIS

Provide details of your calculations (methods used) for analysis for each of the following:

- 1. Step 8 in Section 2.3.1.1, Step response with PV controller
- 2. Step 12 in Section 2.3.1.1, Step response with PV controller using high-pass filter
- 3. Step 9 in Section 2.3.1.2, Step response with PV controller

IV. CONCLUSIONS

Interpret your results to arrive at logical conclusions for the following:

- 1. Step 8 in Section 2.3.1.1, Step response simulation with PV controller
- 2. Step 12 in Section 2.3.1.1, Step response simulation with PV controller using High-pass filter
- 3. Step 9 in Section 2.3.1.2, Step response with the implemented PV controller

2.5.2 Template for Content (Ramp Response with PV)

I. PROCEDURE

- 1. Ramp response with PV controller
 - Briefly describe the main goal of this simulation.
 - Briefly describe the procedure (Section 2.3.2.1)
- 2. Implementing Ramp Response Using PV
 - · Briefly describe the main goal of this experiment.
 - Briefly describe the experimental procedure (Section 2.3.2.2)

II. RESULTS

Do not interpret or analyze the data in this section. Just provide the results.

- 1. Response plot from step 8 in Section 2.3.2.1, Simulated PV controller with ramp input
- 2. Response plot from step 8 in Section 2.3.2.2, Ramp response of implemented PV controller
- 3. Provide applicable data collected in this laboratory (from Table 2.2).

III. ANALYSIS

Provide details of your calculations (methods used) for analysis for each of the following:

- 1. Step 9 in Section 2.3.2.1, Simulated PV controller with ramp input
- 2. Step 9 in Section 2.3.2.2, Ramp response of implemented PV controller

IV. CONCLUSIONS

Interpret your results to arrive at logical conclusions for the following:

1. Step 9 in Section 2.3.2.2, Ramp response with the implemented PV controller



2.5.3 Template for Content (Ramp Response with No Steady-State Error)

I. PROCEDURE

- 1. State the hypothesis of your experiment and describe the anticipated cause-and-effect leading to the expected result (Step 1 in Section 2.3.3).
- 2. List the independent and dependent variables for the controller. Explain their relationship (Step 2 in Section 2.3.3).
- 3. List the assumptions you made in this experiment. State the reasons for your assumptions (Step 3 in Section 2.3.3).
- 4. Briefly list the steps of your experimental procedure for two cases: (1) Simulation, and (2) Implementation (Step 4 in Section 2.3.3).

II. RESULTS

Do not interpret or analyze the data in this section. Just provide the results.

- 1. Response plot from step 5 in Section 2.3.3, Simulated controller with ramp input
- 2. Response plot from step 5 in Section 2.3.3, Implemented controller with ramp input
- 3. Provide applicable data collected in this laboratory (from Table 2.2).

III. ANALYSIS

Provide details of your calculations (methods used) for analysis for each of the following:

- 1. Step 6 in Section 2.3.3, Simulated controller with ramp input
- 2. Step 6 in Section 2.3.3, Implemented controller with ramp input

IV. CONCLUSIONS

Interpret your results to arrive at logical conclusions for the following:

1. Step 7 in Section 2.3.3, for both simulated and implemented controllers

2.5.4 Tips for Report Format

PROFESSIONAL APPEARANCE

- Has cover page with all necessary details (title, course, student name(s), etc.)
- Each of the required sections is completed (Procedure, Results, Analysis and Conclusions).
- · Typed.
- · All grammar/spelling correct.
- · Report layout is neat.
- · Does not exceed specified maximum page limit, if any.
- · Pages are numbered.
- Equations are consecutively numbered.
- Figures are numbered, axes have labels, each figure has a descriptive caption.
- Tables are numbered, they include labels, each table has a descriptive caption.
- Data are presented in a useful format (graphs, numerical, table, charts, diagrams).
- · No hand drawn sketches/diagrams.
- · References are cited using correct format.



2.6 Scoring Sheet for Pre-Lab Questions

Student Name:

Question ¹	A-1	A-2	A-3
1			
2			
3			
4			
5			
6			
7			
Total			

¹This scoring sheet is for the Pre-Lab questions in Section 2.2

2.7 Scoring Sheet for Lab Report (STEP)

			FORMAT							
Item ¹	K-1	K-3	B-5	B-6	B-9	GS-1	GS-2			
I. PROCEDURE										
I.1. Closed-loop simulation										
1										
I.2. PV with high-pass filter										
2										
I.3. Step r	esponse wi	th PV								
3										
II. RESUL	TS									
1										
2										
3										
4										
III. ANALY	YSIS									
1										
2										
3										
IV. CONC	LUSIONS									
1					_					
2										
3										
Total										

¹This scoring sheet corresponds to the report template in Section 2.5.1.



2.8 Scoring Sheet for Lab Report (RAMP PV)

			FORMAT								
Item ¹	K-1	K-3	B-5	B-6	B-9	GS-1	GS-2				
I. PROCEDURE											
I.1. Ramp response with PV controller											
1											
I.2. Impler	menting Ra	mp Respon	se Using P\	/							
2											
II. RESUL	TS										
1											
2											
3											
III. ANALY	/SIS										
1											
2											
IV. CONC	IV. CONCLUSIONS										
1											
Total											

¹This scoring sheet corresponds to the report template in Section 2.5.2.

2.9 Scoring Sheet for Lab Report (Ramp Response with No Steady-State Error)

•	CONTENT									RMAT
Item ¹	K-1	K-3	B-1	B-2	B-3	B-4	B-6	B-9	GS-1	GS-2
I. PROC	EDURE									
1										
2										
3										
4										
II. RESU	LTS									
1										
2										
3										
III. ANAL	YSIS									
1										
2										
IV. CON	IV. CONCLUSIONS									
1										
Total										

¹This scoring sheet corresponds to the report template in Section 2.5.3.



LABORATORY 3

SRV02 SPEED CONTROL

The objective of this laboratory is to develop feedback systems that control the speed of the rotary servo load shaft. A proportional-integral (PI) controller and a lead compensator are designed to regulate the shaft speed according to a set of specifications.

Topics Covered

- Design of a proportional-integral (PI) controller that regulates the angular speed of the servo load shaft.
- · Design of a lead compensator.
- Simulation of the PI and lead controllers using the plant model to ensure the specifications are met without any actuator saturation.
- Implemention of the controllers on the Quanser SRV02 device to evaluate their performance.

Prerequisites

In order to successfully carry out this laboratory, the user should be familiar with the following:

- Data acquisition device (e.g. Q2-USB), the power amplifier (e.g. VoltPAQ-X1), and the main components of the SRV02 (e.g. actuator, sensors), as described in References [2], [4], and [6], respectively.
- Wiring and operating procedure of the SRV02 plant with the amplifier and data-aquisition (DAQ) device, as discussed in Reference [6].
- Transfer function fundamentals, e.g. obtaining a transfer function from a differential equation.
- Laboratory described in Appendix A to get familiar with using QUARC® with the SRV02.

Completion Time

The approximate times to complete each section is summarized in Table 3.1.

Section	Time (min)
Pre-lab (Section 3.2)	60 min
In-lab: PI Step Response (Section 3.3.1)	45 min
In-lab: LEAD Step Response (Section 3.3.2)	60 min

Table 3.1: Approximate Time to Complete Speed Control Lab



3.1 Background

3.1.1 Desired Response

3.1.1.1 SRV02 Speed Control Specifications

The time-domain requirements for controlling the speed of the SRV02 load shaft are:

$$e_{ss} = 0$$
 (3.1.1)

$$t_p \le 0.05 \text{ s, and}$$
 (3.1.2)

$$PO \le 5 \%$$
 (3.1.3)

Thus, when tracking the load shaft reference, the transient response should have a peak time less than or equal to 0.05 seconds, an overshoot less than or equal to 5 %, and zero steady-state error.

In addition to the above time-based specifications, the following frequency-domain requirements are to be met when designing the *Lead Compensator*:

$$PM \ge 75.0 \text{ deg}$$
 (3.1.4)

and

$$\omega_q = 75.0 \text{ rad/s} \tag{3.1.5}$$

The phase margin mainly affects the shape of the response. Having a higher phase margin implies that the system is more stable and the corresponding time response will have less overshoot. The overshoot will not go beyond 5% with a phase margin of at least 75.0 degrees.

The crossover frequency is the frequency where the gain of the Bode plot is 1 (or 0 dB). This parameter mainly affects the speed of the response, thus having a larger ω_g decreases the peak time. With a crossover frequency of 75.0 radians the resulting peak time will be less than or equal to 0.05 seconds.

3.1.1.2 Overshoot

In this laboratory we will use the following step setpoint (input):

$$\omega_d(t) = \begin{cases} 2.5 \text{ rad/s} & t \le t_0 \\ 7.5 \text{ rad/s} & t > t_0 \end{cases}$$
 (3.1.6)

where t_0 is the time the step is applied. Initially, the SRV02 should be running at 2.5 rad/s and after the step time it should jump up to 7.5 rad/s. From the standard definition of overshoot in step response, we can calculate the maximum overshoot of the response (in radians):

$$\omega(t_p) = \omega_d(t_0) + (\omega_d(t) - \omega_d(t_0)) \left(1 + \frac{PO}{100}\right)$$
 (3.1.7)

with the given values the maximum overshoot of the response is

$$\omega(t_p) = 7.75 \text{ rad/s} \tag{3.1.8}$$

The closed-loop speed response should therefore not exceed the value given in Equation 3.1.8.

3.1.1.3 Steady State Error

Consider the speed control system with unity feedback shown in Figure 3.1. Let the compensator be C(s) = 1.




Figure 3.1: Unity feedback loop.

We can find the steady-state error using the final value theorem:

$$e_{ss} = \lim_{s \to 0} s E(s) \tag{3.1.9}$$

where

$$E(s) = \frac{R(s)}{1 + C(s) P(s)}$$
 (3.1.10)

The voltage-to-speed transfer function for the SRV02 was found in Section 1 as:

$$P(s) = \frac{K}{\tau \, s + 1} \tag{3.1.11}$$

Substituting $R(s)=\frac{R_0}{s}$ and C(s)=1 gives:

$$E(s) = \frac{R_0}{s\left(1 + \frac{K}{\tau s + 1}\right)}$$
 (3.1.12)

Applying the final-value theorem to the system gives

$$e_{ss} = R_0 \left(\lim_{s \to 0} \frac{\tau \, s + 1}{\tau \, s + 1 + K} \right) \tag{3.1.13}$$

When evaluated, the resulting steady-state error due to a step response is

$$e_{ss} = \frac{R_0}{1+K} {(3.1.14)}$$

3.1.2 PI Control Design

3.1.2.1 Closed Loop Transfer Function

The proportional-integral (PI) compensator used to control the velocity of the SRV02 has the following structure:

$$V_m(t) = k_p \left(b_{sp} \,\omega_d(t) - \omega_l(t) \right) - k_i \int \left(\omega_d(t) - \omega_l(t) \right) dt \tag{3.1.15}$$






Figure 3.2: Block diagram of SRV02 PI speed control.

where k_p is the proportional control gain, k_i is the integral control gain, $\omega_d(t)$ is the setpoint or reference angular speed for the load shaft, $\omega_l(t)$ is the measured load shaft angular speed, b_{sp} is the setpoint weight, and $V_m(t)$ is the voltage applied to the SRV02 motor. The block diagram of the PI control is given in Figure 3.2.

We can take Laplace transform of the controller given in Equation 3.1.15:

$$V_m(s) = k_p \left(b_{sp} \, \Omega_d(s) - \Omega_l(s) \right) + \frac{k_i \, \left(\Omega_d(s) - \Omega_l(s) \right)}{s} \tag{3.1.16}$$

To find the closed-loop speed transfer function, $\Omega_l(s)/\Omega_d(s)$, we can use the process transfer function from Equation 3.1.11 and solve for $\Omega_l(s)/\Omega_d(s)$ as:

$$\frac{\Omega_l(s)}{\Omega_d(s)} = \frac{K (k_p s b_{sp} + k_i)}{s^2 \tau + (1 + K k_p) s + K k_i}$$
(3.1.17)

3.1.2.2 Finding PI Gains to Satisfy Specifications

In this section, we will first calculate the minimum damping ratio and natural frequency required to meet the specifications given in Section 3.1.1.1. Then, using these values we will calculate the necessary control gains k_p and k_i to achieve the desired performance with a PI controller.

The minimum damping ratio and natural frequency needed to satisfy a given percent overshoot and peak time are:

$$\zeta = -\ln\left(\frac{PO}{100}\right)\sqrt{\frac{1}{\ln\left(\frac{PO}{100}\right)^2 + \pi^2}}$$
(3.1.18)

and

$$\omega_n = \frac{\pi}{t_p \sqrt{1 - \zeta^2}} \tag{3.1.19}$$

Substituting the percent overshoot specifications given in 3.1.3 into Equation 3.1.18 gives the required damping ratio

$$\zeta = 0.690 \tag{3.1.20}$$

Then, by substituting this damping ratio and the desired peak time, given in 3.1.2, into Equation 3.1.19, the minimum natural frequency is found as:

$$\omega_n = 86.7 \text{ rad/s} \tag{3.1.21}$$

Now, let's look at how we can calculate the gains. When the setpoint weight is zero, i.e. $b_{sp}=0$, the closed-loop SRV02 speed transfer function has the structure of a *standard second-order system*. We can find expressions for the control gains k_p and k_i by equating the characteristic equation (denominator) of the SRV02 closed-loop transfer function to the *standard characteristic equation*: $s^2 + 2 \zeta \omega_n s + \omega_n^2$.

The denominator of the transfer function can be re-structured into the following:

$$s^2 + \frac{(1 + K k_p) s}{\tau} + \frac{K k_i}{\tau}$$
 (3.1.22)

equating the coefficients of this equation to the coefficients of the standard characteristic equation gives:

$$\frac{Kk_i}{\tau} = \omega_n^2 \tag{3.1.23}$$

and

$$\frac{1+Kk_p}{\tau} = 2\zeta\,\omega_n\tag{3.1.24}$$

Then, the proportional gain k_p can be found as:

$$k_p = \frac{-1 + 2\zeta \omega_n \tau}{K}$$
 (3.1.25)

and the integral gain k_i is

$$k_i = \frac{\omega_n^2 \, \tau}{K} \tag{3.1.26}$$

3.1.3 Lead Control Design

Alternatively, a lead or lag compensator can be designed to control the speed of the servo. The lag compensator is actually an approximation of a PI control and this, at first, may seem like the more viable option. However, due to the saturation limits of the actuator the lag compensator cannot achieve the desired zero steady-state error specification. Instead, a lead compensator with an integrator, as shown in Figure 3.3, will be designed.




Figure 3.3: Closed-loop SRV02 speed control with lead compensator.

To obtain zero steady-state error, an integrator is placed in series with the plant. This system is denoted by the transfer function

$$P_i(s) = \frac{P(s)}{s}$$
 (3.1.27)

where P(s) is the plant transfer function in Equation 3.1.11.

The phase margin and crossover frequency specifications listed in equations 3.1.4 and 3.1.5 of Section 3.1.1.1 can then be satisfied using a proportional gain K_c and the lead transfer function

$$G_{lead}(s) = \frac{1 + aTs}{1 + Ts} \tag{3.1.28}$$

The a and T parameters change the location of the pole and the zero of the lead compensator which changes the gain and phase margins of the system. The design process involves examining the stability margins of the *loop transfer function*, $L(s) = C(s) \cdot P(s)$, where the compensator is given by:

$$C(s) = \frac{K_c (1 + aTs)}{(1 + Ts) s}$$
(3.1.29)



3.1.3.1 Finding Lead Compensator Parameters

The Lead compensator is an approximation of a proportional-derivative (PD) control. A PD controller can be used to add damping to reduce the overshoot in the transient of a step response and effectively making the system more stable. In other words, it increases the phase margin. In this particular case, the lead compensator is designed for the following system:

$$L_p(s) = \frac{K_c P(s)}{s}$$
 (3.1.30)

The proportional gain Kc is designed to attain a certain crossover frequency. Increasing the gain crossover frequency essentially increases the bandwidth of the system which decreases the peak time in the transient response (i.e. makes the response faster). However, as will be shown, adding a gain $K_c > 1$ makes the system less stable. The phase margin of the $L_p(s)$ system is therefore lower than the phase margin of the $P_i(s)$ system and this translates to having a large overshoot in the response. The lead compensator is used to dampen the overshoot and increase the overall stability of the system, i.e increase its phase margin.

The frequency response of the lead compensator given in 3.1.28 is

$$G_{lead}(\omega j) = \frac{1 + a T \omega j}{1 + T \omega j}$$
(3.1.31)

and its corresponding magnitude and phase equations are

$$|G_{lead}(\omega j)| = \sqrt{\frac{T^2 \omega^2 a^2 + 1}{1 + T^2 \omega^2}}$$
 (3.1.32)

and

$$\phi_G = \arctan(aT\omega) - \arctan(T\omega) \tag{3.1.33}$$

The Bode plot of the lead compensator is shown in Figure 3.4.




Figure 3.4: Bode of lead compensator.

3.1.3.2 Lead Compensator Design using MATLAB

In this section, we will use Matlab®to design a lead compensator that will satisfy the frequency-based specifications given in Section 3.1.1.1.

1. Bode plot of the open-loop uncompensated system, $P_i(s)$, must first be found. To generate the Bode plot of $P_i(s)$, enter the following commands in Matlab[®]. NOTE: If your system has not been set up yet, then you

need to first run the the $setup_srv02_exp03_spd.m$ script. This script will store the model parameter K and tau in the Matlab®workspace. These parameters are used with the commands tf and series to create the $P_i(s)$ transfer function. The margin command generates a Bode plot of the system and it lists the gain and phase stability margins as well as the phase and gain crossover frequencies.

```
% Plant transfer function
P = tf([K],[tau 1]);
% Integrator transfer function
I = tf([1],[1 0]);
% Plant with Integrator transfer function
Pi = series(P,I);
% Bode of Pi(s)
figure(1)
margin(Pi);
set (1,'name','Pi(s)');
```

The entire Lead compensator design is given in the $d_{lead.m}$ script file. Run this script after running the setup_srv02_exp03_spd.m script when CONTROL_TYPE = 'AUTO' to generate a collection of Bode diagrams including the Bode of $P_i(s)$ given in Figure 3.5.




Figure 3.5: Bode of Pi(s) system.

2. **Find how much more gain is required** such that the gain crossover frequency is 50.0 rad/s (use the *ginput* Matlab®command). As mentioned before, the lead compensator adds gain to the system and will increases the phase as well. Therefore, gain K_c is not to be designed to meet the specified 75.0 rad/s fully.

As given in Figure 3.5, the crossover frequency of the uncompensated system is 1.53 rad/s. To move the crossover frequency to 50.0 rad/s, a gain of

$$K_c = 34.5 \text{ dB}$$
 (3.1.34)

or

$$K_c = 53.1 \text{ V/rad}$$
 (3.1.35)

in the linear range is required. The Bode plot of the loop transfer function $L_p(s)$ (from Section 3.1.3) is given in Figure 3.6. This initial estimate of the gain was found using the *ginput* command. The gain was then adjusted according to the crossover frequency calculated in the generated Bode plot of the $L_p(s)$ system. The commands used to generate the Bode plot are given in the d_lead.m script.






Figure 3.6: Bode of Lp(s) system.

3. **Gain needed for specified phase margin** must be found next so that the lead compensator can achieve the specified phase margin of 75 degrees. Also, to ensure the desired specifications are reached, we'll add another 5 degrees to the maximum phase of the lead.

To attain the necessary phase margin, the maximum phase of the lead can be calculated using

$$\phi_m = PM_{des} - PM_{meas} + 5 \tag{3.1.36}$$

Given that the desired phase margin in Equation 3.1.4 and the phase margin of $L_p(s)$ is

$$PM_{meas} = 21.5 \text{ deg}$$
 (3.1.37)

the maximum lead phase has to be about

$$\phi_m = 41.8 \text{ deg}$$
 (3.1.38)

or

$$\phi_m = 0.728 \text{ rad}$$
 (3.1.39)

The lead compensator, as explained in Section 3.1.3.1, has two parameters: a and T. To attain the maximum phase ϕ_m shown in Figure 3.4, the Lead compensator has to add $20\log_{10}(a)$ of gain. This is determined using the equation

$$a = -\frac{1 + \sin(\phi_m)}{-1 + \sin(\phi_m)} \tag{3.1.40}$$

The gain needed is found by inserting the max phase into this equation to get

$$a = 4.96$$
 (3.1.41)

which is

$$20 \log 10(a) = 13.9 \, \mathsf{dB} \tag{3.1.42}$$

4. The frequency at which the lead maximum phase occurs must be placed at the new gain crossover frequency $\omega_{g,new}$. This is the crossover frequency after the lead compensator is applied. As illustrated in Figure 3.4, ω_m occurs halfway between 0 dB and $20\log_{10}(a)$, i.e. at $10\log_{10}(a)$. So, the new gain crossover frequency in the $L_p(s)$ system will be the frequency where the gain is $-10\log_{10}(a)$.

From Figure 3.6, it is found that the frequency where the $-10\log_{10}(a)$ gain in the $L_p(s)$ system occurs is at about 80.9 rad/s. Thus, the maximum phase of the lead will be set to

$$\omega_m = 80.9 \text{ rad/s} \tag{3.1.43}$$

As illustrated earlier in Figure 3.4 in Section 3.1.3.1, the maximum phase occurs at the maximum phase frequency ω_m . Parameter T given by:

$$T = \frac{1}{\omega_m \sqrt{a}} \tag{3.1.44}$$

is used to attain a certain maximum phase frequency. This changes where the Lead compensator breakpoint frequencies 1/(a*T) and 1/T shown in Figure 3.4 occur. The slope of the lead compensator gain changes at these frequencies. We can find the parameter T by substituting $\omega_m=80.9$ and the lead gain value from Equation 3.1.41 into Equation 3.1.44:

$$T = 0.00556 \text{ s/rad}$$
 (3.1.45)

Therefore, the lead breakpoint frequencies are:

$$\frac{1}{aT} = 36.1 \text{ rad/s}$$
 (3.1.46)

and

$$\frac{1}{T} = 180.9 \text{ rad/s}$$
 (3.1.47)

5. Bode plot of the lead compensator $C_{lead}(s)$, defined in 3.1.28 can be generated using the $d_{lead}(s)$ script.




Figure 3.7: Bode of lead compensator $C_{lead}(s)$.

- 6. Bode plot of the loop transfer function L(s), as described in 3.1.30, can be generated using the <u>d_lead.m</u> script. The phase margin of L(s) is 68.1 degrees and is below the desired phase margin of 75.0 degrees, as specified in Section 3.1.1.
- 7. Check response by simulating the system to make sure that the time-domain specifications are met. Keep in mind that the goal of the lead design is the same as the PI control, the response should meet the desired steady-state error, peak time, and percentage overshoot specifications given in Section 3.1.1. Thus, if the crossover frequency and/or phase margin specifications are not quite satisfied, the response should be simulated to verify if the time-domain requirements are satisfied. If so, then the design is complete. If not, then the lead design needs to be re-visited.

You will work on this later in the laboratory as described in Section 3.3.2.1.






Figure 3.8: Bode of loop transfer function L(s).

3.1.4 Sensor Noise

When using analog sensors, such as a tachometer, there is often some inherent noise in the measured signal.

The peak-to-peak noise of the measured SRV02 load gear signal can be calculated using

$$e_{\omega} = \frac{1}{100} K_n \,\omega_l \tag{3.1.48}$$

where K_n is the peak-to-peak ripple rating of the sensor and ω_l is the speed of SRV02 load gear. The rated peak-to-peak noise of the SRV02 tachometer is given in Appendix B of Reference [6] as:

$$K_n = 7 \%$$
 (3.1.49)

Based on this specification, the peak-to-peak noise, when the load shaft runs at 7.5 rad/s, will be

$$e_{\omega} = 0.525 \text{ rad/s}$$
 (3.1.50)

Thus, the signal will oscillate ± 0.2625 rad/s about the 7.5 rad/s setpoint, or approximately between 7.24 rad/s and 7.76 rad/s. Then, taking the noise into account, what would be the maximum peak in the speed response that is to be expected?

Equation 3.1.7 was used to find the peak value of the load gear response for a given percent overshoot. To take into account the noise in the signal, this formula is modified as follows:

$$\omega(t_p) = \omega_d(t_0) + (\omega_d(t) - \omega_d(t_0)) \left(1 + \frac{PO}{100}\right) + \frac{1}{2}e_{\omega}$$
(3.1.51)

Given a reference signal that goes between 2.5 rad/s to 7.5 rad/s, as described in Section 3.1.1.1, and the peak-to-peak ripple estimate in Equation 3.1.50, the peak speed of the load gear, including the noise, can be found as:

$$\omega(t_p) = 8.01 \text{ rad/s}$$
 (3.1.52)

Using

$$PO = \frac{100 \ (\omega(t_p) - \omega_d(t))}{\omega_d(t) - \omega_d(t_0)}$$
 (3.1.53)

the new maximum percent overshoot for a 5.0 rad/s step is

$$PO \le 10.2 \%$$
 (3.1.54)

3.2 Pre-Lab Questions

1. A-3 Based on the steady-state error result of a step response from Equation ,what *type* of system is the SRV02 when performing speed control (Type 0, 1, or 2) and why?

Answer 3.2.1

Outcome Solution

A-3 This is a *Type 0* system because the steady-state error is a constant given a step reference.

2. A-2 The nominal SRV02 model parameters, K and τ , found in SRV02 Modeling Laboratory (Section 1) should be about 1.53 (rad/s-V) and 0.0254 sec, respectively. Calculate the PI control gains needed to satisfy the time-domain response requirements.

Answer 3.2.2

Outcome Solution

A-2 Using the nominal SRV02 model parameters

$$K = 1.53 \text{ rad/(V.s)}$$
 (Ans.3.2.1)

and

$$\tau = 0.0254 \text{ s}$$
 (Ans.3.2.2)

along with the damping ratio given in Equation 3.1.20 with Equation 3.1.25 generates the proportional control gain

$$k_p = 1.34 \text{ V/(rad/s)}$$
 (Ans.3.2.3)

The integral control gain is obtained by substituting the model parameters given above with the minimum natural frequency specification given in 3.1.21 into Equation 3.1.26

$$k_i = 124.9 \text{ V/rad}$$
 (Ans.3.2.4)

Thus, if these gains are used, the speed response of the load gear on an SRV02 with a disc load will satisfy the specifications listed in Section 3.1.1.1.

3. A-2 Find the frequency response magnitude, $|P_i(\omega)|$, of the transfer function $P_i(s)$ given in Equation 3.1.27.

Answer 3.2.3

Outcome Solution

A-2 The frequency response of $P_i(s)$ is found by substituting $s=j\,\omega$ in 3.1.27.

$$P_i (j\omega) = \frac{K}{(\tau j\omega + 1) j\omega}$$
 (Ans.3.2.5)

Taking the magnitude of this expression gives the frequency response gain

$$|P_i(\omega)| = \frac{K}{\omega \sqrt{\tau^2 \omega^2 + 1}}$$
 (Ans.3.2.6)



4. A-2 Calculate the DC gain of $P_i(s)$ given in Equation 3.1.27. **Hint:** The DC gain is the gain when the frequency is zero, i.e. $\omega = 0 \, rad/s$. However, because of its integrator, $P_i(s)$ has a singularity at zero frequency. Therefore, the DC gain is not technically defined for this system. Instead, approximate the DC gain by using $\omega = 1 \, rad/s$. Make sure the DC gain estimate is evaluated numerically in dB using the nominal model parameters, K = 1.53 and $\tau = 0.0254$, (or use what you found for K and τ in Section 1).

Answer 3.2.4

Outcome Solution

A-2 Substituting $\omega = 1$ rad/s gives the approximate DC gain of

$$|P_i(1)| = \frac{K}{\sqrt{\tau^2 + 1}}$$
 (Ans.3.2.7)

Substituting the nominal SRV02 model parameters in the above expression results in the DC gain estimate of

$$|P_i(1)| = 1.53$$
 (Ans.3.2.8)

or

$$|P_i(1)|_{dB} = 3.70 \text{ dB}$$
 (Ans.3.2.9)

5. A-1, A-2 The gain crossover frequency, ω_g , is the frequency at which the gain of the system is 1 or 0 dB. Express the crossover frequency symbolically in terms of the SRV02 model parameters K and τ . Then, evaluate the expression using the nominal SRV02 model parameters K=1.53 and $\tau=0.0254$, (or use what you found for K and τ in Section 1).

Answer 3.2.5

Outcome Solution

A-1 The crossover frequency is found by setting $|P_i(\omega_g)|=1$ in equation Ans.3.2.6 and solving for ω_g

A-2

$$\omega_g = \frac{\sqrt{2}\sqrt{\frac{-1+\sqrt{1+4}\tau^2 K^2}{\tau^2}}}{2}$$
 (Ans.3.2.10)

When evaluated with the nominal SRV02 parameters, the frequency where the gain is 0 dB is

$$\omega_q = 1.524 \text{ rad/s}$$
 (Ans.3.2.11)

3.3 Lab Experiments

The main goal of this laboratory is to explore closed-loop speed control of the SRV02 load shaft.

In this laboratory you will conduct two experiments:

- 1. Step response with PI control, and
- 2. Step response with Lead control

In each of the experiments, you will first simulate the closed-loop response of the system. Then, you will implement the controller using the SRV02 hardware and software to compare the real response to the simulated one.

3.3.1 Step Response with PI Control

3.3.1.1 Simulation

First you will simulate the closed-loop speed response of the SRV02 with a PI controller to step input. Our goals are to confirm that the desired reponse specifications in an ideal situation are satisfied and to verify that the motor is not saturated. Then, you will explore the effect of the setpoint weight.

Experimental Setup

The s_srv02_spd Simulink® diagram shown in Figure 3.9 is used to simulate the closed-loop speed response of the SRV02 when using either the PI or Lead controls. The SRV02 Model uses a *Transfer Fcn* block from the Simulink® library to simulate the system. The PI compensator subsystem contains the PI control detailed in Section 3.1.2 and the *Lead Compensator* block has the compensator described in Section 3.1.3.




Figure 3.9: Simulink diagram used to simulate the closed-loop SRV02 speed response.

IMPORTANT: Before you can conduct these experiments, you need to make sure that the lab files are configured according to your SRV02 setup. If they have not been configured already, then you need to go to Section 3.4.2 to configure the lab files first.

- 1. Enter the proportional and integral control gains found in Section 3.1.2.2 as kp and ki in Matlab[®].
- 2. The speed reference signal is to be a 0.4 Hz square wave that goes between 2.5 rad/s and 7.5 rad/s (i.e. between 23.9 rpm and 71.6 rpm). Set the *SRV02 Signal Generator block* parameters to the following:
 - Signal type = square
 - Amplitude = 1



- Frequency = 0.4 Hz
- 3. In the Speed Control Simulink®model, set the Amplitude (rad/s) gain block to 2.5 rad/s and the Offset (rad/s) block to 5.0 rad/s.
- 4. Set the *Manual Switch* to the upward position to activate the PI control.
- 5. Open the load shaft position scope, w_l (rad), and the motor input voltage scope, Vm (V).
- 6. Start the simulation. By default, the simulation runs for 5 seconds. The scopes should be displaying responses similar to figures 3.10 and 3.11. Note that in the w_I (rad) scope, the yellow trace is the setpoint position while the purple trace is the simulated speed (generated by the SRV02 Model block).




Figure 3.10: Simulated PI speed response.




Figure 3.11: Simulated PI motor input voltage.

7. K-3, B-5 Generate a Matlab[®] figure showing the simulated PI speed response and its input voltage. After each simulation run, each scope automatically saves their response to a variable in the Matlab workspace. The w_I (rad) scope saves its response to the variable called data_spd and the Vm (V) scope saves its data to the data_vm variable. The data_spd variable has the following structure: data_spd(:,1) is the time vector, data_spd(:,2) is the setpoint, and data_spd(:,3) is the simulated angular speed. For the data_vm variable, data_vm(:,1) is the time and data_vm(:,2) is the simulated input voltage.

Answer 3.3.1

Outcome Solution

B-5 If the experimental procedure is followed correctly, the measured SRV02 closed-loop speed step response should be similar to Figure 3.12.

K-3 The closed-loop speed response when using the PI control is shown in Figure 3.12. This is generated using the sample_meas_tp_os_spd.m script. To generate this figure from the simulation, do the following:

- (a) Execute the setup_srv02_exp03_spd.m script with CONTROL_TYPE = 'AUTO'
- (b) Run the s srv02 spd Simulink model.
- (c) Run the sample_meas_tp_os_spd.m script.

8. K-1, B-9 Measure the steady-state error, the percent overshoot, and the peak time of the simulated response. Does the response satisfy the specifications given in Section 3.1.1.1?




Figure 3.12: Simulated PI response.

Outcome Solution

K-1 The steady-state error, peak time, and percent overshoot measured from the simulated PI speed response shown in Figure 3.12 are

$$e_s s = 0$$
 (Ans.3.3.1)

$$t_p = 0.05 [s]$$
 (Ans.3.3.2)

and

$$PO = 5.0 \, [\%]$$
 (Ans.3.3.3)

See Section 2 for more information on measuring the steady-state error, peak time, and percent overshoot. Note also that these parameters are found automatically in the <code>sample_meas_tp_os_spd.m</code> script using the response saved in the <code>data_spd</code> variable (after running <code>s_srv02_spd</code>).

B-9 The response with the PI control gains matches the specifications given in Section 3.1.1.1 while maintaining an input voltage less than 10 V, i.e. the motor is not saturated.

3.3.1.2 Implementing PI Speed Control

Experimental Setup

The q_srv02_spd Simulink®diagram shown in Figure 3.13 is used to perform the speed control exercises in this laboratory. The SRV02-ET Speed subsystem contains QUARC®blocks that interface with the DC motor and sensors of the SRV02 system, as discussed in Section A. The PI control subsystem implements the PI control detailed in Section 3.1.2 and the Lead Compensator block implements the lead control described in Section 3.1.3.






Figure 3.13: Simulink model used with QUARC to run the PI and lead speed controllers on the SRV02.

- 1. Run the setup_srv02_exp03_spd.m script.
- 2. Enter the proportional and integral control gains found in Section 3.2 as kp and ki in Matlab®.
- 3. To generate a square reference speed signal, set the *SRV02 Signal Generator* block parameters to the following:
 - Signal type = square
 - Amplitude = 1
 - Frequency = 0.4 Hz
- 4. In the Speed Control Simulink®model, set the *Amplitude (rad/s)* gain block to 2.5 rad/s and the *Offset (rad/s)* constant block to 5.0 rad/s.
- 5. Open the load shaft speed scope, w_I (rad/s), and the motor input voltage scope, Vm (V).
- 6. Set the Manual Switch to the upward position to activate the PI control.
- 7. Click on QUARC | Build to compile the Simulink® diagram.
- 8. Select QUARC | Start to run the controller. The scopes should be displaying responses similar to figures Figure 3.14 and Figure 3.15. Note that in the *w_l* (*rad/s*) scope, the yellow trace is the setpoint position while the purple trace is the measured position.




Figure 3.14: Measured PI speed step response.




Figure 3.15: PI motor input voltage.

9. K-2, B-5 When a suitable response is obtained, click on the *Stop* button in the Simulink® diagram toolbar (or select QUARC | Stop from the menu) to stop running the code. Generate a Matlab®figure showing the PI speed response and its input voltage. As in the s_srv02_spd Simulink®diagram, when the controller is stopped each scope automatically saves their response to a variable in the Matlab®workspace. Thus, the theta_I (rad) scope saves its response to the data_spd variable and the Vm (V) scope saves its data to the data_vm variable.

Answer 3.3.3

Outcome Solution

- B-5 If the experimental procedure is followed correctly, the measured SRV02 closed-loop speed step response should be similar to Figure 3.16.
- K-2 The measured SRV02 closed-loop speed step response with the PI control is shown in Figure 3.16. To generate this response, execute the <code>sample_meas_tp_os_spd.m</code> script with the saved MAT files <code>data_pi_spd_rsp_wl.mat</code> and <code>data_pi_spd_rsp_vm.mat</code>. Alternatively, to generate a <code>Matlab®</code> figure from a new experimental run, do the following:
 - (a) Execute the setup_srv02_exp03_spd.m script with CON-TROL TYPE = 'AUTO'
 - (b) Run the *q_srv02_spd* Simulink model (with the Manual Switch up) until a response fills the scopes.
 - (c) Stop QUARC.
 - (d) Execute the sample_meas_tp_os_spd.m script.




Figure 3.16: Measured speed response using PI control.

10. K-2 Due to the noise in the measured speed signal, it is difficult to obtain an accurate measurement of the specifications. In the Speed Control Simulink®mode, set the Amplitude (rad) block to 0 rad/s and the Offset (rad) block to 7.5 rad/s in order to generate a constant speed reference of 7.5 rad/s. Generate a Matlab®figure showing the noise in the signal.

Outcome Solution

K-2 The noise in the measured speed signal is displayed in the top plot of Figure 3.17. This figure can be generated using the tach_noise.m script with the saved data files data_cnst_spd_rsp_wl.mat and data_cnst_spd_rsp_vm.mat.




Figure 3.17: Noise in measured speed signal.

11. B-8, B-9 Measure the peak-to-peak ripple found in the speed signal, $e_{\omega,meas}$, and compare it with the estimate in Section 3.1.4. Then, find the steady-state error by comparing the average of the measured signal with the desired speed. Is the steady-state error specification satisfied?

Answer 3.3.5

Outcome Solution

B-8 When the reference is held at 10.0 rad/s the noise signal oscillates between approximately ± 0.15 rad/s. The measured peak-to-peak ripple is therefore approximately

$$e_{\omega,meas} = 0.3 \left[\frac{rad}{s} \right]$$
 (Ans.3.3.4)

B-9 The mean of the measured speed signal is 7.5 rad/s. Thus it follows that the steady-state error is

$$e_{ss} = 0$$
 (Ans.3.3.5)

and this specification is satisfied. The mean is taken using the Matlab®mean command, as detailed in the tach_noise.m script.

12. K-1, B-9 Measure the percent overshoot and the peak time of the SRV02 load gear step response. Taking into account the noise in the signal, does the response satisfy the specifications given in Section 3.1.1.1?

Outcome Solution

K-1 The peak time and percent overshoot of the response shown in Figure

3.16 is

$$t_p = 0.039 [s]$$
 (Ans.3.3.6)

and

$$PO = 5.4 \, [\%]$$
 (Ans.3.3.7)

B-9 The peak time specification satisfies the requirement given in Section 3.1.1.1 and the percent overshoot satisfies the specification given in 3.1.34 (which takes into account the measurement noise). Thus, the specifications are satisfied and the servo motor was not saturated. To find the peak time and percent overshoot of a response saved in data_spd automatically, run the sample_meas_tp_os_spd.m script after running q_srv02_spd. Alternatively, the response shown in Figure 3.16 can be loaded from the saved MAT files data_pi_spd_rsp_wl.mat and data_pi_spd_rsp_wl.mat and the above measurements can be made.

- 13. Click the Stop button on the Simulink®diagram toolbar (or select QUARC | Stop from the menu) to stop the experiment.
- 14. Turn off the power to the amplifier if no more experiments will be performed on the SRV02 in this session.

3.3.2 Step Response with LEAD Control

3.3.2.1 Simulation

You will simulate the closed-loop speed response of the SRV02 with a Lead controller to step input. Our goals are to confirm that the desired reponse specifications in an ideal situation are satisfied and to verify that the motor is not saturated.

As in the step response with PI control experiment in Section 3.3.1.1, in this experiment you need to use the $s_srv02_spd\ Simulink^{@}$ diagram shown in Figure 3.13 again.

- 1. Enter the Lead control parameters found in Section 3.1.3.2. These are denoted as Kc, a, and T in Matlab[®].
- 2. Set the SRV02 Signal Generator block parameters to the following:
 - Signal type = square
 - Amplitude = 1
 - Frequency = 0.4 Hz
- 3. In the Speed Control Simulink®model, set the *Amplitude (rad/s)* gain block to 2.5 rad/s and the *Offset (rad/s)* constant block to 5.0 rad/s.
- 4. To engage the lead control, set the *Manual Switch* to the downward position.
- 5. Open the load shaft position scope, w_I (rad), and the motor input voltage scope, Vm (V).
- 6. B-5 Start the simulation. By default, the simulation runs for 5 seconds. The scopes should be displaying responses similar to Figures 3.10 and 3.11.
- 7. K-1, B-9 Verify if the time-domain specifications in Section 3.1.1.1 are satisfied and that the motor is not being saturated. To calculate the steady-state error, peak time, and percent overshoot, use the simulated response data stored in the *data_spd* variable.



Outcome Solution

K-1 The steady-state error, peak time, and percent overshoot measured from the simulated lead speed response are

$$e_{ss} = 0$$
 (Ans.3.3.8)

$$t_p = 0.036 [s]$$
 (Ans.3.3.9)

and

$$PO = 1.9 \, [\%]$$
 (Ans.3.3.10)

Note also that the steady-state error, peak time, and percent overshoot are found automatically in the *sample_meas_tp_os.m* script using the response saved in the *data_spd* variable (after running *s_srv02_spd*).

- B-9 Even though the phase margin requirement was not met with the designed lead parameters, the response with the lead compensator satisfies the specifications given in Section 3.1.1.1 while maintaining an input voltage less than 10 V, i.e. the motor is not saturated.
- 8. If the specifications are not satisfied, go back in the lead compensator design. You may have to, for example, add more maximum phase in order to increase the phase margin. If the specifications are met, move on to the next step.
- 9. K-2 Generate a Matlab® figure showing the Simulated Lead speed response and its input voltage.

Answer 3.3.8

Outcome Solution

K-2 The closed-loop speed response when using the lead compensator is shown in Figure 3.18. This is generated using the sample_meas_tp_os.m script. To generate this figure from the simulation, do the following:

- (a) Execute the setup_srv02_exp03_spd.m script with CON-TROL_TYPE = 'AUTO'
- (b) Run the s srv02 spd Simulink model.
- (c) Run the sample meas to os.m script.

3.3.2.2 Implementing LEAD Speed Control

In this section the speed of the SRV02 is controlled using the lead compensator. Measurements will be taken to see if the specifications are satisfied.

- 1. Run the setup_srv02_exp03_spd.m script.
- 2. Enter the Kc, a, and T, lead parameters found in Section 3.1.3.2 in Matlab[®].
- 3. Set the SRV02 Signal Generator block parameters to the following:
 - Signal type = square
 - Amplitude = 1
 - Frequency = 0.4 Hz




Figure 3.18: Simulated response using lead compensator.

- 4. In the Speed Control Simulink®model, set the Amplitude (rad/s) gain block to 2.5 rad/s and the Offset (rad/s) constant block to 5.0 rad/s.
- 5. To engage the lead compensator, set the *Manual Switch* in the Speed Control Simulink® diagram to the downward position.
- 6. Open the load shaft speed scope, w_l (rad/s), and the motor input voltage scope, Vm (V).
- 7. Click on QUARC | Build to compile the Simulink® diagram.
- 8. Select QUARC | Start to run the controller. The scopes should be displaying responses similar to figures 3.14 and 3.15.
- 9. K-2, B-5 When a suitable response is obtained, click on the *Stop* button in the Simulink diagram toolbar (or select QUARC | Stop from the menu) to stop running the code. Generate a Matlab[®] figure showing the lead speed response and its input voltage.

Outcome Solution

- B-5 If the experimental procedure is followed correctly, the measured SRV02 closed-loop speed step response should be similar to Figure 3.19.
- K-2 The measured SRV02 closed-loop speed lead response with the lead compensator is shown in Figure 3.19. To generate this response, execute the sample_meas_tp_os_spd.m script with the saved MAT files data_lead_spd_rsp_wl.mat and data_lead_spd_rsp_vm.mat. Alternatively, to generate a Matlab®figure from a new experimental run, do the following:
 - (a) Execute the setup_srv02_exp03_spd.m script with CON-TROL TYPE = 'AUTO'
 - (b) Run the *q_srv02_spd* Simulink®model (with the *Manual Switch down*) until a response fills the scopes.
 - (c) Stop QUARC®.
 - (d) Execute the *sample_meas_tp_os_spd.m* script.








Figure 3.19: Measured lead step response.

10. K-1, B-9 Measure the steady-state error, the percent overshoot, and the peak time of the SRV02 load gear. For the steady-state error, it may be beneficial to give a constant reference and take its average as done in Section 3.3.1.2. Does the response satisfy the specifications given in Section 3.1.1.1?

Answer 3.3.10

Outcome Solution

K-1 The measured speed response, shown in Figure 3.19, is stabilized about the setpoint when it is held constant and therefore

$$e_{ss} = 0$$
 (Ans.3.3.11)

The peak time and percentage overshoot of the response shown in Figure 3.19 is

$$t_p = 0.023 [s]$$
 (Ans.3.3.12)

and

$$PO = 3.6 \, [\%]$$
 (Ans.3.3.13)

B-9 The steady-state error, peak time, and overshoot specifications satisfy the requirements given in Section 3.1.1.1. The peak time and percent overshoot are calculated automatically in the sample_meas_tp_os_spd.m script.

11. B-9 Using both your simulation and implementation results, comment on any differences between the PI and lead controls.

Outcome Solution

B-9

On the actual SRV02, the speed response overshoot with the lead compensator was higher than with the PI control. This is contrary to what was observed in the simulations where the lead possessed both a faster peak time and less overshoot.

The larger overshoot in the lead control is probably due to the inherent structure of the compensator and the noise in the speed signal, i.e. the noisy signal is amplified with a large proportional gain and then passed through an integrator.

- 12. Click the Stop button on the Simulink® diagram toolbar (or select QUARC | Stop from the menu) to stop the experiment.
- 13. Turn off the power to the amplifier if no more experiments will be performed on the SRV02 in this session.

3.3.3 Results

B-6 Fill out Table 3.2 below with your answers to the Pre-Lab questions and your results from the lab experiments.

Section / Ques-	Description	Symbol	Value	Unit
tion				
Question 2	Pre-Lab: Pl Gains			
	Proportional Gain	k_p	1.34	V/(rad.s)
	Integral Gain	k_i	124.9	V/(rad.s)
	Open-Loop Time Constant	au	0.0254	S
	Open-Loop Steady-state Gain	K	1.53	rad/(V.s)
Question 4	Pre-Lab: DC Gain Estimate			
	DC Gain Estimate of $P_i(s)$	$ P_i(1) $	3.70	dB
Question 5	Pre-Lab: Gain Crossover Frequency			
	Gain crossover frequency	ω_g	1.524	rad/s
Section 3.3.1.1	In-Lab: PI Step Response Simulation			
	Peak time	$\mid t_p \mid$	0.05	S
	Percent overshoot	PO	5.0	%
	Steady-state error	e_{ss}	0.00	rad/s
Section 3.3.1.2	In-Lab: PI Speed Control Implementa-			
	tion			
	Measured peak-to-peak ripple	$e_{\omega,meas}$	0.3	rad/s
	Steady-state error	e_{ss}	0.00	rad/s
	Peak time	$\mid t_p \mid$	0.039	S
	Percent overshoot	PO	5.4	%
Section 3.3.2.1	In-Lab: Step Response Simulation			
	with Lead Control			
	Peak time	$\mid t_p \mid$	0.036	S
	Percent overshoot	PO	1.9	%
	Steady-state error	e_{ss}	0.00	rad/s
Section 3.3.2.2	In-Lab: Lead Speed Control Imple-			
	mentation			
	Peak time	t_p	0.023	S
	Percentage overshoot	PO	3.6	%
	Steady-state error	e_{ss}	0.00	rad/s

Table 3.2: Summary of results for the Speed Control laboratory.



3.4 System Requirements

Before you begin this laboratory make sure:

- QUARC® is installed on your PC, as described in Reference [1].
- You have a QUARC® compatible data-aquisition (DAQ) card installed in your PC. For a listing of compliant DAQ cards, see Reference [5].
- SRV02 and amplifier are connected to your DAQ board as described Reference [6].

3.4.1 Overview of Files

Table 3.3: Files supplied with the SRV02 Speed Control laboratory.

File Name	Description
03 - SRV02 Speed Control - Student Manual.pdf	This laboratory guide contains pre-lab questions and lab experiments demonstrating how to design and implement a speed controller on the Quanser SRV02 rotary plant using QUARC [®] .
setup_srv02_exp03_spd.m	The main Matlab script that sets the SRV02 motor and sensor parameters as well as its configuration-dependent model parameters. Run this file only to setup the laboratory.
config_srv02.m	Returns the configuration-based SRV02 model specifications <i>Rm</i> , <i>kt</i> , <i>km</i> , <i>Kg</i> , <i>eta</i> _g, <i>Beq</i> , <i>Jeq</i> , and <i>eta</i> _m, the sensor calibration constants K_POT, K_ENC, and K_TACH, and the amplifier limits VMAX_AMP and IMAX_AMP.
d_model_param.m	Calculates the SRV02 model parameters <i>K</i> and <i>tau</i> based on the device specifications <i>Rm</i> , <i>kt</i> , <i>km</i> , <i>Kg</i> , <i>eta_g</i> , <i>Beq</i> , <i>Jeq</i> , and <i>eta_m</i> .
calc_conversion_constants.m	Returns various conversions factors.
s_srv02_spd.mdl	Simulink file that simulates the closed-loop SRV02 speed control using either the PI control or the lead compensator.
q_srv02_spd.mdl	Simulink file that runs the PI or Lead speed control on the actual SRV02 system using QUARC [®] .
03 - SRV02 Speed Control - Instructor Manual.pdf	Same as the student version except with solutions.
srv02_exp03_speed_control.mws	Maple worksheet used to design the speed controller for
	the experiment. Waterloo Maple 9, or a later release, is
	required to open, modify, and execute this file.

(Continued on the next page)

File Name	Description
srv02_exp03_speed_control.html	HTML presentation of the Maple Worksheet. It allows users to view the content of the Maple file without having Maple 9 installed. No modifications to the equations can be performed when in this format.
d_pi_design.m	Matlab script file that calculates the control gains <i>kp</i> and <i>ki</i> based on the model parameters K and tau as well as the peak time an overshoot specifications tp and PO.
d_lead.m	Matlab script file that calculates the lead compensator parameters Kc , a , and T based on the model parameters K and tau as well as the desired gain crossover frequency and phase margin.
sample_meas_tp_os_spd.m	Finds the peak time and overshoot of a step response stored in the variables data_spd and data_vm in the Matlab workspace. Users can also use the saved responses contained in the MAT files data_pi_spd_rsp_wl.mat and data_pi_spd_rsp_vm.mat.
tach_noise.m	Plots a sample speed and input voltage response depicting the noise found in the measured tachometer signal. The response is saved in the MAT files data_cnst_spd_rsp_vm.mat and data_cnst_spd_rsp_wl.mat. The steady-state error is computed as well.
data_pi_spd_rsp_wl.mat	Sample measured closed-loop PI step response - load gear angular rate.
data_pi_spd_rsp_vm.mat	Sample measured closed-loop PI step response - servo input voltage.
data_lead_spd_rsp_wl.mat	Sample measured closed-loop lead compensator step response - load gear angular rate.
data_lead_spd_rsp_vm.mat	Sample measured closed-loop lead compensator step response - servo input voltage.
data_cnst_spd_rsp_wl.mat	Sample measured closed-loop PI constant response - load gear angular rate.
data_cnst_spd_rsp_vm.mat	Sample measured closed-loop PI constant response - servo input voltage.

3.4.2 Setup for Speed Control Simulation

Follow these steps to configure the Matlab® setup script and the Simulink® diagram for the Speed Control simulation laboratory:

- 1. Load the Matlab®software.
- 2. Browse through the Current Directory window in Matlab® and find the folder that contains the SRV02 speed controller files, e.g. s_srv02_spd.mdl.
- 3. Double-click on the s_srv02_spd.mdl file to open the SRV02 Speed Control Simulation Simulink diagram shown in Figure 3.9.
- 4. Double-click on the setup_srv02_exp03_spd.m file to open the setup script for the position control Simulink models.
- 5. **Configure setup script:** The controllers will be run on an SRV02 in the high-gear configuration with the disc load, as in Section 1. In order to simulate the SRV02 properly, make sure the script is setup to match this configuration, e.g. the EXT GEAR CONFIG should be set to 'HIGH' and the LOAD TYPE should be set to



'DISC'. Also, ensure the ENCODER_TYPE, TACH_OPTION, K_AMP, AMP_TYPE, and VMAX_DAC parameters are set according to the SRV02 system that is to be used in the laboratory.

Instructors: Set CONTROL_TYPE = 'AUTO' to load the PI and Lead control parameters that meet the specifications.

6. Run the script by selecting the Debug | Run item from the menu bar or clicking on the Run button in the tool bar. The messages shown below, should be generated in the Matlab[®] Command Window. The correct model parameters are loaded but the control gains and related parameters loaded are default values that need to be changed. That is, the PI control gains are all set to zero, the lead compensator parameters a and T are both set to 1, and the compensator proportional gain Kc is set to zero.

```
SRV02 model parameters:
   K = 1.53 rad/s/V
   tau = 0.0254 s
PI control gains:
   kp = 0 V/rad
   ki = 0 V/rad/s
Lead compensator parameters:
   Kc = 0 V/rad/s
   1/(a*T) = 1 rad/s
  1/T = 1 rad/s
```

3.4.3 Setup for Speed Control Implementation

Before beginning the in-lab exercises on the SRV02 device, the q_srv02_spd Simulink® diagram and the setup_srv02_exp03_spd script must be configured.

Follow these steps to get the system ready for this lab:

- 1. Setup the SRV02 in the high-gear configuration and with the disc load as described in Reference [6].
- 2. Load the Matlab software.
- 3. Browse through the *Current Directory* window in Matlab[®] and find the folder that contains the SRV02 speed control files, e.g. q_srv02_spd.mdl.
- 4. Double-click on the q srv02 spd.mdl file to open the Speed Control Simulink diagram shown in Figure 3.13.
- Configure DAQ: Double-click on the HIL Initialize block in the SRV02-ET subsystem (which is located inside the SRV02-ET Speed subsystem) and ensure it is configured for the DAQ device that is installed in your system. See Section A for more information on configuring the HIL Initialize block.
- Configure Sensor: To perform the speed control experiment, the angular rate of the load shaft should be measured using the tachometer. This has already been set in the Spd Src Source block inside the SRV02-ET Speed subsystem.
- 7. **Configure setup script:** Set the parameters in the setup_srv02_exp03_spd.m script according to your system setup. See Section 3.4.2 for more details.

3.5 Lab Report

This laboratory contains two experiments, namely,

- 1. step response with PI control, and
- 2. step response with lead control.

When you are writing your report, follow the outline corresponding to the experiment you conducted to build the *content* of your report. Also, in Section 3.5.3 you can find some basic tips for the *format* of your report.



3.5.1 Template for Content (PI Control Experiments)

I. PROCEDURE

I.1. Step Response with PI Control

- 1. Simulation
 - Briefly describe the main goal of this simulation.
 - Briefly describe the procedure (Section 3.3.1.1)
- 2. Implementation
 - · Briefly describe the main goal of this experiment.
 - Briefly describe the experimental procedure (Section 3.3.1.2)

II. RESULTS

Do not interpret or analyze the data in this section. Just provide the results.

- 1. Response plot from step 7 in Section 3.3.1.1, Step response simulation with PI Control
- 2. Response plot from step 9 in Section 3.3.1.2, Step response implementation with PI Control
- 3. Signal noise plot from step 10 in Section 3.3.1.2, Step response implementation with PI Control
- 4. Provide data collected in this laboratory (from Table 3.2).

III. ANALYSIS

Provide details of your calculations (methods used) for analysis for each of the following:

III.1. Step Response with PI Control

- 1. Step 8 in Section 3.3.1.1, Step response simulation with PI Control
- 2. Step 11 in Section 3.3.1.2, Step response implementation with PI Control
- 3. Step 12 in Section 3.3.1.2, Step response implementation with PI Control

IV. CONCLUSIONS

Interpret your results to arrive at logical conclusions for the following:

- 1. Step 8 in Section 3.3.1.1, Step response simulation with PI Control
- 2. Step 11 in Section 3.3.1.2, Step response implementation with PI Control
- 3. Step 12 in Section 3.3.1.2, Step response implementation with PI Control

3.5.2 Template for Content (Lead Control Experiments)

I. PROCEDURE

I.1. Step Reponse with Lead Control

- 1. Simulation
 - · Briefly describe the main goal of this simulation.
 - Briefly describe the procedure (Section 3.3.2.1)
- 2. Implementation
 - Briefly describe the main goal of this experiment.
 - Briefly describe the experimental procedure (Section 3.3.2.2)

II. RESULTS

Do not interpret or analyze the data in this section. Just provide the results.

- 1. Response plot from step 9 in Section 3.3.2.1, Step response simulation with Lead Control
- 2. Response plot from step 9 in Section 3.3.2.2, Step response implementation with Lead Control
- 3. Provide data collected in this laboratory (from Table 3.2).

III. ANALYSIS

Provide details of your calculations (methods used) for analysis for each of the following:

III.1. Step Response with Lead Control

- 1. Step 7 in Section 3.3.2.1, Step response simulation with Lead Control
- 2. Step 10 in Section 3.3.2.2, Step response implementation with Lead Control

IV. CONCLUSIONS

Interpret your results to arrive at logical conclusions for the following:

- 1. Step 7 in Section 3.3.2.1, Step response simulation with Lead Control
- 2. Step 10 in Section 3.3.2.2, Step response implementation with Lead Control
- 3. Step 11 in Section 3.3.2.2, Step response implementation with Lead Control



3.5.3 Tips for Report Format

PROFESSIONAL APPEARANCE

- Has cover page with all necessary details (title, course, student name(s), etc.)
- Each of the required sections is completed (Procedure, Results, Analysis and Conclusions).
- · Typed.
- · All grammar/spelling correct.
- · Report layout is neat.
- · Does not exceed specified maximum page limit, if any.
- · Pages are numbered.
- Equations are consecutively numbered.
- Figures are numbered, axes have labels, each figure has a descriptive caption.
- Tables are numbered, they include labels, each table has a descriptive caption.
- Data are presented in a useful format (graphs, numerical, table, charts, diagrams).
- · No hand drawn sketches/diagrams.
- · References are cited using correct format.

3.6 Scoring Sheet for Pre-Lab Questions

Student Name:

Question ¹	A-1	A-2	A-3
1			
2			
3			
4			
5			
Total			

¹This scoring sheet is for the Pre-Lab questions in Section 3.2



3.7 Scoring Sheet for Lab Report (PI)

		FOR	MAT							
Item ¹	K-1	K-2	K-3	B-5	B-6	B-8	B-9	GS-1	GS-2	
I. PROCEDURE										
I.1. Step response with PI Control										
1										
2										
II. RESU	LTS									
1										
2										
3										
4										
III. ANAL										
III.1. Ste	p response	e with PI C	ontrol							
1										
2										
3										
IV. CON	IV. CONCLUSIONS									
1										
2										
3										
Total										

¹This scoring sheet corresponds to the report template in Section 3.5.1.

3.8 Scoring Sheet for Lab Report (LEAD)

Student Name:

			CONTENT			FOR	MAT
Item ¹	K-1	K-2	B-5	B-6	B-9	GS-1	GS-2
I. PROCED							
I.1. Step re	sponse with	Lead Control					
1							
2							
II. RESULT	S				,		
1							
2							
3							
III. ANALY							
III.1. Step r	esponse with	Lead Contro	ol				
1							
2							
IV. CONCL	USIONS						
1							
2							
3							
Total							

¹This scoring sheet corresponds to the report template in Section 3.5.2.



Appendix A

SRV02 QUARC INTEGRATION

In this section, we explain how to send command voltages to the Quanser®SRV02 and measure the position and speed of its load shaft in real-time using your computer.

System Requirements

Before you begin this laboratory make sure:

- QUARC® is installed on your PC, as described in [1].
- You have a QUARC® compatible data-acquisition (DAQ) card installed in your PC. For a listing of compliant DAQ cards, see [5].
- SRV02 and amplifier are connected to your DAQ board as described in [6].

Prerequisites

The user should be familiar with the following:

- · System hardware:
 - Data acquisition card (e.g. Q2-USB in [2])
 - Amplifier (e.g. VoltPAQ in [4]).
 - Main components of the SRV02, i.e. DC motor and sensors such as the potentiometer [6].
- Basics of Simulink[®].



A.1 Applying Voltage to SRV02 Motor

Here are the basic steps to apply a voltage to the SRV02 motor using QUARC®:

- 1. Make a Simulink® model that interacts with your installed data-acquisition device using blocks from the *QUARC Targets* library. This is explained in Section A.1.1.
- 2. From the Simulink® model, build real-time code as shown in Section A.1.2, and
- 3. Execute the code as explained in Section A.1.3.

A.1.1 Making the Simulink Model

In this section, we will make a Simulink® model as shown in Figure A.1 using QUARC® blocks to feed a sinusoidal voltage to the SRV02 dc motor. The blocks from the QUARC Targets library are used to interact with a data-acquisition board, e.g. Quanser Q2-USB or Q8-USB device.




Figure A.1: Simulink model used with QUARC to apply voltage to SRV02

Follow these steps to make the Simulink® diagram:

- 1. Load the Matlab® software.
- 2. Create a new Simulink®diagram. To do this, go to File | New | Model item in the menu bar.
- 3. Open the Simulink Library Browser window by clicking on the View | Library Browser item in the Simulink menu bar or clicking on the Simulink icon.
- 4. Expand the *QUARC Targets* item and go to the Data Acquisition | Generic | Configuration folder, as shown in Figure A.2.
- Click-and-drag the HIL Initialize block from the library window into the blank Simulink®model. This block is used to configure your data-acquisition device, e.g. the Quanser Q2-USB or Q8-USB hardware-in-the-loop (HIL) boards.
- 6. In the Library Browser, go to the Data Acquisition | Generic | Immediate I/O category. This contains various blocks used to interact with actuators and sensors.
- Click-and-drag the HIL Write Analog block from the library into the Simulink® diagram. This block is used to
 output a voltage from an Analog Output channel, i.e. digital-to-analog (D/A) channel, on the data-acquisition
 device.




Figure A.2: QUARC Targets in Simulink® Library Browser

- 8. Add the *Signal Generator* block, found in the Simulink® | Source folder, and the *Slider Gain* block, from the Simulink® | Math Operations category, into the Simulink® model. Connect the blocks as shown in A.1.
- 9. Double-click on the HIL Initialize block:
 - In the Board type field, select the board that is installed in your PC. For example, if you have a Quanser Q2-USB board then select q2_usb.
 - If more than one of the same board is installed (e.g. two Q2-USB devices), ensure the *Board number* field is set correctly, e.g. if two boards are used, then choose either 0 or 1.
- 10. Go to the Analog Output pane shown in Figure A.3. Make sure the Analog output channels field includes 0. This will ensure 0 V is output from Analog Output channel #0 when the QUARC controller is stopped. For more information, click on the Help button. Otherwise, click on the OK button and proceed.

Note: If you are using a NI DAQ device, make sure you enter [0] in the Analog Output channel box. The analog output channels for the NI boards are not selected by default.

- 11. Double-click on the *HIL Write Analog* block.
 - Make sure Board name is set to HIL-1 (i.e. points to the HIL Initialize block).
 - Set Channels to 0 (default setting). Recall that, as instructed in Reference [6], the dc motor is connected
 to Analog Output Channel #0 on the hardware-in-the-loop board. Therefore, Channels should be set to
 0.
 - Set Sample time to -1 (default setting). This implies that the sampling interval is inherited from the previous block.
- 12. Click on the OK button to save and close the HIL Write Analog block properties.
- 13. Save the Simulink®mode by selecting the File | Save item in the menu bar or clicking on the Save icon.






Figure A.3: Configuring Analog Output channel on DAQ device

A.1.2 Compiling the Model

The Simulink®model we made in Section A.1 can now be used by QUARC to generate code. When you execute this code, a voltage is sent to the SRV02.

Follow these steps to generate code from a Simulink® diagram:

- 1. In the Simulink® diagram made in Section A.1, go to the QUARC | Set default options item to set the correct Real-Time Workshop parameters and setup the Simulink® model for external use (as opposed to the simulation mode).
- To view the compiler options shown in Figure A.4, go to QUARC | Options in the Simulink® model tool bar.
- 3. Real-Time Workshop pane:
 - System target file is set to Target Language Compiler file quarc_windows.tlc.
 - Make command is set to make_rtw and the Template makefile is set to quarc_default_tmf file.
- Solver pane:
 - Stop time is set to inf in order for the code to be executed continuously until it is stopped manually by the user. Alternatively, the Stop time parameter can be set to the desired duration (code will cease executing when the stop time value is reached).
 - *Type* parameter is set to Fixed-step. When compiling real-time code, the solver must be fixed-step as opposed to variable step which can be used in simulations.
 - Solver is set to discrete. There are no continuous blocks inside the designed Simulink® model, therefore having a discrete solver is fine. However, if an Integrator block or another continuous system were be added, then the Solver field would have to be changed to an integration method such as ode1 (Euler).
 - Fixed-step size field sets the sampling interval, or sampling time, of the controller. By default this is set to 0.002 seconds, which is a sampling rate of 500 Hz.




Figure A.4: Default QUARC solver settings

- 5. Click on the OK button to close the Configuration Parameters window.
- 6. Select the QUARC | Build item. Various lines in the Matlab® Command Window should be displayed as the model is being compiled.
- 7. Once done compiling, a QUARC Windows executable file along with a folder containing various ``C" and Matlab[®] files are generated. Note that once the executable is created, the folder is no longer needed. If you like, you can remove the executable and associated code folder may be removed from the current directory by clicking on QUARC | Clean item.

See [5] for more information about configuring QUARC®.

A.1.3 Running QUARC Code

Once the Simulink® model has been compiled, the code can be executed and the voltage set in the Simulink® model can be sent to the SRV02 motor. Here are the steps to follow:

- 1. Power ON your power amplifier (e.g. Quanser VoltPAQ).
- 2. To begin executing the code, click on the QUARC | Start item in the Simulink® model. The SRV02 external gears on the SRV02 should begin rotating back-and-forth. This command actually does two things: it connects to the target and then executes the code. Alternatively, users may decide to go through these steps individually:
 - **Option 1:** In the Simulink® model tool bar, click on the *Connect to target* icon and then click on the *Run* icon. These buttons are shown in Figure A.5.
 - **Option 2:** Select the Simulation | Connect to target item from the menu bar and the select Simulation | Start Real-Time Code item.
- 3. Double-click on the Signal Generator block to open its parameter window.
- 4. Set the *Frequency* field to 0.5 Hz and click on the OK button. Notice how the parameter change effects the SRV02 immediately: the gears on the SRV02 begin to switch back-and-forth slowly.





Figure A.5: Simulink® model toolbar: connect to target and compilation

- 5. Vary the value of the Slider Gain block between 0 and 2. Examine how the angular rate of the SRV02 gears change proportionally with the amplitude of the sine wave.
- 6. Select the QUARC | Stop item to stop the code execution (or click on the Stop button in the Simulink® model tool bar).
- 7. Power OFF the amplifier if no more experiments will be run in this session.

A.2 Reading Position using Potentiometer

In this section, the Simulink® model previously designed in Section A.1 is modified to obtain readings from the potentiometer sensor.

A.2.1 Reading the Potentiometer Voltage

Follow the procedure below to design the Simulink® diagram as shown in Figure A.6 to read the potentiometer voltage.




Figure A.6: Simulink® model used with QUARC to read potentiometer

1. From the Generic | Timebases category in the Simulink® Library Browser, click-and-drag the *HIL Read Analog Timebase* block into the Simulink® diagram created previously in Section A.1. This block will be used to read a voltage from an Analog Input channel, i.e. analog-to-digital (A/D), on the data-acquisition device.

Note: Using a *Timebase* type block causes the running model to be triggered by the hardware timer on the data-acquisition board as opposed to the system clock. This increases performance of the controller by reducing jitter and allowing for greater sampling rates. If you want to use system clock instead (some DAQ cards do not support hardware-based timing, see [5] for details), then use blocks from the *Immediate I/O* category instead.

- 2. Recall that, as instructed in [6], the potentiometer is connected to Analog Input #0 on the DAQ board. Therefore, the default setting of 0 in the block is fine.
- 3. Add a Scope block from the Simulink[®] | Sinks folder in the Library Browser and connect it to the output of the *HIL Read Analog Timebase* block, as shown in Figure A.6.
- 4. Set the Frequency parameter in the Signal Generator block to 1.0 Hz and the Slider Gain block to 1.
- 5. Double-click on the Scope block to open the scope.
- 6. Save the Simulink®model (if you want to save the model as a different file, go to Save As).
- 7. Power ON the power amplifier.
- 8. Go to QUARC | Build to compile the code.
- Click on QUARC | Start to execute the code. As the SRV02 rotates back-and-forth, the Scope should display
 the potentiometer readings similar to Figure A.7. Notice that the readings shown are the voltage output of the
 potentiometer and not an angular measurement in degrees or radians.






Figure A.7: Reading raw voltage from the SRV02 potentiometer

Note: If the SRV02 gears are rotating but the scope is not plotting any data, then you must re-configure the RTW Signal & Triggering properties inside the Simulink® diagram. See the Signal Triggering section under QUARC Basics in [5] for more information.

10. Vary the sine wave frequency between 0.1 and 2 Hz and the Slider Gain value between 0 and 2. Notice how the controller is updated in real-time and the measurement in the scope changes with the new parameters.

Note: The potentiometer has an electrical range of 352 degrees across \pm 5 V [6]. As a result, the potentiometer outputs a discontinous voltage signal as seen in Figure A.8. Then, a disadvantage is that you cannot surpass the \pm 180 degree range when controlling the position or take the derivative of this sensor to control velocity.




Figure A.8: Potentiometer reading when encountering its discontinuity

11. Stop the code by clicking on QUARC | Stop.

A.2.2 Measuring Position

The Simulink® model will now be modified to read the *load angle* from the potentiometer and the voltage commanded to the motor as shown in Figure A.9.




Figure A.9: Simulink®model used with QUARC to send voltage to the SRV02 and read its load shaft angle using potentiometer.

Modify the Simulink® diagram built in the previous section following these steps:

- 1. Label the Scope block that is presently connected to the *HIL Read Analog Timebase* block to *theta_I (deg)*. This will display the angular measurement of the load gear in degrees.
- 2. Add a Scope block from the Simulink[®] | Sinks folder in the Library Browser and connect it to the output of the Slider Gain block, as shown in Figure A.9, above. Label the Scope block *Vm (V)* which stands for the input motor voltage.
- 3. From the Simulink® | Math Operations category in the Library Browser, add two Gain blocks into the Simulink® model.
- 4. Connect the gain blocks as illustrated in Figure A.9.
 - One gain block between the Amplifier Pre-Compensation and HIL Write Analog blocks and label it Motor Calibration (V/V).
 - Another gain block between the HIL Read Analog Timebase and theta_I Scope blocks and denote it Potentiometer Calibration (deg/V).
- 5. Re-compile the Simulink®model, i.e. click on QUARC | Build.
- 6. Click on QUARC | Start to run the code.
- 7. Open the Vm (V) and theta_I (deg) scopes.
- 8. In the Signal Generator, set the *Frequency* parameter to 0.25 Hz.
- 9. Set the Slider Gain block to 1.
- 10. Currently when the voltage goes positive the load gear rotates in the clockwise direction. However, the desired convention is for the load gear to rotate in the counter-clockwise direction when the voltage goes positive. Thus, set the *Motor Calibration (V/V)* block to -1.
- 11. As described in [6], the potentiometer outputs between \pm 5 V when it rotated 352 degrees. Enter the value 352/10 in the *Potentiometer Calibration (deg/V)*block.
- 12. In the theta_I (deg) scope, click on the Autoscale icon so the y-axis range is increased and the full signal can be viewed.
- 13. Set the Slider Gain block to 0.
- 14. Rotate the load gear manually and examine the corresponding response in the *theta_I* (*deg*) scope. Confirm that, indeed, the correct measurement is being taken.
- 15. Position the load gear such that 0 is read in the theta_I (deg) scope .



- 16. Set the Slider Gain block to 1.
- 17. Examine the relationship between the input voltage and load position. When the input voltage increases in the positive direction, the potentiometer angle decreases. Add a negative sign to the *Potentiometer Calibration* (deg/V) block so the entered value becomes -352/10. Now, the angular position of the load gear, displayed in the theta_I (deg) scope, reads increasingly positive when the commanded motor input voltage, i.e. signal in the Vm (V) scope, is positive.

Note: The theoretical model assumes that the velocity increases when the voltage is positive. The feedback control design is based on the model. Therefore, it is imperative that the actual system follows the same conventions as the model that will be developed.




Figure A.10: Sinusoidal input voltage.




Figure A.11: Load gear position reading using potentiometer.

- 18. Select the QUARC | Stop item to stop the code from running.
- 19. Power OFF the amplifier if no more experiments will be run in this session.

A.3 Measuring Speed using Tachometer

In this section, we will modify the Simulink® diagram designed in Section A.2 to include the readings from the tachometer.

Before continuing, please ensure that the SRV02 unit being used has a tachometer, i.e. SRV02-T option.




Figure A.12: Simulink® model used with QUARC to send voltage to SRV02 and read the potentiometer and tachometer sensors.

Using the Simulink® diagram built in Section A.2, go through this procedure to add the tachometer functionality:

- 1. Double-click on the HIL Read Analog Timebase block to open its properties.
- 2. As detailed in [6], the tachometer is connected to Analog Input #1 on the hardware-in-the-loop board. To add a channel, set the *Analog channels* field to [0,1] and click on the OK button.
- Add a Scope block and a Gain block from Library Browser into the Simulink®model.
- Connect the Scope and Gain blocks as depicted in Figure A.12, above.
 - Connect the Gain block to the output of Channel #1 from the *HIL Read Analog Timebase* block and label it *Tachometer Calibration (krpm/V)*.
 - Connect the output of this gain block to the input of the Scope block and label the scope w_l (rpm). The speed of the load gear is denoted by the ω_l . This scope will display the measured speed of the load gear in thousand revolutions per minute.
- 5. Set the Signal Generator Frequency parameter to 1.0 Hz and the Slider Gain block to 1.
- 6. Open the Vm (V) and the w_I (krpm) scopes.
- 7. Power ON the amplifier.
- 8. Go to QUARC | Build to compile the code.
- Click on QUARC | Start to execute the code. As the SRV02 rotates back-and-forth, the w_I (rpm/V) scope should display the tachometer readings. Since the Tachometer Calibration (krpm/V) gain has not been configured yet, the scope is displaying the tachometer output voltage, which is proportional to the speed of the load shaft.



10. The back-emf constant of the tachometer sensor is 1.5 mV/rpm. However, the measurement is taken directly from the motor itself (see [6]). Thus, to read the velocity of the gear the tachometer calibration gain must be divided by the gear ratio. Enter 1 / 1.5 / 70 in the *Tachometer Calibration (krpm/V)* gain block when using the SRV02 in the high-gear configuration (or 1 / 1.5 / 14 if using the low-gear configuration).

Note: The measurement will be very small. Click on the *Autoscale* icon in the scope to zoom up on the signal. Alternatively, the y-range of the scope can be set manually. To do this, right-click on the y-axis, select Axes Properties from the drop-down menu, and set the desired y-range values.

11. Examine the relationship between the input voltage and load speed. When the input voltage increases in the positive direction, the tachometer velocity decreases. Similar to the potentiometer, the speed of the load shaft should go positive when the input voltage is positive. To fix this, add a negative sign to the *Tachometer Calibration (krpm/V)* block so the entered value becomes -1 / 1.5 / 70 (or -1 / 1.5 / 14 for low-gear). The input voltage and load velocity scopes should read as shown in Figure A.13 and Figure A.14.

Note: If you want the measurement to be in RPM instead of kRPM, enter -1000 / 1.5 / 70 gear (or -1000 / 1.5 / 14 for low-gear).




Figure A.13: Sinusoidal input voltage.




Figure A.14: High gear velocity reading using tachometer.

- 12. Select the QUARC | Stop item to stop the code from running.
- 13. Power OFF the amplifier if no more experiments will be run in this session.

A.4 Measuring Position using Encoder

The Simulink® diagram designed previously is modified to include an encoder measurement, as illustrated in Figure A.15 below.

Before continuing, please ensure that the SRV02 unit being used has an encoder, i.e. SRV02-E option.




Figure A.15: Simulink®model used with QUARC to send voltage to SRV02 and reads the potentiometer, tachometer, and encoder sensors.

Using the Simulink® model designed in either Section A.2 or A.3, follow this procedure to add encoder functionality:

- From the QUARC Targets | Data Acquisition | Generic | Immediate I/O category in the Library Browser, add a HIL Read Encoder block.
- 2. Recall that, as instructed in [6], the encoder is connected to Encoder Input #0 on the data acquisition board. The HIL Read Encoder block is already configured for to read channel 0 and the default encoder configurations in the HIL Initialize block are fine (but keep in mind that these can be changed).
- 3. Add a Gain block and a Scope block from the *Math Operations* and *Sinks* folders in the Library Browser, respectively, into the Simulink®model.
- 4. Connect the scope and gain blocks as depicted in Figure A.15.
 - Connect the HIL Read Timebase block output e0 to a Gain block and label it Encoder Calibration (deg/count).
 - Connect the output of this gain block to the input of the Scope block and label the scope enc: theta_I (deg). This scope will display the measured angular position of the load gear in degrees.
- 5. Set the Frequency parameter in the Signal Generator block to 1.0 Hz and the Slider Gain block to 1.
- 6. Open the Vm (V) and enc: theta_I (deg) scopes.
- 7. Save the Simulink® model (you may want to save the model as a different file).
- 8. Power ON the power amplifier.
- 9. Go to QUARC | Build to compile the code.



10. Click on QUARC | Start to execute the code. As the SRV02 rotates back-and-forth, the enc: theta_I (deg) should display the encoder readings. Since the Encoder Calibration (deg/count) gain has not been configured yet, the scope is displaying the number of counts from the encoder output, which is proportional to the position of the load shaft.

Note: The measurement will be very large. Click on the Autoscale icon in the scope to zoom out and view the entire signal. Alternatively, the y-range of the scope can be set manually. To do this, right-click on the y-axis, select Axes Properties from the drop-down menu, and set the desired y-range values.

- 11. As discussed in [6], the encoder outputs 4096 counts for every full revolution. To measure the load gear angle, set the *Encoder Calibration (deg/count)* gain block to 360 / 4096 degrees per count.
- 12. The measurement will be very small. Click on the *Autoscale* icon in the scope to zoom up on the signal or adjust the range of the y-axis manually. The input voltage and position scopes should appear similarly as shown in Figure A.16 and Figure A.17. Note that no further calibration is needed since the encoder position increases when the input voltage goes positive.




Figure A.16: Sinusoidal input voltage.




Figure A.17: Position reading using encoder.

- 13. Select the QUARC | Stop item to stop the code from running.
- 14. Power OFF the amplifier if no more experiments will be run in this session.

A.5 Saving Data

The scopes in the Simulink®model can be configured to save variables in the Matlab®workspace. For instance, to configure the load gear position scope *theta_I* (*deg*) in the Simulink®model from Section A.2 perform the following:

- 1. Open the theta I (deg) scope.
- 2. Click on Parameters icon and select the Data History tab, as shown in Figure A.18.
 - Select the Save data to workspace check box.
 - Set the Variable name field to a desired variable, e.g. theta 1.
 - · Set Format to Array.




Figure A.18: Adjusting scope parameters to save data

Note: By default, the Limit data points to last box is set to 5000. This means that only the last 5000 points of data will be saved in the variable. Thus, given that the controller runs at 500 Hz, this implies that the last 10 seconds of data shown in the *theta I (deg)* scope will be captured.

- 3. Click on the OK button.
- 4. Save the Simulink® model.
- 5. Select QUARC | Build to rebuild the model.
- 6. Click on QUARC | Run.
- 7. Run the controller for a few seconds and stop QUARC.
- 8. When the controller is stopped, the variable *theta_I* is saved to the workspace. The variable is a two-dimensional array with a maximum of 5000 elements. The first vector is the running time and the second vector is the position of the load gear. You can plot the data into a Matlab figure using a script like:

```
t = theta_l(:,1);
th_l = theta_l(:,2);
plot(t,th_l,'r-');
```

You can then add Matlab®commands such as *xlabel*, *ylabel*, and *title* to desribe the data and units you are plotting.

Note: If the controller has not run for the full 10 seconds then, it will have t_f/T_s number of elements, where t_f is the duration of the controller and T_s is the sampling interval. For instance, if you ran QUARC for 4 seconds then there will be 4/0.002 = 2000 elements.






Figure A.19: Plotting saved data

9. Running the script generates a Matlab figure as shown in Figure A.19.

Note: Use the Matlab® command *ginput* to measure points directly from the Matlab figure.

There are many different ways to save data for offline analysis, e.g. saving data to a Matlab MAT file. Go to [5] in the QUARC Basics | Data Collection category for more information.

Appendix B

SRV02 INSTRUCTOR'S GUIDE

Every laboratory chapter in this manual is organized into four sections.

Background section provides all the necessary theoretical background for the experiments. Students should read this section first to prepare for the Pre-Lab questions and for the actual lab experiments.

Pre-Lab Questions section is not meant to be a comprehensive list of questions to examine understanding of the entire background material. Rather, it provides targetted questions for preliminary calculations that need to be done prior to the lab experiments.

Lab Experiments section provides step-by-step instructions to conduct the lab experiments and to record the collected data.

System Requirements section describes all the details of how to configure the hardware and software to conduct the experiments. It is assumed that the hardware and software configuration have been completed by the instructor or the teaching assistant *prior* to the lab sessions. However, if the instructor chooses to, the students can also configure the systems by following the instructions given in this section.

Assessment of ABET outcomes is incorporated into this manual as shown by indicators such as A-1, A-2. These indicators correspond to specific performance criteria for an outcome.



B.1 Pre-lab Questions and Lab Experiments

B.1.1 How to use the pre-lab questions

All or some of the questions in the Pre-Lab Questions sections can be assigned to students as homework. One possibility is to assign them as a homework one week prior to the actual lab session and ask the students to bring their assignment to the lab session. This would help them get ready for the lab session. You should encourage them to study the background section of the chapter prior to attempting the pre-lab questions. **Note** that solutions for some of the Pre-Lab questions are parameters needed for the experiments in the lab session.

Another possibility is to go over some of these questions either in class or in the lab session together with the students. This could generate an interactive learning opportunity for them prior to the lab.

Finally, it is possible to use some of the pre-lab questions in your mid-term or final exams. This would reinforce the concepts covered in the labs; connections between the abstract theory and the real hardware; and would give you an option to integrate some of the work done in the lab sessions into your exams.

B.1.2 How to use the laboratory experiments

In many universities, controls courses have two lectures and one lab session per week. This manual is organized under five laboratory chapters. However, each chapter contains several experiments. Therefore, one possible way to use this material is to conduct the individual experiments in your weekly lab sessions. For example, when you finish the topic of position control in your lectures, you can have your students conduct the step response experiment (Section 2.3.1) in one week and the ramp response experiments (Sections 2.3.2 and 2.3.3) in the following week.

Another possibility is to divide the class into teams and have each team conduct an experiment given in a chapter. For example, after you finish the topic of position control in your lectures, in the lab session of that week you can have all three experiments (step, ramp PV and ramp PIV) conducted by separate teams during the same lab session. Then, you can have them exchange their findings with the rest of the class by having each team present their experiment and results to the rest of the class. This approach would cover an entire laboratory chapter in one lab session.

B.2 Assessment for ABET Accreditation

In the United States, accreditation is a peer-review process. Educational institutions or programs volunteer to undergo this review periodically to determine if certain criteria are being met. The *Accreditation Board for Engineering and Technology*, ABET, is responsible for the specialized accreditation of educational programs in applied science, computing, engineering, and technology. ABET accreditation is assurance that a college or university program meets the quality standards established by the profession for which it prepares its students.

It is the responsibility of the program seeking accreditation to demonstrate clearly that the program meets a set of criteria. One of these criteria is the ``Criterion 3: Program Outcomes". Engineering programs must demonstrate that their students attain program outcomes (a) through (k). Much more information about this can be found in the ``Criteria for Engineering Accreditation" document ABET publishes on its website annually (http://www.abet.org).

For fulfillment of Criterion 3, a program must show that there is an assessment and evaluation process in place that periodically documents and demonstrates the degree to which the program outcomes are attained by their students. Most programs do this by mapping the outcomes (a) through (k) to the courses in the curriculum¹. Then, these outcomes are assessed in the courses. Finally, the assessment results are collected from the courses and compiled into program-level data to demonstrate the ``degree to which the program outcomes are attained by their students''.

If your course is part of a similar assessment effort in your program, you probably need to assess the following outcomes in your course:

- (A) An ability to apply knowledge of mathematics, science, and engineering,
- (B) An ability to design and conduct experiments, as well as to analyze and interpret data,
- (G) An ability to communicate effectively, and
- (K) An ability to use the techniques, skills, and modern engineering tools necessary for engineering practice.

These outcomes can be assessed in your course using various assessment tools, such as student surveys and assignments or questions targeting specific outcomes. To measure achievement of an outcome (such as outcome ``A" in the list above), typically some performance criteria are defined for the outcome. The *performance criteria* are a set of measurable statements to define each learning outcome. They identify the specific knowledge, skills, attitudes, and/or behavior students must demonstrate as indicators of achieving the outcome.

For the purpose of this laboratory curriculum, we defined a set of performance criteria for each outcome. These criteria are labeled as ``A-1, A-2, B-3, ..., K-3" as indicated in the rubrics in Section B.3 below. We also embedded these performance criteria in the curriculum shown by indicators such as A-1, A-2.

B.2.1 Assessment in your course

Assessment of outcomes is different than grading. A course grade (or a grade on an assignment or exam), is a composite indicator. For example, if a student receives "B" as a grade in your course, it is probably difficult to tell his/her level of achievement in outcome "A" versus "G". One of the purposes of assessment is to "measure" the level of achievement of these specific skills and knowledge so that improvements can be made in the future offerings of the course.

So, how should you introduce outcomes assessment into your course? The outcomes assessment approach described here can be applied to *each* pre-lab homework assignment and lab report of *each* student throughout the semester. This may or may not be feasible depending on your class size. In general, a *representative sample* of student work is assessed.

¹Disclaimer: The opionions expressed or the assessment techniques described here have not been endorsed by ABET in any way.



You can continue to give assignments/exams and grade them in the traditional way. To introduce assessment into your course, you can pick a representative sample of student work and "score" their work using the scoring sheets and rubrics given in this manual. This is a good way to start introducing assessment into your course.

Recall that for fulfillment of Criterion 3, a program must ``document" the assessment process. Programs collect sample student work in the academic year prior to the site visit by an ABET team. You can retain the sample homeworks, lab reports, their scoring sheets and the assessment workbook as ``evidence" for the ongoing assessment effort in your course. This collection can then be given to the assessment committee in your program to be incorporated into the program-level evidence they will compile prior to the ABET site visit.

B.2.2 How to score the pre-lab questions

If you choose to assign the pre-lab questions as homework, then the outcome targetted by these questions can be assessed using the student work. The pre-lab questions require students to ``apply" their math and engineering science knowledge through calculations and problem solving strategies. Therefore, outcome ``A" was mapped to the pre-lab questions through its performance criteria.

If you assign the pre-lab questions as homework, you can ``score" the returned homeworks using the rubric for outcome ``A" given in Section B.3 and the scoring sheet provided for that pre-lab in that chapter. For example, if you assigned the pre-lab questions in Section 1.2, then you would use the scoring sheet from Section 1.6.

To score homework of one student:

- Print the scoring sheet for the Pre-Lab Questions section you assigned as homework. One sheet is used per student.
- 2. Use the rubric for ``Outcome A" (Section B.3) to assign a score for each question. The rubric gives the description of ``levels of achievement" (4 = exemplary, 3 = proficient, 2 = developing and 1 = beginning/incomplete) for each criterion. As an example, below is a completed scoring sheet (from Section 1.6) after evaluating the homework of one student for the Modeling Chapter (Section 1.2).

Question	A-1	A-2	A-3
1	3	2	
2	4	2	
3		3	
4		3	
5		4	
6		3	
7		3	
8		3	
9	3	3	
10		3	4
11		3	4
Total	10	32	8

3. You can then enter the ``Total" for each performance criterion into the assessment workbook [3] as shown in Figure B.1.

B.2.3 How to score the lab reports

As mentioned earlier in Section B.1.2, there are various ways in which you can use the material provided in this manual. In any case, the outcomes targetted by the lab experiments can be assessed from the lab reports submitted by the students. These reports should follow the specific template for content given at the end of each laboratory chapter. This will provide a basis to assess the outcomes easily.




Figure B.1: Pre-Lab entry into the assessment workbook for one student.

The lab activities correspond to the ``applied" part of engineering. Therefore, outcomes ``B" and ``K" were mapped to the lab activities through their performance criteria. The lab reports themselves match outcome ``G" on effective communication skills.

If you choose to do an individual experiment in your weekly lab session, such as the step response in position control in Section 2.3.1, then you can ask the students to submit a lab report using the report template provided in Section 2.5.1 for this experiment. The template contains the main ``content" sections you would expect in a typical lab report (procedure, results, analysis, conclusions). Each section of the report template ties back to the activities in the lab and the corresponding assessment indicators. It also contains performance criteria related to the ``format" of the report.

You can score the lab reports using the rubric for outcome ``G" given in Section B.3 and the scoring sheet provided for the experiment in that chapter. **Note** that each lab report scoring sheet directly corresponds to the lab report content template for that experiment. For example, the scoring sheet for the modelling lab (Section 1.7) corresponds to the report template for content in Section 1.5.1. Also, note that the rubric for outcome ``G" already contains rubrics for outcomes ``B" and ``K" since these outcomes appear as an integral part of the report.

To score the lab report of one student:

- Print the scoring sheet for the Lab Report for the experiment they conducted in the lab. One sheet is used per student.
- 2. Use the "Content" rubric (Section B.3) to assign a score for each entry in the scoring sheet. The rubric gives the description of "levels of achievement" (4 = exemplary, 3 = proficient, 2 = developing and 1 = beginning/incomplete) for each criterion. As an example, below is a completed scoring sheet (from Section 1.7) after evaluating the lab report of one student for the Modeling Experiments (Section 1.6).
- 3. Use the ``Format" rubric (Section B.3) for the ``GS-1 and GS-2" criteria to score the formatting of the report on the same scoring sheet.



			CON	TENT			FOR	MAT		
Item ¹	K-1	K-2	B-5	B-6	B-7	B-9	GS-1	GS-2		
I. PROCI	EDURE									
I.1. Freq	uency Res	sponse Ex	periment							
1			4							
I.2. Bum	I.2. Bump Test Experiment									
1			4							
I.3. Mode	el Validatio	n Experim	nent							
1			4							
II. RESU	LTS									
1		4								
2		3								
3		3								
4				3						
III. ANAI	YSIS									
III.1. Fre	quency Re	esponse E	xperiment							
1					2					
2	3									
III.2. Bur	np Test Ex	periment								
1	3									
IV. CON	CLUSION	S								
1						3				
Total	6	10	12	3	2	3	4	3		

4. You can then enter the ``Total" for each performance criterion into the assessment workbook [3] as show in Figure B.2.

В	С	D	E	F	G	H	1	J
				Mod	elling			
		Lab Report Content						Format
ID	K-1	K-2	B-5	B-6	B-7	B-9	GS-1	GS-2
1	6	10	12	3	5	3	4	3
2	8	12	8	-	-	4	2	2
3	8	8	8	4	4	4	4	3
4	8	8	8	4	3	4	4	4
5	8	12	10	4	3	4	3	4
6	6	10	10	3	4	3	3	3
7	5	8	10	4	4	3	4	4
8	5	7	12	3	4	2	4	4
9	7	9	12	3	4	3	3	4
10	7	9	10	2	3	4	4	4
Total Possible	8	12	12	4	4	4	4	4
Scaled Average	3.40	3.10	3.33	3.40	3.80	3.40	3.50	3.50
Std. Dev.	1.23	1.70	1.63	0.70	0.63	0.70	0.71	0.71

Figure B.2: Lab report score entries in the workbook for one student.

B.2.4 Assessment of the outcomes for the course

As explained earlier, the performance criteria, such as A-1, A-2, A-3, are used to describe a set of measurable statements to define each learning outcome. Up to this point, we explained how to assess each performance criterion using the pre-labs, the lab reports and the scoring sheets.

A *single* score for each outcome can be computed to indicate the level of attainment of that outcome by the entire class. One approach is to simply average the scores for the performance criteria for that outcome. For example, in case of outcome ``A", you can use:

$$SCORE_A = \frac{SCORE_{A-1} + SCORE_{A-2} + SCORE_{A-3}}{3}$$
 (B.2.1)

Another possibility is to use a weighted-average where some of the performance criteria are considered to be more important than the others. In case of outcome ``A", you can use:

$$SCORE_{A} = \frac{w_1 \cdot SCORE_{A-1} + w_2 \cdot SCORE_{A-2} + w_3 \cdot SCORE_{A-3}}{w_1 + w_2 + w_3}$$
 (B.2.2)

where w_1, w_2 and w_3 are weights you can assign (on the 0 to 1 scale) for the performance criteria A-1, A-2 and A-3, respectively. The total of all weights should equal 1.

B.2.4.1 Course Score for outcome A

The assessment workbook [3] incorporates the simple average approach as shown in Figure B.3.

K	L	M	N	0	Р	Q	R
	В	eam and Ba	all		Overall		
ns	Pre-	Lab Quest	ions	Pre-	Lab Quest	ions	
A-3	A-1	A-2	A-3	A-1	A-2	A-3	
6	8	14	6	3.40	3.31	3.43	
8	7	12	8	3.00	3.08	3.86	
8	8	10	8	2.40	5.05	3.00	
6	6	8	6	3.20	3.38	2.29	
4	6	14	4	3.60	2.92	2.29	
8	7	16	8	3.60	4.00	3.43	
4	4	16	4	2.80	3.31	2.29	
7	5	16	7	2.20	4.00	3.71	
7	8	10	7	3.20	3.08	3.43	
8	6	12	8	3.00	3.00	3.57	
8	8	16	8	40	104	28	
3.30	3.25	3.20	3.30				
			Average	3.04	3.38	3.13	
			Std. Dev.	0.47	0.40	0.62	
			_		_	_	
		SC	ORE for A:	3.18			

Figure B.3: Computation of single score for outcome ``A" in the assessment workbook.

B.2.4.2 Course Scores for outcomes B, K and G

Similarly, the simple average approach is also used for outcomes B, K and G. Referring to the rubrics in Section B.3, it should be noted that outcome ``G" contains performance criteria for both ``B" and ``K" to assess the *content* of the report. In addition, there are two performance criteria, GS-1 and GS-2, to assess the *format* of the report. The scores for all of these performance criteria are averaged to arrive at the single score for outcome G. For example, the single score for outcome G in Figure B.4 for the *Modelling* experiment was calculated using:

$$SCORE_G = AVERAGE(S_{K-1} + S_{K-2} + S_{B-5} + S_{B-6} + S_{B-7} + S_{B-9} + S_{GS-1} + S_{GS-2})$$
 (B.2.3) where $S_{K-1} \cdots S_{GS-2}$ are the scaled average scores for K-1 through GS-2 in the workbook.

В	С	D	Е	F	G	Н	1	J	K
				Mod	elling				
			Lab Repo	rt Content			Report	Format	
ID	K-1	K-2	B-5	B-6	B-7	B-9	GS-1	GS-2	
1	6	10	12	3	5	3	4	3	
2	8	12	8	4	4	4	2	2	
3	8	8	8	4	4	4	4	3	
4	8	8	8	4	3	4	4	4	
5	8	12	10	4	3	4	3	4	
6	6	10	10	3	4	3	3	3	
7	5	8	10	4	4	3	4	4	
8	5	7	12	3	4	2	4	4	
9	7	9	12	3	4	3	3	4	
10	7	9	10	2	3	4	4	4	
Total Possible	88	12	12	4	4	4	4	4	
Scaled Average	3.40	3.10	3.33	3.40	3.80	3.40	3.50	3.50	
Std. Dev.	1.23	1.70	1.63	0.70	0.63	0.70	0.71	0.71	
SCORE for K:	3.25								
SCORE for B:	3.48								
SCORE for G:	3.43								
							1		

Figure B.4: Computation of single score for outcome "G" in the assessment workbook.



B.2.5 Assessment workbook

The assessment workbook [3] was developed using Microsoft Excel[®]. It is intented to give a general idea for how the assessment scores can be tracked and brought together. On purpose we designed the workbook to have no automatic features. You can use it as is or customize it in any way you like.

The assessment workbook has a tab for the Pre-Lab Questions and a tab for each of the laboratory chapters. Only 10 students were listed assuming you would use samples of student work and not the entire class. If you want to add more students, you can insert rows into the spreadsheets. **Note:** *If you insert new rows, make sure that the formula ranges in the cells with calculations are correct.*

At the bottom of each pre-lab section, there is a row entitled ``Total Possible". To count a pre-lab assignment in the calculation of the overall scores, you need to enter the correct totals here. For example, to count the Pre-Lab for modeling, you need to enter 12, 44 and 8 (Figure B.1). If you want to exclude an assignment from the overall calculation, enter ``0" as shown in Figure B.5. Of course, if you are excluding a pre-lab, then do not enter any scores for the students under those columns.

K	L	M	N	0	Р	Q		
	В	Beam and Ball			Overall			
ns	Pre-	Lab Quest	ions	Pre-Lab Questions				
A-3	A-1	A-2	A-3	A-1	A-2	A-3		
6				3.25	3.27	3.60		
8				2.88	3.09	3.80		
8				2.00	3.91	2.60		
6				3.25	3.64	2.00		
4				3.75	2.82	2.40		
8				3.63	4.00	3.20		
4				3.00	3.18	2.40		
7				2.13	4.00	3.80		
7				3.00	3.18	3.40		
8				3.00	3.00	3.40		
8 (0	0	0	32	88	20		
3.30								
			Average	2.99	3.41	3.06		
			Std. Dev.	0.56	0.44	0.65		
		SC	ORE for A:	3.15				

Figure B.5: Enter ``0" to exclude or ``correct totals" to include a Pre-Lab assignment in the calculation of the overall scores.

B.3 Rubrics

	Code	Perf. Criteria	4 Exemplary	3 Proficient	2 Developing	1 Beginning or incomplete
Apply math, science and engineering	A-1	Has strategies to solve the problem	Uses a sophisticated strategy. Employs refined and complex reasoning to arrive at the solution.	Uses an appropriate strategy for solution. Content knowledge is used correctly.	Has a strategy for solution but content knowledge has some conceptual errors.	Uses a wrong strategy or there is no evidence of a strategy. Content knowledge has many errors.
	A-2	Performs calculations	Arrived at correct answer. Calculations are complete. Precise math language, symbolic notation, graphs diagrams, etc. are used.	Arrived at correct answer with correct calculations.	Arrived at correct answer. Calculations are mostly correct but there are some minor errors.	No answer or arrived at wrong answer. Calculations are mostly or completely wrong.
	A-3	Explains results	Explains the result in the context of the completed calculations by providing complex reasoning and interpretations. Clear logical conclusions are drawn.	Explains the result in the context of the completed calculations. Logical conclusions are drawn.	Some explanation of the result is provided but it does not demonstrate logical reasoning.	There are no explanations of the result or an attempt was made to provide an explanation but it is incomplete or wrong.

Table B.1: **OUTCOME A**: An ability to apply knowledge of mathematics, science, and engineering



	Code	Perf. Criteria	4 Exemplary	3 Proficient	2 Developing	1 Beginning or incomplete
	B-1	Identifies hy- pothesis to test	Framed a testable question correctly and explained the anticipated cause-and-effect expectation leading to the question	Framed a testable question correctly	Framed a question that may or may not be testable	Incomplete or no testable question
Design	B-2	Identifies inde- pendent and dependent variables	All variables are identified correctly, explanations about their relations are provided	All variables are identified correctly	Most variables are identified correctly	None or only a few variables are identified correctly
	B-3	Lists assumptions made	All assumptions and their rea- sons are clearly listed	All assumptions are listed	Assumptions are listed but some are missing	No assumptions listed or most of them are missing
	B-4	Formulates experimental plan to investigate a phenomenon	Developed a sophisticated experimental procedure complete with details of every step to test the hypothesis	Developed cor- rect experimen- tal procedure to test the hypoth- esis	Attempted but could not completely develop an experimental procedure to test the hypothesis	Could not develop an accurate experimental procedure

(Continued on the next page)

	Code	Perf. Criteria	4 Exemplary	3 Proficient	2 Developing	1 Beginning or incomplete
Conduct	B-5	Follows ex- perimental procedures	Follows experimental procedures carefully with great attention to detail. Makes precise measurements	Follows experimental procedures leading to correct measurements	Follows experimental procedures with some mistakes leading to mostly correct measurements	Follows experimental procedures with many mistakes leading to mostly wrong measurements
	B-6	Documents data collected	Systematically documents all data in an exemplary way and by using accurate units	Documents all data and with accurate units.	Documents data with some mistakes in the units or some data missing. Data organi- zation needs improvement	No data are documented or there are major mistakes in the units
	B-7	Uses appropriate methods to analyze data	Excellent, in- depth analysis of the data us- ing appropriate methods	Appropriate level of analysis of data using correct methods	Some data analysis but incomplete	No analysis or attempts to analyze with wrong methods
Analyze	B-8	Accounts for experimental uncertainties	Is aware of all potential experimental errors and can fully account for them with suggestions to improve them	Is aware of all potential experi- mental errors	Is aware of some of the potential experi- mental errors	Is unaware of any experimental errors
Interpret	B-9	Interprets results with respect to the original hypothesis	Provides clear, in-depth, accurate explanations, including trends, and arrives at logical conclusions based on data and results	Provides accurate explanations and logical conclusions based on data and results	Provides expla- nations and con- clusions but with some errors	No explanation or conclusions are provided or they are wrong

Table B.2: **OUTCOME B**: An ability to design and conduct experiments, as well as to analyze and interpret data.



	Code	Perf. Crite-	4 Exemplary	3 Proficient	2 Developing	1 Beginning or incomplete
lure	B-1	Identifies hypothesis to test	Framed a testable question correctly and explained the anticipated cause-and-effect expectation leading to the question	Framed a testable question correctly	Framed a question that may or may not be testable	Incomplete or no testable question
	B-2	Identifies indepen- dent and dependent variables	All variables are identified correctly, explanations about their relations are provided	All variables are identified correctly	Most variables are identified correctly	None or only a few variables are identified correctly
Procedure	B-3	Lists as- sumptions made	All assumptions and their reasons are clearly listed	All assumptions are listed	Assumptions are listed but some are missing	No assumptions listed or most of them are missing
-	B-4	Formulates experimen- tal plan to investigate a phe- nomenon	Developed a sophisticated experimental procedure complete with details of every step to test the hypothesis	Developed correct experimental pro- cedure to test the hypothesis	Attempted but could not completely develop an experimental procedure to test the hypothesis Could not develop an accurate experimental procedure	
	B-5	Follows ex- perimental procedures	Follows experimental procedures carefully with great attention to detail. Makes precise measurements	Follows experimental procedures leading to correct measurements	Follows experimental procedures with some mistakes leading to mostly correct measurements	Follows experimental procedures with many mistakes leading to mostly wrong measurements

(Continued on the next page)

	Code	Perf. Crite-	4 Exemplary	3 Proficient	2 Developing	1 Beginning or incomplete
	B-6	Documents data col- lected	Systematically doc- uments all data in an exemplary way and by using accu- rate units	Documents all data and with accurate units.	Documents data with some mistakes in the units or some data missing. Data organization needs improvement	No data are documented or there are major mistakes in the units
Results	K-2	Uses soft- ware tools to present data in use- ful format (graphs, numeri- cal, table, charts, diagrams)	Can use various software tools and their advanced features correctly for data presentation	Can use software tools correctly for data presentation	Can use software tools for data presentation with only a few mistakes	Cannot use soft- ware tools for data presentation or attempts to use them but with many mistakes (missing labels, etc.)
	K-3	Uses soft- ware tools to simulate physical systems	Can use software tools and their advanced features correctly for simulation	Can use software tools correctly for simulation	Can use software tools for simulation with only a few mistakes	Cannot use software tools for simulation or attempts to use them but with many mistakes
	B-7	Uses appropriate methods to analyze data	Excellent, in-depth analysis of the data using appropriate methods	Appropriate level of analysis of data using correct methods	Some data analysis but incomplete	No analysis or at- tempts to analyze with wrong methods
Analysis	B-8	Accounts for exper- imental uncertain- ties	Is aware of all potential experimental errors and can fully account for them with suggestions to improve them	Is aware of all poten- tial experimental er- rors	Is aware of some of the potential experi- mental errors	Is unaware of any experimental errors
	K-1	Uses soft- ware tools for analysis	Can use various software tools and their advanced features correctly for analysis	Can use software tools correctly for analysis	Can use software tools for analysis with only a few mistakes	Cannot use software tools for analysis or attempts to use them but with many mistakes
Conclusions	B-9	Interprets results with respect to the original hypothesis	Provides clear, in-depth, accurate explanations, including trends, and arrives at logical conclusions based on data and results	Provides accurate explanations and logical conclusions based on data and results	Provides explanations and conclusions but with some errors	•

Table B.3: **OUTCOME G**: Ability to communicate effectively. (for Lab Report - **CONTENT**)



Code	Perf. Criteria	4 Exemplary	3 Proficient	2 Developing	1 Beginning or incomplete
GS-1	Content presen- tation well or- ganized	 Each of the required sections is completed. If necessary, subsections are used All necessary background principles and information for the experiment are given All grammar/spelling correct References are cited 	Two of the conditions for the "ex-emplary" category were not met	Three of the conditions for the "exemplary" category were not met	Four or none of the conditions for the "exemplary" category were not met
GS-2	Profession appear- ance	 Has cover page with all necessary details (title, course, student name(s), etc.) Typed Report layout is neat Does not exceed specified maximum page limit Pages are numbered Equations are consecutively numbered Figures are numbered, axes have labels, each figure has a descriptive caption Tables are numbered, they include labels, each table has a descriptive caption No hand drawn sketches/diagrams References are cited using correct format 	Two of the conditions for the "ex-emplary" category were not met	Four of the conditions for the "ex-emplary" category were not met	Five or more of the conditions for the "exemplary" category were not met

Table B.4: **OUTCOME G**: Ability to communicate effectively. (for Lab Report - **FORMAT**)

	Code	Perf. Criteria	4 Exemplary	3 Proficient	2 Developing	1 Beginning or incomplete
Use techniques, skills and modern eng. tools	K-1	Uses software tools for analysis	Can use various software tools and their advanced features correctly for analysis	Can use software tools correctly for analysis	Can use software tools for analysis with only a few mistakes	Cannot use software tools for analysis or attempts to use them but with many mistakes
	K-2	Uses software tools to present data in useful format (graphs, numerical, table, charts, diagrams)	Can use various software tools and their advanced features correctly for data presentation	Can use software tools correctly for data presentation	Can use software tools for data presentation with only a few mistakes	Cannot use software tools for data presentation or attempts to use them but with many mistakes (missing labels, etc.)
	K-3	Uses software tools to simulate physical systems	Can use software tools and their advanced features correctly for simulation	Can use software tools correctly for simulation	Can use software tools for simulation with only a few mistakes	Cannot use software tools for simulation or attempts to use them but with many mistakes

Table B.5: **OUTCOME K**: An ability to use the techniques, skills, and modern engineering tools necessary for engineering practice



BIBLIOGRAPHY

- [1] Quanser Inc. QUARC Installation Guide, 2009.
- [2] Quanser Inc. Q2-USB User's Manual, 2010.
- [3] Quanser Inc. SRV02 Assessment Workbook (Microsoft Excel file), 2010.
- [4] Quanser Inc. VoltPAQ User's Manual, 2010.
- [5] Quanser Inc. QUARC User Manual, 2011.
- [6] Quanser Inc. SRV02 User Manual, 2011.

Ten modules to teach controls from the basic to advanced level



With the SRVO2 Base Unit, you can select from 10 add-on modules to create experiments of varying complexity across a wide range of topics, disciplines and courses. All of the experiments/workstations are compatible with LabVIEW™ and MATLAB®/Simulink®.

To request a demonstration or a quote, please email info@quanser.com.

©2011 Quanser Inc. All rights reserved. LabVIEW™ is a trademark of National Instruments. MATLAB® and Simulink® are registered trademarks of The MathWorks, Inc.

