

1. List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

No.	Issue	Possible Solution
1	Keyboard or mouse is not detected by the laptop	Unplug and reconnect the USB device or try a different USB port.
2	Keyboard keys are not responding	Clean the keyboard and restart the laptop. Check if the drivers are installed properly.
3	Mouse cursor is not moving	Reconnect the mouse, replace the battery (if wireless), or update the mouse driver.
4	USB device disconnects frequently	Check for a loose connection, use another USB port, or disable USB power-saving settings.
5	Keyboard or mouse works slowly (lagging)	Update device drivers and remove unnecessary background applications.

2. Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Troubleshooting Flow: Bluetooth Headphones Not Connecting to a Phone

Step 1: Check Headphone Power

Ensure the Bluetooth headphones are turned ON. Check the LED indicator light. If the battery is low, charge the headphones for at least 15–30 minutes.

Step 2: Check Bluetooth on the Phone

- Open **Settings** → **Bluetooth**. Verify that Bluetooth is enabled. If Bluetooth is OFF, turn it ON.

Step 3: Verify Pairing Mode

- Put the headphones into **pairing mode** (usually by holding the power button for 5–10 seconds). Look for a blinking blue or blue/red LED indicator, which shows the device is ready to pair.

Step 4: Search for the Device

- On the phone, tap **Scan** or **Search for Devices**. Wait for the headphone name to appear in the list of available devices.

Step 5: Connect the Device

- Tap the headphone name. If prompted, confirm the pairing request or enter the PIN (usually **0000** or **1234**).

Step 6: Check Existing Connections

- If the headphones were previously connected to another device (laptop, tablet, etc.), disconnect them from that device. Try connecting again to the phone.

Step 7: Forget and Re-Pair

- Go to **Settings** → **Bluetooth** → **Paired Devices**. Select the headphones and tap **Forget Device**. Restart the pairing process from Step 3.

Step 8: Restart Devices

- Turn OFF the headphones. Restart the phone. Turn the headphones ON and try connecting again.

Step 9: Check Bluetooth Range

- Keep the headphones within 1–2 meters of the phone. Remove obstacles that may interfere with the signal.

Step 10: Reset the Headphones

- Perform a factory reset according to the headphone manual. Put them back into pairing mode and reconnect.

Step 11: Test with Another Device

- Try connecting the headphones to another phone or laptop. If they connect successfully, the issue may be with the original phone.

Step 12: Update Software

- Check for phone software updates. Install any available Bluetooth or system updates.

3. A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem. Hint: Consider device manager, privacy settings, and app permissions.

No.	Check	Action to Take
1	Check USB Connection	Unplug the webcam and reconnect it to a different USB port. Make sure the cable is securely connected.
2	Verify Webcam in Device Manager	Open Device Manager → Cameras/Imaging Devices and check if the webcam appears. If there is a warning icon, update or reinstall the driver.
3	Check Windows Privacy Settings	Go to Settings → Privacy → Camera and make sure Camera Access is turned ON for the device.
4	Check App Permissions	Under Settings → Privacy → Camera , ensure that Allow desktop apps to access your camera is enabled and Zoom has permission to use the camera.
5	Verify Camera Selection in Zoom	Open Zoom → Settings → Video and select the correct webcam from the camera drop-down menu.
6	Update Drivers and Restart	Update the webcam driver through Device Manager, restart the computer, and try the Zoom call again.

4.You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

Using Windows Troubleshooter to Fix a Printer Showing "Offline"

Step-by-Step Procedure

1. **Open Windows Settings**
 - Press **Windows + I** to open Settings.
 - Click **Update & Security**.
 - Select **Troubleshoot** from the left menu.
2. **Open Additional Troubleshooters**
 - Click **Additional troubleshooters**.
 - Select **Printer**.
3. **Run the Troubleshooter**
 - Click **Run the troubleshooter**.
 - Windows will begin scanning for printer-related problems.
4. **Select the Printer**
 - If multiple printers are installed, choose the printer showing **Offline** status.
 - Click **Next**.
5. **Allow Windows to Diagnose**
 - The tool checks:
 - Printer connection status
 - Printer drivers

- Print Spooler service
- Network connectivity (for network printers)
- Default printer settings

6. **Apply Recommended Fixes**

- If Windows finds an issue, click **Apply this fix**.
- Follow any additional instructions displayed on the screen.

7. **Test the Printer**

- After troubleshooting is complete, print a test page to confirm the printer is online and working properly.