

XEBEX Rower Maintenance Manual


After Every Use

1) Cleaning the monorail

Items Needed: Cloth or towel, avoid abrasive cleaning pads as they may scratch monorail

Water, soap or any glass cleaner or disinfectant wipe

Wipe down the monorail to keep sweat off the rail and to keep clean. Keep any protruding dirt or sand off the rail as they can get caught in the wheels of the seat rollers.




Every 100 Hours Usage


2) Chain Lubrication

Items Needed: 3-in-1 oil, cloth or towel.

Apply 3-in-1 oil to paper towel or non-abrasive cloth. Pull the chain to extend to the max length and rub towel along the way. Do not leave excess oil on the chain. Repeat if necessary.



Please unscrew 2 x A22 Tapping Screw to disassemble A23 Sensor cover from rower, then add lubrication on Chain.



3) Tighten all screws/bolts from assembly

Items Needed: Allen key and wrench



Every 300 Hours Usage

4) Inspect Chain- Handle Connection for wear

Check the handle connection. If the connection point looks worn or elongated, please contact GETRXD for replacement parts.

