

Xebex Runner Maintenance Suggestions and How to Clear Console Message

Maintenance Recommendations

TASK	Daily	Monthly
Wipe down all surfaces with a mild soap solution and dry thoroughly.	X	
Inspect unit for noisy, damaged or loose components.	X	
Ensure the unit does not rock. If necessary, re-adjust the leveling feet.	X	
Inspect the entire unit for loose hardware, including the uprights, handrail, frame and plastic covers.		X
Lubricate the twelve running belt guide pulleys; one drop per pulley.		X
Move the treadmill and clean/vacuum dust, lint or debris found inside the belt and under the frame.		X

To clear Maintenance Reminder Message from Console:

- A. Press "Enter" and "START" buttons at the same time for 2 seconds, and the buzzer will sound
- B. When you see repair icon  , electronic scroll will show "clear service interval", from right to left and it will show "YES".
 - To remove the monthly service, please press "ENTER" when shows "YES".
 - To keep monthly service, please press "UP" or "DOWN" for switching to "NO" and press "ENTER".