

XEBEX ABVR-2L AIR BIKE
Maintenance Information

Service	Daily	Monthly	Quarterly	Annually
Clean/Dry Frame & Console	X			
Inspect Unit for Noise or loose components	X			
Ensure Unit is level-Adjust Stabilizer Feet	X			
Tighten Crank & Pedals		X		
Tighten Handlebars & Pegs		X		
Tighten Front / Rear stabilizer bolts		X		
Change Console Batteries			X	

-See detailed instructions below



1. **Dry and Clean the Main Frame and Console (Daily):**
2. **Pedal Check (Monthly):**

Tighten the pedals with a wrench. The right side pedals will tighten “righty tightly” (clockwise) and the left side pedal will tighten “lefty tightly” (counter-clockwise).



3. **Handlebar Assembly Check (Monthly):**

Check and tighten the handlebar / the bolt inside H2 Foot Triangle Tube for both sides.



XEBEX ABVR-2L AIR BIKE
Maintenance Information

4. Tightening front / rear stabilizer bolts

Check and tighten the front / rear stabilizer bolts.

