


AIR BIKE ELITE

Console Manual



Assembly Instructions / Owner's Manual

IMPORTANT:

READ ALL ASSEMBLY INSTRUCTIONS AND SAFETY PRECAUTIONS BEFORE USING THIS PRODUCT. REFERENCE ALL SAFETY GUIDELINES AND WARNING LABELS. RETAIN PRODUCT LITERATURE FOR FUTURE REFERENCE.

SAFETY:

PROPERLY WARM UP AND STRETCH BEFORE EXERCISING. IF YOU FEEL PAIN OR DIZZINESS AT ANY TIME WHILE EXERCISING, STOP IMMEDIATELY AND CONSULT YOUR PHYSICIAN.

ASSEMBLY PREPARATION

- To ensure ease of product assembly, please take time to verify the size and quantities of all required assembly hardware. Use the itemized parts listing and hardware chart for reference.
- The product assembly process has been documented in easy to follow steps. Please read all assembly instructions carefully. Take time to review the manual and familiarize yourself with the entire assembly process before proceeding.
- Assembly Tip: It is always helpful to pre-stage the items needed for each assembly step.
- Perform product assembly in a 4-ft. x 10-ft. flat area. Note: After assembly is completed, allow a minimal 2-3 feet of space on each side of rower for user access and dismounting.
- Do not dispose of any packaging materials until assembly of the product is completed.
- Assembly tools are included, but you may also use standard household tools to complete assembly of this product.

IMPORTANT PRECAUTIONS

WARNING: To reduce the risk of injury, please read the following precautions before assembling or using your new product.




- It is the responsibility of the owner to ensure that all users of this equipment are adequately informed of stated precautions.
- Read all instructions and enclosed literature carefully. Understand the assembly and operation before using the equipment.
- Use equipment on a flat level surface. Use adjustment levelers on the bottom of equipment to help stabilize unit.
- It's recommended to place an exercise mat beneath the equipment for added protection of floors or carpets.
- Keep children and pets away from equipment at all times.
- Inspect product on a frequent basis. Tighten loose assemblies or hardware as needed. Replace worn or damaged parts.
 - This equipment is intended for indoor use only. Use in non-recommended environment can lead to serious injury and will void all related warranties and liabilities.
- Recommended user weight should not exceed the maximum weight limit.
- Keep equipment clean and properly maintained.
- Observe and adhere to all warning labels posted on equipment.
- Properly warm up and stretch before starting any strength training or cardio exercise routine.
- If you feel pain or dizziness at any time while exercising, stop immediately and consult your physician.

SAFETY WARNING: Before starting an exercise program, consult your physician. This is especially important for individuals over the age of 35 or persons with pre-existing health problems. It's important to read all instructions carefully. We assume no responsibility for personal injury or consequential damages sustained by or through the use of this equipment. Additional terms and conditions are listed in the back of this manual or enclosed owner's manual.


Colors and specifications subject to change without notice.

NOTE: Before assembly please lay out ALL pieces accordingly to ensure you are not missing any items. PLEASE BE CAUTIOUS as some components may be sharp and can cause harm if not handled correctly. Always use safety measurements when assembling any piece of equipment or machinery.

Part List

A Main frame**B** Front stabilizer**C** Rear stabilizer**D** Swing Handle Bar**F** Console**G** Pedal**E** Console Tube**H** (H1) Console Tube Cover

(H2) AL Triangle Tube




(H3) Triangle Tube End Cap

(H4) Bolt
M10x20mm(H5) Bolt
M8x40mm

(H6) Sleeve

(H7) Flat Washer
10x20x1.5t(H8) Bolt
M10x100mm(H9) Tapping Screw
M4x15mm(H10) Bolt
M6x50mm(H11) M8 spring washer
for handlebars*Tool*

Customized Wrench



4m/m



5m/m



6m/m



8m/m





ASSEMBLE THE FRONT & REAR STABILISER

Step 1.
Loosen the two screws (H4) from the front and rear paper tube.
The paper tube is used for packaging purposes only and won't be needed again during/after the assembly.

Step 2.
Attach the front stabiliser (B) onto main frame (A) and secure it with screws (H4)

Step 3.
Attach the rear stabiliser (C) onto main frame (A) and secure it with screws (H4).





ASSEMBLE LEFT AND RIGHT SWING HANDLE BARS AND FOOT & SUPPORT

Step 1.

Attach right swing handle bar (D2) with main frame (A) with bolts (H5) and with spring washers (H11).

Step 2.

Insert the sleeve (H6) into the foot support (H2).

Then attach the foot support (H2) with main frame (A) with a washer (H7) and bolt (H8).

Step 3.

Attach the end cap (H3) to the foot support (H2) with screws (H9).

At

Repeat the same steps to assemble the left side swing handlebar and foot support.


Re

ASSEMBLE THE CONSOLE TUBE WITH MAIN FRAME

Step 1. Insert the console tube cover (H1) onto the main frame (A).

Step 2. Connect the sensor wire (E2) with sensor wire (A7).
The insert the console tube (E) into the main frame (A).


Step 3. Secure console (F1) onto console tube (E1) with the previously removed screws (F2).



ASSEMBLE THE PEDALS

Remove the bolt (A67). Attach the right pedal (G2) onto the right crank (A2-22) by screwing in clockwise and fasten it by bolt (A67).

Repeat for left pedal by screwing in counter-clockwise.



Part List

P/N	Description	Qty	P/N	Description	Qty
A1	Main Frame	1	A4-3	Magnet Set	1
A2-1	Sleeve	1	A4-4	Screw	22
A2-2	Bearing BR-6005zz	2	A4-5	Screw	2
A2-3	Belt Wheel	1	A4-6	Nut	3
A2-4	Axle	1	A4-7	Spring	1
A2-5	Bolt M6x20mm	1	A4-8	Nylong Nut	2
A2-6	Spring Pin M6x20mm	1	A4-9	Flat Washer	1
A2-7	Magnet	1	A4-10	Screw	2
A2-9	Bearing	1	A4-11	Bolt	2
A2-10	E Clip	1	A5	Belt	1
A2-11	Nut M25	2	A6	Tension Adjust Bar	1
A2-12	Left Crank	4	A7	Sensor	1
A2-13	Bolt M8x40mm	2	A8	Sensor Clip	1
A2-14L	Swing the Connecting Rod L	1	A9	Screw	1
A2-14R	Swing the Connecting Rod R	1	A10	Main Frame End Cap	1
A2-15	Bearing	2	A11	Left Chain Cover	1
A2-16	Spacer Washer	4	A12	Right Chain Cover	1
A2-17	Nut M10	2	A13	Sticker	1
A2-18L	Connecting Rod L	1	A14	Sticker	1
A2-18R	Connecting Rod R	1	A15	Sticker	1
A2-19	Bearing	4	A16	Sticker	1
A2-20	E Clip	2	A17	Sticker	2
			A18	Left Crank Cover	1
A2-22L	Crank L	1	A19	Right Crank Cover	1
A2-22R	Crank R	1	A20	Screw	4
A2-23	Bolt M8x40mm	2	A21	Chain Cover Screw M4x15mm	12
A3-1	Steel Fan Wheel	1	A22	Stainless Cover	1
A3-2	Pulley	1	A23	Tapping Screw M4x25mm	4
A3-3	Spring Washer M6	6	A24	Left Steel Line Cover	1
A3-4	Bolt M6x12	6	A25	Left Small Steel Line Cover	1
A3-5	Aluminum Plate	4	A26	Right Steel Line Cover	1
A3-6	Aluminum Pad Seat	4	A27	Right Small Steel Line Cover	1
A3-7	Tapping Screw M4x35mm	8	A28	Iron Net Cover	2
A3-8	Fan Wheel Axle	1	A29	Tapping Screw M4x15mm	4
A3-9	Bearing	1	A30	Flat Washer	8
A3-10	Washer	1	A31	Screw	8
A3-11	Clip	1	A32	Cover	1
A3-12	Bearing	2	A33	Bolt	4
A3-13	Nut M12	4	A36	Seat Post Cover	1
A3-14	Adjust Screw M8	2	A37	Seat Post Sleeve	1
A3-15	Fixing Holder	2	A38	Bolt	2
A3-16	Nylon Nut	2	A39	Sleeve ø10x43.2mm	1
A4-1	Base Board	1	A40	Fixing Grip	1
A4-2	Magnet Base	1	A41	Bushing	2

MCBIAR03

P/N	Description	Qty	P/N	Description	Qty
A42	Bolt M6x20mm	1	E1	Console Tube	1
A43	Block	2	E2	Console Tube	1
A44	Spring	1			
A45	Gasket	1	F1	Console	1
A46	Plate	1	F2	Screw M5x30mm	4
A47	Saddle Base	1			
A48	Nylon Nut M8	3	G1	Pedal (L)	1
A49	Spring Washer M8	3	G2	Pedal (R)	1
A50	Saddle Post	1			
A51	Bolt M6x12mm	1	H1	Console Tube Cover	1
A52	Saddle Sleeve	1	H2	Aluminum Triangle Tube	2
A53	Square End Cap	1	H3	Triangle Tube End Cap	2
A54	Bolt M6x25mm	1	H4	Bolt M10x20mm	8
A55	Steel Ball	1	H5	Bolt M8x40mm	4
A56	Tapping Screw M6x15mm	2	H6	Sleeve	2
A57	Nylon Nut M6	1	H7	Flat Washer 10x20x1.5t	2
A58	Saddle Adjust Bar	1	H8	Bolt M10x100mm	2
A59	Quick Release Axle	1	H9	Tapping Screw M4x15mm	6
A60	Threaded Rod	1	H10	Bolt M6x50mm	2
A61	Spring	1	H11	M8 Spring Washer for Handlebars	4
A62	Spacer Block	1			
A63	Spring	1			
A64	Sleeve Ø8x12.7mm	1			
A65	Saddle	1			
A66	Tapping Screw M5x15mm	3			
A67	Bolt M6x8mm	2			
B1	Front Stabiliser	1			
B2	End Cap	2			
B3	Wheel with Spacers	2			
B4	Bolt M8x40mm	2			
B5	Nut M8	2			
B6	Foot Pad	2			
B7	Tapping Screw M4x12mm	4			
C1	Rear Stabiliser	1			
C2	End Cap Ø101.6	2			
C3	Knob	2			
C4	Wing Nut M12	2			
D1	Swing Handlebar(L)	1			
D2	Swing Handlebar(R)	1			