


AIR CYCLE ELITE

Owner's Manual



Assembly Instructions / Owner's Manual

IMPORTANT:

READ ALL ASSEMBLY INSTRUCTIONS AND SAFETY PRECAUTIONS BEFORE USING THIS PRODUCT. REFERENCE ALL SAFETY GUIDELINES AND WARNING LABELS. RETAIN PRODUCT LITERATURE FOR FUTURE REFERENCE.

SAFETY:

PROPERLY WARM UP AND STRETCH BEFORE EXERCISING. IF YOU FEEL PAIN OR DIZZINESS AT ANY TIME WHILE EXERCISING, STOP IMMEDIATELY AND CONSULT YOUR PHYSICIAN.

Assembly Preparation

- To ensure ease of product assembly, please take time to verify the size and quantities of all required assembly hardware. Use the itemized parts listing and hardware chart for reference.
- The product assembly process has been documented in easy to follow steps. Please read all assembly instructions carefully. Take time to review the manual and familiarize yourself with the entire assembly process before proceeding.
- Assembly Tip: It is always helpful to pre-stage the items needed for each assembly step.
- Perform product assembly in a 4-ft. x 10-ft. flat area. Note: After assembly is completed, allow a minimal 2-3 feet of space on each side of rower for user access and dismounting.
- Do not dispose of any packaging materials until assembly of the product is completed.
- Assembly tools are included, but you may also use standard household tools to complete assembly of this product.

Important Precautions

WARNING: To reduce the risk of injury, please read the following precautions before assembling or using your new product.


1. It is the responsibility of the owner to ensure that all users of this equipment are adequately informed of stated precautions.
2. Read all instructions and enclosed literature carefully. Understand the assembly and operation before using the equipment.
3. Use equipment on a flat level surface. Use adjustment levelers on the bottom of equipment to help stabilize unit.
4. It's recommended to place an exercise mat beneath the equipment for added protection of floors or carpets.
5. Keep children and pets away from equipment at all times.
6. Inspect product on a frequent basis. Tighten loose assemblies or hardware as needed. Replace worn or damaged parts.
7. This equipment is intended for indoor use only. Use in non-recommended environment can lead to serious injury and will void all related warranties and liabilities.
8. Recommended user weight should not exceed the maximum weight limit.
9. Keep equipment clean and properly maintained.
10. Observe and adhere to all warning labels posted on equipment.
11. Properly warm up and stretch before starting any strength training or cardio exercise routine.
12. If you feel pain or dizziness at any time while exercising, stop immediately and consult your physician.

SAFETY WARNING: Before starting an exercise program, consult your physician. This is especially important for individuals over the age of 35 or persons with pre-existing health problems. It's important to read all instructions carefully. We assume no responsibility for personal injury or consequential damages sustained by or through the use of this equipment. Additional terms and conditions are listed in the back of this manual or enclosed owner's manual. Colors and specifications subject to change without notice.


NOTE: Before assembly please lay out ALL pieces accordingly to ensure you are not missing any items.

PLEASE BE CAUTIOUS as some components may be sharp and can cause harm if not handled correctly. Always use safety measurements when assembling any piece of equipment or machinery.


MCBIAR05




AS-Main Frame Set




DS-Front Stabilizer Set



CS-Rear Stabilizer Set




E-Handle Bar




GS-Console Set

G2-Right Pedal




G1-Left Pedal




J9-Nut Cap



J7-Console Pivot Bushing




J2-Bolt M10 x 55mm



J4-Nut



J8-Hex Head Screw





J6-Flat Washer




J5-Flat Washer




J3-Flat Washer




Step 1.


Use the 6mm Allen wrench to remove 2x Bolts M8x12mm (B1) and disassemble the Packaging Tube (B) from the Main Frame Set (AS). The Packaging Tube (B) is used for packaging purposes only and won't be needed again during/after the assembly.

Step 2.


Attach the Front Stabilizer Set (DS) & the Rear Stabilizer Set (CS) onto the Main Frame Set (AS) and secure them with 4x Bolt M10x55mm (J2) and 4x Flat Washer (J3).

Step 3.

Remove 1x Hex Head Screw (J8), 2x Flat Washer (J6), 2x Flat Washer (J5), 1x Nut (J4) and 2x Console Pivot Bushing (J7) from the Handlebar (E). Slightly loosen the knob (A11) and then inset the Handlebar (E) to the Main Frame Set-(AS). Secure the Console Set(GS) onto the Handle Bar (E) with 1x Head Screw (J8), 2x Flat Washer (J6), 2x Flat Washer (J5), 1x Nut (J4) and 2x Console pivot Bushing (J7). Finally, put on 2x Nut Cap (J9). Connect the Console Wire (M4) with console wire in Console Set (GS). Secure the Console Wire (M4) to the Handle Bar (E) with 1x Screw (M5).


Step 4.

Attach the Left Pedal (G1) onto the Main Frame Set(AS) by screwing in Counter-Clockwise; repeat for the Right Pedal (G2) by screwing in Clockwise.

Step 5.

Press the Lever (A14) and pull upwards the seat post to desired height.

MCBIAR05



MCBIAR05

PARTS LIST

NO.	NAME	SPECIFICATION	Q'TY	NO.	NAME	SPECIFICATION	Q'TY
A	Main Frame		1	E2	Clip	S20	2
A1	Retractable Sleeve		2	E3	Steel Washer		2
A2L	Square Inner Sleeve-L		2	E4	One-Way Bearing	FC2016	1
A2R	Square Inner Sleeve-R		2	E5	Flywheel Bearing Holder		1
A3	Double-Head Screw	Ø8 x 65mm	1	E6	Bearing	6004	2
A4	Nut	M8	2	E7	Clip	R42	2
A5	Round Steel Rod	Ø6 x 50mm	2	E8	Spring Washer	M5	4
A6	Screw	M6 x 10mm	30	E9	Screw	M5×10mm	4
A7	Screw	M6 x 10mm	6	E11	Magnet Base		1
A8	Spring Washer	M6	1	E12	Ring Magnet		1
A9	Screw	M8 x 80mm	2	E15	Flywheel Shaft		1
A10	Nut	M8	2	E16	Drive Belt Pulley- PJ		1
A11	Knob	M8	2	E18	Inner Main Cover		1
A13	Lever Support Column	Ø10 x 49.5mm	2	E19	Outer Main Cover		1
A14	Lever		2	E20	Plug	Ø17	1
A15	Upper Steel Cover	Stainless Steel 0.8T	1	E25	Tapping Screw	M4 x 10mm	2
A16	Screw	M6 x 6mm	15	E26	Tapping Screw	M4 x 20mm	4
				E27	Damper Disc Cover		1
				E28	Plastic Flywheel Fan		1
B	Packing Tube		2	E29	Fan Plate		1
B1	Screw	M8 x 12mm	4	E30	Mesh		1
				E31	Tapping Screw	M4 x 10mm	4
C	Rear Stabilizer		1				
C1	Wing Nut	M12	2	F	Saddle Post		1
C2	Knob		2	F1	Adjuster Plate		2
				F2	Screw	M6 x 12mm	6
D	Front Stabilizer		1	F3	Screw	M6 x 10mm	2
D1	Transportation Wheel			F4	Saddle Set		1
D2	Nut	M8	2	F5	Saddle		1
D3	Screw	M8 x 50mm	2	F7	Handle Bar Post		1
D4	Tapping Screw	M4 x 12mm	12	F8L	Handle Bar Post Sleeve-L		2
D5	Square Pad		2	F8R	Handle Bar Post Sleeve-R		2
D6	Tube End Cap	40 x 100	4				
				G-E	Console		1
E	Handle Bar Assembly		1	G3	Console Base		1
E1	Screw	M4	8				

MCBIAR05

NO.	NAME	SPECIFICATION	Q'TY	NO.	NAME	SPECIFICATION	Q'TY
J2	Bolt	M8 10 x 55mm	8	K23	Bearing	6002	2
J3	Flat Washer	Ø10 x 2T x Ø 18	8	K24	Flywheel Bearing Sleeve	Ø15 x 50mm	1
J4	Nut	½"-12UNC	1	K25L	Bearing Holder(L)		1
J5	Flat Washer	½"x1TxØ32	2	K25R	Bearing Holder(R)		1
J6	Flat Washer	½"x2TxØ23	2	K26	Bolt	M6x10mm	12
J7	Console Pivot Bushing		2	K27	Bearing		2
J8	Hex Head Screw	½"x3 ¼"	1	K28	Bearing with buckle	6201ZZ	1
J9	Nut Cap		2	K29	Flat Washer	M6×2T×19	1
J10	Bottle Holder (Optional)		1	K30	Screw with nylok	M6×12mm	1
J11	Screw	M5x10mm	2	K31	Bearing Cap		1
				K32	Bolt	M6x12mm	5
G1	Left Pedal		1	K37	Spring Rod	Ø6x65mm	2
G2	Right Pedal		1	K38	Spring		2
				K39	Iron Side Cover-L		1
K1L	Left Crank		1	K40	Iron Side Cover-R		1
K1R	Right Crank		1	K41	Screw	M5×8mm	3
K	Drive Belt Disc- PK	Ø180	1	K42	Bearing with buckle	BR-6003ZZ.Z3TPX-1	1
K3	Nut		2	K43	Screw	M5×6mm	3
K4	Shaft Cap		2	K44	Airproof Cover		1
K5	Screw	M8x16mm	4	K45	Tapping Screw	M4×10mm	2
K6	Spring Washer	M8	8				
K7	Shaft		1	M4	Console Wire		1
K8	Nut	M20	2				
K9	Drive Belt	1095PK6	1				
K10	Drive Belt	430J6	1				
K11	Idler Pulley Bracket		2				
K12	Idler Pulley Shaft	Ø10x30mm	2				
K13	Idler Pulley Sleeve	Ø10x50mm	2				
K14	Clip	S10	2				
K15	Flat Washer	Ø10x2TxØ20	2				
K16	Flat Washer	Ø10x1TxØ20	4				
K17	Bearing	6300	4				
K18	Drive Belt Disc-PJ	Ø180	1				
K19	Drive Belt Pulley-PJ		1				
K20	Bolt	M8x16mm	2				
K21	Clip	S15	2				
K22	Screw	M8x12mm	4				