


SKI TRAINER PRO

Owner's Manual



ASSEMBLY INSTRUCTIONS / OWNER'S MANUAL

IMPORTANT :

READ ALL ASSEMBLY INSTRUCTIONS AND SAFETY PRECAUTIONS BEFORE USING THIS PRODUCT. REFERENCE ALL SAFETY GUIDELINES AND WARNING LABELS. RETAIN PRODUCT LITERATURE FOR FUTURE REFERENCE.

SAFETY :

PROPERLY WARM UP AND STRETCH BEFORE EXERCISING. IF YOU FEEL PAIN OR DIZZINESS AT ANY TIME WHILE EXERCISING, STOP IMMEDIATELY AND CONSULT YOUR PHYSICIAN.

Assembly Preparation

- To ensure ease of product assembly, please take time to verify the size and quantities of all required assembly hardware. Use the itemized parts listing and hardware chart for reference.
- The product assembly process has been documented in easy to follow steps. Please read all assembly instructions carefully. Take time to review the manual and familiarize yourself with the entire assembly process before proceeding.
- Assembly Tip: It is always helpful to pre-stage the items needed for each assembly step.
- Perform product assembly in a 4-ft. x 10-ft. flat area. Note: After assembly is completed, allow a minimal 2-3 feet of space on each side of rower for user access and dismounting.
- Do not dispose of any packaging materials until assembly of the product is completed.
- Assembly tools are included, but you may also use standard household tools to complete assembly of this product.


Important Precautions

WARNING: To reduce the risk of injury, please read the following precautions before assembling or using your new product.


- It is the responsibility of the owner to ensure that all users of this equipment are adequately informed of stated precautions.
- Read all instructions and enclosed literature carefully. Understand the assembly and operation before using the equipment.
- Use equipment on a flat level surface. Use adjustment levelers on the bottom of equipment to help stabilize unit.
- It's recommended to place an exercise mat beneath the equipment for added protection of floors or carpets.
- Keep children and pets away from equipment at all times.
- Inspect product on a frequent basis. Tighten loose assemblies or hardware as needed. Replace worn or damaged parts.
- This equipment is intended for indoor use only. Use in non-recommended environment can lead to serious injury and will void all related warranties and liabilities.
- Recommended user weight should not exceed 350 pounds.
- Keep equipment clean and properly maintained.
- Observe and adhere to all warning labels posted on equipment.
- Properly warm up and stretch before starting any strength training or cardio exercise routine.
- If you feel pain or dizziness at any time while exercising, stop immediately and consult your physician.

SAFETY WARNING:

Before starting an exercise program, consult your physician. This is especially important for individuals over the age of 35 or persons with pre-existing health problems. It's important to read all instructions carefully. We assume no responsibility for personal injury or consequential damages sustained by or through the use of this equipment. Additional terms and conditions are listed in the back of this manual or enclosed owner's manual. Colors and specifications subject to change without notice.




MCSTAR01
Page 1




MCSTAR01
Page 2


PART LIST




A01




B01




C01




D01



E01-E



F01



G01



G02



H01



H02




B03 x4

M8X16mm



D08 x3

M6X16mm



E02 x4

M5x 10mm

(Pre-installed on E01-HBA)



F06 x4

M8X35mm




G03 x2

M6x45mm



G04 x2



H03 x8


M6x16mm



Follow these steps if you are installing ski trainer to floor stand.


Step 1:

1. Remove top cover of carton
2. Remove top half of Styrofoam from ski trainer main frame
3. Remove staples from bottom half of carton and lay flaps of carton flat



Step 2:

1. Stand ski trainer main frame upright
2. Remove bottom half of Styrofoam from ski trainer main frame




IMPORTANT :

Do not remove red plastic at this step


Step 3:

1. Install (F01) Base Frame and secure (F06) Socket Screw
2. Cut bottom 2x white-colored zip-ties near logo shown in picture






Step 4:

1. Upright the (B01) main frame

**FRONT****Step 5:**

1. Use 2x (B03) Socket Screw to secure (B01) Support Frame to (A01) main frame



B03 X2
M8X16mm



BACK


Step 6:

1. Cut the 2x white-colored zip-ties shown in picture
2. Use 2x (B03) Socket Screw to secure (B01) Support Frame to (A01) main frame




Step 7:

1. Secure (H01) L_Lower Handrail Tube and (G01) L_Upper Handrail Tube with (H03) Socket Screw
2. Secure (H02) R_Lower Handrail Tube and (G02) R_Upper Handrail Tube with (H03) Socket Screw
3. Secure R & L_Handrail and (A01) Mainframe with (G03) Socket Screw and (G04) Nylon Nut
4. Secure R & L_Handrail and (F01) Base Frame with (H03) Socket Screw




Step 8:

1. Untangle the Red Plastic Rope Buckle from the rope (Careful not to damage or cut the rope)
2. Secure (D01) Console Holder with (D08) M6X16mm - Socket Screw
3. Install (C01) Handle Bar on (B01) Support Frame




D08 x3

Step 9:


1. Remove the Pre-installed (E02) Truss head Screw from (E01-E) Econ Console ,
and use them to install (E01-E) Econ Console Smart Connect onto (D01) Console Holder

E01-E**E02 x4**


M5x 10mm
Pre-installed on
(E01-E)
Econ Console

D01

PART LIST



A01




B01




C01




D01




E01-E





J01




J02



J03



K01



K02



B03 x4

M8X16mm



D08 x3

M6X16mm



E02 x4

M5x 10mm
(Pre-installed on E01-HBA)



J04 x4

M6x16mm



K03 x4


M8X35mm



Follow these steps if you are installing ski trainer to wall-mount bracket.

Step 1:

1. Remove top cover of carton
2. Remove top half of styrofoam from ski trainer main frame
3. Remove staples from bottom half of carton and lay flaps of carton flat




Step 2:

1. Stand ski trainer main frame upright
2. Remove bottom half of styrofoam from ski trainer main frame

IMPORTANT :


Do not remove red plastic at this step




Step 3:

1. Secure (K01) L_Bottom Tube and (K02) R_Bottom Tube with (K03) Socket Screw
2. Cut bottom 2x white-colored zip-ties near logo shown in picture


K03 x2
M8X35mm



K03 x2
M8X35mm



K01




K02




Step 4:

1. Secure (J01) L_Top wall-mount Plate ,(J02) R_Top wall-mount Plate and (J03) Fixed Plate with (J04) Socket Screw





Step 5:

1. Upright the (B01) main frame

**FRONT****Step 6:**

1. Use 2x (B03) Socket Screw to secure (B01) Support Frame to (A01) main frame



B03 X2
M8X16mm



BACK

Step 7:

1. Cut the 2x white-colored zip-ties shown in picture
2. Use 2x (B03) Socket Screw to secure (B01) Support Frame to (A01) main frame






Step 8:

1. Untangle the Red Plastic Rope Buckle from the rope (Careful not to damage or cut the rope)
2. Secure (D01) Console Holder with (D08) M6X16mm - Socket Screw
3. Install (C01) Handle Bar on (B01) Support Frame




D08 x3
M6X16mm







Step 9:



1. Remove the Pre-installed (E02) Truss head Screw from (E01-E) Econ Console, and use them to install (E01-E) Econ Console Smart Connect onto (D01) Console Holder

E01-E

E02 x4
M5x 10mm
Pre-installed on
(E01-E) Econ Console

D01





NO.	NAME	Q'TY
A01	Main Frame	1
A02	L_Cover Plate	1
A03	R_Cover Plate	1
A04	Maintenance Hole Cover	1
A05	Rear Housing	1
A06	Front Cover	1
A07	Rear Cover	1
A08	Drive Belt(250-J6)	1
A09	φ133 - Drive Belt Bracket	1
A10	φ50 - Drive Belt Bracket	1
A11	Fan Axle	1
A12	S20 - Retaining Rings	2
A13	M5X6mm - Truss head Screw	8
A14	Bearing6004	3
A15	M10X25mm - Socket Screw	1
A16	Bearing6200	2
A17	M10 - Plain Washer 1T	1
A18	M8 - Nylon Nut	1
A19	Idler Rack	1
A20	M4x10mm - Self-Tapping Screw	12
A21	M6X30mm - Socket Screw	1
A22	M6 - Hex Nut	1
A23	Spring and Rope Housing (Including Rope)	1
A23-1	Rope (Without rope housing and spring)	X
A24	M8X20mm - Socket Screw	1
A26	Wire Axle	1
A27	Anti-Eccentric Axle	1
A28	φ42mm - Pulley	2
A29	Spacer Ring-Short	1
A30	S10 - Retaining Rings	2
A31	STM-1 _ Bracket	4
A34	Fan Center Tube	1
A35	Wire End Cap	4
A36	Rear Chain Cover	1
A37	Mesh	1
A38	Right Chain Cover	1
A39	Adjust Disc	1
A40	Fan	1
A41	Fan Stable Bracket	1
A44	Magnet Bracket	1
A45	Round Magnet	1
A46	M4X20mm-Truss head Self-Tapping Screw	4
A47	M4XP0.75X10mm - Hex Cross Washer	8
A48	M5X10mm - Socket Screw	4
A50	M4X12mm - Truss head Self-Tapping Screw	6
A51	M6X20mm - Hex Socket Screw	2

NO.	NAME	Q'TY
A52	M3X8mm - Truss head Self-Tapping Screw	2
A53	M3X15mm - Pan Head Screw	2
A54	M3 - Hex nut	2
A62	M5X10mm - Button Head Socket Screw	24
A63	M5X6mm - Button Head Socket Screw	2
A67	φ7X15.8mm - Pulley Axle	2
A68	Bearing6201	1
A69	M6X1TX13mm - Flat Washer	4
A70	M6X10mm - Truss head Screw	4
B01	Support Frame	1
B02	Tube Cap	2
B03	M8X16mm - Socket Screw	4
C01	Handle Bar	2
C02	M6X16mm - Socket Screw	8
C03	Pulley Bracket	2
C04	Pulley Bracket Fixed Plate	2
C05	Casing- Long	2
C06	Casing- Short	2
C07	Pulley Bracket Bushing	4
C08	M6X65mm - Socket Screw	2
C09	M6 - Nylon Nut	2
C10	M5X8mm - Button Head Socket Screw	8
C11	φ42mm - Pulley With Two Spacers	4
C12	Carabiner	2
C13	Rope Protective Case	2
C14	Knot Bracket A	2
C15	M5 - Nylon Nut	2
C16	Knot Bracket B	2
C17	M5X16mm - Socket Screw	2
C18	Pulley Bracket Protective Case	2
D01	Console Holder	1
D02	Connecting Tube	1
D03	Console Bushing	2
D04	1/2" - Nut Cap	2
D05	1/2" x 3-1/4" - Socket Screw	1
D06	1/2" - Nylon Nut	1
D07	1/2"x1Tx32 Flat Washer	2
D08	M6X16mm - Socket Screw	3
D09	1/2"x2Tx23 Flat Washer	2
E01-E	Econ Console	1
E02	M5x10 - mm Truss head Screw	1
E03	Induction Coil Connecting Wire	1
E04	Console Connecting Wire	1
E05	VR	1
E06	VR Connecting Wire	1
E07	Induction Coil	1

NO.	NAME	Q'TY
Parts Of Floor Stand		
F01	Base Frame	1
F02	Caster	2
F03	Bushing	4
F04	M8X45mm - Truss Head Hex Socket Screw	2
F05	M8 - Hex Nut	2
F06	M8X35mm - Socket Screw	4
F07	30X30MM - Tube Cap	2
F08	Pad	1
G01	L_Upper Handrail Tube	1
G02	R_Upper Handrail Tube	1
G03	M6X45mm - Socket Screw	2
G04	M6 - Nylon Nut	2
H01	L_Lower Handrail Tube	1
H02	R_Lower Handrail Tube	1
H03	M6X16mm - Socket Screw	8
Parts Of Wall-mount		
J01	L_ Top wall-mount Plate	1
J02	R_ Top wall-mount Plate	1
J03	Fixed Plate	2
J04	M6X16mm - Socket Screw	4
K01	L_Bottom wall-mount Tube	1
K02	R_Bottom wall-mount Tube	1
K03	M8X35mm - Socket Screw	4
K04	30X30MM - Tube Cap	4
K05	Bottom Rubber Pad	4
K06	M4X12mm - Truss head Self-Tapping Screw	8