


Step 1



Find a suitable objection to
raise the running belt set

Step 2




1. Please use some grease on axle of magnet group.
2. Please push the magnet group to ensure that the oil enters the axle.



Video Link:

https://www.dropbox.com/scl/fi/0sa7bt3282i6tb58fcm_e0/Please-push-the-magnet-group-to-check-if-the-spring-can-move-backward-and-forward-freely.mp4?rlkey=nps4f26sacrrpxdnajt6s7nn1&st=znzhyygg&dl=0

Step 3



1. Please push the **magnet group** to check if **the spring** can move backward and forward freely.

2. A new spring will be needed if the spring can't move freely after applying some grease.