

系统1(Sys1)						系统2(Sys2)					
	INT	BIT	Trig Cond	报警信息 (CN)	Alarm information		INT	BIT	Trig Cond	报警信息 (CN)	Alarm information
40001	0	1:TRIG	系统1压缩机1电流报警	1# COMP1 Current High Protection	1# COMP1 Current High Protection	0	1:TRIG	系统2压缩机1电流报警	2# COMP1 Current High Protection	2# COMP1 Current High Protection	
	1	1:TRIG	系统1压缩机2电流报警	1# COMP2 Current High Protection	1# COMP2 Current High Protection	1	1:TRIG	系统2压缩机2电流报警	2# COMP2 Current High Protection	2# COMP2 Current High Protection	
	2	1:TRIG	系统1压缩机1通讯断升故障	1# COMP1 Communication Failure	1# COMP1 Communication Failure	2	1:TRIG	系统2压缩机1通讯断升故障	2# COMP1 Communication Failure	2# COMP1 Communication Failure	
	3	1:TRIG	系统1压缩机2通讯断升故障	1# COMP2 Communication Failure	1# COMP2 Communication Failure	3	1:TRIG	系统2压缩机2通讯断升故障	2# COMP2 Communication Failure	2# COMP2 Communication Failure	
	4	1:TRIG	系统1与系统2通讯断升故障	Sys1 and Sys2 Communication Failure (SYS1)	Sys1 and Sys2 Communication Failure (SYS1)	4	1:TRIG	系统2与系统2通讯断升故障	Sys1 and Sys2 Communication Failure (SYS2)	Sys1 and Sys2 Communication Failure (SYS2)	
	5	1:TRIG	机组水泵故障	Water Malfuction	Water Malfuction	/	/	/	/	/	
	6	1:TRIG	浪涌故障	Be Struck By Lightning Protection	Be Struck By Lightning Protection	/	/	/	/	/	
	7	1:TRIG	蒸发器水流故障	Insufficient Water Flow Protection	Insufficient Water Flow Protection	/	/	/	/	/	
	8	1:TRIG	流量计传感器故障	Flow meter	Flow meter	/	/	/	/	/	
	9	1:TRIG	电源切换故障	Power change Malfuction	Power change Malfuction	/	/	/	/	/	
	10	1:TRIG	电源故障	Power Malfuction	Power Malfuction	/	/	/	/	/	
	11	1:TRIG	系统1压缩机1吸气电动阀全开反馈故障	1# 1suction Valve Is Not Fully Opened Protection	1# 1suction Valve Is Not Fully Opened Protection	11	1:TRIG	系统2压缩机1吸气电动阀全开反馈故障	2# 1suction Valve Is Not Fully Opened Protection	2# 1suction Valve Is Not Fully Opened Protection	
	12	1:TRIG	系统1压缩机1吸气电动阀全开反馈故障	1# 1suction Valve Is Not Fully Closed Protection	1# 1suction Valve Is Not Fully Closed Protection	12	1:TRIG	系统2压缩机1吸气电动阀全开反馈故障	2# 1suction Valve Is Not Fully Closed Protection	2# 1suction Valve Is Not Fully Closed Protection	
	13	1:TRIG	系统1压缩机2吸气电动阀全开反馈故障	1# 2suction Valve Is Not Fully Opened Protection	1# 2suction Valve Is Not Fully Opened Protection	13	1:TRIG	系统2压缩机2吸气电动阀全开反馈故障	2# 2suction Valve Is Not Fully Opened Protection	2# 2suction Valve Is Not Fully Opened Protection	
	14	1:TRIG	系统1压缩机2吸气电动阀全开反馈故障	1# 2suction Valve Is Not Fully Closed Protection	1# 2suction Valve Is Not Fully Closed Protection	14	1:TRIG	系统2压缩机2吸气电动阀全开反馈故障	2# 2suction Valve Is Not Fully Closed Protection	2# 2suction Valve Is Not Fully Closed Protection	
15	1:TRIG	系统1压缩机1启动失败故障	1# COMP1 START Failure	1# COMP1 START Failure	15	1:TRIG	系统2压缩机1启动失败故障	2# COMP1 START Failure	2# COMP1 START Failure		
0	1:TRIG	系统1压缩机2启动失败故障	1# COMP2 START Failure	1# COMP2 START Failure	0	1:TRIG	系统2压缩机2启动失败故障	2# COMP2 START Failure	2# COMP2 START Failure		
1	1:TRIG	系统1压缩机1不停机故障	1# COMP1 Non-Stop Protection	1# COMP1 Non-Stop Protection	1	1:TRIG	系统2压缩机1不停机故障	2# COMP1 Non-Stop Protection	2# COMP1 Non-Stop Protection		
2	1:TRIG	系统1压缩机2不停机故障	1# COMP2 Non-Stop Protection	1# COMP2 Non-Stop Protection	2	1:TRIG	系统2压缩机2不停机故障	2# COMP2 Non-Stop Protection	2# COMP2 Non-Stop Protection		
3	1:TRIG	系统1风机故障	1# Group1 Fan Malfuction	1# Group1 Fan Malfuction	3	1:TRIG	系统2风机故障	2# Group1 Fan Malfuction	2# Group1 Fan Malfuction		
4	1:TRIG	公用风机故障	1# Group2 Fan Malfuction	1# Group2 Fan Malfuction	/	/	/	/	/		
5	1:TRIG	系统1压缩机1内部故障	1# COMP1 Malfuction	1# COMP1 Malfuction	5	1:TRIG	系统2压缩机1内部故障	2# COMP1 Malfuction	2# COMP1 Malfuction		
6	1:TRIG	系统1压缩机2内部故障	1# COMP2 Malfuction	1# COMP2 Malfuction	6	1:TRIG	系统2压缩机2内部故障	2# COMP2 Malfuction	2# COMP2 Malfuction		
7	1:TRIG	系统1压力过高故障	1# Discharge Pressure High Protection (1)	1# Discharge Pressure High Protection (1)	7	1:TRIG	系统2压力过高故障	2# Discharge Pressure High Protection (1)	2# Discharge Pressure High Protection (1)		
8	1:TRIG	系统1高压开关动作保护	1# Discharge Pressure High Protection (2)	1# Discharge Pressure High Protection (2)	8	1:TRIG	系统2高压开关动作保护	2# Discharge Pressure High Protection (2)	2# Discharge Pressure High Protection (2)		
9	1:TRIG	系统1低压保护1	1# Suction Pressure Low Protection (1)	1# Suction Pressure Low Protection (1)	9	1:TRIG	系统2低压保护1	1# Suction Pressure Low Protection (1)	1# Suction Pressure Low Protection (1)		
10	1:TRIG	系统1低压保护2	1# Suction Pressure Low Protection (2)	1# Suction Pressure Low Protection (2)	10	1:TRIG	系统2低压保护2	1# Suction Pressure Low Protection (2)	1# Suction Pressure Low Protection (2)		
11	1:TRIG	蒸发器出水温度传感器故障	Leaving Water TEMP Sensor Malfuction	Leaving Water TEMP Sensor Malfuction	/	/	/	/	/		
12	1:TRIG	蒸发器回水温度传感器故障	Return Water TEMP Sensor Malfuction	Return Water TEMP Sensor Malfuction	/	/	/	/	/		
13	1:TRIG	环境温度传感器故障	Ambient TEMP Sensor Malfuction	Ambient TEMP Sensor Malfuction	/	/	/	/	/		
14	1:TRIG	机柜内部温度传感器故障	Cabinet TEMP Sensor Malfuction	Cabinet TEMP Sensor Malfuction	/	/	/	/	/		
15	1:TRIG	系统1吸气压力传感器故障	1# Suction Pressure Sensor Malfuction	1# Suction Pressure Sensor Malfuction	15	1:TRIG	系统2吸气压力传感器故障	2# Suction Pressure Sensor Malfuction	2# Suction Pressure Sensor Malfuction		
0	1:TRIG	系统1排气压力传感器故障	1# Discharge Pressure Sensor Malfuction	1# Discharge Pressure Sensor Malfuction	0	1:TRIG	系统2排气压力传感器故障	2# Discharge Pressure Sensor Malfuction	2# Discharge Pressure Sensor Malfuction		
1	1:TRIG	系统1排气温度传感器故障	1# Discharge Gas TEMP Sensor Malfuction	1# Discharge Gas TEMP Sensor Malfuction	1	1:TRIG	系统2排气温度传感器故障	2# Discharge Gas TEMP Sensor Malfuction	2# Discharge Gas TEMP Sensor Malfuction		
2	1:TRIG	系统1压缩机1ECO补气温度传感器故障	1# 1ECO Auxiliary-side TEMP Sensor Malfuction	1# 1ECO Auxiliary-side TEMP Sensor Malfuction	2	1:TRIG	系统2压缩机1ECO补气温度传感器故障	1# 1ECO Auxiliary-side TEMP Sensor Malfuction	1# 1ECO Auxiliary-side TEMP Sensor Malfuction		
3	1:TRIG	系统1压缩机2ECO补气温度传感器故障	1# 2ECO Auxiliary-side TEMP Sensor Malfuction	1# 2ECO Auxiliary-side TEMP Sensor Malfuction	3	1:TRIG	系统2压缩机2ECO补气温度传感器故障	1# 2ECO Auxiliary-side TEMP Sensor Malfuction	1# 2ECO Auxiliary-side TEMP Sensor Malfuction		
4	1:TRIG	系统1压缩机1ECO补气压力传感器故障	1# 1ECO Auxiliary-side Pressures Sensor Malfuction	1# 1ECO Auxiliary-side Pressures Sensor Malfuction	4	1:TRIG	系统2压缩机1ECO补气压力传感器故障	1# 1ECO Auxiliary-side Pressures Sensor Malfuction	1# 1ECO Auxiliary-side Pressures Sensor Malfuction		
5	1:TRIG	系统1压缩机2ECO补气压力传感器故障	1# 2ECO Auxiliary-side Pressures Sensor Malfuction	1# 2ECO Auxiliary-side Pressures Sensor Malfuction	5	1:TRIG	系统2压缩机2ECO补气压力传感器故障	1# 2ECO Auxiliary-side Pressures Sensor Malfuction	1# 2ECO Auxiliary-side Pressures Sensor Malfuction		
6	1:TRIG	系统1排气温度过高保护	1# Discharge Gas TEMP High Protection	1# Discharge Gas TEMP High Protection	6	1:TRIG	系统2排气温度过高保护	2# Discharge Gas TEMP High Protection	2# Discharge Gas TEMP High Protection		
7	1:TRIG	进出水温差过大	TEMP DIFF Between Inflow and Outflow High Protect	TEMP DIFF Between Inflow and Outflow High Protect	/	/	/	/	/		
8	1:TRIG	水温过低保护	Leaving Water TEMP Low Protection	Leaving Water TEMP Low Protection	/	/	/	/	/		
0	1:TRIG	水流开关低信号	Water flow signal	Water flow signal	/	/	/	/	/		
1	1:TRIG	机组供电信号	Power signal	Power signal	/	/	/	/	/		
2	1:TRIG	水泵启动信号	Pump run signal	Pump run signal	/	/	/	/	/		
3	1:TRIG	运行信号	Unit run signal	Unit run signal	/	/	/	/	/		
4	1:TRIG	故障信号	Unit alarm signal	Unit alarm signal	/	/	/	/	/		
5	1:TRIG	旁通阀信号	Bypass valve signal	Bypass valve signal	/	/	/	/	/		
6	1:TRIG	进水阀信号	LW valve signal	LW valve signal	/	/	/	/	/		
7	1:TRIG	出水阀信号	EW valve signal	EW valve signal	/	/	/	/	/		
40005	x10.0(%)	机组目标负荷	Unit target load	Unit target load	/	/	/	/	/		
40006	x1.0(KW)	系统1压缩机1实际功率	1# COMP1 Actual power	1# COMP1 Actual power	40106	x1.0(KW)	系统2压缩机1实际功率	2# COMP1 Actual power	2# COMP1 Actual power		
40007	x1.0(KW)	系统1压缩机2实际功率	1# COMP2 Actual power	1# COMP2 Actual power	40107	x1.0(KW)	系统2压缩机2实际功率	2# COMP2 Actual power	2# COMP2 Actual power		
40008	x1.0(KW)	系统1压缩机1需求功率	1# COMP1 Required power	1# COMP1 Required power	40108	x1.0(KW)	系统2压缩机1需求功率	2# COMP1 Required power	2# COMP1 Required power		
40009	x1.0(KW)	系统1压缩机2需求功率	1# COMP2 Required power	1# COMP2 Required power	40109	x1.0(KW)	系统2压缩机2需求功率	2# COMP2 Required power	2# COMP2 Required power		
40010	x1.0(RPM)	系统1压缩机1实际转速	1# COMP1 Actual speed	1# COMP1 Actual speed	40110	x1.0(RPM)	系统2压缩机1实际转速	2# COMP1 Actual speed	2# COMP1 Actual speed		
40011	x1.0(RPM)	系统1压缩机2实际转速	1# COMP2 Actual speed	1# COMP2 Actual speed	40111	x1.0(RPM)	系统2压缩机2实际转速	2# COMP2 Actual speed	2# COMP2 Actual speed		
40012	x100.00(%)	系统1电子膨胀阀开度	1# Main EVX position	1# Main EVX position	40112	x100.00(%)	系统2电子膨胀阀开度	2# Main EVX position	2# Main EVX position		
40013	x10.0(%)	系统1风机转速	1# Group1 Fan speed	1# Group1 Fan speed	40113	x10.0(%)	系统2风机转速	2# Group1 Fan speed	2# Group1 Fan speed		
40014	x10.0(%)	公用风机转速	1# Group2 Fan speed	1# Group2 Fan speed	/	/	/	/	/		
40015	x100.00(Bar)	系统1吸气压力	1# Suction Pressure	1# Suction Pressure	40115	x100.00(Bar)	系统2吸气压力	2# Suction Pressure	2# Suction Pressure		
40016	x100.00(Bar)	系统1排气压力	1# Discharge Pressure	1# Discharge Pressure	40116	x100.00(Bar)	系统2排气压力	2# Discharge Pressure	2# Discharge Pressure		
40017	x10.0(m³/h)	蒸发器流量	Evaporator flow rate	Evaporator flow rate	/	/	/	/	/		
40018	x100.00 (Bar)	出水压力	Leaving Water Pressure	Leaving Water Pressure	/	/	/	/	/		
40019	x100.00 (Bar)	回水压力	Return Water Pressure	Return Water Pressure	/	/	/	/	/		
40020	x10.0 (°C)	环境温度	Ambient TEMP	Ambient TEMP	/	/	/	/	/		
40021	x10.0 (°C)	蒸发器进水温度	Return Water TEMP	Return Water TEMP	/	/	/	/	/		
40022	x10.0 (°C)	蒸发器出水温度	Leaving Water TEMP	Leaving Water TEMP	/	/	/	/	/		
40023	x10.0 (°C)	出水温度设定值显示	LWT set point display	LWT set point display	/	/	/	/	/		
40024	x100.0 (Hz)	水泵频率设定值显示	Pump frequency set point display	Pump frequency set point display	/	/	/	/	/		
40071	x10.0 (°C)	蒸发器出水温度设定	LWT set point	LWT set point	/	/	/	/	/		
40072	1:TRIG	机组远程开关机	Remote SATART/STOP	Remote SATART/STOP	/	/	/	/	/		
40073	x100.00 (Hz)	水泵频率设定	Pump Frequency set point	Pump Frequency set point	/	/	/	/	/		