ARPIE Case

- Peel the backing film (if present) from each plastic panel.
- Remove the screws from base of the ARPIE and use the longer (12mm) screws and the 3mm spacers (fitted between plastic panel and PCB) to attach the base plate.
- Remove the screws from the control surface (top) of the ARPIE, Assemble the four sides, selecting the appropriate back plate for your ARPIE revision.
- Put the face plate in place and use the 10mm screws to secure it, making sure it is the right way round. (check the recess around the 20 pin header)

http://six4pix.com/arpie sixtyfourpixels@gmail.com

ARPIE Case

- Peel the backing film (if present) from each plastic panel.
- Remove the screws from base of the ARPIE and use the longer (12mm) screws and the 3mm spacers (fitted between plastic panel and PCB) to attach the base plate.
- Remove the screws from the control surface (top) of the ARPIE, Assemble the four sides, selecting the appropriate back plate for your ARPIE revision.
- Put the face plate in place and use the 10mm screws to secure it, making sure it is the right way round. (check the recess around the 20 pin header)

http://six4pix.com/arpie sixtyfourpixels@gmail.com

ARPIE Case

- Peel the backing film (if present) from each plastic panel.
- Remove the screws from base of the ARPIE and use the longer (12mm) screws and the 3mm spacers (fitted between plastic panel and PCB) to attach the base plate.
- Remove the screws from the control surface (top) of the ARPIE, Assemble the four sides, selecting the appropriate back plate for your ARPIE revision.
- Put the face plate in place and use the 10mm screws to secure it, making sure it is the right way round. (check the recess around the 20 pin header)

http://six4pix.com/arpie sixtyfourpixels@gmail.com

ARPIE Case

- Peel the backing film (if present) from each plastic panel.
- Remove the screws from base of the ARPIE and use the longer (12mm) screws and the 3mm spacers (fitted between plastic panel and PCB) to attach the base plate.
- Remove the screws from the control surface (top) of the ARPIE, Assemble the four sides, selecting the appropriate back plate for your ARPIE revision.
- Put the face plate in place and use the 10mm screws to secure it, making sure it is the right way round. (check the recess around the 20 pin header)

http://six4pix.com/arpie sixtyfourpixels@gmail.com

ARPIE Case

- Peel the backing film (if present) from each plastic panel.
- Remove the screws from base of the ARPIE and use the longer (12mm) screws and the 3mm spacers (fitted between plastic panel and PCB) to attach the base plate.
- Remove the screws from the control surface (top) of the ARPIE, Assemble the four sides, selecting the appropriate back plate for your ARPIE revision.
- Put the face plate in place and use the 10mm screws to secure it, making sure it is the right way round. (check the recess around the 20 pin header)

http://six4pix.com/arpie sixtyfourpixels@gmail.com

ARPIE Case

- Peel the backing film (if present) from each plastic panel.
- Remove the screws from base of the ARPIE and use the longer (12mm) screws and the 3mm spacers (fitted between plastic panel and PCB) to attach the base plate.
- Remove the screws from the control surface (top) of the ARPIE, Assemble the four sides, selecting the appropriate back plate for your ARPIE revision.
- Put the face plate in place and use the 10mm screws to secure it, making sure it is the right way round. (check the recess around the 20 pin header)

http://six4pix.com/arpie sixtyfourpixels@gmail.com

ARPIE Case

- Peel the backing film (if present) from each plastic panel.
- Remove the screws from base of the ARPIE and use the longer (12mm) screws and the 3mm spacers (fitted between plastic panel and PCB) to attach the base plate.
- Remove the screws from the control surface (top) of the ARPIE, Assemble the four sides, selecting the appropriate back plate for your ARPIE revision.
- Put the face plate in place and use the 10mm screws to secure it, making sure it is the right way round. (check the recess around the 20 pin header)

http://six4pix.com/arpie sixtyfourpixels@gmail.com

ARPIE Case

- Peel the backing film (if present) from each plastic panel
- Remove the screws from base of the ARPIE and use the longer (12mm) screws and the 3mm spacers (fitted between plastic panel and PCB) to attach the base plate.
- Remove the screws from the control surface (top) of the ARPIE, Assemble the four sides, selecting the appropriate back plate for your ARPIE revision.
- Put the face plate in place and use the 10mm screws to secure it, making sure it is the right way round. (check the recess around the 20 pin header)

http://six4pix.com/arpie sixtyfourpixels@gmail.com