
ENGINEERING GRAPHICS

Topic: Letter Writing

Letter Writing




Letter Writing

- The written information on the drawings should be legible, neat in appearance and correct in style.
- So, all written information on the drawing is always in the form of lettering and not in handwriting.
- Letter writing is an art of writing text on a drawing by using alphabets, numerals and symbols.

Letter Writing

Types of letter writing —

- (1) Single stroke.
- (2) Double stroke.



Single stroke letters are legible, neat in appearance and correct in style, therefore they are universally used for engineering drawings.

 Letters having all strokes of uniform thickness are classified as Gothic.


The style of the letter, when the thickness of the strokes is such that it can be made with a single stroke of pencil, is called Single Stroke Gothic.


Single stroke vertical letters:


Letters are designated by their height.


The ratio of height to width for single stroke vertical gothic letters is given below.


SR.	HEIGHT TO WIDTH RATIO	LETTER/NUMERAL
1.	7:5	All letters except I, J, L, M, W
2.	7:4	All numerals except 1
3.	7:1	1
4.	7:3	1
5.	7:4	L&J
6.	7:6	M
7.	7:8	W


































































































Rules of Letter Writing

- 1. The height of all the letters in one line should be the same.
- 2. The gap between two letters in a word should be 2 mm.
- 3. Words should be spaced one letter width apart and distance between two lines is equal to height of one letter.
- 4. They should appear upright from Bottom Edge, except when they are used for dimensioning.
- 5. Round-off the sharp corners wherever necessary, e.g., D, P, S, etc.
- 6. Letters and numerals are designated by their heights.

.

