COMPUTER ORGANIZATION AND DESIGN

The Hardware/Software Interface

Chapter 2

Instructions: Language of the Computer

Instruction Set

- The repertoire of instructions of a computer
- Different computers have different instruction sets
 - But with many aspects in common
- Early computers had very simple instruction sets
 - Simplified implementation
- Many modern computers also have simple instruction sets

The MIPS Instruction Set

- Used as the example throughout the book
- Stanford MIPS commercialized by MIPS Technologies (<u>www.mips.com</u>)
- Large share of embedded core market
 - Applications in consumer electronics, network/storage equipment, cameras, printers, ...
- Typical of many modern ISAs
 - See MIPS Reference Data tear-out card, and Appendixes B and E

Arithmetic Operations

- Add and subtract, three operands
 - Two sources and one destination
 - add a, b, c # a gets b + c
- All arithmetic operations have this form
- Design Principle 1: Simplicity favours regularity
 - Regularity makes implementation simpler
 - Simplicity enables higher performance at lower cost

Arithmetic Example

C code:

```
f = (g + h) - (i + j);
```

Compiled MIPS code:

```
add t0, g, h # temp t0 = g + h add t1, i, j # temp t1 = i + j sub f, t0, t1 # f = t0 - t1
```

Register Operands

- Arithmetic instructions use register operands
- \blacksquare MIPS has a 32 imes 32-bit register file
 - Use for frequently accessed data
 - Numbered 0 to 31
 - 32-bit data called a "word"
- Assembler names
 - \$t0, \$t1, ..., \$t9 for temporary values
 - \$s0, \$s1, ..., \$s7 for saved variables
- Design Principle 2: Smaller is faster
 - cf. main memory: millions of locations

REGISTER NAME, NUMBER, USE, CALL CONVENTION

NAME NUMBER		USE	PRESERVEDACROS: A CALL?	
\$zero	0	The Constant Value 0	N.A.	
\$at	1	Assembler Temporary	No	
\$v0-\$v1	2-3	Values for Function Results and Expression Evaluation	No	
\$a0-\$a3	4-7	Arguments	No	
\$t0-\$t7	8-15	Temporaries	No	
\$s0-\$s7	16-23	Saved Temporaries	Yes	
\$t8-\$t9	24-25	Temporaries	No	
\$k0-\$k1	26-27	Reserved for OS Kernel	No	
\$gp	28	Global Pointer	Yes	
\$sp	29	Stack Pointer	Yes	
\$fp	30	Frame Pointer	Yes	
\$ra	31	Return Address	Yes	

Register Operand Example

C code:

```
f = (g + h) - (i + j);

• f, ..., j in $s0, ..., $s4
```


Compiled MIPS code:

```
add $t0, $s1, $s2
add $t1, $s3, $s4
sub $s0, $t0, $t1
```

Memory Operands

- Main memory used for composite data
 - Arrays, structures, dynamic data
- To apply arithmetic operations
 - Load values from memory into registers
 - Store result from register to memory
- Memory is byte addressed
 - Each address identifies an 8-bit byte
- Words are aligned in memory
 - Address must be a multiple of 4
- MIPS is Big Endian
 - Most-significant byte at least address of a word
 - cf. Little Endian: least-significant byte at least address

Data Transfer: Load from and Store to memory



Memory Operand Example 1

C code:

```
g = h + A[8];
```

- g in \$s1, h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32
 - 4 bytes per word

```
lw $t0, 32($s3) # load word add $s1, $s2, $t0

offset base register
```

Memory Operand Example 2

C code:

```
A[12] = h + A[8];
```

- h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32

```
Tw $t0, 32($s3)  # Toad word
add $t0, $s2, $t0
sw $t0, 48($s3)  # store word
```

Registers vs. Memory

- Registers are faster to access than memory
- Operating on memory data requires loads and stores
 - More instructions to be executed
- Compiler must use registers for variables as much as possible
 - Only spill to memory for less frequently used variables
 - Register optimization is important!

Immediate Operands

- Constant data specified in an instruction addi \$s3, \$s3, 4
- No subtract immediate instruction
 - Just use a negative constant addi \$s2, \$s1, -1
- Design Principle 3: Make the common case fast
 - Small constants are common
 - Immediate operand avoids a load instruction

The Constant Zero

- MIPS register 0 (\$zero) is the constant 0
 - Cannot be overwritten
- Useful for common operations
 - E.g., move between registers add \$t2, \$s1, \$zero

Unsigned Binary Integers

Given an n-bit number

$$x = x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- Range: 0 to +2ⁿ 1
- Example
 - 0000 0000 0000 0000 0000 0000 0000 1011₂ = 0 + ... + $1 \times 2^3 + 0 \times 2^2 + 1 \times 2^1 + 1 \times 2^0$ = 0 + ... + 8 + 0 + 2 + 1 = 11_{10}
- Using 32 bits
 - 0 to +4,294,967,295

2s-Complement Signed Integers

Given an n-bit number

$$x = -x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \dots + x_12^1 + x_02^0$$

- Range: −2ⁿ⁻¹ to +2ⁿ⁻¹ − 1
- Example
- Using 32 bits
 - -2,147,483,648 to +2,147,483,647

2s-Complement Signed Integers

- Bit 31 is sign bit
 - 1 for negative numbers
 - 0 for non-negative numbers
- $-(-2^{n-1})$ can't be represented
- Non-negative numbers have the same unsigned and 2s-complement representation
- Some specific numbers
 - 0: 0000 0000 ... 0000
 - –1: 1111 1111 ... 1111
 - Most-negative: 1000 0000 ... 0000
 - Most-positive: 0111 1111 ... 1111

Signed Negation

- Complement and add 1
 - Complement means 1 → 0, 0 → 1

$$x + \overline{x} = 1111...111_2 = -1$$

 $\overline{x} + 1 = -x$

- Example: negate +2
 - $+2 = 0000 \ 0000 \ \dots \ 0010_2$

$$-2 = 1111 \ 1111 \ \dots \ 1101_2 + 1$$

= 1111 \ 1111 \ \dots \ 1110_2

Sign Extension

- Representing a number using more bits
 - Preserve the numeric value
- In MIPS instruction set
 - addi: extend immediate value
 - 1b, 1h: extend loaded byte/halfword
 - beq, bne: extend the displacement
- Replicate the sign bit to the left
 - cf. unsigned values: extend with 0s
- Examples: 8-bit to 16-bit
 - +2: 0000 0010 => 0000 0000 0000 0010
 - -2: 1111 1110 => 1111 1111 1111 1110

Representing Instructions

- Instructions are encoded in binary
 - Called machine code
- MIPS instructions
 - Encoded as 32-bit instruction words
 - Small number of formats encoding operation code (opcode), register numbers, ...
 - Regularity!
- Register numbers
 - \$t0 \$t7 are reg's 8 15
 - \$t8 \$t9 are reg's 24 25
 - \$s0 \$s7 are reg's 16 23

MIPS R-format Instructions

ор	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

Instruction fields

- op: operation code (opcode)
- rs: first source register number
- rt: second source register number
- rd: destination register number
- shamt: shift amount (00000 for now)
- funct: function code (extends opcode)

R-format Example

ор	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

add \$t0, \$s1, \$s2

special	\$s1	\$s2	\$tO	0	add
0	17	18	8	0	32
000000	10001	10010	01000	00000	100000

 $00000010001100100100000000100000_2 = 02324020_{16}$

Hexadecimal

- Base 16
 - Compact representation of bit strings
 - 4 bits per hex digit

0	0000	4	0100	8	1000	С	1100
1	0001	5	0101	9	1001	d	1101
2	0010	6	0110	а	1010	е	1110
3	0011	7	0111	b	1011	f	1111

- Example:
 - Instr code: ae0b 0004


MIPS I-format Instructions




- Immediate arithmetic and load/store instructions
 - rt: destination or source register number
 - Constant: -2¹⁵ to +2¹⁵ 1
 - Address: offset added to base address in rs
- Design Principle 4: Good design demands good compromises
 - Different formats complicate decoding, but allow 32-bit instructions uniformly
 - Keep formats as similar as possible

Stored Program Computers

The BIG Picture





- Instructions represented in binary, just like data
- Instructions and data stored in memory
- Programs can operate on programs
 - e.g., compilers, linkers, ...
- Binary compatibility allows compiled programs to work on different computers
 - Standardized ISAs

Logical Operations

Instructions for bitwise manipulation

Operation	С	Java	MIPS	
Shift left	<<	<<	s11	
Shift right	>>	>>>	srl	
Bitwise AND	&	&	and, andi	
Bitwise OR			or, ori	
Bitwise NOT	~	~	nor	

 Useful for extracting and inserting groups of bits in a word

Shift Operations



- shamt: how many positions to shift
- Shift left logical
 - Shift left and fill with 0 bits
 - s11 by i bits multiplies by 2i
- Shift right logical
 - Shift right and fill with 0 bits
 - srl by i bits divides by 2i (unsigned only)

AND Operations

- Useful to mask bits in a word
 - Select some bits, clear others to 0

```
and $t0, $t1, $t2
```

```
$t2 | 0000 0000 0000 0000 00<mark>00 11</mark>01 1100 0000
```

OR Operations

- Useful to include bits in a word
 - Set some bits to 1, leave others unchanged

```
or $t0, $t1, $t2
```

\$t0 | 0000 0000 0000 0000 00<mark>11 11</mark>01 1100 0000

NOT Operations

- Useful to invert bits in a word
 - Change 0 to 1, and 1 to 0
- MIPS has NOR 3-operand instruction
 - a NOR b == NOT (a OR b)

```
nor $t0, $t1, $zero ← ____
```

Register 0: always read as zero

```
$t1 | 0000 0000 0000 0001 1100 0000 0000
```

\$t0 | 1111 | 1111 | 1111 | 1100 | 0011 | 1111 | 1111

Conditional Operations


- Branch to a labeled instruction if a condition is true
 - Otherwise, continue sequentially
- beq rs, rt, L1
 - if (rs == rt) branch to instruction labeled L1;
- bne rs, rt, L1
 - if (rs != rt) branch to instruction labeled L1;
- j L1
 - unconditional jump to instruction labeled L1

Compiling If Statements

C code:

```
if (i==j) f = g+h;
else f = g-h;
```

- f, g, ... in \$s0, \$s1, ...
- Compiled MIPS code:



```
bne $s3, $s4, Else
add $s0, $s1, $s2
j Exit
Else: sub $s0, $s1, $s2
```

Exit: *...

Assembler calculates addresses

Compiling Loop Statements

C code:


```
while (save[i] == k) i += 1;
```

- i in \$s3, k in \$s5, address of save in \$s6
- Compiled MIPS code:

```
Loop: sll $t1, $s3, 2
add $t1, $t1, $s6
lw $t0, 0($t1)
bne $t0, $s5, Exit
addi $s3, $s3, 1
j Loop
Exit: ...
```

Basic Blocks

- A basic block is a sequence of instructions with
 - No embedded branches (except at end)
 - No branch targets (except at beginning)



- A compiler identifies basic blocks for optimization
- An advanced processor can accelerate execution of basic blocks

More Conditional Operations

- Set result to 1 if a condition is true
 - Otherwise, set to 0
- slt rd, rs, rt
 - if (rs < rt) rd = 1; else rd = 0;
- slti rt, rs, constant
 - if (rs < constant) rt = 1; else rt = 0;</p>
- Use in combination with beq, bne

```
slt $t0, $s1, $s2 # if ($s1 < $s2)
bne $t0, $zero, L # branch to L</pre>
```

Branch Instruction Design

- Why not blt, bge, etc?
- Hardware for <, ≥, ... slower than =, ≠</p>
 - Combining with branch involves more work per instruction, requiring a slower clock
 - All instructions penalized!
- beq and bne are the common case
- This is a good design compromise

Signed vs. Unsigned

- Signed comparison: slt, slti
- Unsigned comparison: sltu, sltui
- Example

 - slt \$t0, \$s0, \$s1 # signed
 -1 < +1 ⇒ \$t0 = 1</pre>
 - sltu \$t0, \$s0, \$s1 # unsigned ■ +4,294,967,295 > +1 \Rightarrow \$t0 = 0
 - Bounds check shortcut

Case/Switch Statement

- A chain of if-then-else statements
- Jump address table/Jump table
 - jr instruction

Check Yourself

Why does C provide two sets of operators for AND (& and &&) and two sets of operators for OR (| and ||), while MIPS doesn't?

```
#include <stdio.h>
int main()
{
     int i = 1, j = -1;
     int test = (i>0) && (j<0);
     printf("test = %d\n", test);
     return 0;
}</pre>
```

http://reliant.colab.duke.edu/c2mips/

Procedure Calling

- Steps required
 - 1. Place parameters in registers
 - 2. Transfer control to procedure
 - 3. Acquire storage for procedure
 - 4. Perform procedure's operations
 - 5. Place result in register for caller
 - 6. Return to place of call

Register Usage

- \$a0 \$a3: arguments (reg's 4-7)
- \$v0, \$v1: result values (reg's 2 and 3)
- \$t0 \$t9: temporaries (reg's 8-15, 24, 25)
 - Can be overwritten by callee
- \$s0 \$s7: saved (reg's 16-23)
 - Must be saved/restored by callee
- \$gp: global pointer for static data (reg 28)
- \$sp: stack pointer (reg 29)
- \$fp: frame pointer (reg 30)
- \$ra: return address (reg 31)

Procedure Call Instructions

- Procedure call: jump and link jal ProcedureLabel
 - Address of following instruction put in \$ra
 - Jumps to target address
- Procedure return: jump register jr \$ra
 - Copies \$ra to program counter
 - Can also be used for computed jumps
 - e.g., for case/switch statements

Leaf Procedure Example

C code:

```
int leaf_example (int g, h, i, j)
{ int f;
    f = (g + h) - (i + j);
    return f;
}
```

- Arguments g, ..., j in \$a0, ..., \$a3
- f in \$s0 (hence, need to save \$s0 on stack)
- Result in \$v0

Leaf Procedure Example

MIPS code:

<pre>leaf_example:</pre>									
addi	\$sp,	\$sp,	-4						
SW	\$s0,	0(\$sp	o)						
add	\$t0,	\$a0,	\$a1						
add	\$t1,	\$a2,	\$a3						
sub	\$s0,	\$t0,	\$t1						
add	\$v0,	\$s0,	\$zero						
٦w	\$s0,	0(\$sp	o)						
addi	\$sp,	\$sp,	4						
jr	\$ra								

Save \$s0 on stack

Procedure body

Result

Restore \$s0

Return

Non-Leaf Procedures

- Procedures that call other procedures
- For nested call, caller needs to save on the stack:
 - Its return address
 - Any arguments and temporaries needed after the call
- Restore from the stack after the call

Non-Leaf Procedure Example

C code:

```
int fact (int n)
{
  if (n < 1) return 1;
  else return n * fact(n - 1);
}</pre>
```


- Argument n in \$a0
- Result in \$v0

Non-Leaf Procedure Example

MIPS code:

```
fact:
   addi $sp, $sp, -8
    sw $ra, 4($sp)
    sw $a0, 0($sp)
    slti $t0, $a0, 1
    beq $t0, $zero, L1
   addi $v0, $zero, 1
   addi $sp, $sp, 8
    jr $ra
L1: addi $a0, $a0, -1
       fact
    jal
    lw $a0, 0($sp)
    lw $ra, 4($sp)
    addi $sp, $sp, 8
   mul $v0, $a0, $v0
         $ra
    jr
```


Local Data on the Stack



- Local data allocated by callee
 - e.g., C automatic variables
- Procedure frame (activation record)
 - Used by some compilers to manage stack storage

Memory Layout

- Text: program code
- Static data: global variables
 - e.g., static variables in C, constant arrays and strings
 - \$gp initialized to address allowing ±offsets into this segment
- Dynamic data: heap
 - E.g., malloc in C, new in Java
- Stack: automatic storage



Character Data

- Byte-encoded character sets
 - ASCII: 128 characters
 - 95 graphic, 33 control
 - Latin-1: 256 characters
 - ASCII, +96 more graphic characters
- Unicode: 32-bit character set
 - Used in Java, C++ wide characters, ...
 - Most of the world's alphabets, plus symbols
 - UTF-8, UTF-16: variable-length encodings

Byte/Halfword Operations

- Could use bitwise operations
- MIPS byte/halfword load/store
 - String processing is a common case

```
lb rt, offset(rs) lh rt, offset(rs)
```

Sign extend to 32 bits in rt

```
lbu rt, offset(rs) lhu rt, offset(rs)
```

- Zero extend to 32 bits in rt
- sb rt, offset(rs) sh rt, offset(rs)
 - Store just rightmost byte/halfword

String Copy Example

- C code (naïve):
 - Null-terminated string

```
void strcpy (char x[], char y[])
{ int i;
    i = 0;
    while ((x[i]=y[i])!='\0')
        i += 1;
}
```

- Addresses of x, y in \$a0, \$a1
- i in \$s0

String Copy Example

MIPS code:

```
strcpy:
   addi $sp, $sp, -4
    sw $s0, 0($sp)
    add $s0, $zero, $zero
L1: add $t1, $s0, $a1
   1bu $t2, 0($t1)
   add $t3, $s0, $a0
    sb $t2, 0($t3)
    beq $t2, $zero, L2
    addi $s0, $s0, 1
        L1
L2: lw $s0, 0($sp)
   addi $sp, $sp, 4
        $ra
    jr
```

Quick Test

- Types are associated with declaration in C (normally), but are associated with instructions (operators) in MIPS32.
- Since there are only 32 registers, we can't write MIPS32 for C expressions that contain > 32 vars.
- If p (stored in \$9) were a pointer to an array of ints, then p++; would be addi \$9 \$9 1
- add \$10, \$11,4(\$12)is valid in MIPS32
- can byte address 8GB of memory with an MIPS32 word
- imm must be multiple of 4 for lw \$10,imm(\$10) to be valid

Quick Test

What's in \$12?

```
addi $11,$0,0x83F5
sw $11,0($5)
lb $12,1($5)
```

Quick Test

(1)We want to translate *x=*y into MIPS (x,y ptrs stored in \$s0,\$s1)

```
(2) int x = 5;

*p =*p + x + 10;

assume $s0 holds p; $s1 is x
```


lw t0, 0(\$s1) sw t0, 0(\$s0) addi \$\$1, \$0, 5 lw \$t0, 0(\$\$0) add \$t0, \$t0, \$\$1 addi \$t0, \$t0, 10 sw \$t0, 0(\$\$0)

32-bit Constants

- Most constants are small
 - 16-bit immediate is sufficient
- For the occasional 32-bit constant lui rt, constant
 - Copies 16-bit constant to left 16 bits of rt
 - Clears right 16 bits of rt to 0

Branch Addressing

- Branch instructions specify
 - Opcode, two registers, target address
- Most branch targets are near branch
 - Forward or backward



- PC-relative addressing
 - Target address = PC + offset × 4
 - PC already incremented by 4 by this time

Jump Addressing

- Jump (j and jal) targets could be anywhere in text segment
 - Encode full address in instruction

ор	address
6 bits	26 bits

- (Pseudo)Direct jump addressing
 - Target address = $PC_{31...28}$: (address × 4)

Target Addressing Example

- Loop code from earlier example
 - Assume Loop at location 80000

Loop:	s11	\$t1,	\$s3,	2	80000	0	0	19	9	2	0	
	add	\$t1,	\$t1,	\$ s6	80004	0	9	22	9	0	32	
	٦w	\$t0,	0(\$t	1)	80008	35	9	8		0		
	bne	\$t0,	\$s5,	Exit	80012	5	8	21	?**************			
	addi	\$s3,	\$s3,	1	80016	8	19	19		1		
	j	Loop			80020	2	I E E E E E E E	***	?			
Exit:					80024							

Target Addressing Example

- Loop code from earlier example
 - Assume Loop at location 80000

Loop:	s11	\$t1,	\$s3,	2	80000	0	0	19	9	2	0
	add	\$t1,	\$t1,	\$ s6	80004	0	9	22	9	0	32
	٦w	\$t0,	0(\$t	1)	80008	35	9	8	0		
	bne	\$t0,	\$s5,	Exit	80012	5	8.	21	2		
	addi	\$s3,	\$s3,	1	80016	8	19	19	A N N N N N N N N N N N N N N N N N N N	1	
	j	Loop			80020	2	20000				
Exit:					80024						


Branching Far Away

- If branch target is too far to encode with 16-bit offset, assembler rewrites the code
- Example

```
beq $s0,$s1, L1

↓
bne $s0,$s1, L2
j L1
L2: ...
```

Addressing Mode Summary



Chapter 2 — Instructions: Language of the Computer — 65

关于PC寻址的几个问题

- 1、如果代码移动了,分支字段的值会改变吗?
- 2、如果目标地址与分支地址相差>215,怎么办?
- 3、我们为什么需要多种寻址方式?一个可以吗?
- 4、如果确实需要一个32位转移地址,怎么办?
- 5、把A和B两个C语言程序分别编译,然后合成一个 执行程序, Jump和Branch指令都不需要变化吗?

Synchronization

- Two processors sharing an area of memory
 - P1 writes, then P2 reads
 - Data race if P1 and P2 don't synchronize
 - Result depends of order of accesses
- Hardware support required
 - Atomic read/write memory operation
 - No other access to the location allowed between the read and write
- Could be a single instruction
 - E.g., atomic swap of register

 memory
 - Or an atomic pair of instructions

Synchronization in MIPS

- Load linked: 11 rt, offset(rs)
- Store conditional: sc rt, offset(rs)
 - Succeeds if location not changed since the 11
 - Returns 1 in rt
 - Fails if location is changed
 - Returns 0 in rt
- Example: atomic swap (to test/set lock variable)

C Sort Example

- Illustrates use of assembly instructions for a C bubble sort function
- Swap procedure (leaf)
 void swap(int v[], int k)
 {
 int temp;
 temp = v[k];
 v[k] = v[k+1];
 v[k+1] = temp;
 }
 - v in \$a0, k in \$a1, temp in \$t0

The Procedure Swap

The Sort Procedure in C

```
Non-leaf (calls swap)
  void sort (int v[], int n)
    int i, j;
    for (i = 0; i < n; i += 1) {
       for (j = i - 1;
            j >= 0 \& v[j] > v[j + 1];
            i -= 1) {
         swap(v,j);
v in $a0, n in $a1, i in $s0, j in $s1
```

The Procedure Body


```
move $s2, $a0
                        # save $a0 into $s2
                                                             Move
       move $s3, $a1  # save $a1 into $s3
                                                             params
       move $s0, $zero # i = 0
                                                            Outer loop
for1tst: slt $t0, $s0, $s3 # $t0 = 0 if $s0 \ge $s3 (i \ge n)
        beq t0, zero, exit1 # go to exit1 if s0 \ge s3 (i \ge n)
        addi $$1, $$0, -1  # j = i - 1
for2tst: slti t0, s1, 0 # t0 = 1 if s1 < 0 (j < 0)
       bne t0, zero, exit2 # go to exit2 if s1 < 0 (j < 0)
       sll $t1, $s1, 2 # $t1 = j * 4
                                                             Inner loop
        add $t2, $s2, $t1 # $t2 = v + (j * 4)
       1w $t3, 0($t2) # $t3 = v[i]
       1w $t4, 4($t2) # $t4 = v[j + 1]
        \$1t \$t0, \$t4, \$t3  # \$t0 = 0 if \$t4 \ge \$t3
       beq t0, zero, exit2 # go to exit2 if t4 \ge t3
       move $a0, $s2  # 1st param of swap is v (old $a0)
                                                            Pass
       move $a1, $s1  # 2nd param of swap is j
                                                             params
                                                             & call
        jal swap # call swap procedure
        addi $s1, $s1, -1 # j -= 1
                                                            Inner loop
                     # jump to test of inner loop
        i for2tst
exit2:
       addi $s0, $s0, 1  # i += 1
                                                            Outer loop
        i for1tst
                             # jump to test of outer loop
```

The Full Procedure

```
addi $sp,$sp, -20
                            # make room on stack for 5 registers
sort:
        sw $ra, 16($sp)
                            # save $ra on stack
        sw $s3,12($sp) # save $s3 on stack
        sw $s2, 8($sp) # save $s2 on stack
        sw $s1, 4($sp) # save $s1 on stack
        sw $s0, 0(\$sp)
                            # save $s0 on stack
                            # procedure body
exit1:
       lw $s0, 0($sp)
                            # restore $s0 from stack
        lw $s1, 4($sp)
                            # restore $s1 from stack
        lw $s2, 8($sp)  # restore $s2 from stack
        lw $s3,12($sp) # restore $s3 from stack
        lw $ra,16($sp) # restore $ra from stack
        addi $sp,$sp, 20
                            # restore stack pointer
        jr $ra
                            # return to calling routine
```


Effect of Compiler Optimization





Chapter 2 — Instructions: Language of the Computer — 74

Effect of Language and Algorithm



Chapter 2 — Instructions: Language of the Computer — 75

Lessons Learnt

- Instruction count and CPI are not good performance indicators in isolation
- Compiler optimizations are sensitive to the algorithm
- Java/JIT compiled code is significantly faster than JVM interpreted
 - Comparable to optimized C in some cases
- Nothing can fix a dumb algorithm!

2.14 Arrays vs. Pointers

- Array indexing involves
 - Multiplying index by element size
 - Adding to array base address
- Pointers correspond directly to memory addresses
 - Can avoid indexing complexity

Example: Clearing an Array

```
clear1(int array[], int size) {
                                        clear2(int *array, int size) {
 int i;
                                          int *p;
 for (i = 0; i < size; i += 1)
                                          for (p = \&array[0]; p < \&array[size];
   array[i] = 0;
                                               p = p + 1
                                            *p = 0:
                                        }
      move t0,\zero # i = 0
                                               move t0,a0 # p = & array[0]
loop1: sll $t1,$t0,2  # $t1 = i * 4
                                               $11 $t1,$a1,2  # $t1 = size * 4
      add $t2,$a0,$t1 # $t2 =
                                               add t2,a0,t1 # t2 =
                       # &array[i]
                                                                   &array[size]
      sw zero, 0(t2) # array[i] = 0
                                        loop2: sw zero_0(t0) # Memory[p] = 0
                                               addi t0,t0,4 # p = p + 4
      addi $t0,$t0,1 # i = i + 1
      s1t $t3.$t0.$a1 # $t3 =
                                               s1t $t3.$t0.$t2 # $t3 =
                       # (i < size)
                                                               #(p<&array[size])
      bne $t3,$zero,loop1 # if (...)
                                               bne $t3,$zero,loop2 # if (...)
                          # goto loop1
                                                                   # goto loop2
```

Comparison of Array vs. Ptr


- Multiply "strength reduced" to shift
- Array version requires shift to be inside loop
 - Part of index calculation for incremented i
 - cf. incrementing pointer
- Compiler can achieve same effect as manual use of pointers
 - Induction variable elimination
 - Better to make program clearer and safer

Fallacies

- Powerful instruction ⇒ higher performance
 - Fewer instructions required
 - But complex instructions are hard to implement
 - May slow down all instructions, including simple ones
 - Compilers are good at making fast code from simple instructions
- Use assembly code for high performance
 - But modern compilers are better at dealing with modern processors
 - More lines of code ⇒ more errors and less productivity

Fallacies

- Backward compatibility ⇒ instruction set doesn't change
 - But they do accrete more instructions



Pitfalls

- Sequential words are not at sequential addresses
 - Increment by 4, not by 1!
- Keeping a pointer to an automatic variable after procedure returns
 - e.g., passing pointer back via an argument
 - Pointer becomes invalid when stack popped

Concluding Remarks

- Design principles
 - 1. Simplicity favors regularity
 - 2. Smaller is faster
 - 3. Make the common case fast
 - 4. Good design demands good compromises
- Layers of software/hardware
 - Compiler, assembler, hardware
- MIPS: typical of RISC ISAs
 - c.f. x86

Concluding Remarks

- Measure MIPS instruction executions in benchmark programs
 - Consider making the common case fast
 - Consider compromises

Instruction class	MIPS examples	SPEC2006 Int	SPEC2006 FP
Arithmetic	add, sub, addi	16%	48%
Data transfer	lw, sw, lb, lbu, lh, lhu, sb, lui	35%	36%
Logical	and, or, nor, andi, ori, sll, srl	12%	4%
Cond. Branch	beq, bne, slt, slti, sltiu	34%	8%
Jump	j, jr, jal	2%	0%

Homework

- 2.4, 2.5
- 2.25
- **2.39**, 2.40, 2.41, 2.42
- **2.43**, 2.44

X86与MIPS32过程调用的异同比较