TIE

SIDE R

K

K

K

P

ARM

sensor here

trigger

sling

K

K

P

K

K

FRONT

pin

TIE

pin

TROUGH GUIDE

TROUGH GUIDE

P

FRONT

WALL

SIDE L

K

P

K

P

FRONT

45

WALL

FLOOR

P

30

P

PULL

15

P

basket

BALL

basket

BALL

6

SENSOR

60

TRIGGER

FRONT

throwing direction ^

BASE

4ea

trigger

4ea