

★ O N T A P ★

HOW TO TAP A KEYKEG

SET-UP GUIDE · 20L KEYKEG · AIR / CO₂

1

CHILL IT FIRST

Keep the keg **cold** before **tapping**. Store cold, serve cold — a warm keg pours all foam.

2

STAND IT UP & UNCAP

Set the KeyKeg **upright** on a stable surface. Pull off the cap and check the spear valve is clean.

3

FIT THE COUPLER

Push the **KeyKeg coupler** straight down onto the valve and **lock the lever** until it clicks tight.

4

CONNECT GAS & BEER LINE

Attach the **gas / air line** (drives the bag) and the **beverage line** to the dispense outlet.

5

SET THE PRESSURE

Open the gas and set the regulator to the **serving pressure** (approx. 2–2.5 bar). Do not over-pressurise.

6

POUR & ENJOY

Open the tap and pour. When empty: **close gas, vent, disconnect**, then recycle the KeyKeg.



KeyKeg is pressurised. Never exceed the rated working pressure, keep the keg upright while connected, and release gas before disconnecting.

