### Microcontroller: A key contributor in ES\* (from here: session 5)

#### Amir Mahdi Hosseini Monazzah

Room 332, School of Computer Engineering, Iran University of Science and Technology, Tehran, Iran.

monazzah@iust.ac.ir

Fall 2024

<sup>\*</sup> Parts of slides are adopted from Prof. Prabal Dutta lectures, Department of Electrical Engineering and Computer Science. University of Michigan

#### Outline

- Different types of processors
  - Characteristics
- How dose ES affect the processor architecture?
  - ES tasks
  - Architectural differences

#### **Processors**

- Execute programs
  - Serial execution of instructions
  - Simple, universal
- Instruction execution engine: fetch/execute cycle
  - Flow of control determined by modifications to program counter
  - Instruction classes:
    - Data: move, arithmetic and logical operations
    - Control: branch, loop, subroutine call
    - Interface: load, store from external memory

# Processors (cont.)

- Traditional architecture goal: Performance
  - Caches
  - Branch prediction
  - Multiple/Out of Order (OoO) issue



#### **Processors**

- Processor is a universal computing engine
  - Program can compute arbitrary functions
  - Use a processor for simple/specific tasks
- Advantages:
  - High-level language
  - Compilers/debuggers
  - Arbitrary control structures
  - Arbitrary data structures
- Disadvantages:
  - Cost / Size




## Embedded processor (microcontroller)

- Processor optimized for low cost
  - No cache
  - Small memory
  - No disks
  - 4 bit/8 bit/16 bit
  - No FP
  - No complicated datapath
  - Multicycle instruction interpretation
  - Simple/no operating system
  - Programs are static



## Embedded processor (microcontroller)

- Low performance
  - 1 MIPS is enough if 1 ms is the time scale
- Integrate on a single chip



#### General-purpose processor

- Programmed by user
- New applications are developed routinely
- General-purpose
  - Must handle a wide ranging variety of applications
- Interacts with environment through memory
  - All devices communicate through memory
  - DMA operations between disk and I/O devices
  - Dual-ported memory (as for display screen)
- Oblivious to passage of time (takes all the time it needs)




#### Embedded processors


- Programmed once by manufacturer of system
- Executes a single program (or a limited suite) with few parameters
- Task-specific
  - Can be optimized for specific application
- Interacts with environment in many ways
  - Direct sensing and control of signal wires
  - Communication protocols to environment and other devices
  - Real-time interactions and constraints



## Typical general-purpose architecture



# Typical Task-Specific Architecture



### How does ES change things?

- Sense and control of environment
  - Processor must be able to "read" and "write" individual signal wires
  - Controls I/O devices directly
- Program has to do everything
  - Sense input bits
  - Change output bits
  - Do computation
  - Measure time
    - Many applications require precise spacing of events

## How does ES change things?

- Problems with this
  - Precise timing?
  - Too slow?

# Connecting to inputs/outputs

- Map external wire to a bit of a variable (memory or register)
  - if (a & 1) . . . X = 2

#### In-class assignment (from here: session 6)

- Write a C program that measures the acceleration
  - Accelerometer output has one wire!
    - Acceleration coded as the duty cycle
    - Pulse-width/cycle-length
      - » 20% = -128
      - > 80% = +127
    - Cycle time = 10ms
  - Input is low-order bit of variable X
  - Assign result to variable Z
  - Make up whatever you need

#### In-class assignment: answer

Answer by Mr. Arshia Moghimi (SUT)

```
#include <stdio.h>
      #include <stdlib.h>
      #include <sys/time.h>
      #define CYCLE LENGTH 10
    = int main() {
          int X=0, Z=0, counter = 0, counter1 = 0;
          float step = 256 / 0.6;
          struct timeval tv;
          gettimeofday(&tv, NULL);
          unsigned long start = 1000000 * tv.tv sec + tv.tv usec; // time in microsecond
          while (1) {
              scanf ("%d", &X);
16
              counter++;
              counter1 += (X & 1);
              gettimeofday(&tv. NULL);
              if (1000000 * tv.tv_sec + tv.tv_usec - start >= 1000000 * CYCLE_LENGTH) {
                  Z = (1.0 * counter1 / counter - 0.2) * step - 128;
                  printf("acceleration = %d\n", Z);
                  gettimeofday(&tv, NULL);
                  start = 10000000 * tv.tv sec + tv.tv usec;
                  counter1 = 0;
                  counter = 0:
          return 0:
```


#### In-class assignment: answer

Answer by Mr. Mohammad Javad Mirshekari Haghighi (IUST)

```
#include <iostream
 using namespace std;
 char X = 1; // input port, update auto
 char OUT = 0; // output port, acceleration
 char MAX OUT = 127; // 'b01111111
 struct TimePoint
      int ms: // time in milisecond
L): // sample time struct
FilmePoint time() (
     // return current time as TimePoint
     struct TimePoint now;
     return now;
Fint main() (
      struct TimePoint start 1://
      struct TimePoint end 1; //
                                                    __ positive pulse
      struct TimePoint start_0://___
                                                      negative pulse
      struct TimePoint end 0://
     bool value = false; // value of the pulse
      bool is high = false; // true, if value is true
      float duty_cycle = 0; // duty cycle
      while(true) ( // read input port continuously
         // get pulse value
         value = (X >> 0) & 0x1;
         // set, update duty cycle
         if (value - true && !is high) (
             is high = true;
             start 1 = time();
             end 0 = start 1;
         else if (value == false && is_high) {
             is high = false;
             end 1 = time();
             start 0 = end 1;
         // calculate duty cycle
         duty cycle = (end 1.ms - start 1.ms) / (end 0.ms - start 0.ms) + (end 1.ms - start 1.ms);
         // set OUT, according to the range [0.2, 0.8] of duty cycle
         OUT = (MAX_OUT * (duty_cycle - 0.8)) / 0.8;
      return 0/
```


### Memory-mapped inputs

- Map external wire to a bit in the address space of the processor
- External register buffers values coming from environment
  - Map register into address space
  - Decoder needed to select register for reading
  - Output enable (OE) so that many registers can use the same data bus



### Memory-mapped outputs

- Map external wire to a bit in the address space of the processor
- Connect output of memory-mapped register to environment
  - Map register into address space
  - Decoder need to select register for writing (holds value indefinitely)
  - Input enable (EN) so that many registers can use the same data bus



#### On-chip support for communication (up to here: session 5)

- Processor may not be fast enough
  - Offload standard protocols
- Built-in device drivers
  - For common communication protocols
  - Serial-line protocols most common as they require few pins
    - e.g. RS-232 serial interface Special registers in memory space for interaction
- Increases level of integration
  - Pull external devices on-chip
    - Must be standard
  - Eliminate need for shared memory or system bus



### Measuring time

- Keep track of detailed timing of each instruction's execution
  - Highly dependent on code
  - Hard to use with compilers
  - Not enough control over code generation
  - Interactions with caches/instruction-buffers
- Loops to implement delays
  - Keep track of time in counters
  - Keeps processor busy counting and not doing other useful things

## Measuring time (cont.)

- Real-time clock
  - Sample at different points in the program
  - Simple difference to measure time delay



#### **Timers**


- Separate and parallel counting unit(s)
  - Co-processor to microprocessor
  - Does not require microprocessor intervention
  - In simple case, like a real-time clock
    - Set timer/read timer
  - Interrupt generated when expired
- More interesting timer units
  - Self reloading timers for regular interrupts
  - Pre-scaling for measuring larger times
  - Started by external events

### Timer: Input/output events


- Input capture
  - Record precise time when input event occurred
  - To be used in later handling of event
- Output compare
  - Set output to happen at a point in the future
  - Reactive outputs set output to happen a pre-defined time after some input
  - Processor can go on to do other things in the meantime

#### Microprocessor vs microcontroller

 What is the main difference between microcontroller and microprocessor?



Microcontroller: CPU on a single chip.



#### What is a microcontroller?

- A microcontroller (MCU for microcontroller unit, or UC for μ-controller)
  - A small computer on a single integrated circuit.
  - It is similar to, but less sophisticated than, a system on a chip (SoC)
    - SoC may include a microcontroller as one of its components.



## What is a microcontroller? (cont.)

- A microcontroller contains
  - One or more CPUs (processor cores)
  - Memory
    - Ferroelectric RAM
    - NOR flash
    - OTP ROM
    - RAM
  - Programmable input/output peripherals.
- Microcontrollers are designed for embedded applications



