Panasonic®

取扱説明書

ルームエアコン(家庭用)






室内ユニット品番							
CS-EX223D CS-EX363D CS-EX633D2	CS-EX253D CS-EX403D2 CS-EX713D2	CS-EX283D CS-EX563D2					
CS-E223DZ CS-E403D2Z	CS-E253DZ CS-E563D2Z	CS-E283DZ CS-E633D2Z					
CS-223DEE CS-363DEE CS-633DE2E	CS-253DEE CS-403DE2E CS-713DE2E	CS-283DEE CS-563DE2E					
CS-223DEX CS-363DEX CS-633DEX2	CS-253DEX CS-403DEX2 CS-713DEX2	CS-283DEX CS-563DEX2					
CS-223DEXE3 CS-403DEX2E3	CS-253DEXE3 CS-563DEX2E3	CS-283DEXE3					
CS-223DEXK CS-363DEXK CS-633DEX2K	CS-253DEXK CS-403DEX2K CS-713DEX2K	CS-283DEXK CS-563DEX2K					
室外ユニット品番	≰						

至外ユーツト品番

CU-EXシリーズ CU-EDZシリーズ CU-DEEシリーズ CU-DEXシリーズ CU-DEXE3シリーズ CU-DEXKシリーズ



このたびは、パナソニック製品をお買い上げいただき、まことにありが とうございます。

- 取扱説明書をよくお読みのうえ、正しく安全にお使いください。
- で使用前に「安全上のご注意」(P.4~6)を必ずお読みください。
- 保証書は「お買い上げ日・販売店名」などの記入を確かめ、 取扱説明書、据付工事説明書とともに大切に保管してください。
- 商品の品番は、本体の品番表示(P.66)と仕様(P.53~54)でご確認ください。

パナソニックの会員サイト

「CLUB Panasonic」で「商品登録」をお願いします 詳しくは裏表紙をご覧ください



エアフィルターに付いたほこりは 自動でお掃除しますが、 「ダストボックス方式」で設置工事を された場合は、お手入れが必要です。 →P.32

ナノイーXで 部屋の空気をきれいに!(P.39)



もくじ

									^	°-	_	シ	;
•	•	•		•	•				•			4	
												7	
•	•	•	•		•	•	•	•	•			8	
•	•	•	•	•	•	•	•	•	•		1	0	
											1	1	
•		•			•	•					1	2	
•								•	•		1	3	
•	•	•	•	•	•	•	•	•	•		1	4	
•	•	•	•	•	•	•	•	•	•			5	
		·	•	·	•	•	•	•	•		1	6	
				•							1	8	
												3	
											2	a	
I	3	#									_	J	
											2	2	
				_					_		J	_	
											_		
•	•	•	•	•	•	•	•	•	•			6	
•	•	•	•	•	•	•	•	•	•		<u>ح</u>	7	
	•	•	•			•		•			3	8	
•											3	9	
•	•		•			•	•	•	•		4		
•	•	•	•	•	•	•	•	•			4	3	
•	•			•	•		•	•	•		4	4	
•	•	•	•			•	•	•	•		4		
•	•		•			•					5	1	

	111	1	
		A	
1			

エアコン操作をスマートフォンで!(P.18)



●パナソニックの加湿空気清浄機と連動して、暖房運転時 に加湿することもできます。(P.11)

必ずお読みください	
安全上のご注意	4
使用上のお願い	7
各部の名前と役割・付属品・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	8
リモコンを準備する	10
使いかた	
運転する	11
AI快適機能で自動調節する・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	12
風向・風量を調節する・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	13
部屋のにおいを軽減する	14
停止中に室温みはりを使う・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	15
タイマーを予約する	16
●おやすみ切タイマー ●切タイマー/入タイマー	10
エオリア アプリを使う	18
お買い上げ時の設定を変更する(メニュー) …	23
キレイにお使いいただくために	
	29
●おそうじタイマー ●手動おそうじ運転	
●おでかけクリーン ●カビみはり お手入れ ····································	20
	32
もっと詳しく知りたいとき	
自動・冷房切換・除湿切換について	36
暖房について	37
●霜取り運転	20
「AI快適」「AI快適エコナビ」について ··········	38
「ナノイーX」について ······	39
おそうじ機能について・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	40
風向・風量自動時の風の動き	43
必要なとき	
よくあるお問い合わせ	44
故障かな?	46
タイマーランプが点滅するときは	51
こんなときは	52
長期使用製品安全表示制度に基づく本体表示について …	52
仕様	53
著作権など	55
保証とアフターサービス・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	66 ±•π
ご相談窓口/商品登録 裏	

安全上のご注意①

必ずお守りください

人への危害、財産の損害を防止するため、必ずお守りいただくことを説明しています。

■ 誤った使い方をしたときに生じる危害や損害の程度を区分して、説明しています。

⚠ 警告

「死亡や重傷を負うおそれがある 内容 | です。 ⚠ 注意

「軽傷を負うことや、財産の損害が 発生するおそれがある内容」です。

■ お守りいただく内容を次の図記号で説明しています。



してはいけない内容(禁止事項)です。



実行しなければならない内容(強制事項)です。



火災や感電、 大けがを防ぐために

▲ 警告

異常・故障時



● すぐに使用を中止し、電源プラグを抜く またはブレーカーを切る

(発煙・発火・感電の原因)

異常・故障例

- ブレーカーがたびたび切れる。
- こげ臭いにおいがする。
- 電源のプラグ・コードが異常に熱くなる。
- 異常な音がする。ガタガタと振動する。
- タイマーランプが点滅する。
- 室内ユニットから水が漏れる。
- ・風量が調節できない。
- ・運転しても、すぐに停止する。
- ・停止ボタンを数回押しても風が止まらない。

すぐ、販売店に点検・修理を依頼してください。 タイマーランプが点滅するときは、P.51の内容にしたがって 対応してください。

電源のプラグ・コード —



- ●途中で接続したり、延長コードの使用、 タコ足配線をしない
- 東ねたり、無理に 曲げたりしない



- ●ぬれた手で 抜き差ししない
- ●運転中にプラグを抜かない
- ■コードを持って抜かない

(感電や、放電・絶縁不良・断線などによる発熱・ 発火・火災の原因)



- ●破損した場合は、使用せず販売店に 修理を依頼する
- 必ず守る ●プラグは、根元まで確実に差し込む
 - 定期的にプラグのほこりを 乾いた布でふき取る

(接触不良・絶縁不良による 発熱・発火・火災や、接触不良 による感電の原因)



お手入れ時



- お客様自身で、工具を使った 分解掃除、内部洗浄はしない (水漏れや発煙、発火の原因)
 - ・お買い上げの販売店または パナソニック修理ご相談窓口 にご相談ください。



運転時や取り扱い時



- リモコンを乳幼児の手の届く所に置かない (乾電池を取り出し、誤飲するおそれ)
- リモコンの乾電池の⊕ ⊝を逆に入れない (ショートによる発火や液漏れの原因)
- ●室内ユニットの左右風向ルーバーより奥 に、指や棒などを入れない
- ■室外ユニットの吹出口に、指や棒などを 入れない

(内部でファンが高速回転 しているため、けがをする 原因)



- ●長時間、冷風を体に直接当てたり、 体を冷やしすぎたりしない
 - (体調不良の原因)
 - ・特に、ご自身で調節できない乳幼児や身体の 不自由な方・高齢者などにはご注意ください。




- ■室外ユニットの上に乗ったり、 物を載せたりしない
 - (転落や落下の原因)
 - 特にベランダなど高い場所 に設置の場合はご注意 ください。



▲ 警告

室内ユニット



無線装置



● 室内ユニットに医療機器や自動制御機器 (自動ドア、火災警報器など)を近づけない (室内ユニットからの電波が機器に影響を及ぼ すことがあり、誤動作による事故の原因)



● 心臓ペースメーカーを装着している方は、 装着部を室内ユニットから15 cm以上離す (室内ユニットからの電波による誤作動の原因)

据え付けや移設・修理時

必ずお買い上げの販売店 <u>または専門業</u>者に依頼してください



販売店や専門業者に次のことを確認する

- エアコン専用の電源コンセントおよび ブレーカーが単独 で使われていること (火災の原因)
- ▼アースや漏電しゃ断器が設置されていること (感電の原因)
- ●冷媒が漏れていないこと (冷媒が火気に触れると、有毒ガスの発生や火 災の原因)
 - ・ 通常は漏れませんが、冷えない・暖まらない 場合は漏れている可能性があるので、販売店 にご相談ください。
- ■指定冷媒が使用されていること (指定以外の冷媒を使用すると、機器の故障や破裂、けがなどの原因)

- 本体に付属のリモコン以外 で遠隔操作をするとき

宅外やエアコン設置場所以外の部屋から操作するときは、エアコンやその周辺、在室する人などの状態を確認することができません。また、無線通信を利用するため通信環境や使用状況、ネットワーク障害などにより、遠隔操作がご利用できない場合があります。場合によっては、人などが死亡・重傷を負ったり、財産の損害が発生したりするおそれがあります。事前に安全を十分確認してお使いください。



事前に以下の内容を確認しておく

- ●電源プラグが確実に差し込まれていること。プラグにほこりがたまっていないこと (接触不良や絶縁不良によるプラグからの発熱や発火、火災の原因)
- ●他の人が設定したタイマー予約などの 設定状況 (思わぬ運転や停止により、体調をくずす原因。

動植物に悪影響を及ぼす原因)

- ■エアコンに異常がないこと。風の変化があっても、人や部屋に悪影響がでないこと (飛びやすい物がない等)「風により物が落下」、水がかけが、家財活場の
 - (風により物が落下し、火災やけが、家財汚損の 原因)
- 遠隔操作ができなくても、人や財産などに 悪影響がでないこと (運転や停止ができず、体調をくずす原因。 動植物に悪影響を及ぼす原因)
 - ・操作が必要な場合は、付属のリモコンで操作してください。
 - ・乳幼児や身体の不自由な方・高齢者などご自 身でリモコン操作ができない方のみで在室し ている場合は、ご利用にならないでください。

操作前・操作中に以下の内容を確認する

- 人がいることが分かっているときは、室外から運転や停止することを知らせておく (台などに乗っていた場合、突然の運転や停止に驚いて落下・転倒の原因。また、急激な外気温・室温の変化等により、体調をくずす原因)
 - ・ 温度調節や停止は、付属のリモコンでも操作できます。
- こまめに設定内容や運転状況を確認する (急激な外気温・室温の変化等により、体調を くずす原因。動植物に悪影響を及ぼす原因)
 - ・操作が反映されなかった場合は、付属のUモ コンで操作してください。
 - エラーが表示されたときは、運転を停止し、 お買い上げの販売店にご相談ください。 エアコンが停止していることを再確認してく ださい。

安全上のご注意(2) 必ずお守りください



漏電やけがを 防ぎ、家財など を守るために

⚠ 注意

運転時や取り扱い時




- 落雷のおそれがあるときは、運転を停止し て、エアコンに触れない (感電の原因)
- 直接水洗いしたり、水の入った容器を 載せたりしない (水が中に入ると感電や発火の原因)
- 室内ユニット・室外ユニットのアルミ部分 に触らない (手を切る原因)
- 据付台を破損したままで使用しない (室外ユニットや据付台の落下・転倒の原因)
- 風を動植物に直接当てない
- ■室内ユニットの下に電気製品や家財などを 置かない

(水滴が落ちる場合があり、汚損や故障の原因) テレビやベッドなどを置かないでください。

- 湿度が高いとき(80 %以上)に、窓や戸を 開けたままで冷房や除湿を長時間運転しない (室内ユニットから水滴が落ちて家財などを汚 損する原因)
 - ・特に雨の日や梅雨の時期にはご注意ください。
- 床などにワックスをかけるときは運転しない。 (内部にワックス成分が付着

すると、結露による水漏れや 水飛びの原因)



ワックスをかけた後は窓や ドアを開けて十分に換気後、 運転してください。

●ドレンホースは排水を確実にし、 先端をふさがない

(室内ユニットから水漏れする原因)

- ・虫や落ち葉などが詰まらないようご注意ください。
- 精密機器や食品、動植物、美術品の保存な どに使わない

(品質低下などの原因)




- 長期間使用しないときは電源プラグを抜く (ほこりによる発熱や発火の原因)
- 必ず守る 燃焼器具は風が直接当たらない場所で 使用する

(不完全燃焼の原因)

● 燃焼器具と一緒に運転するときはこまめに 換気する

(酸素不足による頭痛などの原因)

このエアコンで換気はできません。



●不安定な台に乗らない



必ず守る

● 運転を停止し、電源プラグを抜く (ファンが高速回転しているため、 けがをする原因)


前面パネルの水洗い後は、水気を十分 ふき取る

(漏電の原因)




据え付け・移設時

可燃性ガスの漏れるおそれのない場所に、 据え付けされていることを確認する (万一ガスが漏れてユニットの周囲にたまると、 発火の原因)



使用上のお願い





リモコンは 室内ユニットの 受信部に向けて!

操作は、室内ユニット正面から 7 m以内で行ってください。


●受信は音でお知らせします。

受信音	お知らせしている内容
ピッ	運転開始や設定、設定の取り消し
ピッピッ	設定温度の上限または下限
ピー	停止

●リモコンホルダー(付属品)

リモコンを壁などに取り付けることができます。

取り付け場所で、リモコンの運転開始ボタンを押し、受信できることを確認してから取り付けてください。 取り付け後、部屋の環境変化などによって、受信しないことがあります。



✓ まず、室内・室外ユニット周辺の確認を!

〈室内ユニット〉

- □ 吸込口・吹出口付近がタンスなどでふさがれていませんか?
- □ 火災警報器は吹出口から 1.5 m以上離れていますか?
- □ テレビやラジオは、1 m以上離れていますか? (映像の乱れ、雑音の原因)

〈リモコン〉

- □ 他のリモコンのボタンが押されていませんか? (リモコンラックなどに当たって押されていると、 混信して受信できない原因)
- □ 複数台のエアコンを使うときは、混信を防ぐ 設定にできます。(P.24)



〈室外ユニット〉

- □ 吸込口や吹出口が積雪や植木鉢などでふさがれていませんか?
- □ ドレンホースの先端(排水口)がふさがれていませんか? また、排水したときに、動植物に影響がでませんか?
- □ 吹出口からの風が、周囲の迷惑になったり動植物に直接当たったりしませんか?

※スペースを確保してください。

- ●油煙の多い場所への設置は避けてください。 (調理場や機械工場など)
- ●積雪の多い地域では、防雪対策をおすすめします。お買い上げの販売店へご相談ください。

リモコンの乾電池について

■ 乾電池は

- ●寿命は約1年です。消耗すると、受信しにくくなったり、リモコンの表示が薄くなったり、バックライトが暗くなったりします。
- ●長期間使わないときは、取り出してください。 (液漏れ防止のため)
- ●乾電池が切れたときは、本体で応急運転が できます。(P.52)


■ 乾電池を交換するときは

- ●単4形アルカリ乾電池(LRO3タイプ)を2本同時に交換してください。(マンガン乾電池では、使用期間が短くなります)
- ●充電式電池(Ni-Cd、ニッケル水素など)は使わないでください。(サイズ、形、性能の一部が異なるため)
- ●交換後、時刻を合わせてください。(P.10)


各部の名前と役割・付属品

室内ユニット

■この製品は、遠隔操作をするための 無線装置を搭載しています。




〈前面パネルを開けたとき〉



表示部(本体ランプ) 運転や設定の状況をお知らせ。本体に付属のリモコン以外で遠隔操作をしたときにも 点灯・点滅することがあります。

表示	ランプ名	色	状態	お知らせしている内容
d١	少運転		点灯	冷房切換・暖房・除湿切換・自動・ナノイーX送風運転中(P.11)
0			点滅	自動・暖房運転開始時、または霜取り運転中(P.36、37)
\Box	タイマー		点灯	おやすみ切タイマー・切タイマー/入タイマー予約中(P.16、17)
•			点滅	本体の異常(P.51)
ۥ	ナノイーX	青	点灯	ナノイーX発生中(P.11、14、30、39、42)
無線LAN		青	点灯	無線LANの通信ができる状態(P.18~22)
			点滅	無線接続の交信中
每	な おそうじ		点灯	フィルターおそうじ・内部クリーン運転中(P.30、40~42)
L *	ال عادة	橙	点滅	ダストボックスのお手入れ時期をお知らせ(P.32、33)

室外ユニット



品番によって、形状・大きさが異なります。


付属品

- リモコン
 - …表示部の保護シート(傷付き防止用)をはが してからご使用ください。
- 単4形アルカリ乾電池(2本)
 - …最初に使用するために付属しています。 1年未満で消耗することがあります。
- リモコンホルダー
- リモコンホルダー 取付用ネジ(2本)





リモコン


〈ふたを開けたとき〉



リモコンを準備する







運転する


詳しくは ▶ P.36、37、39



■ 運転を止めるとき

停止

停止



■ 設定温度を変えるとき

○自動

温度

- 設定範囲
 - 冷房・しっとり冷房・暖房・冷房除湿・自動: 16.0 ℃~30.0 ℃(0.5 ℃刻み) (結露の原因となるため、冷房・しっとり冷房は20℃以上で調節してください)

餔

- 除湿:「標準* |+1 ℃~「標準 |-3 ℃(1 ℃刻み) ※「標準」温度(快適と感じる温・湿度)まで自動調節します。
- ●衣類乾燥時は調節できません。

ナノイーX送風

冷房・暖房・除湿のいらない季節などにおすすめします。





…設定温度などに応じて、運転モード

を自動で選んで運転。

(冷房・暖房・冷房除湿のいずれか)

(青)

- ●停止中に押すとナノイーXを送風する運転ができます。
- ●ナノイーX送風運転時は、温度調節ができません。
- ●冷房などの運転中に押すと、ナノイーXの取り消し・設定ができます。



暖房運転時にパナソニックの加湿空気清浄機と連動し、自動で加湿を運転させ ることができます。ご利用には、初期設定が必要です。 初期設定や対象機種など詳しくは、


https://panasonic.jp/aircon/airpurifier link/howto.html




AI快適機能で自動調節する

詳しくは ▶ P.38

人が快適と感じるための情報を検知・学習・記憶し、温度をコントロールします。






「AI快適エコナビ」設定時

- ●「AI快適エコナビ」設定中に、風量調節でパワフルを設定したりパワフルの表示を通過したりすると(P.13)、「AI快適エコナビ」は取り消され「AI快適」になります。
- ●消費電力を抑える調節をするため、設定温度に到達するまで、時間がかかることがあります。


人が快適と感じるための情報



風向・風量を調節する

風向・風量自動時の風の動きは ▶ P.43





しずか設定時

■風量を抑えた静かな運転です。冷房感・暖房感が快適に得られるように、風量が やや強めになることがあります。


パワフル設定時

- ●冷房感・暖房感を強く感じる運転です。冷房感・暖房感が快適に得られるように、 風量が弱めになることがあります。
- ■温度調節は、リモコンの表示より冷房・冷房除湿で低め、暖房で高めになります。

部屋のにおいを軽減する

部屋のにおいを軽減する運転(においケア運転)を行い、自動で終了します。 来客前など、においが気になるときにおすすめします。





▮冷房などの運転中に、においケア運転

冷房などの運転を続けながら、においケア運転をします。

運転内容

- ●冷房・しっとり冷房・冷房除湿運転中(室温が高めのとき) 弱い風を天井に向けます。(運転時間:約30分間)
 - •ナノイーXを取り消していても、においの軽減効果を得るために、においケア運転後も、約30分間は強制的にナノイーXを発生させます。
- ●冷房・しっとり冷房・冷房除湿運転中(室温が低めのとき)、除湿・衣類乾燥・暖房・ナノイーX送風運転中

強い風をスイングします。(運転時間:約30分間)

■ 元の運転に戻すとき

においケア を 1 回押し、

回押し、決定

を押すと、元の運転に戻ります。

/手動おそうじ/おでかけ

▮停止時に、においケア運転

運転内容

●室温が高めのとき

弱い風で冷房→ナノイー×送風→暖房→ナノイー×送風の順に上下風向ルーバーを 変化させながら運転します。(運転時間:約95分間)

強い風でスイングしながらナノイーX送風運転をします。(運転時間:約30分間)

■ 途中で止めるとき




お知らせ

- ■風向・風量は自動になります。
- ●においケア運転中は室温が上がったり、下がったりする ことがあります。
- ●ナノイーXは、取り消していても発生します。
- ●においケア運転中に切タイマー/入タイマー(P.17) の時刻になると、においケア運転の終了を待って 切タイマー/入タイマーが動作します。
- ●効果は、部屋の環境や使用状況によって異なります。

停止中に室温みはりを使う

停止中に部屋の温度などを検知し、自動で冷房または暖房(室温みはり運転)を開始したり、停止したりします。 室温が高くなりすぎたり、低くなりすぎたりするのを防ぎます。






■ 設定を取り消すとき

上記の手順で「室温みはり 無」に設定する。

運転条件

- ・部屋の温度・湿度が高くなりすぎたとき冷房 室内ユニット天面付近の温度が31 ℃以上、湿度が60 %以上の状態が10分間続いたとき。
- · 部屋の温度が低くなりすぎたとき暖房 室内ユニット天面付近の温度が 15 ℃以下の状態が 10 分間続いたとき。

動作例



■ 室温みはり運転を一時的に止めるとき



●室温みはりを続けるため 「停止」は表示しません。

お知らせ

- ●熱中症や低体温症を防止する機能ではありません。 室内ユニットの設置位置や使用環境によっては温度 や湿度を誤検知して運転しないことがあります。 補助機能としてお使いください。
- ●運転中は運転ランプ(緑)が点灯します。 ナノイーXは、リモコンの設定にしたがって動作します。 「AI快適」「AI快適エコナビ」は動作しません。 設定温度・風量・風向は自動になります。調節したい ときは、運転開始ボタンで運転後、調節してください。
- ●冷房などの停止後(おそうじ運転停止後)約30分間は、 温度・湿度の誤検知防止のため、室温みはりは動作し ません。(室温みはり運転が自動で止まった後も同様)
- ●室温みはり運転は切タイマー(P.17)で停止しません。
- ●室温みはり運転が自動で止まった後に、おそうじ運転をすることがあります。(P.40~42)
- ●室温みはりは運転条件になると運転するため、長時間 使用しない場合は、設定を取り消しておくことをおす すめします。

タイマーを予約する

おやすみ切タイマー(下記)

おやすみ時に、決めた時間がたったら運転を止めたい




●自動で温度調節され、冷やしすぎ・暖めすぎを防ぎます。


切/入タイマー(P.17)

決めた時刻に、運転を切/入したい



●切タイマーと入タイマーは、運転の「切」「入」を予約でき、 取り消すまで毎日繰り返されます。






調節内容

おやすみ切タイマー設定から1時間経過後、設定温度に近づく、または「AI快適エコナビ」 設定時に部屋が暗いと検知すると、温度や風量、風向を次のように自動調節します。

- 設定温度は冷房・しっとり冷房・冷房除湿時に約1℃上げ、暖房時に約1℃下げます。 ただし、自動調節後、ご自身で設定温度を変更された場合は、その変更内容を学習し、 次の運転時に自動調節する温度を補正します。(設定温度を上げた場合は、少し高め に。下げた場合は少し低めに)
- 風量は弱くなります。(しずか設定中(P.13)を除く) ただし、しっとり冷房運転時は弱くならないことがあります。
- 風向は、上下自動時、上向きになることがあります。


お知らせ

- ●おやすみ切タイマーで停止した後は内部クリーン運転を行いません。フィルターおそうじ運転は、運転時間の合計が約24時間を超えて停止したときに行います。
- ●おやすみ切タイマーで停止した後に、フィルターおそうじ 運転をさせたくない場合は、お好みの時刻におそうじタ イマーを予約してください。(P.29)



■ 予約を取り消すとき

切/入の を押して、 「切の」または「入の」を 選び、 取消 を押す。 (すべての予約を取り消す ときは、 取消 のみを 押す)



┃切タイマーを予約する

例:23時を予約する。

切/入〇



▶ 予約時刻を設定する

すすむ

もどる



●押すたびに10分単位で変わり、 長押しすると早送りできます。 (夜の12時は「0:00」)

(橙)

(

→ 予約時刻を確定する

決定

切②23:88

▮入タイマーを予約する

例:7時を予約する。

切/入①2回押す



2 上記 2~3 の手順で予約を確定する

አወ 7:00

●30秒間、ボタン操作がないと、元の表示に戻ります。


■ 予約時刻を変更するとき

予約と同じ手順 1~3で変更する。

お知らせ


- ●入タイマーは、予約時刻に設定温度近くになるよう、 早めに運転が始まります。(最長約50分前)
- ●入タイマーでの運転は、停止前に設定していた内容で 始まります。
- ●現在時刻は、予約をすると表示されません。

●おやすみ切タイマーと切タイマーを組み合わせたとき は、おやすみ切タイマーが優先され、切タイマー時刻に は停止しません。



エオリア アプリを使う①

「エオリア アプリ」をインストールし無線LANに接続すると、スマートフォンで自宅のエアコンを操作、運転状況を確認するなど便利にお使いいただけます。



- ●アプリは無料ですが、インストールや操作には別途通信料が発生します。
- ●アプリのアイコン、画面、サービスや対応するスマートフォンなどは、更新により変わることがあります。

必要な準備

- インターネット環境を整え、機器をご準備ください。
- □ インターネット環境

常時インターネット接続が可能な環境が必要です。

- ●FTTH (光ファイバー)、ADSL、CATV (ケーブルテレビ)などのブロードバンド回線。 ダイヤルアップ回線はご利用になれません。
- インターネット接続の詳細は、プロバイダーや回線業者との契約内容をご確認ください。
- ●インターネットの通信料はお客様のご負担となります。
- □ 無線LANブロードバンドルーター(以下、無線LANルーター)
 - ●無線LANルーターが2.4 GHz帯の通信規格であることを確認してください。 (通信規格: IEEE802.11b、IEEE802.11g、IEEE802.11n) 上記以外のルーターは使用できません。
 - ●セキュリティ対策のため、必ず暗号化方式WPA3、WPA2、WPAのいずれかの設定ができる無線LANルーターを使用してください。 暗号化方式は、WPA3、WPA2(AES)をおすすめします。 設定方法は、無線LANルーターの取扱説明書を参照してください。
 - ●WEPのみ対応の機種はお使いいただけません。
 - ●モバイルルーターは動作保証をしていません。
- □ スマートフォン

iOS (iPhone) 13.0 / Android 6.0 以降 (2022年11月現在)

●無線LANルーターと接続ができることを確認しておいてください。



設定は、アプリ画面 の案内にしたがって 操作します

初期設定をする

初めてアプリをお使いになるときは、エアコンと無線LANルーターの接続、機器の登録などの初期設定が必要です。 リモコンの操作ができる位置で設定してください。

エオリア アプリを起動し、「CLUB Panasonic」にログインする

- エアコンに遠隔操作を許可する
 - エアコンにスマートフォンからの遠隔操作を許可します。(P.28)
- エアコンと無線LANルーターを接続する
 - 「スキャン設定 |または 「詳細設定 |で 接続します。

リモコンの表示







▲ エアコンをサーバーに登録する

無線LANルーターに接続した エアコンをPanasonicクラウド サーバーに登録します。 (My 家電登録)



無線LANの接続や設定時のリモコン基本操作方法

- 無線LAN 接続をするとき 無線LAN設定をするとき

無線LANボタンを2秒間、 長押しする

- ② すすむボタンまたは、もどるボタンで設定項目を選ぶ
- ③ 決定ボタンを押して確定する
- ●30秒間、ボタン操作がないと、元の表示に戻ります。

すすむ 決定 もどる 無線LANボタン= 0 0 0 0

必ず

室内ユニットに 向けて!

エアコン本体の設定をリモコンで行う

- ●遠隔ひと検知のサービスを利用するには、リモコンのメニューで「遠隔 ひと」の設定を「有」にします。(P.28) 「遠隔 ひと」を「有」にすると、ひと・ものセンサーで検知した人(発熱体)の反応の有無や多さをスマートフォンで確認 できることを許可したことになります。
- ●シーン設定のサービスを利用するには、リモコンのメニューで「遠隔 みはり」の設定を「有」にします。 (P.28)

エオリア アプリを使う②

ご利用の前に知っておいてください

サービスご利用時は、無線LANランプが点灯していることを確認しておいてください。

通信状態が悪いと、ご利用できないことがあります。

遠隔操作では、次のような事例が考えられます。

- ・運転できない、運転時間が反映されない。
- ・リモコンで運転したエアコンを、外出先から停止しようとしても 操作が反映されず停止できない。

操作後は、アプリのメイン画面で操作結果を確認してください。 操作が反映されていなかった場合は、本体に付属のリモコンで操作してください。


- ■スマートフォンは画面のロックをおすすめします。 (誤操作防止)
- ●エオリア アプリ利用規約の最新版に同意のうえ、ご利用ください。「遠隔ひと検知」のご利用は、モニターされる方の同意も得てください。
- 「遠隔ひと検知」は、ご家族の急な体調変化をお知らせする緊 急通報サービスではありません。



- ●アプリで時間を決めて運転中、または予約中にタイマーランプが 点灯します。
- ●無線LANランプ点灯中は、遠隔操作により運転したり、部屋の 状態確認などのために動作したりします。
- ●アプリで操作した内容は、リモコンには反映されません。

■ 無線LAN接続を切断できます


部屋にいる人が、遠隔操作をされたくない、在室状況を知られたくない、などのときは、リモコンで切断できます。



無線LANボタンを2秒間、長押しする

・操作後は、無線LANランプが消灯したことを確認してください。

- ●リモコンが使えないときは、室内ユニットの 応急運転ボタンで切断できます。
 - ①前面パネルを開ける。
 - ②応急運転ボタンを2秒間、長押しし、無線LANランプが消灯したら指を離す。





無線LAN使用上の注意とお願い

■ 使用周波数带

本機は2.4 GHz 帯の周波数帯を使用しますが、他の無線機器も同じ周波数を使っていることがあります。他の無線機器との電波干渉を防止するため、下記事項に留意してご使用ください。

無線LAN機器使用上の注意事項

この機器の使用周波数帯では、電子レンジなどの産業・科学・医療用機器のほか、工場の製造ラインなどで使用されている移動体識別用の構内無線局(免許を要する無線局)および特定小電力無線局(免許を要しない無線局)、ならびにアマチュア無線局(免許を要する無線局)が運用されています。

- 1 この機器を使用する前に、近くで移動体識別用の 構内無線局および特定小電力無線局ならびにア マチュア無線局が運用されていないことを確認し てください。
- 2 万一、この機器から移動体識別用の構内無線局に対して有害な電波干渉の事例が発生した場合には、すみやかに電波の使用を停止したうえ下記の連絡先にご連絡いただき、混信回避のための処置などについてご相談ください。
- 3 その他、この機器から移動体識別用の特定小電力 無線局あるいはアマチュア無線局に対して有害な 電波干渉の事例が発生した場合など、何かお困り のことが起きたときは、次の連絡先へお問い合わ せください。

連絡先:パナソニック株式会社

アプリの初期設定に関するお問い合わせ

(裏表紙)

■ 機器認定

本機は、電波法に基づく工事設計認証を受けた無線装置を内蔵しているので、無線局の免許は不要です。 ただし、以下の行為は電波法で禁止されています。

- ・無線装置を分解/改造する。
- ・本体銘板(P.52)をはがす。
- •本体銘板に記載している適合表示を消す。

■ 使用制限

使用に当たり、以下の制限がありますので、あらかじめで了承ください。

制限をお守りいただけなかった場合、および本機の 使用または使用不能から生じる付随的な損害などについては、当社は一切の責任を負いかねます。

- ●日本国内でのみ使用できます。
- ●利用権限のない無線ネットワークには接続しないでください。

無線ネットワーク環境の自動検索時に利用する権限のない無線ネットワーク(SSID※)が表示されることがありますが、接続すると不正アクセスと見なされるおそれがあります。

- ※ 無線LANで特定のネットワークを識別するための名前のことです。このSSIDが双方の機器で一致した場合、通信可能となります。
- ●本機は電気通信事業者(移動通信会社、固定通信会社、インターネットプロバイダ等)の通信回線(公衆無線LANを含む)に直接接続することができません。本機をインターネットに接続する場合は、必ず無線LANルーター等を経由し接続してください。
- ●磁場・静電気・電波障害が発生するところで使用しないでください。

次の機器の付近などで使用すると、通信が途切れたり、速度が遅くなったりすることがあります。

- ・電子レンジ、デジタルコードレス電話機
- ・他の無線LAN機器
- ・その他2.4 GHz帯の電波を使用する機器 (Bluetooth 対応機器、ワイヤレスオーディオ機器、ゲーム機、パソコン周辺機器など)
- 電波が反射しやすい金属物など

■ セキュリティ対策

- ●無線LANは電波を使ってデータを送受信するため、 不正なアクセスを受けるおそれがあります。データ の安全を確保するため無線LANルーターは、セキュ リティ対策を行ってください。(P.18) セキュリティ対策を実施せず問題が発生した場合、当
 - セキュリティ対策を実施せず問題が発生した場合、当社は一切の責任を負いかねますのでご了承ください。
- ●無線LANルーターのパスワード(暗号化キー)は、 8文字以上、63文字以下に設定することをおすすめ します。(文字数の制限は無線LANルーターの取扱 説明書をご確認ください)

パスワードを変更したときは、アプリの「設定メニュー」 →「機器全般タブ」→「修理・交換・初期化時の対応」 から「ルーターを交換したとき」を行ってください。

■ ファームウェアについて

- ●本機は、インターネットを通じて当社のファームウェア アップデートサーバーに接続し、自身のファームウェア を自動で最新版に更新する機能を持っています。 更新中は、無線通信が一時中断されるため、通信が 途切れたり、速度が遅くなったりすることがあります。
- ●ファームウェアの解析、改造は行わないでください。

エオリア アプリを使う③

Q & A

アプリをインストール できない



■スマートフォンのOSが対応していることをご確認ください。(P.18)

エアコンと 無線LAN ルーターの 接続ができない

無線通信が



●スマートフォンと無線LANルーターが接続できることをご確認ください。 →スマートフォンの説明書をご確認ください。

●無線LANルーターにより接続方法やセキュリティの設定方法が異なります。 →無線LANルーターの取扱説明書をご確認ください。

スマートフォンに 他のエアコンも登録したい ●アプリの「設定メニュー」→「機器全般タブ」から「新しいエアコンを追加」 を行ってください。

My 家電登録時に、区別しやすい名前を付けることをおすすめします。

●無線LANルーターを室内ユニットに近づけると、安定する場合があ ります。電波強度を確認してみてください。

電波強度の確認方法

① エアコンを停止し、リモコンの無線LANボタンを押す。

- ② もどるボタンを3回押す。 ▶ 🛂 (電波強度)
- ③ 室内ユニットに向けて決定ボタンを押す。(運転は停止します) →約5秒後、本体ランプの点灯で、電波強度を確認する。

電波強度		点灯するランプ	
強	ட ு	(6 •
中	ட ு	(
弱	0		

- •約10分後、自動で終了。すぐに終了したいときは、停止ボタンを押す。
- ・無線LANランプは電波強度にかかわらず点灯しています。

途切れる・中断する

意図しない設定になるなど 不正なアクセスに よる利用が疑われる

●エアコンの初期化(下記「エアコンを廃棄または譲渡するとき」の①~③ の操作)をし、初期設定の手順2~4(P.19)を再度行ってください。

無線LANルーターを 交換したい

●アプリの「設定メニュー」→「機器全般タブ」→「修理・交換・初期化時の 対応 | から 「ルーターを交換したとき | を行ってください。

スマートフォンを 機種変更したい

■スマートフォンのOSを確認し(P.18)、対応していれば、アプリをインストー ルして登録済みのログインIDでログインすると、引き続き利用できます。

エアコンを交換したとき

●アプリの「設定メニュー | → 「機器全般タブ | → 「修理·交換·初期化時の 対応 | から「エアコンを修理したとき | を行ってください。

制御基板の修理をしたとき

エアコンを廃棄または

譲渡するとき

- ●エアコンの初期化(①~③)とスマートフォンの登録削除(④)が必要です。
 - ① 無線LANランプの点灯を確認し、 リモコンの無線LANボタンを押す。 🕨 👢 📗 (スキャン設定)
 - ② もどるボタンを押す。 > 1 (初期化)


③ 室内ユニットに向けて決定ボタンを3秒間、長押しする。 →無線LANランプが消灯する。(初期化完了)

④ アプリの「設定メニュー」→「機器全般タブ」の「My 家電リスト」から 廃棄または譲渡するエアコンの登録を削除する。

お買い上げ時の設定を変更する①

■ **設定項目一覧** メニュー を押すたびに、表示項目が順に切り換わります。

表示項目	設定方法	表示項目	設定方法
セーブ(パワーセーブ)		クリーン	P.27
A (リモコンNo.)		おそうじ	
₹(設置位置)	P.24	間隔(お手入れ間隔)	
カビみはり		(ダストボックス方式のみ)	
室温みはり		冷房(冷房立上げ)	P.28
チャージ(おはようチャージ)	P.25	遠隔	
オートオフ		遠隔 ひと	
におい(においカット)	P.26	遠隔 みはり(シーン設定)	
室外音			



設定を変更する(共通の操作です)

運転中または停止中に

(上ュー) 項目を選ぶ

2 すすむ 設定内容を選ぶ(**もどる** は逆順で表示)

3 決定 室内ユニットに向けて確定する(変更内容が記憶されます)

●30秒間、ボタン操作がないと、元の表示に戻ります。


■ 途中で設定操作を中止するとき

取消

お知らせ

●メニューで変更した内容は、乾電池を交換するとリモコン表示のみお買い上げ時の設定に戻ります。(リモコンNo.を除く) 本体は変更した内容を記憶しています。

お買い上げ時の設定を変更する②



で選択(もどる は逆順で表示) ▶ 決定 メニュー で項目選択 すすむ ※は、お買い上げ時の設定です。 * ●「チャージ 有」に設定すると、暖房・自 チャージ チャ-ジ 動運転停止後、リモコンに「チャージ」と 表示されます。 チャージ ●時刻表示「12:00」が点滅するときは、 操作を中止して時刻を合わせてください。 おはようチャージを (P.10)動作できます (動作なし) (動作あり)

■ おはようチャージについて

朝の暖房を開始する時間帯を学習し、その時間帯に暖房ボタンを押すとすぐ温風が出せるように予熱運転を行います。朝の暖房開始時、すぐ温風を出したいときにおすすめします。


学習

午前3時~10時の暖房開始時刻を学習。(よく利用される時間帯を2つまで記憶します)



予熱運転

学習した時間帯の前から、予熱開始。 (最長60分前)



- 上下風向ルーバーが開きます。
- 運転ランプは点灯しません。
- ●前回の運転が暖房のときのみ、予熱されます。
- 1 つ目の時間帯の予熱中に 暖房を始めたときは、2つ目の時間帯には予熱されません。

すぐ暖房!

暖房ボタンを押すと、すぐに温風が出ます。



●暖房ボタンを押さなかったとき は、学習した時間帯後、約60分 で予熱運転が終了します。

- ●予熱運転開始条件:室温約 18 ℃以下・屋外温度約 10 ℃以下で、前回の運転を暖房で停止したとき。
- ●予熱中に運転を始めても、本体が十分暖まっていないと、すぐに風が出ないことがあります。(運転ランプが点滅)
- ●一時的におはようチャージを働かせたくないときは、「チャージ」表示中に停止ボタンを押してください。(「停止」表示) 動作を再開したいときは、リモコンで運転して停止するか、「チャージ 有」を再設定してください。
- ●予熱中に切タイマーの時刻になっても、予熱運転は停止しません。
- ●シーズン中に暖房を長期間ご使用にならない場合は、「チャージ 無」にすることをおすすめします。(1回の予熱は最長2時間で、消費電力は約300W*です)
 - ※CS-EX403D2、当社実験室(洋室 14畳)において、屋外温度2℃、室温 11℃で予熱した場合。

お買い上げ時の設定を変更する③

すすむ で選択(もどる は逆順で表示) ▶ ×-1- で項目選択 決定 ※は、お買い上げ時の設定です。 ●「オートオフ 有」に設定すると、「AI快適」 「AI快適エコナビ」設定で運転中、リモコ ンに **オートオフ** が表示されます。 ●部屋に人がいない状態が約3時間続く オートオフ *** 7-177** オートオフ と、自動で運転を停止します。 ●室温みはり運転中は、動作しません。 「AI快適」「AI快適 ●運転停止後に人を検知しても、運転は再開 エコナビ | 設定中に しません。 へ 無く 人の不在を検知す ●動きが少ない人(乳児や病気の人など)の ると自動停止でき いる部屋では「オートオフ無」をおすすめ ます します。(人がいないと判断し、停止す ることがあるため) ●おやすみ切タイマーとの併用時は、おや すみ切タイマーが優先されます。 ●においカットとは、冷房・しっとり冷房・除 ①動作なし・ありを選べます。 湿・冷房除湿の運転開始時、本体内部に * 付いた生活臭(化粧品やペット臭)が風と ともに出るのを防ぐ機能です。(約1分間 におい におい は風が出ません) 除湿・冷房除湿時は、約30秒間送風 (動作なし) (動作あり) 後、動作します。 におい • パワフル設定中は動作しません。 • 運転中、室温が設定温度に近づくと、 ②動作なしを選ぶと、風量自動時のみ、におい においカット機能を 風が出たり止まったりを繰り返すこと カット機能を動作させる設定が選べます。 動作できます があります。室温が上がると元の運転 **※** に戻り、このときにも、においカット機能 が働きます。 におい におい (動作なし) (動作あり) ●「室外音 Lo」に設定すると、能力が制限 **※** されるため、暖まるまで時間がかかる場 室外音 合があります。 ●室温が設定温度に近い場合などは、 暖房時の室外ユニッ

1

「室外音 Lo」を設定しても、運転音が

下がらないときがあります。

トの運転音を低減


できます

メニュー で項目選択

で選択(もどる は逆順で表示) ▶ 決定 すすむ

※は、お買い上げ時の設定です。

①送風のみの内部クリーン運転、または、自動で 内部クリーン動作をさせない設定が選べます。




「クリーン 暖房 有」「クリーン 送風 有」 → ②に進む

「クリーン 無」→ ④に進む


内部クリーン運転 (P.42)の動作内容 を変更できます

クリーン


②冷房切換・除湿切換(室温約16℃以上のと き)の運転中にも、内部クリーン運転を動作 させる設定が選べます。



③切タイマー(P.17)で停止した後に内部クリー ン運転を動作させない設定が選べます。



④本体内部に付着した油汚れを低減する動作 をさせない設定が選べます。



- ●「クリーン 送風 有」に設定したとき 冷房切換・除湿切換(室温約 16 ℃以上の とき)運転後は、暖房をしないでナノイーX 送風のみを運転します。ただし、運転時間 は長くなります。(約150分~240分間)
- ●「クリーン 送風 有 | 「クリーン 無 | に設定 していても「手動おそうじ運転」と「おでか けクリーン」の内部クリーン運転は、お買 い上げ時の設定と同じ動作をします。 (「手動おそうじ運転」は、停止中と、②の 手順で「クリーン 24h 無」設定中に 行うときのみ)
- ●「クリーン 無」に設定したとき エアコン内部を清潔に保つため、毎日「手 動おそうじ運転 | (P.30) することをおす すめします。また、カビみはり(P.31)を 設定しておくと、停止中に自動で内部ク リーン運転をします。

- ●「クリーン 24h 有」に設定したとき 次の場合、フィルターおそうじ運転の後 に内部クリーン運転が動作します。
 - 連続で24時間運転したとき。



フィルターおそうじ(約15分間)

- 冷房などを30分以上運転中に「手動 おそうじ運転」(P.30)をしたとき。
- 冷房などを30分以上運転中におそう じタイマー(P.29)の予約時刻になった とき。

運転時間は、①の手順で「クリーン 暖房 有」を設定時、計約65分間、「クリーン 送風 有 |を設定時、計約 105 分間にな ります。

(4)

●「クリーン 2」(油汚れ低減動作なし)に 設定したとき

本体内部の油汚れを低減する運転を行 いません。

- 暖房・除湿切換(室温約 16 ℃未満の とき)・ナノイー X 送風運転後は、内部 クリーン運転が動作しなくなります。
- 運転時間は、①の手順で「クリーン 暖房 有 |を設定時とカビみはりで動作すると きは、約60分~100分間になります。
- ナノイーXは、リモコンの設定にした がって発生します。

お買い上げ時の設定を変更する4


火ューで項目選択

すすむ で選択(もどる は逆順で表示) ▶ 決定

※は、お買い上げ時の設定です。

おそうじ

フィルターおそうじ 運転(P.40、41) の掃除度合いを 設定できます



フィルターおそうじの運転時間


標準:約15分間 念入:約60分間

- ●「標準」で使っていても汚れが気になる ときは、「念入」に変更してください。
- ●「念入」にしてもおでかけクリーン (P.30)のときは、「標準」の運転時間に なります。

ダストボックス方式 のみ表示します

間隔

ダストボックスの お手入れ時期を お知らせする間隔 を設定できます



標準:運転時間の合計 約2000時間 (約1年間)


- 短:運転時間の合計 約1000時間 (約半年間)
- 長:運転時間の合計 約4000時間 (約2年間)
- おそうじランプが点滅し、お手入れ時期を お知らせする間隔を、短くしたり長くした りすることができます。

次のようなほこりが発生しやすい環境では、「間隔 短」に変更することをおすすめします。

- 人が多く集まる部屋
- 布団の上げ下ろしの多い部屋など

冷房

冷房・しっとり冷房 運転開始時の温度 変化を緩やかにで きます




●「冷房 2」(立上げシフトなし)に設定すると、冷房・しっとり冷房運転開始時の温度変化が緩やかになります。

「冷房 1」(立上げシフトあり)のときより、設定温度に到達するまで時間がかかることがあります。

遠隔

遠隔操作を許可で きます




●遠隔操作をしたいときは「遠隔 有」にします。

遠隔操作をしないときは、必ず「遠隔 無」 にしてください。

(自動で停止する場合があります)

遠隔 ひと


エオリア アプリの 「遠隔ひと検知」 (P.18~20)を 許可できます



●エオリア アプリで、「遠隔ひと検知」をしたいときは、「遠隔 ひと 有」にします。 (ひと・ものセンサーで検知した人(発熱体)の反応の有無や多さをスマートフォンで見られます)

遠隔 みはり

エオリア アプリの 「シーン設定」を 許可できます (P.18、19)



●エオリア アプリの「シーン設定」を利用したいときは、「遠隔 みはり 有」にします。 (自動で運転を開始したり、通知を受け取ったりできます)

おそうじ運転を使いこなす①

ふだんのおそうじはエアコンにおまかせ!

お買い上げ時の設定では、運転停止後などにエアフィルターやエアコン内部のおそうじ運転が自動で始まります。 長時間連続運転中は、内部クリーン運転を行いません。(P.40~42)



1日1回、時間を決めておそうじ運転をしたいとき おそうじタイマー 予約時刻になるとフィルターおそうじ運転を行います。 (約15分間) 予約の前に、現在時刻が合っていることを確認してくだ さい。(P.10) タイマーランプは 例:15時を予約する 点灯しません 切/入〇 を5秒間、長押しする 掃除開始時刻を設定する ●押すたびに10分単位で変わり、 すすむ 長押しすると早送りできます。 18:00 もどる (夜の12時は「0:00」) 予約する 決定 (約2秒後、 <u>15:00</u> 14:30 元の表示に戻る) 掃除開始時刻 ●30秒間、ボタン操作がないと、元の表示に戻ります。 ■ 予約を取り消すとき ■ 予約時刻を確認するとき 切/入のを5秒間、長押しし、 切/入のを5秒間、長押しする。

取消 「おが②」が点滅したら を押す。 (約30秒後、元の表示に戻る)

- ●暖房などを積算で20分以上運転していないときは、予約時刻になってもおそう じ運転を行いません。
- ●暖房中などに掃除開始時刻がくると、暖房などの運転を一時中断します。
- ●内部クリーン運転ができていなかった場合は、フィルターおそうじ運転に続い て運転します。(計約85分間または約115分間) 「クリーン 無」にしたとき(P.27)は運転しません。
- ●毎日掃除するため、ほこりや油汚れが多い場所で使うときにおすすめです。 ただし、 汚れが気になるときはエアフィルターをはずして水洗いしてください。(P.35)
- ●音が気になる場合に設定するときは、停止時に自動で内部クリーン運転を行わな い、おやすみ切タイマーもご使用ください。(P.16)

お知らせ

●おそうじ運転中に切タイマー/入タイマー(P.17)の時刻になると、終了を待って 切タイマー/入タイマーが動作します。

おそうじ運転を使いこなす②

シーズンの終わりなど、すぐにおそうじ運転をしたいとき



手動おそうじ運転

フィルターおそうじ運転を行った後、内部クリーン運転を行い、自動で停止します。 (約15分~115分間)

においケア

2回押す

メーク 扱うじ

2 決定

室内ユニットに向けて確定する

おそうじ

リモコン表示のみ ▶ 約10分後、 元の表示に戻る (橙) は内部クリーン運転中は

ナノイーXランプ点灯

●30秒間、ボタン操作がないと、元の表示に戻ります。

■ おそうじ運転を途中で止めるとき



- ●冷房などの運転中に手動おそうじ運転をすると、終了後、元の運転に戻ります。
- ●内部クリーン運転は、自動で行われていないときのみ動作します。
- ●冷房などの運転を毎回おやすみ切タイマーで止めているときは自動で内部クリーン運転を行いません。 1日1回手動おそうじ運転することをおすすめします。

お出かけ中に、部屋のにおいを軽減し、おそうじ運転をしたいとき

おでかけクリーン

約120分間、ナノイーX送風運転で部屋のにおいを軽減した後、フィルターおそうじ運転、 内部クリーン運転の順に行い、終了後、自動で停止します。 (計約135分~235分間)

外出前に

1

においケア

3回押す

2

決定

室内ユニットに 向けて確定する

おでかけ

リモコン表示のみ ▶ 約10分後、 「停止」を表示する (青) 🚱

(橙) 🙀

エアフィルター掃除中は ナノイーXランプ消灯

- ●30秒間、ボタン操作がないと、元の表示に戻ります。
- おでかけクリーンを途中で止めるとき



- ●冷房などの運転中におでかけクリーンをすると、終了後すべての運転が停止されます。(受信音"ピー")
- ●内部クリーン運転は、自動で行われていないときのみ動作します。





エアコン内部のカビの成長を抑えたいとき

カビみはり


停止中に部屋の温度・湿度を検知して、エアコン内部がカビの成長しやすい状態になっているかどうかをみはります。

カビの成長しやすい状態が続くと、内部クリーン運転*1を約80分~100分間自動で行い、カビ*2の成長を抑制します。

運転中または停止中に

X_1-

4回押す



2

すすむ もどる 「カビ みはり 有」 を選ぶ



3 (

決定

室内ユニットに 向けて確定する

- ●30秒間、ボタン操作がないと、元の表示に戻ります。
- 設定を取り消すとき

上記の手順で「カビ みはり 無」に設定する。

動作条件

カビの成長しやすい状態が累積で12時間を超え、ひと・ものセンサーで人がいないと判断したときに運転します。人が居続けた場合には、累積で24時間を超えたときに運転します。

- ●運転中は、おそうじランプ(橙)とナノイーXランプ(青)が点灯します。
- ●エアフィルターに汚れがたまっていた場合は、内部クリーン運転の前にフィルター おそうじ運転も行われます。

※1:カビみはりの内部クリーン運転は、ナノイーX送風と暖房の運転を行います。

※2:カビみはりの効果(カビの成長抑制)について

39 m³、室温25 ℃、湿度70 %の試験室にて、エアコン内部にカビセンサーを設置。 冷房運転を3時間運転後、内部クリーン運転を12時間ごとに動作させ、7日後のカビの菌糸長を比較。カビセンサー内のすべてのカビ(2種類)で発芽はなく、カビの成長が抑制されることを確認。(試験機関:環境生物学研究所)

お知らせ

●おそうじ運転または、おでかけクリーン中に切タイマー/入タイマー(P.17)の時刻になると、終了を待って切タイマー/入タイマーが動作します。

お手入れ①

ダストボックス方式




「自動排出方式」で設置工事をされた場合、 ダストボックスのお手入れは不要です

(エアフィルターに付いたほこりを自動的に 屋外に排出するため)

「自動排出方式」と「ダストボックス方式」 の確認のしかた

①前面パネルを開ける。

前面パネルの 両端を持って 上げる。




自動排出 方式 ダスト ボックス 方式

●確認後、前面パネルを閉める。

「ダストボックス方式」の場合は、

おそうじランプが点滅し、 お手入れ時期をお知らせします。



- ●点滅したときダストボックスをお手入れする
- 5回点滅を繰り返したとき (お手入れ時期が過ぎています)


ダストボックスとエアフィルターを すぐにお手入れする

おそうじランプが点滅したとき

ダストボックス


運転を停止する

▶ 電源プラグを抜き、前面パネルを開ける




→ ダストボックスを取り出す

①フィルター扉のロック(4か所)を解除する。



- ②フィルター扉の取っ手(2か所)を持ち、上側に開く。
- ③ダストボックスの取っ手を持ち、ゆっくり 引き出す。




● ダストボックスからほこりがあふれていた場合 →お手入れ後、リモコンで本体の設定を 「間隔 短」に設定する。(P.28) (お手入れ時期を早めにお知らせします)


おそうじランプが5回点滅を繰り返したとき

ダストボックスとエアフィルター


- 】 「ダストボックス」のお手入れ 手順 1 ~4 (左記)を行う
- ヱアフィルターを取りはずす



3 掃除機でほこりを吸い取る



- 強い力を加えない。(破損の原因)
- ●油汚れが気になるときは、水洗いする。 (P.35)
- 4 エアフィルターを取り付ける



5 「ダストボックス」のお手入れ 手順5~7 (左記)を行う


◢ 掃除機でほこりを吸い取る



- ●汚れが気になるとき
 - →水かぬるま湯を含ませた布をよくしぼって ふいてください。 化学ぞうきんなどを使うと きは、その注意書きにしたがってください。
- 5 ダストボックスを取り付ける
 - ①ダストボックスを奥まで押し込む。
 - ②フィルター扉を閉じる。
 - ③ロックする。(4か所)
- 6 前面パネルを閉めて、電源プラグを差し込む

7 リモコンでお手入れ完了の設定をする

① 取消 を5秒間、長押しする。




② 決定 を押す。



→おそうじランプが消灯します。(積算された運転時間をリセット)

■ ブラシや周辺のほこりが気になるとき

掃除機でほこりを吸い取る。



- ■掃除機の先をブラシに 強く押し当てない。 (変形の原因)
- ブラシは、取りはずしや 水洗いはできません。

お願い


- ●台などをご使用の場合、転倒に注意してください。
- 電源プラグを抜くと、室温みはり、タイマー予約、おはようチャージを設定していても動作しません。設定し直してください。(P.15、17、25、29)

おそうじ運転していても、お手入れ・交換が必要です。

約2年に1回(目安)

空気清浄フィルター

交換する



- ●裏表はありません。●フィルターは、不燃物
- フィルターは、不然初 ゴミとして、地域のゴ ミ分別方法にしたがっ て廃棄してください。

水洗いはできません。

- ①電源プラグを抜き、前面パネルを 開ける。
- ②空気清浄フィルターを交換する。 図のようにツメ(6か所)の下に納めてください。

■ 別売品

品名: 空気清浄フィルター 品番: CZ-SAF16

希望小売価格(税込): 1,980円/1コ(2022年11月現在)

●別売品の仕様(形状や材質など)は、お買い上げ時に付属している仕様と異なる場合があります。

別売品は販売店でお買い求めいただけます。

パナソニックの家電製品直販サイトでもお買い求めいただけます。

https://ec-plus.panasonic.jp/



汚れが気になったとき

本体・リモコン

電源プラグを抜き、

柔らかい布で、からぶきする

点線の部分は強い力で-ふかないでください。 (変形・傷の原因)



●化学ぞうきんなどを使うときは、その注意書きにしたがってください。

上下風向ルーバーを開けて、内側をお手入れするとき


- ①電源プラグを差し込み、「はがア を5秒間、長押しする。(ルーバーが開く)
- ②電源プラグを抜いてお手入れする。
- ③電源プラグを差し込み、リモコンの停止ボタンを押す。(ルーバーが閉じる)

前面パネルは取りはずして水洗いすることができます

柔らかい布やスポンジで軽くふくように洗い、水気を十分ふき取るか陰干ししてください。

〈取りはずしかた〉

- ①電源プラグを抜く。
- ②両手で前面パネルを開け、止まるまで押し上げる。
- ③左(または右)に寄せ、左(または右)から手前に引いてはずす。




お願い


●洗剤などを含ませた布でふいたり、直接吹きつけたりしないでください。(損傷や故障の原因)

〈取り付けかた〉

①パネルを水平に持ち、アームを片側ずつ 奥まで押し込む。



- ●台などをご使用の場合、転倒に注意してください。
- ●前面パネルの落下に注意してください。



〈前面パネルの開けかた〉

両端を持って開ける。

■ エアフィルターを破損したとき

お近くの販売店でお買い求めください。 品番: ACRD00-0336AZ

希望小売価格(税込):880円/1枚

(2022年11月現在)

ほこりや油汚れが多い環境などでご使用のとき

エアフィルタ-

取りはずして水洗いする

- ●ふだんはエアフィルターを毎日掃除する「おそうじタイマー」(P.29)をおすすめ します。
- ●汚れがひどいときは薄めた中性洗剤でつけ置きし、汚れをやさしく洗い流した後、 十分に乾かしてください。




〈取りはずしかた〉

- ①電源プラグを抜き、前面パネルを開ける。
- ②フィルター扉のロック(4か所)を解除し、 フィルター扉の取っ手(2か所)を持ち、上側に開く。
- ③エアフィルターを持ち、手前に引いて下へ引き出す。


〈取り付けかた〉

- ① 「手前 |表示面を表にして奥まで入れ、ツメの下に納
- ②フィルター扉を閉じてロックする。(4か所)
- ③前面パネルを閉める。



お願い

●エアフィルターに強い力を加えないでください。 (破損の原因)



お知らせ

●お手入れしても汚れが取れなくなったときは、エアフィ ルターをお買い求めいただけます。(上記)

■ 水洗いするとき

次のものは使わない。(変色や変形、傷の原因)

- ●タワシのような硬いもの ●シンナーやみがき粉
- ●漂白剤 ●40 ℃以上のお湯

■ 乾かすとき

次のもので乾かさない。(変色や変形の原因)

- ●ドライヤー ●ストーブ
- ●直射日光
- 電源プラグを抜くと、室温みはり、タイマー予約、おはようチャージを設定していても動作しません。 設定し直してく ださい。(P.15、17、25、29)

自動・冷房切換・除湿切換について

操作方法は ▶ P.11

自動

●屋外・室内・設定の各温度に応じて、冷房・暖房・冷房除湿のいずれかを自動で選び、約30分ごとに選び直します。

●運転開始時

運転モードを選ぶため、運転ランプが約30秒間点滅します。



冷房切換

運転条件

設定温度: 20 ℃以上 室内湿度: 90 %以下 屋外温度: 21 ℃~50 ℃

• 運転条件以外で運転すると、保護装置が働いて停止することがあります。

冷房

- ●室温が設定温度になるように、冷風を循環させて冷やします。
- ●冷風を循環させると空気中の湿気を取り除くため湿度が自然に下がります。

室温が同じでも湿度が低くなると、高いときよりも冷えていると感じることがあります。

しっとり冷房

- ●室温が設定温度になるように、冷風を循環させて冷やします。
- ●冷風を循環させると空気中の湿気を取り除くため湿度が自然に下がりますが、しっとり冷房は湿度の低下を抑えた運転を行います。
- 室温が同じでも湿度の低下を抑えると、湿度が低いとき よりも冷えていると感じにくくなります。
- ●運転開始時は、室温を設定温度に近づけることを優先するため一時的に湿度が下がることがあります。

除湿切換

運転条件

屋外温度:1℃以上

- 運転条件以外で運転すると、保護装置が働いて停止することがあります。
- ●運転開始時、室温検知のため、約30秒間送風します。
- ●室温約 16 ℃以上のとき、やや冷たい風が出ます。
- ●室温約16℃未満のとき、やや暖かい風が出ます。

除湿

●設定温度は、標準温度(快適と感じる温・湿度)になるよう自動調節します。寒い・暑いと感じるときは「標準」+1℃~「標準」-3℃の範囲で調節できます。

●運転中

室温が設定温度に近づくと、約5分間、風が止まります。

冷房除湿

●室温が設定温度に近づくまでは冷 房。近づくと、ごく弱い風量で湿気 を取り除きます。

●運転中


室温が設定温度に近づくと、約5分間、風が止まります。

衣類乾燥

衣類の乾燥が目的のため、温度・風量は調節できません。部屋に人がいないときにおすすめします。

暖房について

操作方法は ▶ P.11



運転条件

屋外温度:24℃以下

• 運転条件以外で運転すると、保護装置が働いて停止することがあります。

風量調節

運転開始時

●吹き出す風の温度が暖まるまで、 風が出ないことがあります。 その間は、運転ランプが点滅します。 ただし、風量を手動で選んでいるときは、 風量調節を優先するため、数分間、 冷たい風が出ることがあります。



朝の運転開始時、すぐに温風を出したいときは、おはようチャージ(P.25)の設定をおすすめします。

運転中

●室温が設定温度に近づくと、室温が上がりすぎるのを 防ぐため、風の温度を少し下げます。このとき、風が 冷たく感じないように風量は弱くなります。 ただし、風量を手動で選んでいるときは、風量調節を 優先するため、弱くならないことがあります。


霜取り運転

屋外の温度が低く、湿度が高いときに、室外ユニットに 霜が付きます。この霜は運転の妨げになるため、暖房を 止め霜取り運転で自動的に溶かして排水します。(最長 約12分間)

- 霜取り運転中は、上下風向ルーバー は開いたまま、運転ランプが点滅 します。
- 霜取り運転が終わると暖房を再開します。


次回の暖房運転を、すばやくするために

運転停止後も、霜取り運転を行うことがあります。 このとき、運転ランプは消灯していますが、室外ユニット のみ運転し、最長約 15 分間で自動終了します。



「AI快適」「AI快適エコナビ」について

操作方法は ▶ P.12



日当たりの変化に合わせて温度を調節

日当たりの変化(晴れ・曇りなど)に合わせて、温度をコントロールします。

- ●「AI快適」設定時 より早く快適性を感じるための温度調節を行います。
- ●「AI快適エコナビ」設定時 快適性を維持しながら、消費電力を抑える*温度調 節を行います。
- ●温度調節内容
 - 晴れた日の昼間は、約1℃~2℃低め
 - 曇りの日や夜は、約1℃~2℃高め (同じ室温でも、日が当たって日射量が多いときは暑く (暖かく)感じ、日射量が少ないときは涼しく(寒く)感じるため)

人がいない状態が続いたとき、不在節電運転

約30分~60分間、人がいないと判断すると設定温度を調節します。

人を検知すると、元の設定温度に戻ります。

- ●設定温度(自動調節)
 - ・冷房・しっとり冷房・冷房除湿時:約1℃~2℃高め
 - 暖房時:約1℃~2℃低め
- ●節電効果(CS-EX403D2冷房運転での測定例) 当社実験室(洋室14畳)において、屋外温度:35℃、 設定温度:25℃、設定風量:風量自動で運転した場合、 安定時の積算消費電力量:不在節電運転時261 Wh、 不在節電運転なし時328 Wh(効果は、設置環境や使 用状況により異なります)

おへや学習機能で、消費電力を抑える (「AI快適エコナビ」設定時のみ)

- ●運転開始から設定温度に到達するまでの運転時間を、晴れの日と曇りの日を区別して学習します。 暖まりやすい、または冷えやすい部屋であれば、緩やかに運転します。
- ●運転中、室内温度が設定温度に近づくと風が弱くなります。 暖まりやすい、または冷えやすい部屋であれば、早めに風を弱くして消費電力を抑えます。**

例)日当たりのよい南向きの部屋で暖房する場合。



Panasonic クラウドサーバーに接続すると (P.18、19)、部屋の情報をより細やかに学習・記憶することができます。

部屋の明るさに合わせて 本体ランプの明るさを調節

(「AI快適エコナビ」設定時のみ)

部屋の明るさに合わせて、本体ランプの明るさを2段階で自動調節します。

暗いときは暗め、明るいときは明るめ









※: 省エネ効果(CS-EX403D2暖房運転での測定例)

当社実験室(洋室 14畳)において、屋外温度:2℃、設定温度:25℃、設定風量:風量自動で運転した場合、安定時の積算消費電力量:「AI快適エコナビ」設定時 641 Wh、「AI快適」「AI快適エコナビ」設定なし時 758 Wh(効果は、部屋の断熱性・気密性や日射など、使用環境により異なります)

「ナノイーX」について

操作方法は ▶ P.11



※ 1: 浮遊菌は 25 m^3 (約6畳)の試験室で 4 時間後、付着菌は 23 m^3 (約6畳)の試験室で 8 時間後の効果であり、実使用空間での実証結果ではありません。

nanoeX(ナノイーX)とは

nanoeX(ナノイーX)は、水に包まれた微粒子イオンです。

- ●本製品はナノイー*2の100倍の量の0Hラジカルを 生成するナノイーX(48兆)を搭載しています。
 - ※2: nanoe (ナノイー)は、高反応成分(OHラジカル)、電荷を有し、 弱酸性を示す5~20 ナノメートルの微細な水粒子です。
- ●ナノイーXは部屋の空気を利用して発生させます。
- ●以下の環境でのご使用をおすすめします。室内温度:約5℃~35℃(露点温度:約2℃以上)相対湿度:約30%~85%
- ●加湿効果はありません。

<u>ナノイー</u>Xの<u>効果</u>

菌・カビ・におい

- ●部屋のにおいを軽減、菌*¹やカビの繁殖を抑制します。 カーテンなどに付着したにおい(タバコや料理臭)・ 菌*¹やカビにも効果があります。
 - ・ 脱臭効果は、周囲環境(温度・湿度)、運転時間、 臭気・繊維の種類などによって異なります。

花粉(アレル物質)

●花粉などアレル物質の活動を抑制します。

肌・髪

- ●肌のうるおい、髪のまとまり感を保ちます。
 - 肌や髪への効果は、季節・周囲環境(温度・湿度)、 使用時間、個人によって異なります。

ナノイーXの効果(抗菌・カビの成長抑制・抗アレル物質)について


効 果	試験機関 試験方法・結果(実使用空間での実証結果ではありません)						
空気中に浮遊、 カーテンなどに付着 した菌の繁殖を抑制 【実機試験】	(一財) 北里環境科学センター	浮遊菌は25 m³(約6畳)の試験室にて、4時間後に検証。 菌(1種類)の繁殖が99 %以上抑制されることを確認。					
	(一財) 日本食品分析センター	付着菌は23 m³ (約6畳)の試験室にて、8時間後に検証。 菌(1種類)の繁殖が99 %以上抑制されることを確認。					
空気中に浮遊、 カーテンなどに付着 したカビの繁殖・成長 を抑制【実機試験】	(一財) 北里環境科学センター	浮遊カビは25 m³ (約6畳)の試験室にて、6時間後に検証。 カビ(1種類)の繁殖が99 %以上抑制されることを確認。					
	(一財) カケンテストセンター	付着カビは30 m³ (約8畳)の試験室にて、2時間後に検証。 2種類のカビの成長が抑制されることを確認。					
花粉などアレル物質の 活動を抑制(不活化) 【実機試験】	パナソニック(株)	ELISA法による測定。23 m³ (約6畳)の試験室において、1 種類の花粉で 検証。1 種類の花粉の活動が3時間後に99 %抑制されることを確認。					
	プロダクト解析センター	電気泳動法による測定。23 m³(約6畳)の試験室において、13種類の花粉のアレル物質で検証。アレル物質が24時間後に抑制されることを確認。					

おそうじ機能について①


お買い上げ時は、「フィルターおそうじ運転」が自動で働くように設定されています。 フィルターおそうじ運転が、「自動排出方式 |か「ダストボックス方式 |のどちらかを確認し、該当する解説をお読みください。

フィルターおそうじ運転(自動排出方式)

エアフィルターに付いたほこりを、ブラシでかき取ってダストボックスに回収。回収したほこりは、屋外へ自動排出します。



ほこりの排出時は、排気ファンが動作するため、"ゴー"という音がします。



運転条件①②のいずれかで、フィルターおそうじ運転を開始します。 暖房などの運転時間の合計は、電源プラグを抜いても、本体で記憶しています。

「運転条件①

前回のフィルターおそうじ運転から、冷房や暖房などを積算で約24時間以上*運転して、停止したとき。

※内部クリーン運転は積算時間に含みません。

フィルターおそうじ運転時間:約15分間



フィルターおそうじ(約15分間)

運転条件②

連続24時間運転したとき。(運転を中断しておそうじします) フィルターおそうじ運転時間:約15分間



お願い_


- ●おそうじ運転中は、なるべく途中で止めないでください。途中で止めると、ほこりが自動排出されません。
 - ほこりがたまり続けると自動で排出できなく なります。
 - 途中で止めたときは、手動おそうじ運転 (P.30)を行うか、次に自動で行うおそうじ運 転で、必ずほこりを排出させてください。 (ダストボックスをはずして、お手入れすること はできません)
- ●おそうじ運転中は、フィルター扉を開けたり、 エアフィルターに触れたりしないでください。 (エアフィルターがはずれて落ちる原因)

お知らせ

- ●汚れが気になるときは、「おそうじタイマー」 (P.29)を予約するか、フィルターおそうじ運転 の掃除度合いを「念入」(P.28)にすることをおす すめします。
- おそうじタイマーを予約したときの運転条件は →P.29
- ●フィルターおそうじ運転を行った後、内部クリーン運転を行う場合があります。(P.42)

フィルターおそうじ運転(ダストボックス方式)

エアフィルターに付いたほこりを、ブラシでかき取ってダストボックスに回収します。



運転条件①②のいずれかで、フィルターおそうじ運転を開始します。 暖房などの運転時間の合計は、電源プラグを抜いても、本体で記憶しています。

運転条件①

前回のフィルターおそうじ運転から、冷房や暖房などを積算で 約24時間以上*運転して、停止したとき。

※内部クリーン運転は積算時間に含みません。

フィルターおそうじ運転時間:約15分間




「フィルターおそうじ(約15分間)

運転条件②

連続24時間運転したとき。(運転を中断しておそうじします)

フィルターおそうじ運転時間:約15分間





お願い

- ●おそうじ運転中は
 - ダストボックスを取りはずさないでください。
 - フィルター扉を開けたり、エアフィルターに 触れたりしないでください。

(エアフィルターがはずれて落ちる原因)

お知らせ)

- ●おそうじ運転を途中で停止すると、次の暖房などの運転停止時に、再度運転します。
- ●ダストボックスのお手入れ時期がくると、おそうじランプが点滅しお知らせします。お手入れをしないで運転を続けると、約120時間後に5回点滅の繰り返しに変わり、すぐにお手入れが必要なことをお知らせします。5回点滅の繰り返しになると、フィルターおそうじ運転は自動で行わなくなります。(ダストボックスからほこりがあふれ出るのを防ぐため)
- ●汚れが気になるときは、「おそうじタイマー」 (P.29)を予約するか、フィルターおそうじ運転の 掃除度合いを「念入」(P.28)にすることをおすす めします。
- おそうじタイマーを予約したときの運転条件は →P.29
- ●フィルターおそうじ運転を行った後、内部クリーン運転を行う場合があります。(P.42)

おそうじ機能について②

お買い上げ時は、「内部クリーン運転」が自動で働くように設定されています。

内部クリーン運転

- ★1:27.7 m³(約6畳)の試験室で4日後の効果であり、実使用空間での実証結果ではありません。
- ★2:内部クリーン運転の動作内容を「クリーン 送風 有」に変更した とき(P.27)は、カビの成長を抑制*2する効果になります。

ナノイーX送風と暖房の運転で本体内部に付着したにおい成分とカビ菌を除去*1*2、付着した油汚れを低減します。

- ●付着したにおい成分やカビ菌をすべて除去する機能ではありません。
- ●お買い上げ時には、内部クリーン運転が自動で動作するように 設定されています。
- ●ナノイーXは、リモコンで設定していなくても発生します。
- 運転中は上下風向ルーバーが開きます。

運転条件

冷房や暖房などを30分以上運転し、停止したとき。 (おやすみ切タイマーで停止したときを除く)

内部クリーン運転時間:約80分~100分間、または約70分間

リモコン操作	停	<u>₹</u>	
本体の動作例	冷房 (30分以上)	内部クリーン (約80分~100分間)	停止

す フィルターおそうじ運転を行うことがあります。

運転内容

- ●冷房切換・除湿切換(室温約16 ℃以上のとき)運転後は、 におい成分、カビ菌の除去と、付着した油汚れの低減を行います。
 - ナノイーX送風→暖房→ナノイーX送風の順に運転します。 ナノイーX送風時は、ナノイーXを室内ユニット内部の すみずみまで行き渡らせます。

(運転時間:約80分~100分間)

- ●暖房・除湿切換(室温約 16 ℃未満のとき)・ナノイーX送風 運転後は、付着した油汚れとにおいの低減を行います。
 - ナノイーXを送風し、室内ユニット内部のすみずみまで行き渡らせます。 (運転時間:約70分間)

■ 途中で止めたいとき

停止ボタンを押す。

- ●におい成分やカビ菌の除去、付着した油汚れを 低減する効果がなくなるため、なるべく止めな いでください。
- 内部クリーン運転の動作内容を変更したいとき→ P 27


お知らせ


- ●冷房切換・除湿切換(室温約 16 ℃以上のとき) 運転後に内部クリーン運転したとき
 - 内部クリーン運転の時間は、本体内部の湿度 が高く、弱い風量で冷房などを長時間運転し ているときほど長くなります。
 - 温風で内部を乾燥させるため、室内の温度や湿度が上がることがあります。
 - 室内温度が低く、湿度が高いときに運転する と、壁や窓などに結露する場合があります。
- ●おやすみ切タイマーで毎回停止しているとき 内部クリーン運転を行いません。エアコン内部を清潔に保つため、リモコンで毎日「手動おそうじ運転」(P.30)をするか、おそうじタイマー(P.29)の予約をおすすめします。
- ●長時間連続運転しているとき 内部クリーン運転を行いません。 エアコン内部を清潔に保つため、「クリーン 24h 有」(P.27)にすることをおすすめしま す。冷房切換・除湿切換を連続で24時間運転 した場合、運転を中断してフィルターおそうじ 運転の後に内部クリーン運転を行います。
 - 毎日決まった時刻に動作させたいときは、 おそうじタイマー(P.29)も予約してください。
- ※1:27.7 m³(約6畳)、室温25 ℃、湿度70 %の 試験室にて、エアコン内部に力ビ菌を滴下した試 験片を設置。1日3時間の冷房運転後に内部ク リーン運転ありとなしの条件において、4日後の 力ビ菌の数を比較。試験片のカビ菌(1種類)が 99%除去されたことを確認。 (試験機関:(一財)北里環境科学センター)
- ※2:27.7 m³(約6畳)、室温25 ℃、湿度70 %の 試験室にて、エアコン内部にカビセンサーを設置。 1日3時間の冷房運転後に内部クリーン運転あ りとなしの条件において、4日後のカビの菌糸長 を比較。カビセンサー内のすべてのカビ(3種類) で、成長が抑制されることを確認。 (試験機関:(一社)カビ予報研究室)


風向・風量自動時の風の動き


操作方法は ▶ P.13

設定内容によって自動調節の内容が変わります。











▮上下風向ルーバーの可動範囲

●運転モードによって異なります。

冷房・しっとり冷房・除湿・冷房除湿・衣類乾燥・ナノイーX送風のときは、天井に向けることができます。



よくあるお問い合わせ



Q 夕 点

タイマーランプ(橙)が 点滅する

A

異常をお知らせしています。 (P.51)

Q

運転ランプ(緑)が点滅する



次のときに点滅します。そのままお待ちください。

- ●自動運転開始時。 (運転モードを選んでいます)
- ●暖房運転開始時。(冷たい風を出さないよう、風を止めています)
- ●暖房運転時、暖房を止めて霜取り運転している とき。(P.37)
- ●入タイマー予約時の運転開始前。(運転開始時刻を決めるため、室温を検知しています)
- ●おはようチャージ設定時。(予熱運転をする・しないを決めるため、室温・外気温を検知しています)

Q

「おはようチャージ」と 「入タイマー」の違いは?

A

「おはようチャージ」は、予熱運転 しておく機能です。

●「おはようチャージ」は、冬の朝の身支度時など、 暖房運転で温風をすばやく出したいときにおすす めします。

学習した(よく利用される)朝の時間帯に暖房ボタンを押すと、エアコン本体が暖められているので、少しの時間で暖房感が得られます。(P.25)

●「入タイマー」は、毎日決まった時刻に部屋全体を冷やしたい・暖めたいときに、おすすめします。 予約時刻に、室温が設定温度になるように運転を 自動で開始します。(P.17)

 $\left[\mathsf{Q}\right]$

入タイマー時刻よりも 早く運転を開始する



予約時刻に室温が設定温度近くになるように、早めに運転が始まります。(最長約50分前)



室外ユニットから 水や湯気が出る




暖房中は、室外ユニットで 除湿した水が排水口から出ます。

また、室外ユニットに付いた霜が溶けて、水や湯気となって出ることがあります。(P.37)

冷房中は、室外ユニットの冷えた配管に 水滴が付き、滴下する場合があります。

●排水工事が必要なときは、 お買い上げの販売店へ ご相談ください。



Q

"ポコポコ"という音がする



ドレンホースから外気が流入し、 発生する音です。

- ●特に、高気密住宅など気密性の高い部屋で、換気 扇を回しているときや、屋外に強風が吹いている ときに発生します。
- ●部屋の吸気口を開けると解消される場合があります。
- ●対応部材(別売品)の取り付けを、お買い上げの 販売店へご相談ください。

おそうじ運転Q&A



停止したのに 動いている



停止後、フィルター や本体内部のおそうじ 運転が始まります。(P.40~42)

译

フィルターおそうじ運転中は、上下風向ルーバーを閉じますが、内部クリーン運転中は、少し開けて運転します。終了すると、自動ですべての動きが止まります。

■ 自動で動くのを止めたいとき

フィルターおそうじ運転

止められませんが、お好みの時刻に変えることができます。(P.29「おそうじタイマー」)

内部クリーン運転

「クリーン 無」(P.27)にしてください。その場合、 リモコンで毎日「手動おそうじ運転」(P.30)する ことをおすすめします。



冷房中などにおそうじ運転する



24時間を超える連続運転中にフィルターおそうじ運転をします。(P.40、41)

- ●約15分間で自動終了し、元の運転に戻ります。
- ●おそうじタイマーを予約すると予約時刻に運転します。(P.29)



おそうじ運転を止めて 冷房などを運転したい



運転開始ボタンを押してください。



おやすみ時など、 おそうじ運転の音が気になる



おやすみ切タイマーとおそうじタイマーのご使用をおすすめします。 停止時、おそうじ運転を行いません。 (P.16、29)

●自動排出方式のとき、ほこりの排出時は、排気ファンが動作し、"ゴー"という音がします。

自動排出方式



おそうじ運転を途中で止めてもいい?



停止ボタンで止められますが、なるべく止めないでください。

(フィルターおそうじ運転は、ほこりが排出できなくなり、内部クリーン運転は、におい成分やカビ菌の除去、付着した油汚れを低減する効果がなくなるため)

●止めた後は、なるべく早く「手動おそうじ運転」 (P.30)をするなど、汚れをためないのが、キレイに使うコツです。

ダストボックス方式



おそうじ運転を途中で止めてもいい?



停止ボタンで止められますが 内部クリーン運転は、なるべく止め ないでください。

(におい成分やカビ菌の除去、付着した油汚れを低減する効果がなくなるため)

- ●フィルターおそうじ運転を途中で止めたときは、次 の暖房などの運転停止時に再度運転します。
- ●止めた後は、なるべく早く「手動おそうじ運転」(P.30)をするなど、汚れをためないのが、キレイに使うコツです。



おそうじ ランプ(橙)が 点滅する





ダストボックスの お手入れ時期を

お知らせしています。(P.32、33)

●お手入れをしないで使い続けると、ランプは5回点滅の繰り返しに変わります。(約120時間後) 5回点滅の繰り返しになるとフィルターおそうじ運転は自動で行わなくなるため、すぐにお手入れをしてください。

故障かな?①

お問い合わせや修理を依頼される前に、まずご確認ください。

	症 状	対処法と原因					
+	運転しない	 ●前回、フィルターおそうじ運転をしてから積算で約24時間以内の運転停止後は、おそうじ運転を行いません。 ●おそうじランプが5回点滅を繰り返していませんか?(ダストボックス方式のみ)ダストボックスから、ほこりがあふれ出るのを防ぐため、フィルターおそうじ運転は自動で行いません。 →ダストボックスとエアフィルターのお手入れをしてください。(P.32、33) ●「クリーン 無」にしていませんか?(P.27) ●「クリーン 2」(油汚れ低減動作なし)にしたとき、暖房やナノイーX送風後、内部クリーン運転は動作しません。(P.27) ●異常が発生していませんか?(タイマーランプ点滅)→異常の内容を確認してください。(P.51) 					
おそうじ運転	冷房中などに運転する	●フィルターおそうじ運転をタイマー予約していませんか? 予約時刻になると冷房などの運転を中断し、エアフィルターなどを掃除します。					
じ運転	運転時間が長い	●「おそうじ 念入」にしていませんか?(P.28) ●「クリーン 送風 有」にしていませんか?(P.27)					
	途中で運転音が変わる	●自動排出方式のとき、運転中にほこりを排出するためです。(P.40)					
	エアフィルターに 汚れが残っている	●油汚れやタバコのヤニは、取りきれない場合があります。→エアフィルターのお手入れをしてください。(P.35)●汚れが気になるときは「おそうじ 念入」に変更できます。(P.28)●フィルターおそうじ運転を途中で止めていませんか?					
	ダストボックスから ほこりがあふれている	●人が多く集まる場所など、ほこりがたまりやすい場合は、おそうじランプが点滅する前に、お手入れが必要です。(ダストボックス方式のみ) →ダストボックスお手入れ後、「間隔短」に設定してください。 お手入れ時期を早めにお知らせします。(P.28)					
	運転しない	●ブレーカーが「切」になっていませんか?●電源プラグがはずれていませんか?●本体に付属のリモコン以外で遠隔操作をするときは、リモコンのメニュー設定を「遠隔 有」(P.28)にすると、運転できる場合があります。					
本体	よく 冷えない・暖まらない	 ●しっとり冷房時 湿度の低下を抑えた運転をするため、室温が設定温度になっていても冷えないと感じることがあります。(P.36) お好みに合わないときは、運転モードを変更してください。(P.11) ●「しずか」にしていませんか?(P.13) 室温や屋外温度によって、設定温度に到達するまでに時間がかかったり、設定温度にならなかったりすることがあります。 ●エアフィルターに汚れが残っていませんか?エアフィルターの掃除は自動で行いますが、ほこりや油汚れが多い環境などでご使用の場合、取りきれないことがあります。 →エアフィルターのお手入れをしてください。(P.35) ●屋外の熱を取り入れて暖房するため、屋外温度が0℃以下になると暖房能力は低下します。また、部屋の広さや外気温などの条件によっては、設定温度に到達しないことがあります。 →他の暖房器具との併用をおすすめします。 					

	症 状	対処法と原因
	よく 冷えない・暖まらない	 室内・室外ユニットの吹出口・吸込口をふさいでいませんか?(P.7) →周辺の障害物を取り除いてください。 →積雪時は室外ユニットの下や周辺の雪を取り除いてください。 積雪の多い地域では、防雪対策をおすすめします。 お買い上げの販売店へご相談ください。 換気扇やガスコンロを使用していませんか? 「セーブ 有」(P.24)または、エオリア アプリで「パワーセーブセレクト」を設定していませんか? 最大電流値が低くなる分、冷えや暖まりが悪くなる場合があります。 本体に付属のリモコン以外で遠隔操作(温度・風量・風向設定など)をされていませんか? 遠隔操作で設定された内容は、リモコンに表示しません。 →リモコンで温度・風量・風向は変えられます。
	暖まるまでに時間がかかる	●「セーブ 有」(P.24)または、「室外音 Lo」(P.26)または、エオリア アプリで「パワーセーブセレクト」を設定していませんか? 暖房能力が制限されるため、設定温度に到達するまで時間がかかります。
本体	冷房切換・除湿切換時、 霧が出ている	●部屋の空気が、エアコンの冷たい風で冷やされて霧状になるためです。
	上下風向ルーバーや 吹出口などに露が付く	 ●冷房切換時に、設定温度を20℃未満にしていませんか? → 20℃以上にしてください。 ●内部クリーン運転を途中で停止した後、続けて冷房・しっとり冷房・除湿・冷房除湿運転をしたときは、本体内部や上下風向ルーバー、吹出口などに結露することがあります。 →時間を空けて、冷房・しっとり冷房・除湿・冷房除湿運転を行ってください。
	タイマー予約時刻に なっても動作しない	●リモコンの現在時刻は合っていますか?(P.10) ●室温みはりを設定していませんか?(P.15) 室温みはり運転中は、切タイマー予約時刻になっても停止しません。
	室温みはり運転が 始まらない	●運転が止まった後、約30分間は温度・湿度の誤検知防止のため、室温みはりは動作しません。●停電などにより、設定が取り消された可能性があります。→リモコンのメニューから「室温みはり有」を設定してください。(P.15)
	おはようチャージを設定 したのに予熱運転が 始まらない	 ●前回の運転を暖房で停止していないときや室温・外気温が高いときは、 予熱運転を行いません。(P.25) ●「チャージ」表示中に停止ボタンを押すと、おはようチャージの設定が一時的に 取り消され、予熱運転を行いません。(P.25) ●停電などにより、本体の時刻情報が消去された可能性があります。 →リモコンのメニューから「チャージ 有」を設定してください。 時刻情報が本体に送信されます。(P.25)
	運転中、上下風向ルーバー・ 左右風向ルーバーが勝手 に動く	●冷房や暖房の風向自動時、室温がリモコン設定温度に近づくと、自動的に上下風向ルーバーの向きが変わることがあります。●冷房・しっとり冷房・冷房除湿の運転中、結露を防ぐため、自動的に上下風向・左右風向ルーバーの向きが変わることがあります。

故障かな?②

お問い合わせや修理を依頼される前に、まずご確認ください。

	症 状	対処法と原因
	停止後、上下風向ルーバー が閉じない	 ●停止時、上下風向ルーバーは、すぐに閉じません。 確実に閉じるため、いったん大きく開いてから閉じます。 ●内部クリーン運転をしていませんか?(P.42、45) ●停止中に上下風向ルーバーを手で動かしていませんか? 手では完全に閉じることができません。 →リモコンの本体リセットボタンを押してから、停止ボタンを押してください。
	停電復帰後、運転しない・ 上下風向ルーバーが閉じない	●復帰しても自動的に運転は開始せず、停止したままとなります。 このとき、上下風向ルーバーは閉じません。 →閉じたいときは、停止ボタンを押してください。
ı	停止後も運転している	●暖房運転停止後、室外ユニットに付いた霜を溶かすため、室外ユニットの 運転を続けることがあります。(最長約 15分間) このとき、室内温度が下がったり、エアコン内部に冷媒ガスが流れる音が したりすることがあります。
本体	勝手に 動き出す・止まる	 ●内部クリーン運転をしていませんか?(P.42) ●自動で動作する機能をリモコンで設定していませんか? ・切タイマー / 入タイマー(P.17) 予約は、取り消すまで毎日繰り返されます。 ・カビみはり(P.31) ・室温みはり(P.15) ・おはようチャージ(P.25) 予熱中は、上下風向ルーバーが開きます。 ・オートオフ(P.26) 人がいない状態が約3時間続くと運転が止まります。(停止後もリモコンの表示は運転状態で「オートオフ」を表示しています) ●本体に付属のリモコン以外で遠隔操作をされていませんか? ●「遠隔 有」を設定していませんか?(P.28) 通信できない状態が続くと、自動で停止することがあります。 ● HEMS (ホームエネルギーマネジメントシステム)にエアコンをつないでいる場合は、エアコンが止まることがあります。 →遠隔操作をしない場合は「遠隔 無」でお使いください。(P.28)
	室内ユニット周辺の 天井や壁が黒く汚れる	●空気中のちりやほこりがエアコンによる空気の循環や静電気で壁などに付着するためです。壁紙の種類によっては、汚れが付着しやすいものがあります。 →エアコン周辺の、こまめなお掃除をおすすめします。
	運転開始時、風がすぐ出ない	●暖房時、冷たい風が出るのを防ぐためです。暖かい風が出るまでに数分かかる場合があります。(風量手動のときは、吹き出しからしばらくの間、冷たい風が出ることがあります)●においカット機能を設定していませんか?(P.26)
風	運転開始時の風が 暖かくない・冷たくない	●停止後すぐに再運転すると、約3分間、送風になります。(エアコン保護のため)●おはようチャージで予熱中に暖房しても、本体が十分に暖まっていない場合は、 温風がすぐ出ないことがあります。(P.25)
7251	風がにおう	 じゅうたんや衣類などにしみこんでいる生活臭が、空気の循環によって出てくることがあります。 冷房から除湿・暖房に切り換えると、約5分間におうことがあります。 冷房・しっとり冷房・除湿・冷房除湿の運転開始時、室内ユニットに付着した生活臭が風とともに出ることがあります。 →においカット機能(P.26)を設定すると、軽減する場合があります。 ドレンホースの先端が、においのたまる排水溝などに入っていませんか?

	症 状	対処法と原因
	風量が勝手に変わる	●室内外の状況や設定温度、設定風量によって、風量が変わることがあります。
	暖房の運転開始時や 運転中に風が冷たく 感じる	 ●風量を ■■■■ にしていませんか? 強い風で早く運転することを優先させるため、風が十分暖まる前に出ます。 →「パワフル」または「風量自動」をおすすめします。 リモコンで設定した温度に近づくと、室内温度が上がりすぎないように風の温度が少し下がります。このとき、風が冷たく感じないよう、風量が弱まりますが、風量手動のときは、弱くならないことがあります。
風	運転中に風が止まる	(除湿・冷房除湿時) ●運転開始時、約30秒間送風後、風を止めることがあります。 (室内温度が低いときに、冷たい風が出るのを防ぐため) ●室内温度が設定温度に近づくと、約5分間、運転が止まります。 〈冷房・しっとり冷房・除湿・冷房除湿時〉 ●においカット機能を設定していませんか?(P.26) 〈暖房時〉 ●室外ユニットに付いた霜を溶かしている間、風が出ません。(霜取り運転) →しばらくお待ちください。(最長約12分間)(P.37)
	本体ランプが 暗い・見にくい	●「AI快適エコナビ」を設定していませんか? 部屋が暗いと検知されると、少し暗めになり、明るいと検知されると元の明 るさに戻ります。 ●暗めに設定していませんか?(P.52)
	ナノイーXランプが 運転中に消える	●ナノイーX機能の異常が考えられます。 →お買い上げの販売店へご相談ください。
ランプ	タイマー予約していない のにタイマーランプが 点灯する・消灯しない	●本体に付属のリモコン以外で、遠隔操作をされていませんか?
ブ	無線LANランプが 点滅している	 エアコンと無線LANルーターとが接続されていないときに点滅します。 エオリア アプリ (P.18)など、本体に付属のリモコン以外でエアコンを操作しないときは、リモコンの無線LANボタンを2秒間、長押しして消灯させてください。 エオリア アプリご利用時は、エアコンと無線LANルーターが接続されていないときに点滅します。下記の内容をご確認ください。 無線LANルーターと通信ができるようになると、点灯に変わります。 無線LANルーターの電源が切れていないか。 無線LANルーターの位置が室内ユニットから遠くないか。 初期設定の手順2~4 (P.19)を再度行い、接続を確認。
リモコン	受信しない	 ・乾電池が消耗していたり、使用推奨期限が近かったりしませんか? →乾電池を交換してください。 ・リモコンを室内ユニットの受信部に向けていますか?(P.7) ・テレビやビデオのリモコンのボタンが、リモコンラックなどで押されていませんか?(混信して受信できない原因) ・インバーター照明がある部屋では信号を受け付けない場合があります。 →お買い上げの販売店へご相談ください。


故障かな?③

お問い合わせや修理を依頼される前に、まずご確認ください。

	症 状	対処法と原因						
	表示が 薄い · 出ない	●バックライトは、操作後約5秒で消灯します。(乾電池の消耗を抑えるため)●乾電池が消耗していませんか? →乾電池を交換してください。●+-が逆になっていませんか? →+-は正しく入れてください。						
	タイマー予約ができない	●時刻表示「12:00」が点滅していませんか?→現在時刻を合わせてください。(P.10)						
リモコン	リモコンの設定どおりに 運転しない	●設置後、初めて運転したときは、リモコンの設定にかかわらず、上下風向 ルーバーとフィルターおそうじ運転の動作チェック(試運転)が行われます。 その後、リモコンの設定に応じた運転で動作チェック(試運転)が行われます。 すべての試運転は約15分間で終了し、そのまま設定された運転が継続され ます。						
	暖房時、リモコンで 風量調節ができない	●室内温度が設定温度に近づくと、自動的に風の温度と風量が少し下がります。 (室内温度が上がりすぎるのを防ぐため)						
ı	設定温度が勝手に変わる 「12:00」が点滅し、 時刻合わせができない	●乾電池が消耗していませんか?消耗すると、リモコンの表示が変わったり、設定ができなくなったりします。→乾電池を交換してください。						
	"ブシュッ"という音	●霜取り運転時や運転停止時に、エアコン内部の冷媒ガスの流れが切り替わる音です。						
	"ピシッ""パキッ"という音	■温度変化でエアコンの樹脂部分が伸び縮みする音です。						
	水の流れるような"シャー" "ボコボコ"という音	●冷媒ガスがエアコン内部に流れている音です。●暖房運転停止後、霜取り運転する音です。						
	"ゴー"という音	●自動排出方式のとき、フィルターおそうじ運転中に、ほこりを排出する音です。 						
	"バサッ""ギシッ"という音	●フィルターおそうじ運転中に発生している音です。 (エアフィルターやブラシが駆動しています)→寝室などでご使用時に音が気になるときは、「おそうじタイマー」の予約をおすすめします。(P.29)						
音	"シャー""ジー"という音	●ナノイーXが発生している音です。→就寝時など音が気になるときは、ナノイーXを取り消してください。(P.11)						
	"ピッピッ"という受信音	●リモコンの設定温度が上限または下限になったことをお知らせしています。						
	何も操作していないのに "ピー""ピーピー""ピッ" "ピッピッ"などの受信音	●本体に付属のリモコン以外で遠隔操作をされていませんか?						
	操作すると"ピーピーピー" "ピーピーピーピー"と いう受信音	●遠隔操作によりコントロールされている場合、本体に付属のリモコンで操作できないことをお知らせしています。						
	"ピピピピ"という音を 繰り返す	●試運転時に、異常が発生したことをお知らせしています。(タイマーランプ点滅) →約3分間で音は止まります。お買い上げの販売店へご連絡ください。						

タイマーランプが点滅するときは


室内または室外ユニットに異常が発生しています。以下の手順でご確認ください。



エアフィルターの確認をする

- エアフィルターを付け直す。(P.35)
 - ●フィルター扉のロックを確認してください。(4か所)
- - ●約15分間、エアフィルターが動くことを確認し、停止してください。 (エアフィルター取り付け状態確認のため)
- ③前面パネルを閉める。

運転の再確認をする



- \bigcirc 本体
- を先の細いもので押す。
- ●本体電源がリセットされ、直る場合があります。
- ②「冷房切換」「暖房」「除湿切換」「自動」ボタンのいずれかを押す。 (正常動作確認のため)

タイマーランプが点滅するとき

点検・修理が必要です

- ① 運転を止める。
- ② 診断コード(英数字)を再確認してください。

タイマーランプが点滅しないとき

正常です

販売店へ診断コードをご連絡ください


- ●電源プラグは抜いておいてください。
- ●次の表示の場合は、修理するまで一時的に運転できます。 (受信音"ピピピピ") H23, H24, H27, H28, H40, H50, H51, H52, H59, H78, H79, H85
- 室温みはり、タイマー予約、 おはようチャージを設定して いたときは、確認または修理 後に設定し直してください。 (P.15, 17, 25, 29)

こんなときは

リモコンが使えないとき

本体で応急運転ができます。

- ① 電源プラグの差し込みを確認する。
- ② 前面パネルを開けて、応急運転ボタンを押す。



■ 止めるときもう一度押す。

- ●設定温度25 ℃の自動運転となり、温度や風量・風向は調節できません。
 - 風量は「風量自動」になります。
 - 風向はリモコンで設定していた風向になります。
- ●電源プラグを抜き差しすると、風量と風向は自動になります。
- ●応急運転ボタンを5秒間、長押しすると、強制冷房運転になります。(据付工事業者用ですので、ふだんは使用しないでください)

リモコンは、お近くの販売店でお買い求めください。 品番: ACRA75C2323OX 希望小売価格(税込): 5,500円

(2022年11月現在)

室外ユニットに背面金網を取り付けたいとき

●お買い上げの販売店へ取り付けをご依頼ください。(別売品)

室内ユニットのランプを暗めにしたいとき

決定

5秒間、長押しする(受信音"ピッ")



■ 元に戻すとき

もう一度 決定

5秒間、長押しする。



好

●お買い上げ時の明るさで、「AI快適エコナビ」 を設定しているときは、明るさ自動調節機能 が働きます。 (P.38)


停電などで電源が切れたとき

- ●運転は停止します。通電後、改めて運転してください。 通電時、上下風向ルーバーは閉じません。閉じたいと きは、停止ボタンを押してください。
- ●タイマー予約は、取り消されます。 通電後、予約し直してください。 (P.17、29)
- ●おはようチャージ設定時は、本体に記憶していた時刻情報が消去されるため、予熱運転が始まりません。 通電後、リモコンのメニューから「チャージ 有」を設定してください(P.25)。 時刻情報が本体に送信されます。
- ■室温みはりは、本体に記憶していた設定が取り消される ため動作しません。

通電後、リモコンのメニューから「室温みはり 有」を設定してください。(P.15)

長期使用製品安全表示制度に基づく本体表示について

経年劣化により、危害の発生が高まるおそれがあることを注意喚起するために、電気用品安全法で義務付けられた以下の表示を本体の銘板近傍に行っています。





【設計上の標準使用期間】* 10年

設計上の標準使用期間を 超えてお使いいただいた 場合は、経年劣化による 発火・けが等の事故に至 るおそれがあります。

- ※【設計上の標準使用期間】とは?
 - ・運転時間や温湿度など、以下の標準的な 使用条件に基づく経年劣化に対して、 製造した年から安全上支障なく使用する ことができる標準的な期間です。
 - ・設計上の標準使用期間は、無償保証期間とは異なります。また、一般的な故障を保証するものでもありません。
- ■標準使用条件…JIS C 9921-3 「ルームエアコンディショナの設計上の標準使用期間を設定するための標準使用条件」による

電源電圧/周波数		制旦の	D定格電圧による/50 Hzまたは60 Hz			
	室内	温度	冷房	27 ℃(乾球温度)	暖房	20 ℃(乾球温度)
環境条件	五四	湿度	冷房	47 %(湿球温度 19 ℃)	暖房	59 %(湿球温度 15 ℃)
	屋外温度		冷房	35 ℃(乾球温度)	暖房	7 ℃(乾球温度)
	注外	湿度	冷房	40 %(湿球温度24 ℃)	暖房	87 %(湿球温度6 ℃)
	設置条件		製品の	D据付工事説明書による標準設置		
台	負荷条件 住宅 部屋の広さ		木造平	7屋、南向き和室、居間		
貝彻木什			製品前	じた見合った広さの部屋(畳数)		
1 左眼の体界口粉		東京モ	ミデル			
想定時間	1 44 10,	1年間の使用日数		6月2日から9月21日までの112日間	暖房	10月28日から4月14日までの169日間
芯足时间	1日の	使用時間	冷房 9時間/日		暖房	7時間/日
1年間の使用時間		の使用時間	冷房	1,008時間/年	暖房	1,183時間/年

設置状況や環境、使用頻度が上記の条件と異なる場合、または、本来の使用目的以外でご使用された場合は、設計上の標準使用期間 より短い期間で経年劣化による発火・けが等の事故に至るおそれがあります。



	種		冷房・暖房兼用セパレート形(インバーター)								
	くシリーズ 内ユニット/室	外ユニット品番	CS- EX223D	CU- EX223D	CS- EX253D	CU- EX253D	CS- EX283D	CU- EX283D	CS- EX363D	CU- EX363D	
	EDZシリーズ 室内ユニット/室外ユニット品番		CS- E223DZ	CU- E223DZ	CS- E253DZ	CU- E253DZ	CS- E283DZ	CU- E283DZ	_	_	
	EEシリーズ 内ユニット/ 室	外ユニット品番	CS- 223DEE	CU- 223DEE	CS- 253DEE	CU- 253DEE	CS- 283DEE	CU- 283DEE	CS- 363DEE	CU- 363DEE	
DE	EXシリーズ	・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	CS- 223DEX	CU-	CS-	CU- 253DEX	CS- 283DEX	CU-	CS- 363DEX	CU- 363DEX	
DE	EXE3シリース		CS- 223DEXE3	CU-	CS- 253DEXE3	CU-	CS-	CU-	_	_	
DE	EXKシリーズ		CS-	CU-	CS-	CU-	CS-	CU-	CS- 363DEXK	CU- 363DEXK	
		源	LEGBE/ (IX				50/60 Hzi		OGGE THE	1000027111	
	電源プラ	ラグ形状	0	_	0	_		_		_	
	定格能	能力(kW)	2.2 (0.5	5~3.1)	2.5 (0.5	5~3.2)	2.8 (0.5	5~3.2)	3.6 (0.6	5~3.8)	
冷	定格消	費電力(W)	520(13	5~820)	640(13	640 (135~840)		770 (135~840)		1,370 (155~1,420)	
1 / 11	運転	電流(A)	5.75		7.10		8.55		14.4		
	運転音(dB:音響パワーレベル)		58	57	59	58	59	58	64	62	
房	冷房面積の	鉄筋アパート南向き洋室	15 m	2/9畳	17 m²	2/10畳	19 m²	₹/12畳	25 m ²	2/15畳	
	目安	木造南向き和室	10 m²/6畳		11 m	² /7畳	13 m²/8畳		16 m²/10畳		
	定格能力		2.2 (0.4~4.8)		2.8 (0.4	1 ∼4.8)	3.6 (0.4	4∼5.0)	4.2 (0.5	5~5.0)	
	(kW)	低温	3.5		3	.5	3	.6	3	.7	
暖	定格消費電力	標準	450 (125~1,410)		620(125	i~1,410)	870 (125	i∼1,440)	1,200(14	5~1,440)	
收	(W)	低温	1,250			1,250		1,270		1,310	
房	運転 <i< th=""><th>電流(A) 最大></th><th></th><th>00 5.0></th><th></th><th>85 5.0></th><th></th><th colspan="2">9.65 <15.0> 12</th><th>2.5 5.0></th></i<>	電流(A) 最大>		00 5.0>		85 5.0>		9.65 <15.0> 12		2.5 5.0>	
נען	運転音(dB:	音響パワーレベル)	59	58	60	58	62	58	64	64	
	暖房面積の	暖房面積の 鉄筋アパート南向き洋室		10 m²/6畳		13 m²/8畳		16 m²/10畳		19 m²/12畳	
	目安	木造南向き和室	8 m²	7/5畳	10 m	2/6畳	13 m²/8畳		15 m²/9畳		
	通年エネルコ	ドー消費効率	6	. 1	5	.8	5.8		5	.0	
	JIS C 96	612:2005	6	.3	5	.8	5	.8	5	.0	
	Þ	公名	A	4	A	4	Α		С		
	質量	(kg)	10.5	20	10.5	20	10.5	21	10.5	22	
(高	外形寸法 さ×幅×奥行)	室内ユニット				295×79	98×239				
(12)	(mm)	室外ユニット	539×655×275								

- ●この仕様値は、JIS C 9612:2013(日本産業規格)に基づいた数値です。
- ●室外ユニットの幅の寸法には配管接続口部分を含んでいません。
- ●リモコンで「停止」のときの消費電力は電源が単相 100 Vの場合 0.8 W、単相 200 Vの場合 0.9 Wです。 (タイマー予約時、おはようチャージ・カビみはり設定時:約1 W、室温みはり中:約4 W)
- ●無線LANランプ点灯中、「停止」のときの消費電力は約2Wです。
- ●室外ユニットを、硫化ガス、機械油の多い所、悪臭や有毒ガスの発生する所、積雪の多い地域でご使用される場合は 販売店へご相談ください。
- ●品番の末尾に"Z"の付いたものは、沖縄地区専用の商品です。

仕様2

種類					冷房・暖房	勇兼用セパレ	ート形(イン	バーター)			
	<mark>くシリーズ</mark> 内ユニット/室	外ユニット品番	CS- EX403D2	CU- EX403D2	CS- EX563D2	CU- EX563D2	CS- EX633D2	CU- EX633D2	CS- EX713D2	CU- EX713D2	
	EDZシリーズ 室内ユニット/室外ユニット品番		CS- E403D2Z	CU- E403D2Z	CS- E563D2Z	CU- E563D2Z	CS- E633D2Z	CU- E633D2Z	_	_	
	EEシリーズ 内ユニット/室	対ユニット品番	CS- 403DE2E	CU- 403DE2E	CS- 563DE2E	CU- 563DE2E	CS- 633DE2E	CU- 633DE2E	CS- 713DE2E	CU- 713DE2E	
	EXシリーズ 内ユニット/室	外ユニット品番	CS- 403DEX2	CU- 403DEX2	CS- 563DEX2	CU- 563DEX2	CS- 633DEX2	CU- 633DEX2	CS- 713DEX2	CU- 713DEX2	
DE 室	EXE3シリース 内ユニット/室	ズ 8外ユニット品番	CS- 403DEX2E3	CU- 403DEX2E3	CS- 563DEX2E3	CU- 563DEX2E3	_	_	_	_	
	EXK シリーズ 内ユニット/室	2外ユニット品番	CS- 403DEX2K	CU- 403DEX2K	CS- 563DEX2K	CU- 563DEX2K	CS- 633DEX2K	CU- 633DEX2K	CS- 713DEX2K	CU- 713DEX2K	
		 源			· 単相	200 V 5	50/60 Hzi	<u> </u>			
	電源プラ		6	_		_	(3)	_		_	
	定格能	能力(kW)	4.0 (0.6	6~4.3)	5.6 (0.7	7~5.7)	6.3 (0.7	7~6.4)	7.1 (0.7	7~7.2)	
冷	定格消	費電力(W)	1,340(15	5~1,500)	2,280 (160~2,390)		2,200(16	2,200(160~2,500)		2,850 (160~3,000)	
רו	運転	電流(A)	7.8	20	12.2		11.8		15.3		
	運転音(dB:	音響パワーレベル)	60	61	65	66	68	68	68	70	
房	冷房面積の	鉄筋アパート南向き洋室	28 m²/17畳		39 m²	39 m²/23畳		43 m²/26畳		49 m²/30畳	
	目安	木造南向き和室	18 m²/11畳		25 m²/15畳		29 m²/17畳		32 m²/20畳		
	定格能力	標準	5.0 (0.5	5~7.7)	6.7 (0.6	6~9.4)	7.1 (0.6	~10.1)	8.5 (0.9	~10.1)	
	(kW)	低温	5.6		6	.8	7	.3	7	.3	
暖	定格消費電力	標準	1,340 (145~2,850)		1,940(15	0~3,440)	2,320(15	0~3,980)	3,200 (15	0~3,980)	
坂	(W)	低温	2,520		3,0)40	3,5	520	3,5	520	
房		電流(A) 最大>	6.80 <15.0>		9.85 <17.0>		11.7 <20.0>		16.1 <20.0>		
כען	運転音(dB:	音響パワーレベル)	63	62	65	65	67	69	68	71	
	暖房面積の	競房面積の 鉄筋アパート南向き洋室		23 m²/14畳		30 m²/18畳		32 m²/20畳		39 m²/23畳	
	目安	木造南向き和室	18 m²	7/11畳	24 m²	7/15畳	26 m²/16畳		31 m²/19畳		
	通年エネルギー消費効率		5	.2	5	.0	5.0		4	.5	
	JIS C 9612:2005		5	.3	5	.0	5.0		4	.5	
	区分名		(5	F	=	[=	(3	
	質量	(kg)	10.5	26	11.5	39.5	11.5	40	11.5	40	
	外形寸法 さ×幅×奥行)	室内ユニット				295×79	98×239				
	(高さ×幅×奥行) (mm) 室外ユニット		551×78	551×780×289 630×799×299							

著作権など①

■ 無線LAN部

無線LAN規格 ·· IEEE802.11 b/g/n

周波数範囲…… 2.4 GHz帯

暗号化方式····· WPA™/WPA2™/WPA3™

変調方式がDSSSとOFDM方式

2.4 GHz帯 電波与干渉距離 を使用 2.4 DS/OF 4 40 m以下

2.4 GHzの帯域を使用し、かつ移動体識別装置の帯域を回避可能であることを意味する

■ Bluetooth®部

バージョン · · · · Bluetooth 5.0

(Bluetooth Low Energy)

接続周波数···· 2.4 GHz band

変調方式がその他の方式

2.4 GHz帯 電波与干渉距離 を使用 2.4 X X 8 80 m以下

2.4 GHzの帯域を使用し、かつ移動体識別装置の帯域を回避不可であることを意味する

- Android および Google Play は Google LLCの商標 または登録商標です。
- ●iPhoneは、米国および他の国々で登録された Apple Inc. の商標です。iPhoneの商標は、アイホン 株式会社のライセンスに基づき使用されています。
- ●"WPA™"、"WPA2™"および"WPA3™"は、 "Wi-Fi Alliance®"の商標です。
- App Storeは Apple Inc. のサービスマークです。
- ●Bluetooth®のワードマークおよびロゴは、 Bluetooth SIG, Inc. が所有する登録商標です。
- ●パナソニック株式会社は、これらのマークをライセンスに基づいて使用しています。 その他の商標およびトレードネームは、それぞれの所有者に帰属します。
- ●その他、本書に記載されている各種名称、会社名、商品 名などは各社の商標または登録商標です。 なお、本文 中では™、®マークは一部記載していません。

■ ソフトウェアについて

本製品は、以下の種類のソフトウェアから構成されています。

- (1) パナソニック株式会社(以下パナソニック)により、 またはパナソニックのために開発されたソフトウェア
- (2) 第三者が保有しており、パナソニックにライセンスされたソフトウェア
- (3) 条件に基づきライセンスされたオープンソースソフト ウェア

上記(3)に分類されるソフトウェアは、これら単体で有用であることを期待して頒布されますが、「商品性」または「特定の目的についての適合性」についての黙示の保証をしないことを含め、一切の保証はなされません。

ソフトウェアに関する詳細および最新の情報は、サポート総合窓口(https://panasonic.jp/support/)の商品別サポートのページで、本製品のカテゴリと品番に対応する形で提供されている取扱説明書をご参照ください。

cJSON

Copyright (c) 2009 Dave Gamble Copyright (c) 2009-2017 Dave Gamble and cJSON contributors

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

著作権など②

wpa_supplicant Copyright (c) 2005-2009, Jouni Malinen <j@w1.fi>Copyright (c) 2008, Jouni Malinen <j@w1.fi>

wpa_supplicant

Copyright (c) 2003-2019, Jouni Malinen <j@w1.fi> and contributors

This program is licensed under the BSD license (the one with advertisement clause removed).

If you are submitting changes to the project, please see CONTRIBUTIONS file for more instructions.

License

This software may be distributed, used, and modified under the terms of BSD license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

©COPYRIGHT(c) 2017 STMicroelectronics

(C) COPYRIGHT STMicroelectronics

Copyright (c) 2017 STMicroelectronics. All rights reserved.

Copyright (c) 2009-2017 ARM Limited. All rights reserved.

Copyright (c) 2009-2018 Arm Limited. All rights reserved.

Copyright (c) 2017-2018 Arm Limited. All rights reserved.

Copyright (c) 2017-2018 IAR Systems

Copyright (C) 2006-2015, ARM Limited, All Rights Reserved

Copyright (C) 2006-2015, ARM Limited, All Rights Reserved
Copyright (C) 2006-2016, ARM Limited, All Rights Reserved
Copyright (C) 2006-2018, ARM Limited, All Rights Reserved
Copyright (C) 2006-2018, ARM Limited, All Rights Reserved
Copyright (C) 2006-2018, Arm Limited (or its affiliates), All Rights Reserved
Copyright (C) 2006-2018, Arm Limited (or its affiliates), All Rights Reserved
Copyright (C) 2006-2019, ARM Limited, All Rights Reserved

Copyright (C) 2006-2019, Arm Limited (or its affiliates), All Rights Reserved

Copyright (C) 2016, ARM Limited, All Rights Reserved

Copyright (C) 2016-2018, ARM Limited, All Rights Reserved

Copyright (C) 2018, Arm Limited (or its affiliates), All Rights Reserved

Copyright (C) 2018, Arm Limited, All Rights Reserved Copyright The Mbed TLS Contributors

RealtekSDK

(C) COPYRIGHT 2011 STMicroelectronics (c) COPYRIGHT 2017 Realtek Semiconductor Corporation

Copyright (C) 2019 Amazon.com, Inc. or its affiliates. All Rights Reserved. Copyright (c) 2006-2013 ARM Limited

Copyright (c) 2009-2016 ARM Limited. All rights reserved.

Copyright (c) 2009-2017 ARM Limited. All rights reserved. Copyright (c) 2009-2018 Arm Limited. All rights reserved.

Copyright (c) 2013 ARM LIMITED All rights reserved.

Copyright (c) 2013 Realtek Semiconductor Corp. Copyright (c) 2013-2016 Realtek Semiconductor Corp.

Copyright (c) 2014, Realtek Semiconductor Corp. All rights reserved.

Copyright (c) 2015, Realsil Semiconductor Corporation. All rights reserved. Copyright (c) 2015, Realtek Semiconductor Corp. All rights reserved. Copyright (c) 2015, Realtek Semiconductor Corporation. All rights reserved.

Copyright (c) 2017, Realsil Semiconductor Corporation. All rights reserved.

Copyright (c) 2017, Realtek Semiconductor Corporation. All rights reserved.

Copyright (c) 2017-2018 Arm Limited. All rights reserved.

Copyright 2014 Tencent. All rights reserved.

Copyright(c) 2007 - 2012 Realtek Corporation. All rights reserved.

Copyright(c) 2007 - 2016 Realtek Corporation. All rights reserved.
Copyright(c) 2007 - 2016 Realtek Corporation. All rights reserved.
Copyright(c) 2007 - 2018 Realtek Corporation. All rights reserved.
Copyright(c) 2014, Realtek Semiconductor Corporation. All rights reserved.
Copyright(c) 2015, Realtek Semiconductor Corporation. All rights reserved.

Copyright(c) 2016, Realtek Semiconductor Corporation. All rights reserved.

Copyright(c) 2017, Realtek Semiconductor Corporation. All rights reserved.

Copyright(c) 2019, Realtek Semiconductor Corporation. All rights reserved.

copyright Kulesh Shanmugasundaram (kulesh [squiggly] isis.poly.edu)

Apache License Version 2.0, January 2004 http://www.apache.org/licenses/

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction. and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work

 Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.

- 3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contribution that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.
- 4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
 - (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
 - (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
 - (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
 - (d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

- 5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
- 6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.
- 7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
- 8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill,

work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.

9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

APPENDIX: How to apply the Apache License to your work.

To apply the Apache License to your work, attach the following boilerplate notice, with the fields enclosed by brackets "[]" replaced with your own identifying information. (Don't include the brackets!) The text should be enclosed in the appropriate comment syntax for the file format. We also recommend that a file or class name and description of purpose be included on the same "printed page" as the copyright notice for easier identification within third-party archives.

Copyright [yyyy] [name of copyright owner]

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at

http://www.apache.org/licenses/LICENSE-2.0

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied

See the License for the specific language governing permissions and limitations under the License.

CMSIS

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of STMicroelectronics nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

lwIP

Copyright (c) 1997 Global Election Systems Inc.

Copyright (c) 2001-2003 Swedish Institute of Computer Science.

Copyright (c) 2001-2003 Swedish Institute of Computer Science. All rights reserved.

Copyright (c) 2001-2004 Axon Digital Design B.V., The Netherlands. All rights reserved.

Copyright (c) 2001-2004 Leon Woestenberg leon.woestenberg@gmx.net Copyright (c) 2001-2004 Swedish Institute of Computer Science. All rights reserved.

Copyright (c) 2002 CITEL Technologies Ltd. All rights reserved.

Copyright (c) 2002-2003, Adam Dunkels.

Copyright (c) 2002-2003, Adam Dunkels. All rights reserved.

Copyright (c) 2003 by Marc Boucher, Services Informatiques (MBSI) inc. Copyright (c) 2003-2004 Axon Digital Design B.V., The Netherlands. All rights reserved.

著作権など(3)

Copyright (c) 2010 Inico Technologies Ltd. All rights reserved. Copyright (c) 2016 The MINIX 3 Project. All rights reserved.

- * Copyright (c) 2001, 2002 Swedish Institute of Computer Science.
- * All rights reserved.
- Redistribution and use in source and binary forms, with or without modification,
- are permitted provided that the following conditions are met:
- * 1. Redistributions of source code must retain the above copyright notice,
- this list of conditions and the following disclaimer.
- * 2. Redistributions in binary form must reproduce the above copyright notice,
- this list of conditions and the following disclaimer in the documentation
- and/or other materials provided with the distribution.
- * 3. The name of the author may not be used to endorse or promote products
- derived from this software without specific prior written permission.
- THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY * EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED
- TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS
- FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL
- THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR
- SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
- INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF
- LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT
- (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT
- * OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE * POSSIBILITY OF SUCH DAMAGE.

- * This file is part of the IwIP TCP/IP stack.
- * Author: Adam Dunkels <adam@sics.se>

FreeRTOS

Copyright (C) 2017 Amazon.com, Inc. or its affiliates. All Rights Reserved. Copyright (C) 2019 Amazon.com, Inc. or its affiliates. All Rights Reserved. Copyright (C) 2020 Amazon.com, Inc. or its affiliates. All Rights Reserved. Copyright (c) 2013 ARM LIMITED All rights reserved. Copyright 2016 STMicroelectronics International N.V. All rights reserved.

The FreeRTOS kernel is released under the MIT open source license, the text of which is provided below.

This license covers the FreeRTOS kernel source files, which are located in the /FreeRTOS/Source directory of the official FreeRTOS kernel download. It also covers most of the source files in the demo application projects, which are located in the /FreeRTOS/Demo directory of the official FreeRTOS download. The demo projects may also include third party software that is not part of FreeRTOS and is licensed separately to FreeRTOS. Examples of third party software includes header files provided by chip or tools vendors, linker scripts, peripheral drivers, etc. All the software in subdirectories of the /FreeRTOS directory is either open source or distributed with permission, and is free for use. For the avoidance of doubt, refer to the comments at the top of each source file.

License text:

Copyright (C) 2019 Amazon.com, Inc. or its affiliates. All Rights Reserved. Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Portions Copyright 2016 STMicroelectronics International N.V. All rights reserved.

Portions Copyright (c) 2013 ARM LIMITED

All rights reserved

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of ARM nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL COPYRIGHT HOLDERS AND CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

easy-ecc

Copyright (c) 2013, Kenneth MacKay All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

* Redistributions of source code must retain the above copyright notice, this

- list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

STM32CubeF4 HAL

©Copyright (c) 2016 STMicroelectronics. All rights reserved.
©Copyright (c) 2017 STMicroelectronics. All rights reserved.
©Copyright (c) 2018 STMicroelectronics. All rights reserved.
©Copyright (c) 2019 STMicroelectronics. All rights reserved. (C) COPYRIGHT STMicroelectronics

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name of the copyright holder nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS

INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

STM32CubeF4 Core

©Copyright (c) 2017 STMicroelectronics. All rights reserved. ©Copyright (c) 2020 STMicroelectronics. All rights reserved. ©Copyright (c) 2021 STMicroelectronics. All rights reserved.

(C) COPYRIGHT STMicroelectronics

Copyright (C) 2017 Amazon.com, Inc. or its affiliates. All Rights Reserved. Copyright (C) 2019 StMicroelectronics, Inc. All Rights Reserved.

SLA0044 Rev5/February 2018

BY INSTALLING COPYING, DOWNLOADING, ACCESSING OR OTHERWISE USING THIS SOFTWARE OR ANY PART THEREOF (AND THE RELATED DOCUMENTATION) FROM STMICROELECTRONICS INTERNATIONAL N.V. SWISS BRANCH AND/OR ITS AFFILIATED COMPANIES (STMICROELECTRONICS), THE RECIPIENT, ON BEHALF OF HIMSELF OR HERSELF, OR ON BEHALF OF ANY ENTITY BY WHICH SUCH RECIPIENT IS EMPLOYED AND/OR ENGAGED AGREES TO BE BOUND BY THIS SOFTWARE LICENSE AGREEMENT.

Under STMicroelectronics' intellectual property rights, the redistribution, reproduction and use in source and binary forms of the software or any part thereof, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistribution of source code (modified or not) must retain any copyright notice, this list of conditions and the disclaimer set forth below as items 10 and 11.
- 2. Redistributions in binary form, except as embedded into microcontroller or microprocessor device manufactured by or for STMicroelectronics or a software update for such device, must reproduce any copyright notice provided with the binary code, this list of conditions, and the disclaimer set forth below as items 10 and 11, in documentation and/or other materials provided with the distribution.
- 3. Neither the name of STMicroelectronics nor the names of other contributors to this software may be used to endorse or promote products derived from this software or part thereof without specific written permission.
- 4. This software or any part thereof, including modifications and/or derivative works of this software, must be used and execute solely and exclusively on or in combination with a microcontroller or microprocessor device manufactured by or for STMicroelectronics.
- 5. No use, reproduction or redistribution of this software partially or totally may be done in any manner that would subject this software to any Open Source Terms. "Open Source Terms" shall mean any open source license which requires as part of distribution of software that the source code of such software is distributed therewith or otherwise made available, or open source license that substantially complies with the Open Source definition specified at www.opensource.org and any other comparable open source license such as for example GNU General Public License (GPL), Eclipse Public License (EPL), Apache Software License, BSD license or MIT license.
- 6. STMicroelectronics has no obligation to provide any maintenance, support or updates for the software.
- 7. The software is and will remain the exclusive property of STMicroelectronics and its licensors. The recipient will not take any action that jeopardizes STMicroelectronics and its licensors' proprietary rights or acquire any rights in the software, except the limited rights specified hereunder.

 8. The recipient shall comply with all applicable laws and regulations affecting
- the use of the software or any part thereof including any applicable export control law or regulation.
- 9. Redistribution and use of this software or any part thereof other than as permitted under this license is void and will automatically terminate your rights under this license.
- 10. THIS SOFTWARE IS PROVIDED BY STMICROELECTRONICS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS, IMPLIED OR STATUTORY WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS, WHICH ARE DISCLAIMED TO THE FULLEST EXTENT PERMITTED BY LAW. IN NO EVENT SHALL STMICROELECTRONICS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
- 11. EXCEPT AS EXPRESSLY PERMITTED HEREUNDER, NO LICENSE OR OTHER RIGHTS, WHETHER EXPRESS OR IMPLIED, ARE GRANTED UNDER ANY PATENT OR OTHER INTELLECTUAL PROPERTY RIGHTS OF STMICROELECTRONICS OR ANY THIRD PARTY.

newlib

The newlib subdirectory is a collection of software from several sources.

Each file may have its own copyright/license that is embedded in the source file. Unless otherwise noted in the body of the source file(s), the following copyright notices will apply to the contents of the newlib subdirectory:

(1) Red Hat Incorporated

Copyright (c) 1994-2009 Red Hat, Inc. All rights reserved.

This copyrighted material is made available to anyone wishing to use, modify, copy, or redistribute it subject to the terms and conditions of the BSD License. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY expressed or implied, including the implied warranties of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. A copy of this license is available at http://www.opensource.org/licenses. Any Red Hat trademarks that are incorporated in the source code or documentation are not subject to the BSD License and may only be used or replicated with the express permission of Red Hat, Inc.

(2) University of California, Berkeley

Copyright (c) 1981-2000 The Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice,
- this list of conditions and the following disclaimer.

 Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(3) David M. Gay (AT&T 1991, Lucent 1998)

The author of this software is David M. Gay.

Copyright (c) 1991 by AT&T.

Permission to use, copy, modify, and distribute this software for any purpose without fee is hereby granted, provided that this entire notice is included in all copies of any software which is or includes a copy or modification of this software and in all copies of the supporting documentation for such software.

THIS SOFTWARE IS BEING PROVIDED "AS IS", WITHOUT ANY EXPRESS OR IMPLIED WARRANTY. IN PARTICULAR, NEITHER THE AUTHOR NOR AT&T MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND CONCERNING THE MERCHANTABILITY OF THIS SOFTWARE OR ITS FITNESS FOR ANY PARTICULAR PURPOSE.

The author of this software is David M. Gay.

Copyright (C) 1998-2001 by Lucent Technologies All Rights Reserved

Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that the copyright notice and this permission notice and warranty disclaimer appear in supporting documentation, and that the name of Lucent or any of its entities not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

LUCENT DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL LUCENT OR ANY OF ITS ENTITIES BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN

著作権など4

ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

(4) Advanced Micro Devices

Copyright 1989, 1990 Advanced Micro Devices, Inc.

This software is the property of Advanced Micro Devices, Inc (AMD) which specifically grants the user the right to modify, use and distribute this software provided this notice is not removed or altered. All other rights are reserved by

AMD MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS SOFTWARE. IN NO EVENT SHALL AMD BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THE FURNISHING, PERFORMANCE, OR USE OF THIS SOFTWARE.

So that all may benefit from your experience, please report any problems or suggestions about this software to the 29K Technical Support Center at 800-29-29-AMD (800-292-9263) in the USA, or 0800-89-1131 in the UK, or 0831-11-1129 in Japan, toll free. The direct dial number is 512-462-4118.

Advanced Micro Devices, Inc. 29K Support Products Mail Stop 573 5900 E. Ben White Blvd. Austin, TX 78741 800-292-9263

(7) Sun Microsystems

Copyright (C) 1993 by Sun Microsystems, Inc. All rights reserved.

Developed at SunPro, a Sun Microsystems, Inc. business. Permission to use, copy, modify, and distribute this software is freely granted, provided that this notice is preserved.

- (8) Hewlett Packard
- (c) Copyright 1986 HEWLETT-PACKARD COMPANY

To anyone who acknowledges that this file is provided "AS IS" without any express or implied warranty:

permission to use, copy, modify, and distribute this file for any purpose is hereby granted without fee, provided that the above copyright notice and this notice appears in all copies, and that the name of Hewlett-Packard Company not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission. Hewlett-Packard Company makes no representations about the suitability of this software for any purpose.

(9) Hans-Peter Nilsson

Copyright (C) 2001 Hans-Peter Nilsson

Permission to use, copy, modify, and distribute this software is freely granted, provided that the above copyright notice, this notice and the following disclaimer are preserved with no changes.

THIS SOFTWARE IS PROVIDED ``AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

(11) Christopher G. Demetriou

Copyright (c) 2001 Christopher G. Demetriou All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER

IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(12) SuperH, Inc.

Copyright 2002 SuperH, Inc. All rights reserved

This software is the property of SuperH, Inc (SuperH) which specifically grants the user the right to modify, use and distribute this software provided this notice is not removed or altered. All other rights are reserved by SuperH.

SUPERH MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS SOFTWARE. IN NO EVENT SHALL SUPERH BE LIABLE FOR INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THE FURNISHING, PERFORMANCE, OR USE OF THIS SOFTWARE.

So that all may benefit from your experience, please report any problems or suggestions about this software to the SuperH Support Center via e-mail at softwaresupport@superh.com.

SuperH, Inc. 405 River Oaks Parkway San Jose CA 95134 USA

(13) Royal Institute of Technology

Copyright (c) 1999 Kungliga Tekniska Högskolan (Royal Institute of Technology, Stockholm, Sweden). All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of KTH nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY KTH AND ITS CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL KTH OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(14) Alexey Zelkin

Copyright (c) 2000, 2001 Alexey Zelkin <phantom@FreeBSD.org> All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
 Redistributions in binary form must reproduce the above copyright notice,
- Redistributions in binary form must reproduce the above copyright notice this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(15) Andrey A. Chernov

Copyright (C) 1997 by Andrey A. Chernov, Moscow, Russia. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(16) FreeBSD

Copyright (c) 1997-2002 FreeBSD Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(17) S. L. Moshier

Author: S. L. Moshier.

Copyright (c) 1984,2000 S.L. Moshier

Permission to use, copy, modify, and distribute this software for any purpose without fee is hereby granted, provided that this entire notice is included in all copies of any software which is or includes a copy or modification of this software and in all copies of the supporting documentation for such software.

THIS SOFTWARE IS BEING PROVIDED "AS IS", WITHOUT ANY EXPRESS OR IMPLIED WARRANTY. IN PARTICULAR, THE AUTHOR MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND CONCERNING THE MERCHANTABILITY OF THIS SOFTWARE OR ITS FITNESS FOR ANY PARTICULAR PURPOSE.

(18) Citrus Project

Copyright (c)1999 Citrus Project, All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE

DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(19) Todd C. Miller

Copyright (c) 1998 Todd C. Miller <Todd.Miller@courtesan.com> All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
 Redistributions in binary form must reproduce the above copyright notice,
- Redistributions in binary form must reproduce the above copyright notice this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(20) DJ Delorie (i386) Copyright (C) 1991 DJ Delorie All rights reserved.

Redistribution, modification, and use in source and binary forms is permitted provided that the above copyright notice and following paragraph are duplicated in all such forms.

This file is distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

(23) Intel (i960)

Copyright (c) 1993 Intel Corporation

Intel hereby grants you permission to copy, modify, and distribute this software and its documentation. Intel grants this permission provided that the above copyright notice appears in all copies and that both the copyright notice and this permission notice appear in supporting documentation. In addition, Intel grants this permission provided that you prominently mark as "not part of the original" any modifications made to this software or documentation, and that the name of Intel Corporation not be used in advertising or publicity pertaining to distribution of the software or the documentation without specific, written prior permission.

Intel Corporation provides this AS IS, WITHOUT ANY WARRANTY, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Intel makes no guarantee or representations regarding the use of, or the results of the use of, the software and documentation in terms of correctness, accuracy, reliability, currentness, or otherwise; and you rely on the software, documentation and results solely at your own risk.

IN NO EVENT SHALL INTEL BE LIABLE FOR ANY LOSS OF USE, LOSS OF BUSINESS, LOSS OF PROFITS, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND. IN NO EVENT SHALL INTEL'S TOTAL LIABILITY EXCEED THE SUM PAID TO INTEL FOR THE PRODUCT LICENSED HEREUNDER.

(26) Mike Barcroft

Copyright (c) 2001 Mike Barcroft <mike@FreeBSD.org> All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

 Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

著作権など(5)

2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(27) Konstantin Chuguev (--enable-newlib-iconv)

Copyright (c) 1999, 2000 Konstantin Chuguev. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright

- notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

iconv (Charset Conversion Library) v2.0

(28) Artem Bityuckiy (--enable-newlib-iconv)

Copyright (c) 2003, Artem B. Bityuckiy, SoftMine Corporation. Rights transferred to Franklin Electronic Publishers.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this

- list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS 'AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES: LOSS OF USE, DATA, OR PROFITS: OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(30) - Alex Tatmanjants (targets using libc/posix)

Copyright (c) 1995 Alex Tatmanjants <alex@elvisti.kiev.ua> at Electronni Visti IA, Kiev, Ukraine. All rights reserved.

Redistribution and use in source and binary forms, with or without

- modification, are permitted provided that the following conditions are met: 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(31) - M. Warner Losh (targets using libc/posix)

Copyright (c) 1998, M. Warner Losh <imp@freebsd.org>

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVÉN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(32) - Andrey A. Chernov (targets using libc/posix)

Copyright (C) 1996 by Andrey A. Chernov, Moscow, Russia. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(33) - Daniel Eischen (targets using libc/posix)

Copyright (c) 2001 Daniel Eischen <deischen@FreeBSD.org>. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS 'AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR

CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO. PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(35) - ARM Ltd (arm and thumb variant targets only)

Copyright (c) 2009-2015 ARM Ltd All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. The name of the company may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY ARM LTD "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL ARM LTD BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(41) Ed Schouten - Free BSD

Copyright (c) 2008 Ed Schouten <ed@FreeBSD.org> All rights reserved

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2016, Synopsys, Inc. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1) Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2) Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3) Neither the name of the Synopsys, Inc., nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR

CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2016 Joel Sherrill < joel@rtems.org>. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(48)

From musl include/elf.h

Copyright © 2005-2014 Rich Felker, et al.t

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Copyright (c) 2008 Otto Moerbeek <otto@drijf.net>

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS" AND THE AUTHOR DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Copyright (c) 2017 embedded brains GmbH All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

著作権など(6)

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, the distributions in binary form must reproduce the above copyright hour this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS
BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL,
EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT
LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES;
LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER
IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE
OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(51)

From musl src/string/strverscmp.c

Copyright © 2005-2014 Rich Felker, et al.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

(52)

++Copyright++ 1983, 1993

Copyright (c) 1983, 1993

The Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS 'AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions Copyright (c) 1993 by Digital Equipment Corporation.

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies, and that the name of Digital Equipment Corporation not be used in advertising or publicity pertaining to distribution of the document or software without specific, written prior permission

THE SOFTWARE IS PROVIDED "AS IS" AND DIGITAL EQUIPMENT CORP. DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL DIGITAL EQUIPMENT CORPORATION BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

--Copyright--

Copyright (c) 2015 John Baldwin <jhb@FreeBSD.org>. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name of the author nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (C) 1995, 1996, 1997, and 1998 WIDE Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

 3. Neither the name of the project nor the names of its contributors may be
- used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE PROJECT AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE PROJECT OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

\$KAME: in6.h,v 1.89 2001/05/27 13:28:35 itojun Exp \$

Copyright (c) 2008, Jeffrey Roberson <jeff@freebsd.org> All rights reserved.

Copyright (c) 2008 Nokia Corporation All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice

- unmodified, this list of conditions, and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR 'AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

\$FreeBSD: head/sys/sys/_bitset.h 299184 2016-05-06 16:41:23Z royger \$

Copyright (c) 1982, 1986, 1990, 1993, 1994

The Regents of the University of California. All rights reserved. (c) UNIX System Laboratories, Inc.

All or some portions of this file are derived from material licensed to the University of California by American Telephone and Telegraph Co. or Unix System Laboratories, Inc. and are reproduced herein with the permission of UNIX System Laboratories, Inc.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

 3. Neither the name of the University nor the names of its contributors may
- be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Configuration for math routines. Copyright (c) 2017 ARM Ltd. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. The name of the company may not be used to endorse or promote products derived from this software without specific prior written permission

THIS SOFTWARE IS PROVIDED BY ARM LTD ''AS IS AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL ARM LTD BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2007 The NetBSD Foundation, Inc. All rights reserved.

This code is derived from software written by Stephen L. Moshier. It is redistributed by the NetBSD Foundation by permission of the author. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice,

- this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE NETBSD FOUNDATION, INC. AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(59) (c) Copyright 2017 Michael R. Neilly All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice. this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the names of the copyright holders nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

保証とアフターサービス(よくお読みください)

使いかた・お手入れ・修理などは

■まず、お買い上げ先へご相談ください。

お買い上げの際に記入されると便利です

■転居や贈答品などでお困りの場合は、 裏表紙の各ご相談窓口へご相談ください。

販売店名 お買い上げ日 年 月 日 雷 話) (

修理を依頼されるときは

「よくあるお問い合わせ | (P.44、45) 「故障かな? | (P.46~50)「タイマーランプが点滅するときは | (P.51)でご確認のあと、直らないときは、運転停止後、 電源プラグを抜いて、お買い上げ日と右の内容をご連絡 ください。



●保証期間中は、保証書の規定にしたがって出張修理いたします。

保証期間: お買い上げ日から本体1年間(ただし、冷媒回路については5年間です)

- ●保証期間終了後は、診断をして修理できる場合はご要望により修理させていただきます。
- ※修理料金は次の内容で構成されています。

| 技術料|| 診断・修理・調整・点検などの費用

部品代制部品および補助材料代


出張料 技術者を派遣する費用

※補修用性能部品の保有期間 10年

当社は、このルームエアコンの補修用性能部品(製品 の機能を維持するための部品)を、製造打ち切り後10 年保有しています。

■「よく冷えない」症状で依頼される場合は

より早くご相談にお応えするため、事前に冷房チェック運転を行ってください。





●お知らせ音がするとき

冷房・しっとり冷房・除湿・冷房除湿が 正常に運転できない要因があります。

⇒お知らせ音が、次のどちらかご連絡 ください。

ピッピッピッピッピッ	冷媒の不足など
ピーピーピー	エアフィルター の目詰まりなど

●お知らせ音・運転ランプの点滅は、 約3分間で止まります。

●お知らせ音がしないとき

故障かな?(P.46、47)を再度ご確認の うえ、冷えない場合はご相談ください。

●冷房チェック運転やお知らせ音、運転ランプの点滅を途中で止めたいとき 停止ボタンを押す。

室内ユニットのクリーニングをご要望される場合は

お買い上げの販売店、または修理ご相談窓口(裏表紙)へご相談ください。 (ただし、室内ユニットの取りはずしができない等、設置状況によっては対応できないことがあります)

MEMO	

ご相談窓口/商品登録

使いかた・お手入れ・修理などはまず、お買い上げ先へご相談ください。 転居や贈答品などでお困りの場合は、次の窓口にご相談ください。

サポート総合窓口

https://panasonic.jp/support/

修理に関するご相談窓口

OO 0120-878-554

03-6633-6700

https://panasonic.jp/support/repair.html

■ 上記電話番号がご利用いただけない場合



エアコン 使い方・お手入れなどのご相談窓口

パナは ロクキュウニ **100** 0120-878-692

9:00~18:00 月曜日~土曜日 (祝日・正月三が日を除く)

- 上記電話番号がご利用いただけない場合 06-6907-1187
- ■FAX フリーダイヤル **図 0120-878-236**


Help desk for foreign residents in Japan Tokyo (03) 3256 - 5444 Osaka (06) 6645 - 8787 Open: 9:00 - 17:30 (closed on Saturdays/Sundays/national holidays)

アプリの初期設定に関するお問い合わせ

パナは ハチサンニ 受付時間 0120-878-832

9:00~18:00 月曜日~土曜日

(祝日・正月三が日を除く)



【ご相談窓口におけるお客様の個人情報のお取り扱いについて】

パナソニック株式会社およびグループ関係会社は、お客様の個人情報をご相談対応や修理対応などに利用させていただき、 ご相談内容は録音させていただきます。また、折り返し電話をさせていただくときのために発信番号を通知いただいており ます。なお、個人情報を適切に管理し、修理業務等を委託する場合や正当な理由がある場合を除き、第三者に開示・提供い たしません。個人情報に関するお問い合わせは、ご相談いただきました窓口にご連絡ください。

パナソニックの会員サイト「CLUB Panasonic」で「商品登録」 をお願いします


特典

- ●お持ちの家電商品、消耗品情報が一元管理できる!
- ●登録商品に関するお知らせやサポート情報が入手できる!
- ●登録者限定のキャンペーンに参加できる!

詳しくはこちら https://club.panasonic.jp/aiyo/



●保証書用封筒に記載されている QRコードを読み取っていただくと、 品番登録と製造番号を入力する必要がなく、 簡単に登録していただけます



・QRコードは、株式会社デンソーウェーブの登録商標です。

長年ご使用のルームエアコンの点検を!



こんな症状は ありませんか

- ブレーカーがたびたび切れる。運転中にこげ臭いにおいがする。
- ●室内ユニットから水が漏れる。
- ●電源コードやプラグが異常に熱くなり、変色している。
- 室内や室外ユニットの取り付け部分が腐食したり、
- 取り付けがゆるんでいる。
- ●その他の異常や故障がある。 ●異常な音や振動がする。



事故防止のため電 源プラグを抜いて、 必ず販売店へ点検 をご依頼ください。



家庭用エアコンにはGWP(地球温暖化係数)が 675のフロン類(R32)が封入されています。 地球温暖化防止のため、移設・修理・廃棄等に あたってはフロン類の回収が必要です。

- ●これは、エアコンに温暖化ガス(フロン類)が封入されている ことを認識いただくための表示です。
- 取りはずし時には、フロン類の回収が必要です。また、廃棄時 は、家電リサイクル法に基づく適正な引渡しをしていただく と、確実にフロン類の適正処理がされます。

廃棄時にご注意 家電リサイクル法では、お客様がご使用済みのルームエアコンを廃棄される場合は、収集・運搬料金、再 商品化等料金をお支払いいただき、対象商品を販売店等に適正に引き渡すことが求められています。

パナソニック株式会社 空調冷熱ソリューションズ事業部

〒525-8520 滋賀県草津市野路東2丁目3番1-1号