


Panasonic®

取扱説明書

ルームエアコン(家庭用)



室内ユニット品番

CS-GX223D	CS-GX253D
CS-GX283D	CS-GX363D
CS-GX403D2	CS-GX563D2
CS-GX633D2	
CS-223DGE	CS-253DGE
CS-283DGE	CS-363DGE
CS-403DG2E	CS-563DG2E
CS-633DG2E	
CS-223DGX	CS-253DGX
CS-283DGX	CS-363DGX
CS-403DGX2	CS-563DGX2
CS-633DGX2	

室外ユニット品番

CU-GXシリーズ
CU-DGEシリーズ
CU-DGXシリーズ

保証書・据付工事説明書 別添付

このたびは、パナソニック製品をお買い上げいただき、まことにありがとうございます。

- 取扱説明書をよくお読みのうえ、正しく安全にお使いください。
- ご使用前に「安全上のご注意」(P.4~6)を必ずお読みください。
- 保証書は「お買い上げ日・販売店名」などの記入を確かめ、取扱説明書、据付工事説明書とともに大切に保管してください。
- 商品の品番は、本体の品番表示(P.8)と仕様(P.53)でご確認ください。

パナソニックの会員サイト
「CLUB Panasonic」で
「商品登録」をお願いします

詳しくは裏表紙をご覧ください

ナノイー×で 部屋の空気をきれいに！(P.39)



ナノイー× 送風

冷暖房のいらない季節におすすめ。
(P.11)

においケア

部屋にいながら、
部屋の“におい”を軽減。
来客の前などにおすすめ。(P.14)

おでかけ クリーン

人のいらない時間を上手に使って
部屋の“におい”を軽減。
エアコンの中もきれいに。(P.30)

Panasonic
エアコン

もくじ

ページ

必ずお読みください

安全上のご注意	4
使用上のお願い	7
各部の名前と役割・付属品	8
リモコンを準備する	10

使いかた

運転する	11
AI快適機能で自動調節する	12
風向・風量を調節する	13
部屋のにおいを軽減する	14
停止中に室温みはりを使う	15
タイマーを予約する	16
●おやすみ切タイマー ●切タイマー／入タイマー	
エオリア アプリを使う	18
お買い上げ時の設定を変更する(メニュー)	23

キレイにお使いいただくために

おそうじ運転を使いこなす	29
●おそうじタイマー ●手動おそうじ運転	
●おでかけクリーン ●カビみはり	
お手入れ	32

もっと詳しく知りたいとき

自動・冷房・除湿切換について	36
暖房について	37
●霜取り運転	
「AI快適」「AI快適エコナビ」について	38
「ナノイーX」について	39
おそうじ機能について	40
風向・風量自動時の風の動き	42

必要なとき

こんなときは	43
よくあるお問い合わせ	44
故障かな?	46
タイマーランプが点滅するときは	52
仕様	53
著作権など	54
長期使用製品安全表示制度に基づく本体表示について	62
保証とアフターサービス	63
ご相談窓口／商品登録	裏表紙

エオリア アプリ

エアコン操作をスマートフォンで! (P.18)



●エオリア アプリのご紹介サイト
<https://panasonic.jp/aircon/app.html>

●パナソニックの加湿空気清浄機と連動して、暖房運転時に加湿することもできます。 (P.11)

安全上のご注意①

必ずお守りください

人への危害、財産の損害を防止するため、必ずお守りいただくことを説明しています。

■誤った使い方をしたときに生じる危害や損害の程度を区分して、説明しています。



警告

「死亡や重傷を負うおそれがある内容」です。



注意

「軽傷を負うことや、財産の損害が発生するおそれがある内容」です。

■お守りいただく内容を次の図記号で説明しています。



してはいけない内容(禁止事項)です。



実行しなければならない内容(強制事項)です。



火災や感電、
大けがを防ぐために



警告

異常・故障時



必ず守る

- すぐに使用を中止し、電源プラグを抜く
またはブレーカーを切る
(発煙・発火・感電の原因)

異常・故障例

- ・ブレーカーがたびたび切れる。
- ・こげ臭いにおいがする。
- ・電源のプラグ・コードが異常に熱くなる。
- ・異常な音がする。ガタガタと振動する。
- ・タイマーランプが点滅する。
- ・室内ユニットから水が漏れる。
- ・風量が調節できない。
- ・運転しても、すぐに停止する。
- ・停止ボタンを数回押しても風が止まらない。

すぐ、販売店に点検・修理を依頼してください。
タイマーランプが点滅するときは、P.52の内容にしたがって
対応してください。

お手入れ時



禁止

- お客様自身で、工具を使った分解掃除、内部洗浄はしない
(水漏れや発煙、発火の原因)
- ・お買い上げの販売店または
パナソニック修理ご相談窓口
にご相談ください。



電源のプラグ・コード



禁止



- 途中で接続したり、延長コードの使用、
タコ足配線をしない
- 束ねたり、無理に
曲げたりしない
- ぬれた手で抜き
差ししない
- 運転中にプラグを抜かない
- コードを持って抜かない
(感電や、放電・絶縁不良・断線などによる発熱・
発火・火災の原因)



必ず守る

- 破損した場合は、使用せず販売店に
修理を依頼する
- プラグは、根元まで確実に差し込む
- 定期的にプラグのほこりを
乾いた布でふき取る
(接触不良・絶縁不良による
発熱・発火・火災や、接触不良
による感電の原因)




運転時や取り扱い時



禁止

- リモコンを乳幼児の手の届く所に置かない
(乾電池を取り出し、誤飲するおそれ)
- リモコンの乾電池の $\oplus\ominus$ を逆に入れない
(ショートによる発火や液漏れの原因)
- 室内ユニットの左右風向ルーバーより奥
に、指や棒などを入れない
- 室外ユニットの吹出口に、指や棒などを
入れない
(内部でファンが高速回転
しているため、けがをする
原因)



- 長時間、冷風を体に直接当てる
体を冷やすすぎたりしない
(体調不良の原因)
・特に、ご自身で調節でき
ない乳幼児や身体の
不自由な方・高齢者など
にはご注意ください。




- 室外ユニットの上に乗ったり、
物を載せたりしない
(転落や落下の原因)
・特にベランダなど高い場所
に設置の場合はご注意
ください。



⚠ 警告

室内ユニット



無線LANランプ点灯中



- 室内ユニットに医療機器や自動制御機器（自動ドア、火災警報器など）を近づけない
(室内ユニットからの電波が機器に影響を及ぼすことがあり、誤動作による事故の原因)



- 心臓ペースメーカーを装着している方は、装着部を室内ユニットから15cm以上離す
(室内ユニットからの電波による誤作動の原因)

据え付けや移設・修理時

必ずお買い上げの販売店

または専門業者に依頼してください



- 販売店や専門業者に次のことを確認する
 - エアコン専用の電源コンセントおよびブレーカーが単独で使われていること
(火災の原因)
 - アースや漏電しゃ断器が設置されていること
(感電の原因)
 - 冷媒が漏れていないこと
(冷媒が火気に触れると、有毒ガスの発生や火災の原因)
 - ・ 通常は漏れませんが、冷えない・暖まらない場合は漏れている可能性があるので、販売店にご相談ください。
 - 指定冷媒が使用されていること
(指定以外の冷媒を使用すると、機器の故障や破裂、けがなどの原因)

本体に付属のリモコン以外で遠隔操作をするとき

宅外やエアコン設置場所以外の部屋から操作するときは、エアコンやその周辺、在室する人などの状態を確認することができません。また、無線通信を利用するため通信環境や使用状況、ネットワーク障害などにより、遠隔操作がご利用できない場合があります。場合によっては、人などが死亡・重傷を負ったり、財産の損害が発生したりするおそれがあります。事前に安全を十分確認してお使いください。



事前に以下の内容を確認しておく

- 電源プラグが確実に差し込まれていること。プラグにほこりがたまっていないこと
(接触不良や絶縁不良によるプラグからの発熱や発火、火災の原因)
- 他の人が設定したタイマー予約などの設定状況
(思わぬ運転や停止により、体調をくずす原因。動植物に悪影響を及ぼす原因)
- エアコンに異常がないこと。風の変化があっても、人や部屋に悪影響がでないこと
(飛びやすい物がない等)
(風により物が落下し、火災やけが、家財汚損の原因)
- 遠隔操作ができなくても、人や財産などに悪影響がでないこと
(運転や停止ができず、体調をくずす原因。動植物に悪影響を及ぼす原因)
 - ・ 操作が必要な場合は、付属のリモコンで操作してください。
 - ・ 乳幼児や身体の不自由な方・高齢者などで自身でリモコン操作ができない方のみで在室している場合は、ご利用にならないでください。

操作前・操作中に以下の内容を確認する

- 人がいることが分かっているときは、室外から運転や停止することを知らせておく
(台などに乗っていた場合、突然の運転や停止に驚いて落下・転倒の原因。また、急激な外気温・室温の変化等により、体調をくずす原因)
 - ・ 温度調節や停止は、付属のリモコンでも操作できます。
- こまめに設定内容や運転状況を確認する
(急激な外気温・室温の変化等により、体調をくずす原因。動植物に悪影響を及ぼす原因)
 - ・ 操作が反映されなかった場合は、付属のリモコンで操作してください。
 - ・ エラーが表示されたときは、運転を停止し、お買い上げの販売店にご相談ください。
エアコンが停止していることを再確認してください。

安全上のご注意②

必ずお守りください



漏電やけがを
防ぎ、家財など
を守るために

⚠ 注意

運転時や取り扱い時



禁止

- 落雷のおそれがあるときは、運転を停止して、エアコンに触れない
(感電の原因)
- 直接水洗いしたり、水の入った容器を載せたりしない
(水が中に入ると感電や発火の原因)
- 室内ユニット・室外ユニットのアルミ部分に触らない
(手を切る原因)
- 据付台を破損したままで使用しない
(室外ユニットや据付台の落下・転倒の原因)
- 風を動植物に直接当てない
- 室内ユニットの下に電気製品や家財などを置かない
(水滴が落ちる場合があり、汚損や故障の原因)
 - ・テレビやベッドなどを置かないでください。
- 湿度が高いとき(80 %以上)に、窓や戸を開けたままで冷房や除湿を長時間運転しない
(室内ユニットから水滴が落ちて家財などを汚損する原因)
 - ・特に雨の日や梅雨の時期にはご注意ください。
- 床などにワックスをかけるときは運転しない
(内部にワックス成分が付着すると、結露による水漏れや水飛びの原因)
 - ・ワックスをかけた後は窓やドアを開けて十分に換気後、運転してください。
- ドレンホースは排水を確実にし、先端をふさがない
(室内ユニットから水漏れる原因)
 - ・虫や落ち葉などが詰まらないようご注意ください。
- 精密機器や食品、動植物、美術品の保存などに使わない
(品質低下などの原因)




必ず守る

- 長期間使用しないときは電源プラグを抜く
(ほこりによる発熱や発火の原因)
- 燃焼器具は風が直接当たらない場所で使用する
(不完全燃焼の原因)
- 燃焼器具と一緒に運転するときはこまめに換気する
(酸素不足による頭痛などの原因)
 - ・このエアコンで換気はできません。

室内ユニット

アルミ部分



お手入れ時



禁止



必ず守る

- 不安定な台に乗らない



- 運転を停止し、電源プラグを抜く
(ファンが高速回転しているため、けがをする原因)
- 前面パネルの水洗い後は、水気を十分ふき取る
(漏電の原因)

据え付け・移設時



必ず守る

- 可燃性ガスの漏れるおそれのない場所に、据え付けされていることを確認する
(万一ガスが漏れてユニットの周囲にたまると、発火の原因)

室外ユニット


吸込口
(裏面)
(アルミフィン
/アルミ部分)

ドレン
ホース

据付台

据付台

使用上のお願い



まず、室内・室外ユニット周辺の確認を!

〈室内ユニット〉

- 吸入口・吹出口付近がタンスなどでふさがれていませんか?
- 火災警報器は吹出口から 1.5 m 以上離れてていますか?
- テレビやラジオは、1 m 以上離れてていますか?
(映像の乱れ、雑音の原因)



リモコンは 室内ユニットの 受信部に向けて!


操作は、室内ユニット正面から
7 m 以内で行ってください。

- 受信は音でお知らせします。

受信音	お知らせしている内容
ピッ	運転開始や設定、設定の取り消し
ピッピッ	設定温度の上限または下限
ピー	停止

●リモコンホルダー（付属品）

リモコンを壁などに取り付けることができます。取り付け場所で、リモコンの運転開始ボタンを押し、受信できることを確認してから取り付けてください。取り付け後、部屋の環境変化などによって、受信しないことがあります。




〈リモコン〉

- 他のリモコンのボタンが押されていませんか?
(リモコンラックなどに当たって押されていると、混信して受信できない原因)
- 複数台のエアコンを使うときは、混信を防ぐ設定にできます。(P.24)



〈室外ユニット〉

- 吸入口や吹出口が積雪や植木鉢などでふさがれていませんか?
- ドレンホースの先端(排水口)がふさがれていませんか?
また、排水したときに、動植物に影響がでませんか?
- 吹出口からの風が、周囲の迷惑になつたり
動植物に直接当たつたりしませんか?
- テレビやラジオは、2 m 以上
離れてていますか?
(映像の乱れ、雑音の原因)



※スペースを確保してください。

- 油煙の多い場所への設置は避けてください。
(調理場や機械工場など)

- 積雪の多い地域では、防雪対策をおすすめします。
お買い上げの販売店へご相談ください。

リモコンの乾電池について

■乾電池は

- 寿命は約1年です。
消耗すると、受信しにくくなったり、リモコンの表示が薄くなったりします。
- 長期間使わないときは、取り出してください。
(液漏れ防止のため)
- 乾電池が切れたときは、本体で応急運転ができます。(P.43)


■乾電池を交換するときは

- 単4形アルカリ乾電池(LR03タイプ)を2本同時に交換してください。(マンガン乾電池では、使用期間が短くなります)
- 充電式電池(Ni-Cd、ニッケル水素など)は使わないでください。(サイズ、形、性能の一部が異なるため)
- 交換後、時刻を合わせてください。(P.10)

各部の名前と役割・付属品


室内ユニット

- この製品は、遠隔操作をするための無線装置を搭載しています。



〈前面パネルを開けたとき〉

空気清浄フィルター
空気中の花粉やほこり
をキャッチします。
(P.34)



応急運転ボタン(P.43)


- 無線LAN接続を切断する
ときにも使います。(P.20)

表示部 (本体ランプ) 運転や設定の状況をお知らせ。本体に付属のリモコン以外で遠隔操作をしたときにも点灯・点滅することがあります。

運転	タイマー	ナノイーX/おそうじ	ボックスお手入れ	無線LAN
ランプ名				お知らせしている内容
運転	緑	点灯	冷房・暖房・除湿切換・自動・ナノイーX送風運転中(P.11)	
		点滅	自動・暖房運転開始時、または霜取り運転中(P.36、37)	
タイマー	橙	点灯	おやすみ切タイマー・切タイマー/入タイマー予約中(P.16、17)	
		点滅	本体の異常(P.52)	
ナノイーX/おそうじ	青	点灯	ナノイーX発生中(P.11、14、39) フィルターおそうじ・内部クリーン運転中(P.30、40、41)	
ボックスお手入れ	橙	点灯	ダストボックスのお手入れ時期をお知らせ(P.32)	
		点滅	ダストボックスのお手入れ時期が過ぎているため、早くお手入れが必要なことをお知らせ(P.32、33)	
(無線LAN)	青	点灯	無線LANの通信ができる状態(P.18~22)	
		点滅	無線接続の交信中	


室外ユニット

- 品番によって、形状・大きさが
異なります。




付属品

- リモコン
…表示部の保護シート(傷付き防止用)を
はがしてからご使用ください。
- 単4形アルカリ乾電池(2本)
…最初に使用するために付属しています。
1年未満で消耗することがあります。
- リモコンホルダー
- リモコンホルダー
取付用ネジ(2本)



リモコン

〈ふたを開けたとき〉



リモコンを準備する

リモコンに乾電池を入れる

1 ふたをはずす

AまたはBの方法で、はずせます。

A ふたを止まる位置まで引き、横に開く。




B ふたを止まる位置まで引き、押し下げる。



- はずすときに思ひぬ力が加わるため、リモコンはしっかりと持ってください。



2 乾電池を入れる



左の表示が出ないときは、乾電池を入れ直し、リモコンリセットボタンを先の細いもので押してください。

3 ふたを取り付ける

- ①リモコン本体側面とふた側面の3本線が合う位置に、ふたの片側を沿わせる。(線は取り付け位置の目安です)
- ②沿わせた側とは反対側のふたの上を押す。



リモコンの時刻を合わせる

タイマー予約などを正しく動作させるため、時刻は必ず合わせてください。

例)午後2時30分に合わせるとき

1 時計 押す



2 すすむ 現在時刻を合わせる
 もどる ●長押しすると早送りします。
(夜の12時は「0:00」)




3 決定 確定する



- 30秒間、ボタン操作がないと、表示している内容で設定されます。

運転する

詳しくは ▶ P.36, 37, 39



冷房・暖房・除湿切換・自動

お買い上げ時には、ナノイーX (P.39)が同時に働くように設定されています。

冷房 **暖房** **除湿切換** **○自動**

●朝の運転開始時、すぐに温風を出したいときは、おはようチャージ (P.25) の設定をおすすめします。

除湿切換 押すたびに
→ **除湿** …冷やしすぎを抑えて湿気を取る。
↓ **冷房除湿** …冷やしながら湿気を取る。
↓ **衣類** …洗濯物などの乾燥を補助します。
(衣類乾燥)

○自動 …設定温度などに応じて、運転モード (冷房・暖房・冷房除湿のいずれか) を自動で選んで運転。

リモコンを
準備する

運転する

■ 運転を止めるとき



ナノイーX送風

冷房・暖房・除湿のいらない季節などにおすすめします。

ナノイーX **送風** **○運転** **ナノイーX/おそうじ**

●停止中に押すとナノイーXを送風する運転ができます。
●ナノイーX送風運転時は、温度調節ができません。
●冷房などの運転中に押すと、ナノイーXの取り消し・設定ができます。





暖房運転時にパナソニックの加湿空気清浄機と連動し、自動で加湿を運転させることができます。ご利用には、初期設定が必要です。
初期設定や対象機種など詳しく述べ、
https://panasonic.jp/aircon/airpurifier_link/howto.html

AI快適機能で自動調節する

詳しくは ▶ P.38


人が快適と感じるための情報を検知・学習・記憶し、温度をコントロールします。



「AI快適エコナビ」設定時

- 「AI快適エコナビ」設定中に、風量調節でパワフルを設定したりパワフルの表示を通過したりすると(P.13)、「AI快適エコナビ」は取り消され「AI快適」になります。
- 消費電力を抑える調節をするため、設定温度に到達するまで、時間がかかることがあります。

人が快適と感じるための情報



風向・風量を調節する

風向・風量自動時の風の動きは ▶ P.42



好みで調節したい

風向上下 押すたびに
上下自動 → (スイング)

● は、冷房と除湿切換、ナノイーX送風の運転時、風を天井に向かって吹き、冷風を体に直接当てません。

風向左右 押すたびに
左右自動 → (スイング)

風量 押すたびに
風量自動 → ← → ↓ ↑

●除湿と衣類乾燥の運転時は「風量自動」になります。
●ナノイーX送風運転時、パワフルは設定できません。
●パワフル設定中に「AI快適エコナビ」を設定すると、パワフルは取り消され「風量自動」になります。

しづか設定時


- 風量を抑えた静かな運転です。冷房感・暖房感が快適に得られるように、風量がやや強めになることがあります。

パワフル設定時

- 冷房感・暖房感を強く感じる運転です。冷房感・暖房感が快適に得られるように、風量が弱めになることがあります。
- 温度調節は、リモコンの表示より冷房・冷房除湿で低め、暖房で高めになります。

部屋のにおいを軽減する

部屋のにおいを軽減する運転(においケア運転)を行い、自動で終了します。
来客前など、においが気になるときにおすすめします。



部屋のにおいを軽減したい

運転中または停止中に

1 **においケア** 1回押す
/手動おそうじ/おかけ

2 **決定** 室内ユニットに向けて確定する

●30秒間、ボタン操作がないと、元の表示に戻ります。
●においケア運転中はナノイーXが発生します。

ナノイーX/おそうじ(青)

約30分後、
▶と点灯に
決定する▶元の表示に
戻る

冷房などの運転中に、においケア運転

冷房などの運転を続けながら、においケア運転をします。

運転内容

●冷房・冷房除湿運転中（室温が高めのとき）

弱い風を天井に向けます。（運転時間：約30分間）

- ナノイーXを取り消していても、においの軽減効果を得るために、においケア運転後も、約30分間は強制的にナノイーXを発生させます。

●冷房・冷房除湿運転中（室温が低めのとき）、除湿・衣類乾燥・暖房・ナノイーX送風運転中

強い風をスイングします。（運転時間：約30分間）

■元の運転に戻すとき

においケア を1回押し、**決定** を押すと、元の運転に戻ります。
/手動おそうじ/おかけ

停止時に、においケア運転

運転内容

●室温が高めのとき

弱い風で冷房→ナノイーX送風→暖房→ナノイーX送風の順に上下風向ルーバーを変化させながら運転します。（運転時間：約95分間）

●室温が低めのとき

強い風でスイングしながらナノイーX送風運転をします。（運転時間：約30分間）

■途中で止めるとき




お知らせ

- 風向・風量は自動になります。
- においケア運転中は室温が上がったり、下がったりすることがあります。
- ナノイーXは、取り消していても発生します。

- においケア運転中に切タイマー／入タイマー(P.17)の時刻になると、においケア運転の終了を待って切タイマー／入タイマーが動作します。
- 効果は、部屋の環境や使用状況によって異なります。

停止中に室温みはりを使う

停止中に部屋の温度などを検知し、自動で冷房または暖房(室温みはり運転)を開始したり、停止したりします。室温が高くなりすぎたり、低くなりすぎたりするのを防ぎます。



室温みはりを設定する

運転中または停止中に
1 メニュー 5回押す
2 すすむ 「室温みはり 有」
もどる を選ぶ
3 決定 室内ユニットに向けて確定する
●30秒間、ボタン操作がないと、元の表示に戻ります。

■ 設定を取り消すとき

上記の手順で「室温みはり 無」に設定する。

運転条件

- ・部屋の温度・湿度が高くなりすぎたとき冷房
室内ユニット天面付近の温度が31 °C以上、湿度が60 %以上の状態が10分間続いたとき。
- ・部屋の温度が低くなりすぎたとき暖房
室内ユニット天面付近の温度が15 °C以下の状態が10分間続いたとき。

動作例

エアコンの状態	▼停止			▼冷房	
	冷房運転	内部クリーン運転	停止	室温みはり	冷房運転
室温みはり運転	↑ 室温みはり設定	約30分後、室温みはり開始	室温みはり運転(冷房) 条件になると開始	涼しくなると停止	室温みはり運転 再度、条件になると開始 室温みはり中断(次回の停止時に再開)

■ 室温みはり運転を一時的に止めるとき



- 室温みはりを続けるため「停止」は表示しません。

お知らせ

- 熱中症や低体温症を防止する機能ではありません。室内ユニットの設置位置や使用環境によっては温度や湿度を誤検知して運転しないことがあります。補助機能としてお使いください。
- 運転中は運転ランプ(緑)が点灯します。ナノイーXは、リモコンの設定にしたがって動作します。「AI快適」「AI快適エコナビ」は動作しません。設定温度・風量・風向は自動になります。調節したいときは、運転開始ボタンで運転後、調節してください。

- 冷房などの停止後(おそうじ運転停止後)約30分間は、温度・湿度の誤検知防止のため、室温みはりは動作しません。(室温みはり運転が自動で止まった後も同様)
- 室温みはり運転は切タイマー(P.17)で停止しません。
- 室温みはり運転が自動で止まった後に、おそうじ運転をすることがあります。(P.40、41)
- 室温みはりは運転条件になると運転するため、長時間使用しない場合は、設定を取り消しておくことをおすすめします。

タイマーを予約する

おやすみ切タイマー(下記)

おやすみ時に、決めた時間がたつたら運転を止めたい




切／入タイマー(P.17)

決めた時刻に、運転を切／入したい



●自動で温度調節され、冷やしすぎ・暖めすぎを防ぎます。

●切タイマーと入タイマーは、運転の「切」「入」を予約でき、取り消すまで毎日繰り返されます。



おやすみ時に、決めた時間がたつと停止する (おやすみ切タイマー)

運転中に

おやすみ①

押すたびに

- 0.5時間後切
- ↓
- 1時間後切
- ↓
- 2時間後切
- ↓
- 3時間後切
- ↓
- 5時間後切
- ↓
- 7時間後切
- ↓
- 9時間後切
- ↓
- (取り消し)

2:00 5 時間後切

残り時間を表示

タイマー
(橙)

調節内容


おやすみ切タイマー設定から1時間経過後、設定温度に近づく、または「AI快適エコナビ」設定時に部屋が暗いと検知すると、温度や風量、風向を次のように自動調節します。

- 設定温度は冷房・冷房除湿時に約1°C上げ、暖房時に約1°C下げます。
ただし、自動調節後、ご自身で設定温度を変更された場合は、その変更内容を学習し、次の運転時に自動調節する温度を補正します。(設定温度を上げた場合は、少し高めに。下げた場合は少し低めに)
- 風量は弱くなります。(しづか設定中(P.13)を除く)
- 風向は、上下自動時、上向きになることがあります。

お知らせ

●おやすみ切タイマーで停止した後は内部クリーン運転を行いません。フィルターおそうじ運転は、運転時間の合計が約24時間を超えて停止したときに行います。

●おやすみ切タイマーで停止した後に、フィルターおそうじ運転させたくない場合は、お好みの時刻におそうじタイマーを予約してください。(P.29)



決めた時刻に運転・停止する (切タイマー／入タイマー)

予約の前に、現在時刻が合っていることを確認してください。
(P.10)

切タイマーを予約する

例：23時を予約する。

- 1 切/入④
- 2 予約時刻を設定する
- 3 予約時刻を確定する

●押すたびに10分単位で変わり、長押しすると早送りできます。
(夜の12時は「0:00」)

入タイマーを予約する

例：7時を予約する。

- 1 切/入④
- 2 上記 2～3 の手順で予約を確定する

●30秒間、ボタン操作がないと、元の表示に戻ります。

■ 予約を取り消すとき


切/入④ を押して、「切④」または「入④」を選び、取消を押す。
(すべての予約を取り消すときは、取消のみを押す)

予約と同じ手順 1～3 で変更する。

お知らせ

- 入タイマーは、予約時刻に設定温度近くになるよう、早めに運転が始まります。（最長約50分前）
- 入タイマーでの運転は、停止前に設定していた内容で始まります。
- 現在時刻は、予約をすると表示されません。

- おやすみ切タイマーと切タイマーを組み合わせたときは、おやすみ切タイマーが優先され、切タイマー時刻には停止しません。





エオリア アプリを使う①

「エオリア アプリ」をインストールし無線LANに接続すると、スマートフォンで自宅のエアコンを操作、運転状況を確認するなど便利にお使いいただけます。



サービスの例

「遠隔操作」……宅外からエアコンを運転!
「シーン設定」……生活シーンに合わせて部屋の状況をお知らせ&自動で運転!



まずは、下記より「エオリア アプリ」をインストールしてください。



■ iOSのとき
App Store



■ Androidのとき
Google Play



- アプリは無料ですが、インストールや操作には別途通信料が発生します。
- アプリのアイコン、画面、サービスや対応するスマートフォンなどは、更新により変わることがあります。

必要な準備

■ インターネット環境を整え、機器をご準備ください。

インターネット環境

常時インターネット接続が可能な環境が必要です。

- FTTH(光ファイバー)、ADSL、CATV(ケーブルテレビ)などのブロードバンド回線。
ダイヤルアップ回線はご利用になれません。
インターネット接続の詳細は、プロバイダーや回線業者との契約内容をご確認ください。
- インターネットの通信料はお客様のご負担となります。

無線LANブロードバンドルーター(以下、無線LANルーター)

- 無線LANルーターが2.4 GHz帯の通信規格であることを確認してください。
(通信規格 : IEEE802.11b, IEEE802.11g, IEEE802.11n)
上記以外のルーターは使用できません。
- セキュリティ対策のため、必ず暗号化方式 WPA2またはWPA(AES)の設定ができる無線LANルーターを使用してください。暗号化方式は、WPA2(AES)の設定をおすすめします。設定方法は、無線LANルーターの取扱説明書を参照してください。
- WEPのみ対応の機種はお使いいただけません。
- モバイルルーターは動作保証をしていません。

スマートフォン

- iOS (iPhone) 13.0 / Android 6.0 以降 (2022年11月現在)
- 無線LANルーターと接続ができることを確認しておいてください。



設定は、アプリ画面
の案内にしたがって
操作します

初期設定をする

初めてアプリをお使いになるときは、エアコンと無線LANルーターの接続、機器の登録などの初期設定が必要です。リモコンの操作ができる位置で設定してください。

1 エオリア アプリを起動し、「CLUB Panasonic」にログインする

2 エアコンに遠隔操作を許可する

エアコンにスマートフォンからの遠隔操作を許可します。(P.28)

3 エアコンと無線LANルーターを接続する

- ・「簡単設定」または「詳細設定」で接続します。

リモコンの表示



(簡単設定)



(詳細設定)

必ず
室内ユニットに
向けて!



4 エアコンをサーバーに登録する

無線LANルーターに接続したエアコンをPanasonicクラウドサーバーに登録します。
(My家電登録)

簡単設定で接続時のみ
リモコンの表示



(端末登録)



無線LANの接続や設定時のリモコン基本操作方法

■ 無線LAN接続をするとき

無線LANボタンを2秒間、長押しする

■ 無線LAN設定をするとき

- ① 無線LANボタンを押す( 設定項目を表示)
 - ② すすむボタンまたは、もどるボタンで設定項目を選ぶ
 - ③ 決定ボタンを押して確定する
- 30秒間、ボタン操作がないと、元の表示に戻ります。

- 上記の手順3で「L2(詳細設定)」を選んだとき、エアコンとの接続に無線ネットワーク(SSID)を使用する場合があります。

SSID : Panasonic-CS-wirelessAP
パスワード : Ac18WLan

エアコン本体の設定をリモコンで行う

- シーン設定のサービスを利用するには、リモコンのメニューで「遠隔 みはり」の設定を「有」にします。(P.28)

エオリア アプリを使う②

ご利用の前に知っておいてください

サービスご利用時は、無線LANランプが点灯していることを確認しておいてください。

通信状態が悪いと、ご利用できないことがあります。

遠隔操作では、次のような事例が考えられます。

- ・運転できない、運転時間が反映されない。
- ・リモコンで運転したエアコンを、外出先から停止しようとしても操作が反映されず停止できない。

操作後は、アプリのメイン画面で操作結果を確認してください。

操作が反映されていなかった場合は、本体に付属のリモコンで操作してください。

- スマートフォンは画面のロックをおすすめします。
(誤操作防止)
- エオリア アプリ利用規約の最新版に同意のうえ、ご利用ください。




アプリのメイン画面

- アプリで時間を決めて運転中、または予約中にタイマーランプが点灯します。
- 無線LANランプ点灯中は、遠隔操作により運転することがあります。
- アプリで操作した内容は、リモコンには反映されません。

■ 無線LAN接続を切断できます

部屋にいる人が、遠隔操作をされたくないときは、リモコンで切斷できます。




- 無線LANボタンを2秒間、長押しする
・操作後は、無線LANランプが消灯したことを確認してください。



- リモコンが使えないときは、室内ユニットの応急運転ボタンで切斷できます。

- ①前面パネルを開ける。
- ②応急運転ボタンを2秒間、長押しし、無線LANランプが消灯したら指を離す。



無線LAN使用上の注意とお願い

■ 使用周波数帯

本機は2.4 GHz帯の周波数帯を使用しますが、他の無線機器も同じ周波数を使っていることがあります。他の無線機器との電波干渉を防止するため、下記事項に留意してご使用ください。

無線LAN機器使用上の注意事項

この機器の使用周波数帯では、電子レンジなどの産業・科学・医療用機器のほか、工場の製造ラインなどで使用されている移動体識別用の構内無線局(免許を要する無線局)および特定小電力無線局(免許を要しない無線局)、ならびにアマチュア無線局(免許を要する無線局)が運用されています。

- 1 この機器を使用する前に、近くで移動体識別用の構内無線局および特定小電力無線局ならびにアマチュア無線局が運用されていないことを確認してください。
- 2 万一、この機器から移動体識別用の構内無線局に対して有害な電波干渉の事例が発生した場合には、すみやかに電波の使用を停止したうえ下記の連絡先にご連絡いただき、混信回避のための処置などについてご相談ください。
- 3 その他、この機器から移動体識別用の特定小電力無線局あるいはアマチュア無線局に対して有害な電波干渉の事例が発生した場合など、何かお困りのことが起きたときは、次の連絡先へお問い合わせください。

連絡先：パナソニック株式会社
アプリの初期設定に関するお問い合わせ
(裏表紙)

■ 周波数表示の見方

周波数表示は、本体銘板(P.62)に記載しています。

変調方式がDSSSとOFDM方式



2.400 GHz～2.4835 GHzの全帯域を使用し、かつ移動体識別装置の帯域を回避可能であることを意味する

■ 機器認定

本機は、電波法に基づく工事設計認証を受けた無線装置を内蔵しているので、無線局の免許は不要です。ただし、以下の行為は電波法で禁止されています。

- ・無線装置を分解／改造する。
- ・本体銘板(P.62)をはがす。
- ・本体銘板に記載している適合表示を消す。

■ 使用制限

使用に当たり、以下の制限がありますので、あらかじめご了承ください。

制限をお守りいただけなかった場合、および本機の使用または使用不能から生じる付随的な損害などについては、当社は一切の責任を負いかねます。

- 日本国内でのみ使用できます。
- 利用権限のない無線ネットワークには接続しないでください。
無線ネットワーク環境の自動検索時に利用する権限のない無線ネットワーク(SSID※)が表示されることがあります、接続すると不正アクセスと見なされるおそれがあります。
- ※ 無線LANで特定のネットワークを識別するための名前のことです。このSSIDが双方の機器で一致した場合、通信可能となります。
- 本機は電気通信事業者(移動通信会社、固定通信会社、インターネットプロバイダ等)の通信回線(公衆無線LANを含む)に直接接続することができません。本機をインターネットに接続する場合は、必ず無線LANルーター等を経由し接続してください。
- 磁場・静電気・電波障害が発生するところで使用しないでください。
次の機器の付近などで使用すると、通信が途切れたり、速度が遅くなったりすることがあります。
 - ・電子レンジ、デジタルコードレス電話機
 - ・他の無線LAN機器
 - ・その他2.4 GHz帯の電波を使用する機器
(Bluetooth 対応機器、ワイヤレスオーディオ機器、ゲーム機、パソコン周辺機器など)
 - ・電波が反射しやすい金属物など

■ セキュリティ対策

●無線LANは電波を使ってデータを送受信するため、不正なアクセスを受けるおそれがあります。データの安全を確保するため無線LANルーターは、セキュリティ対策を行ってください。(P.18)

セキュリティ対策を実施せず問題が発生した場合、当社は一切の責任を負いかねますのでご了承ください。


- 無線LANルーターのパスワード(暗号化キー)は、8文字以上、63文字以下に設定することをおすすめします。(文字数の制限は無線LANルーターの取扱説明書をご確認ください)
パスワードを変更したときは、アプリの「設定メニュー」→「機器全般タブ」→「修理・交換・初期化時の対応」から「ルーターを交換したとき」を行ってください。

■ フームウェアについて

- 本機は、インターネットを通じて当社のフームウェアアップデートサーバーに接続し、自身のフームウェアを自動で最新版に更新する機能を持っています。
更新中は、無線通信が一時中断されるため、通信が途切れたり、速度が遅くなったりすることがあります。
- フームウェアの解析、改造は行わないでください。

エオリア アプリを使う③

Q & A

初期設定	アプリをインストールできない		●スマートフォンのOSが対応していることをご確認ください。(P.18)																	
	エアコンと無線LANルーターの接続ができない		●スマートフォンと無線LANルーターが接続できることをご確認ください。 →スマートフォンの説明書をご確認ください。 ●無線LANルーターにより接続方法やセキュリティの設定方法が異なります。 →無線LANルーターの取扱説明書をご確認ください。																	
	スマートフォンに他のエアコンも登録したい		●アプリの「設定メニュー」→「機器全般タブ」から「新しいエアコンを追加」を行ってください。 My家電登録時に、区別しやすい名前を付けることをおすすめします。																	
無線接続	無線通信が途切れる・中断する		●無線LANルーターを室内ユニットに近づけると、安定する場合があります。電波強度を確認してみてください。 電波強度の確認方法 ① エアコンを停止し、リモコンの無線LANボタンを押す。 ▶ L1 (簡単設定) ② もどるボタンを2回押す。▶ L4 (電波強度) ③ 室内ユニットに向けて決定ボタンを押す。(運転は停止します) →約5秒後、本体ランプの点灯で、電波強度を確認する。 <table border="1"><thead><tr><th>ランプ名</th><th>電波強度</th><th>強</th><th>中</th><th>弱</th></tr></thead><tbody><tr><td>運転</td><td>■ 点灯</td><td>■ 点灯</td><td>■ 点灯</td></tr><tr><td>タイマー</td><td>■ 点灯</td><td>■ 点灯</td><td>□ 消灯</td></tr><tr><td>ナノイーX/おそうじ</td><td>■ 点灯</td><td>□ 消灯</td><td>□ 消灯</td></tr></tbody></table> • 約10分後、自動で終了。すぐに終了したいときは、停止ボタンを押す。 • 無線LANランプは電波強度にかかわらず点灯しています。	ランプ名	電波強度	強	中	弱	運転	■ 点灯	■ 点灯	■ 点灯	タイマー	■ 点灯	■ 点灯	□ 消灯	ナノイーX/おそうじ	■ 点灯	□ 消灯	□ 消灯
ランプ名	電波強度	強	中	弱																
運転	■ 点灯	■ 点灯	■ 点灯																	
タイマー	■ 点灯	■ 点灯	□ 消灯																	
ナノイーX/おそうじ	■ 点灯	□ 消灯	□ 消灯																	
各機器の変更・利用停止	意図しない設定になるなど不正なアクセスによる利用が疑われる		●エアコンの初期化(下記「エアコンを廃棄または譲渡するとき」の①~③の操作)をし、初期設定の手順2~4(P.19)を再度行ってください。																	
	無線LANルーターを交換したい		●アプリの「設定メニュー」→「機器全般タブ」→「修理・交換・初期化時の対応」から「ルーターを交換したとき」を行ってください。																	
	スマートフォンを機種変更したい		●スマートフォンのOSを確認し(P.18)、対応していれば、アプリをインストールして登録済みのログインIDでログインすると、引き続き利用できます。																	
	エアコンを交換したとき制御基板の修理をしたとき		●アプリの「設定メニュー」→「機器全般タブ」→「修理・交換・初期化時の対応」から「エアコンを修理したとき」を行ってください。																	
	エアコンを廃棄または譲渡するとき		●エアコンの初期化(①~③)とスマートフォンの登録削除(④)が必要です。 ① 無線LANランプの点灯を確認し、 リモコンの無線LANボタンを押す。▶ L1 (簡単設定) ② もどるボタンを押す。▶ L5 (初期化) ③ 室内ユニットに向けて決定ボタンを3秒間、長押しする。 →無線LANランプが消灯する。(初期化完了) ④ アプリの「設定メニュー」→「機器全般タブ」の「My家電リスト」から 廃棄または譲渡するエアコンの登録を削除する。																	

居住環境や人に合わせて

お買い上げ時の設定を変更する①

■ 設定項目一覧 **(メニュー)** を押すたびに、表示項目が順に切り換わります。

表示項目	設定方法	表示項目	設定方法
セーブ(パワーセーブ)	P.24	室外音	P.26
A(リモコンNo.)		クリーン	P.27
■(設置位置)		おそうじ	
カビみはり		間隔(お手入れ間隔)	
室温みはり		冷房(冷房立上げ)	P.28
チャージ(おはようチャージ)	P.25	遠隔	
におい(においカット)	P.26	遠隔 みはり(シーン設定)	

お買い上げ時の設定を変更する(メニュー)
エオリアアプリを使う



設定を変更する(共通の操作です)

運転中または停止中に

- 1 **(メニュー)** 項目を選ぶ
- 2 **すすむ** 設定内容を選ぶ(**もどる** は逆順で表示)
- 3 **決定** 室内ユニットに向けて確定する(変更内容が記憶されます)

●30秒間、ボタン操作がないと、元の表示に戻ります。

■途中で設定操作を中止するとき

取消

お知らせ

- メニューで変更した内容は、乾電池を交換するとリモコン表示のみお買い上げ時の設定に戻ります。(リモコンNo.を除く)
本体は変更した内容を記憶しています。

居住環境や人に合わせて

お買い上げ時の設定を変更する②


メニューで項目選択

すすむで選択(もどるは逆順で表示)▶決定

※は、お買い上げ時の設定です。

セーブ


最大電流値を制限した運転に設定できます



- 「セーブ 有」に設定すると、冷房や暖房などの能力は低下します。
- ブレーカー容量が足りない場合、据付時に「セーブ 有」を設定していることがあります。「セーブ 無」で使いたいときは、販売店へご確認ください。

A


リモコンの混信を防ぎます



- 複数台のエアコンを設置したときに、それぞれのリモコンで操作できるエアコンを指定(ペアリング)することができます。
- 設定を変更しないエアコンの電源プラグは抜いておいてください。(リモコンの設定を受信し、ペアリングされてしまうため)

室内ユニット


室内ユニットの設置位置を、本体に記憶させます



- 左右自動時、設置位置から分かる部屋の中心方向へ風が送られます。
- 設置や移設をしたときは、必ず設定してください。

カビみはり


カビみはり(P.31)を動作できます



- 「カビ みはり 有」に設定すると、停止中にエアコン内部の状態をみはり、自動で内部クリーン運転をします。内部クリーン運転の動作を「クリーン 無」(P.27)に設定していても動作します。

室温みはり

室温みはり(P.15)を動作できます



- 「室温みはり 有」に設定すると、停止中に部屋の温度・湿度をみはり、自動で運転・停止をします。


メニューで項目選択

すすむで選択（もどるは逆順で表示）▶ 決定

※は、お買い上げ時の設定です。

チャージ

おはようチャージを動作できます



- 「チャージ 有」に設定すると、暖房・自動運転停止後、リモコンに「チャージ」と表示されます。
- 時刻表示「12:00」が点滅するときは、操作を中止して時刻を合わせてください。（P.10）

■ おはようチャージについて

朝の暖房を開始する時間帯を学習し、その時間帯に暖房ボタンを押すとすぐ温風が出せるように予熱運転を行います。朝の暖房開始時、すぐ温風を出したいときにおすすめします。

学習

午前3時～10時の暖房開始時刻を学習。（よく利用される時間帯を2つまで記憶します）




予熱運転

学習した時間帯の前から、予熱開始。（最長60分前）



すぐ暖房！

暖房ボタンを押すと、すぐに温風が出ます。



- 上下風向ルーバーが開きます。
・運転ランプは点灯しません。
- 前回の運転が暖房のときのみ、予熱されます。
- 1つ目の時間帯の予熱中に暖房を始めたときは、2つ目の時間帯には予熱されません。

- 暖房ボタンを押さなかったときは、学習した時間帯後、約60分で予熱運転が終了します。

- 予熱運転開始条件：室温約18°C以下・屋外温度約10°C以下で、前回の運転を暖房で停止したとき。
- 予熱中に運転を始めても、本体が十分暖まっていないと、すぐに風が出ないことがあります。（運転ランプが点滅）
- 一時的におはようチャージを働かせたくないときは、「チャージ」表示中に停止ボタンを押してください。（「停止」表示）動作を再開したいときは、リモコンで運転して停止するか、「チャージ 有」を再設定してください。
- 予熱中に切タイマーの時刻になっても、予熱運転は停止しません。
- シーズン中に暖房を長期間ご使用にならない場合は、「チャージ 無」にすることをおすすめします。（1回の予熱は最長2時間で、消費電力は約300W*です）

* CS-GX403D2、当社実験室（洋室14畳）において、屋外温度2°C、室温11°Cで予熱した場合。

お買い上げ時の設定を変更する③


メニューで項目選択

すすむ で選択(もどる は逆順で表示) ▶ 決定 ※は、お買い上げ時の設定です。


において

においてカット機能を動作できます

①動作なし・ありを選べます。



②動作なしを選ぶと、風量自動時のみ、においてカット機能を動作させる設定が選べます。




- においカットとは、冷房・除湿・冷房除湿の運転開始時、本体内部に付いた生活臭（化粧品やペット臭）が風とともにに出るのを防ぐ機能です。（約1分間は風が出ません。）

- ・除湿・冷房除湿時は、約30秒間送風後、動作します。
 - ・パワフル設定中は動作しません。
 - ・運転中、室温が設定温度に近づくと、風が出たり止まったりを繰り返すことがあります。室温が上がると元の運転に戻り、このときにもおいカット機能が働きます。

室外音

暖房時の室外ユニットの運転音を低減できます



- 「室外音 LO」に設定すると、能力が制限されるため、暖まるまで時間がかかる場合があります。


- 室温が設定温度に近い場合などは、「室外音 Lo」を設定しても、運転音が下がらないことがあります。

メニューで項目選択

すすむで選択(もどるは逆順で表示)▶決定

※は、お買い上げ時の設定です。

- ①送風のみの内部クリーン運転、または、自動で内部クリーン動作をさせない設定が選べます。




「クリーン 暖房 有」「クリーン 送風 有」


→ ②に進む

「クリーン 無」→ ④に進む


- ②冷房・除湿切換(室温約16℃以上のとき)
の運転中にも、内部クリーン運転を動作させる設定が選べます。



- ③切タイマー(P.17)で停止した後に内部クリーン運転を動作させない設定が選べます。



- ④本体内部に付着した油汚れを低減する動作をさせない設定が選べます。



①

- 「クリーン 送風 有」に設定したとき
冷房・除湿切換(室温約16℃以上のとき)
運転後は、暖房をしないでナノイーX送風
のみを運転します。ただし、運転時間は
長くなります。(約150分～240分間)

- 「クリーン 送風 有」「クリーン 無」に設定
していても「手動おそうじ運転」と「おでかけクリーン」の内部クリーン運転は、お買
い上げ時の設定と同じ動作をします。
(「手動おそうじ運転」は、停止中と、②の
手順で「クリーン 24h 無」設定中に行う
ときのみ)

- 「クリーン 無」に設定したとき
エアコン内部を清潔に保つため、毎日「手
動おそうじ運転」(P.30)することをおす
すめします。また、カビみはり(P.31)を
設定しておくと、停止中に自動で内部ク
リーン運転をします。

②

- 「クリーン 24h 有」に設定したとき
次の場合、フィルターおそうじ運転の後
に内部クリーン運転が動作します。

- ・連続で24時間運転したとき。

本体の動作例	停止	冷房(24時間)	内部クリーン(約50分間)	冷房
(フィルターおそうじ(約12分間))				

- ・冷房などを30分以上運転中に「手動
おそうじ運転」(P.30)をしたとき。
・冷房などを30分以上運転中におそう
じタイマー(P.29)の予約時刻になっ
たとき。

運転時間は、①の手順で「クリーン 暖房
有」を設定時、計約62分間、「クリーン
送風 有」を設定時、計約102分間にな
ります。

④

- 「クリーン 2」(油汚れ低減動作なし)に
設定したとき
本体内部の油汚れを低減する運転を行
いません。

- ・暖房・除湿切換(室温約16℃未満の
とき)・ナノイーX送風運転後は、内部
クリーン運転が動作しなくなります。
- ・運転時間は、①の手順で「クリーン 暖房
有」を設定時とカビみはりで動作する
ときは、約60分～100分間になります。
- ・ナノイーXは、リモコンの設定にした
がって発生します。

居住環境や人に合わせて


お買い上げ時の設定を変更する④

メニューで項目選択

すすむで選択(もどるは逆順で表示)▶決定 ※は、お買い上げ時の設定です。

おそうじ

フィルターおそうじ運転(P.40)の掃除度合いを設定できます




フィルターおそうじの運転時間
標準: 約12分間 念入: 約30分間

- 「標準」で使っていても汚れが気になるときは、「念入」に変更してください。
- 「念入」にしてもおでかけクリーン(P.30)のときは、「標準」の運転時間になります。

間隔

ダストボックスのお手入れ時期をお知らせする間隔を設定できます




標準: 運転時間の合計
約2000時間
(約1年間)
短: 運転時間の合計
約1000時間
(約半年間)
長: 運転時間の合計
約4000時間
(約2年間)

- ボックスお手入れランプが点灯し、お手入れ時期をお知らせする間隔を、短くしたり長くしたりすることができます。次のようなほこりが発生しやすい環境では、「間隔 短」に変更することをおすすめします。
 - 人が多く集まる部屋
 - 布団の上げ下ろしの多い部屋など

冷房


冷房運転開始時の温度変化を緩やかにできます



- 「冷房 2」(立上げシフトなし)に設定すると、冷房運転開始時の温度変化が緩やかになります。
「冷房 1」(立上げシフトあり)のときより、設定温度に到達するまで時間がかかることがあります。

遠隔


遠隔操作を許可できます



- 遠隔操作をしたいときは「遠隔 有」にします。
遠隔操作をしないときは、必ず「遠隔 無」にしてください。
(自動で停止する場合があります)

遠隔 みはり

エオリア アプリの「シーン設定」を許可できます(P.18、19)




- エオリア アプリの「シーン設定」を利用したいときは、「遠隔 みはり 有」にします。
(自動で運転を開始したり、通知を受け取ったりできます)

おそうじ運転を使いこなす①

ふだんのおそうじはエアコンにおまかせ！

お買い上げ時の設定では、運転停止後などにエアフィルターやエアコン内部のおそうじ運転が自動で始まります。長時間連続運転中は、内部クリーン運転を行いません。(P.40, 41)



1日1回、時間を決めておそうじ運転をしたいとき

おそうじタイマー

予約時刻になるとフィルターおそうじ運転を行います。

(約12分間)

予約の前に、現在時刻が合っていることを確認してください。(P.10)

例：15時を予約する

1 切/入 を5秒間、長押しする



2 掃除開始時刻を設定する



- 押すたびに10分単位で変わり、長押しすると早送りできます。(夜の12時は「0:00」)

3 予約する



(約2秒後、元の表示に戻る)

掃除開始時刻

- 30秒間、ボタン操作がないと、元の表示に戻ります。

■ 予約を取り消すとき

切/入 を5秒間、長押しし、

「おそうじ①」が点滅したら 取消 を押す。

■ 予約時刻を確認するとき

切/入 を5秒間、長押しする。

(約30秒後、元の表示に戻る)

- 暖房などを積算で20分以上運転していないときは、予約時刻になってもおそうじ運転を行いません。
- 暖房中などに掃除開始時刻がくると、暖房などの運転を一時中断します。
- 内部クリーン運転ができていなかった場合は、フィルターおそうじ運転に続いて運転します。(計約85分間または約115分間)
「クリーン無」にしたとき(P.27)は運転しません。
- 毎日掃除するため、ほこりや油汚れが多い場所で使うときにおすすめです。ただし、汚れが気になるときはエアフィルターをはずして水洗いしてください。(P.35)
- 音が気になる場合に設定するときは、停止時に自動で内部クリーン運転を行わない、おやすみ切タイマーもご使用ください。(P.16)



タイマーランプは
点灯しません

お知らせ

- おそうじ運転中に切タイマー／入タイマー(P.17)の時刻になると、終了を待って切タイマー／入タイマーが動作します。

おそうじ運転を使いこなす②

シーズンの終わりなど、すぐにおそうじ運転をしたいとき




手動おそうじ運転

フィルターおそうじ運転を行った後、内部クリーン運転を行い、自動で停止します。
(約12分～115分間)

1 **おいケア** 2回押す

2 **決定** 室内ユニットに
向けて確定する



- 30秒間、ボタン操作がないと、元の表示に戻ります。

■ おそうじ運転を途中で止めるとき



- 冷房などの運転中に手動おそうじ運転をすると、終了後、元の運転に戻ります。
- 内部クリーン運転は、自動で行われていないときのみ動作します。
- 冷房などの運転を毎回おやすみ切タイマーで止めているときは自動で内部クリーン運転を行いません。
1日1回手動おそうじ運転することをおすすめします。

お出かけ中に、部屋のにおいを軽減し、おそうじ運転をしたいとき



おでかけクリーン

約120分間、ナノイーX送風運転で部屋のにおいを軽減した後、フィルターおそうじ運転、
内部クリーン運転の順に行い、終了後、自動で停止します。(計約135分～235分間)

外出前に

1 **おいケア** 3回押す

2 **決定** 室内ユニットに
向けて確定する



- 30秒間、ボタン操作がないと、元の表示に戻ります。

■ おでかけクリーンを途中で止めるとき



- 冷房などの運転中におでかけクリーンをすると、終了後すべての運転が停止されます。(受信音“ピー”)
- 内部クリーン運転は、自動で行われていないときのみ動作します。



エアコン内部のカビの成長を抑えたいとき




カビみはり


停止中に部屋の温度・湿度を検知して、エアコン内部がカビの成長しやすい状態になっているかどうかをみはります。カビの成長しやすい状態が続くと、内部クリーン運転^{※1}を約80分～100分間自動で行い、カビ^{※2}の成長を抑制します。

運転中または停止中に

- 1 メニュー 4回押す



- 2 すすむ 「カビ みはり 有」
もどる を選ぶ



- 3 決定 室内ユニットに
向けて確定する**

- 30秒間、ボタン操作がないと、元の表示に戻ります。

■ 設定を取り消すとき

上記の手順で「カビ みはり 無」に設定する。

動作条件

カビの成長しやすい状態が累積で12時間以上経過すると運転します。

- 運転中は、ナノイーX/おそうじランプ(青)が点灯します。
 - エアフィルターに汚れがたまっていた場合は、内部クリーン運転の前にフィルターおそうじ運転も行われます。

※ 1：カビみはりの内部クリーン運転は、ナノイーX送風と暖房の連転を行います。

※2: カビみはりの効果(カビの成長抑制)について

39 m³, 室温25 °C, 湿度70 %の試験室にて、エアコン内部にカビヤンサーを設置。

冷蔵庫運転を3時間運転後 内部クリーニング運転を12時間でとに動作させ 7日後のカビ

培养連続とし時間連続後、内部フラン連続を10時間ごとに動作させ、1日後のカビの菌糸長を比較。カビヤシヰー内のすべてのカビ(2種類)で発芽はなく、カビの成長

の因子を比較。力口ヒドリ内でのりべこの力口(2種類)と発芽はなく、力口の成長が抑制されることを確認（試験機関：環境生物学研究所）


が抑制されることを確認。(試験機関:環境生物子研九州)

お知らせ


- おそうじ運転または、おでかけクリーン中に切タイマー／入タイマー(P.17)の時刻になると、終了を待って切タイマー／入タイマーが動作します。

お手入れ①

ボックスお手入れランプが
点灯・点滅し、お手入れ時期を
お知らせします



- 点灯したとき
ダストボックスをお手入れする
- 点滅したとき(お手入れ時期が過ぎています)
**ダストボックスとエアフィルターを
すぐにお手入れする**




〈前面パネルの開けかた〉

両端の開閉部の位置で前面パネルを持ち、手前に引き上げる。

〈表示部の開けかた〉

前面パネルを開けてから、表示部に指をかけ、下方向に開ける。

前面パネル開閉部
(左右各1か所)



● 台などをご使用の場合、転倒に注意してください。

ボックスお手入れランプが点灯したとき


ダストボックス

1 運転を停止する


2 電源プラグを抜き、前面パネルと表示部を開ける (左記)

3 ダストボックスを取り出す

- ①ロック(2か所)を解除する。
- ②ダストボックスの取っ手を持ち、ゆっくり引き出す。



4 掃除機でほこりを吸い取る



● 汚れが気になるとき


ゴムブレードをはずしてダストボックスと共に水洗いできます。(水洗いするとき、乾かすとき→P.35)

〈取りはずしかた〉

- ・つまみをスライドさせ、解除する。


〈取り付けかた〉

- ・①②の順で受け部に入れる。
(左右の区別はありません)
- ・つまみをスライドさせ、ロックする。




- 5 ダストボックスを取り付ける**
- ①ダストボックスを奥まで押し込む。
 - ②ロックする。(2か所)

- 6 電源プラグを差し込み、本体の「お手入れ完了」ボタンを押す**
→ボックスお手入れランプが消灯します。
(積算された運転時間をリセット)



- 7 表示部と前面パネルを閉める**

- ブラシや周辺のほこりが気になるとき
フィルター扉を開け(右記手順2-①)、掃除機でほこりを吸い取る。
- 掃除機の先をブラシに強く押し当てる。(変形の原因)
 - ブラシは、取りはずしや水洗いはできません。



- ダストボックスからほこりがあふれていた場合
リモコンで本体の設定を「間隔 短」に設定する。
(P.28)
(お手入れ時期を早めにお知らせします)


- 電源プラグを抜くと、室温みはり、タイマー予約、おはようチャージを設定していても動作しません。設定し直してください。(P.15、17、25、29)

ボックスお手入れランプが点滅したとき

ダストボックスとエアフィルター


- 1 「ダストボックス」のお手入れ**
手順1~5(左記)を行う

- 2 エアフィルターを取りはずす**
- ①フィルター扉のロック(3か所)を解除し、フィルター扉の取っ手(2か所)を持ち、上側に開く。
 - ②エアフィルターを持ち、手前に引いて下へ引き出す。



- 3 掃除機でエアフィルターのほこりを吸い取る**
- 強い力を加えない。(破損の原因)
 - 油汚れが気になるときは、水洗いする。(P.35)

- 4 エアフィルターを取り付ける**
- ①「手前」表示面を表にして奥まで入れる。
 - ②フィルター扉を閉じてロックする。(3か所)
 - ・はじめに中央部をロックし、扉が開かないことを確認後、左右をロックしてください。



- 5 「ダストボックス」のお手入れ**
手順6・7(左記)を行う


お手入れ②

おそうじ運転していても、お手入れ・交換が必要です。

約2年に1回(目安)

空気清浄フィルター

交換する



- 水洗いはできません。
- 裏表はありません。
- フィルターは、不燃物ゴミとして、地域のゴミ分別方法にしたがって廃棄してください。

- ①電源プラグを抜き、前面パネルを開ける。
- ②表示部を開ける。(P.32)
- ③空気清浄フィルターを交換する。
図のようにツメ(7か所)の下に納めてください。

■別売品

品名: 空気清浄フィルター

品番: CZ-SAF16

希望小売価格(税込): 1,980円／1コ
(2022年11月現在)

●別売品の仕様(形状や材質など)は、お買い上げ時に付属している仕様と異なる場合があります。

別売品は販売店でお買い求めいただけます。
パナソニックの家電製品直販サイト
でもお買い求めいただけます。
<https://ec-plus.panasonic.jp/>



汚れが気になったとき

本体・リモコン

電源プラグを抜き、


柔らかい布で、からぶきする

- 汚れがひどいときは、水かぬるま湯を含ませた布をよくしぼってふいてください。
- 化学ぞうきんなどを使うときは、その注意書きにしたがってください。

上下風向ルーバーを開けて、内側をお手入れするとき

ルーバーは手でゆっくりと開けてください。

閉じるときは、電源プラグを差し込み、リモコンの停止ボタンを押してください。




点線の部分は強い力でつかないでください。
(変形・傷の原因)

前面パネルは取りはずして水洗いすることができます

柔らかい布やスポンジで軽くふくように洗い、水気を十分ふき取るか陰干してください。

〈取りはずしかた〉

- ①電源プラグを抜く。
- ②両手で前面パネルを開け、止まるまで押し上げる。
- ③左(または右)に寄せ、左(または右)から手前に引いてはずす。




お願ひ


- 洗剤などを含ませた布でふいたり、直接吹きつけたりしないでください。(損傷や故障の原因)

〈取り付けかた〉

- ①パネルを水平に持ち、アームを片側ずつ奥まで押し込む。
- ②パネルを閉める。



- 台などをご使用の場合、転倒に注意してください。
- 前面パネルの落下に注意してください。



〈前面パネルの開けかた〉
両端の開閉部の位置で前面パネルを持ち、手前に引き上げる。

■ エアフィルターを破損したとき

お近くの販売店でお買い求めください。
品番：ACRD00-0335AZ
希望小売価格(税込)：880円／1枚
(2022年11月現在)

ほこりや油汚れが多い環境などでご使用のとき

エアフィルター


取りはずして水洗いする

- ふだんはエアフィルターを毎日掃除する「おそうじタイマー」(P.29)をおすすめします。
- 汚れがひどいときは薄めた中性洗剤でつけ置きし、汚れをやさしく洗い流した後、十分に乾かしてください。




〈取りはずしかた〉

- ①電源プラグを抜き、前面パネルと表示部を開ける。(P.32)
- ②フィルター扉のロック(3か所)を解除し、
フィルター扉の取っ手(2か所)を持ち、上側に開く。
- ③エアフィルターを持ち、手前に引いて下へ引き出す。



〈取り付けかた〉

- ①「手前」表示面を表にして奥まで入れる。
- ②フィルター扉を閉じてロックする。(3か所)
 - ・はじめに中央部をロックし、扉が開かないことを確認後、左右をロックしてください。
- ③表示部と前面パネルを閉める。



お願い

- エアフィルターに強い力を加えないでください。
(破損の原因)

お知らせ

- お手入れしても汚れが取れなくなったときは、エアフィルターをお買い求めいただけます。(上記)

■ 水洗いするとき

次のものは使わない。(変色や変形、傷の原因)

- タワシのような硬いもの
- シンナーやみがき粉
- 漂白剤
- 40 °C以上のお湯

■ 電源プラグを抜くと、室温みはり、タイマー予約、おはようチャージを設定していても動作しません。設定し直してください。(P.15、17、25、29)

■ 乾かすとき

次のもので乾かさない。(変色や変形の原因)

- ドライヤー
- ストーブ
- 直射日光

自動・冷房・除湿切換について

操作方法は ▶ P.11

自動

- 屋外・室内・設定の各温度に応じて、冷房・暖房・冷房除湿のいずれかを自動で選び、約30分ごとに選び直します。

- 運転開始時

運転モードを選ぶため、運転ランプが約30秒間点滅します。



冷房

運転条件

設定温度：20 ℃以上

室内湿度：90 %以下

屋外温度：21 ℃～50 ℃

- 運転条件以外で運転すると、保護装置が働いて停止することがあります。

除湿切換

運転条件

屋外温度：1 ℃以上

- 運転条件以外で運転すると、保護装置が働いて停止することがあります。

- 運転開始時、室温検知のため、約30秒間送風します。

- 室温約 16 ℃以上のとき、やや冷たい風が出ます。

- 室温約 16 ℃未満のとき、やや暖かい風が出ます。

除湿

- 設定温度は、標準温度(快適と感じる温・湿度)になるよう自動調節します。寒い・暑いと感じるときは「標準」+1 ℃～「標準」-3 ℃の範囲で調節できます。

- 運転中

室温が設定温度に近づくと、約5分間、風が止まります。

冷房除湿

- 室温が設定温度に近づくまでは冷房。近づくと、ごく弱い風量で湿気を取り除きます。

- 運転中


室温が設定温度に近づくと、約5分間、風が止まります。

衣類乾燥

- 衣類の乾燥が目的のため、温度・風量は調節できません。
部屋に人がいないときにおすすめします。

暖房について

操作方法は ▶ P.11



運転条件 屋外温度：24 °C以下

- 運転条件以外で運転すると、保護装置が働いて停止することがあります。


風量調節

運転開始時

- 吹き出す風の温度が暖まるまで、風が出ないことがあります。その間は、運転ランプが点滅します。ただし、風量を手動で選んでいるときは、風量調節を優先するため、数分間、冷たい風が出ることがあります。



朝の運転開始時、すぐに温風を出したいときは、おはようチャージ(P.25)の設定をおすすめします。



霜取り運転

屋外の温度が低く、湿度が高いときに、室外ユニットに霜が付きます。この霜は運転の妨げになるため、暖房を止め霜取り運転で自動的に溶かして排水します。(最長約12分間)

- 霜取り運転中は、上下風向ルーバーは開いたまま、運転ランプが点滅します。
- 霜取り運転が終わると暖房を再開します。




運転中

- 室温が設定温度に近づくと、室温が上がりすぎるので防ぐため、風の温度を少し下げます。このとき、風が冷たく感じないように風量は弱くなります。ただし、風量を手動で選んでいるときは、風量調節を優先するため、弱くならないことがあります。

暖房について（霜取り運転）
自動・冷房・除湿切換について

「AI快適」「AI快適エコナビ」について

操作方法は ▶ P.12



日当たりの変化に合わせて温度を調節

日当たりの変化(晴れ・曇りなど)に合わせて、温度をコントロールします。

- 「AI快適」設定時
より早く快適性を感じるための温度調節を行います。
- 「AI快適エコナビ」設定時
快適性を維持しながら、消費電力を抑える^{*}温度調節を行います。
- 温度調節内容
 - 晴れた日の昼間は、約1°C~2°C低め
 - 曇りの日や夜は、約1°C~2°C高め(同じ室温でも、日が当たって日射量が多いときは暑く(暖かく)感じ、日射量が少ないときは涼しく(寒く)感じるため)

おへや学習機能で、消費電力を抑える (AI快適エコナビ)設定時のみ

●運転開始から設定温度に到達するまでの運転時間を、晴れの日と曇りの日を区別して学習します。暖まりやすい、または冷えやすい部屋であれば、緩やかに運転します。

●運転中、室内温度が設定温度に近づくと風が弱くなります。暖まりやすい、または冷えやすい部屋であれば、早めに風を弱くして消費電力を抑えます。^{*}

例)日当たりのよい南向きの部屋で暖房する場合。

部屋の明るさに合わせて 本体ランプの明るさを調節 (AI快適エコナビ)設定時のみ

部屋の明るさに合わせて、本体ランプの明るさを2段階で自動調節します。

- 暗いときは暗め、明るいときは明るめ

— 運転 — タイマー ナノイーX/おそうじ ボックスお手入れ —



* : 省エネ効果(CS-GX403D2暖房運転での測定例)

当社実験室(洋室14畳)において、屋外温度:2°C、設定温度:25°C、設定風量:風量自動で運転した場合、安定時の積算消費電力量:「AI快適エコナビ」設定時 489 Wh、「AI快適」「AI快適エコナビ」設定なし時 578 Wh(効果は、部屋の断熱性・気密性や日射など、使用環境により異なります)

「ナノイーX」について

操作方法は▶P.11



* 1: 浮遊菌は 25 m^3 (約6畳) の試験室で4時間後、付着菌は 23 m^3 (約6畳) の試験室で8時間後の効果であり、実使用空間での実証結果ではありません。

nanoeX(ナノイーX)とは

- nanoeX(ナノイーX)は、水に包まれた微粒子イオンです。
- 本製品はナノイー^{※2}の100倍の量のOHラジカルを生成するナノイーX(48兆)を搭載しています。
 - ※2: nanoe(ナノイー)は、高反応成分(OHラジカル)、電荷を有し、弱酸性を示す5~20ナノメートルの微細な水粒子です。
 - ナノイーXは部屋の空気を利用して発生させます。
 - 以下の環境でのご使用をおすすめします。
室内温度: 約5°C~35°C (露点温度: 約2°C以上)
相対湿度: 約30%~85%
 - 加湿効果はありません。

ナノイーXの効果

菌・カビ・におい

- 部屋のにおいを軽減、菌^{※1}やカビの繁殖を抑制します。
カーテンなどに付着したにおい(タバコや料理臭)・菌^{※1}やカビにも効果があります。
- 脱臭効果は、周囲環境(温度・湿度)、運転時間、臭気・繊維の種類などによって異なります。

花粉(アレル物質)

- 花粉などアレル物質の活動を抑制します。

肌・髪

- 肌のうるおい、髪のまとまり感を保ちます。
• 肌や髪への効果は、季節・周囲環境(温度・湿度)、使用時間、個人によって異なります。

ナノイーXの効果(抗菌・カビの成長抑制・抗アレル物質)について

効 果	試験機関	試験方法・結果(実使用空間での実証結果ではありません)
空気中に浮遊、カーテンなどに付着した菌の繁殖を抑制【実機試験】	(一財) 北里環境科学センター	浮遊菌は 25 m^3 (約6畳) の試験室にて、4時間後に検証。菌(1種類)の繁殖が99%以上抑制されることを確認。
	(一財) 日本食品分析センター	付着菌は 23 m^3 (約6畳) の試験室にて、8時間後に検証。菌(1種類)の繁殖が99%以上抑制されることを確認。
空気中に浮遊、カーテンなどに付着したカビの繁殖・成長を抑制【実機試験】	(一財) 北里環境科学センター	浮遊カビは 25 m^3 (約6畳) の試験室にて、6時間後に検証。カビ(1種類)の繁殖が99%以上抑制されることを確認。
	(一財) カケンテ스트センター	付着力カビは 30 m^3 (約8畳) の試験室にて、2時間後に検証。2種類のカビの成長が抑制されることを確認。
花粉などアレル物質の活動を抑制(不活化)【実機試験】	パナソニック(株) プロダクト解析センター	ELISA法による測定。 23 m^3 (約6畳) の試験室において、1種類の花粉で検証。1種類の花粉の活動が3時間後に99%抑制されることを確認。
		電気泳動法による測定。 23 m^3 (約6畳) の試験室において、13種類の花粉のアレル物質で検証。アレル物質が24時間後に抑制されることを確認。

「ナノイーX」について
「A-快適」「A-快適エコナビ」について

おそうじ機能について

お買い上げ時は、「フィルターおそうじ運転」「内部クリーン運転」が自動で働くように設定されています。

フィルターおそうじ運転

エアフィルターのほこりをブラシで
かき取り、ダストボックスに回収
約12分間

運転停止時

ナノイ-X/おそうじ (青)

- 運転条件②のときは
運転ランプも点灯

エアフィルターを
動かします。

ブラシ

ゴムブレード

ダストボックス

(運転条件①のときの動作例です)

運転条件①②のいずれかで、フィルターおそうじ運転を開始します。暖房などの運転時間の合計は、電源プラグを抜いても、本体で記憶しています。

運転条件①

前回のフィルターおそうじ運転から、冷房や暖房などを積算で約24時間以上*運転して、停止したとき。

*内部クリーン運転は積算時間に含みません。

フィルターおそうじ運転時間：約12分間

リモコン操作	停止	開始	停止	開始	停止
本体の動作例	暖房 (8時間)	停止	暖房 (12時間)	停止	暖房 (6時間)
↓ フィルターおそうじ(約12分間)					

運転条件②

連続24時間運転したとき。（運転を中断しておそうじします）

フィルターおそうじ運転時間：約12分間

リモコン操作	開始			
本体の動作例	停止	暖房 (24時間)	暖房 (24時間)	暖房
↓ フィルターおそうじ(約12分間)				

お願い

- おそうじ運転中は
 - ダストボックスを取りはずさないでください。
 - フィルター扉を開けたり、エアフィルターに触れたりしないでください。
(エアフィルターがはずれて落ちる原因)

お知らせ

- おそうじ運転を途中で停止すると、次の暖房などの運転停止時に、再度運転します。
- ダストボックスのお手入れ時期がくると、ボックスお手入れランプが点灯しお知らせします。お手入れをしないで運転を続けると、約120時間後に点滅に変わり、すぐにお手入れが必要なことをお知らせします。点滅すると、フィルターおそうじ運転は自動で行わなくなります。
(ダストボックスからほこりがあふれ出るのを防ぐため)
- 汚れが気になるときは、「おそうじタイマー」(P.29)を予約するか、フィルターおそうじ運転の掃除度合いを「念入」(P.28)にすることをおすすめします。
- おそうじタイマーを予約したときの運転条件は→P.29
- フィルターおそうじ運転を行った後、内部クリーン運転を行う場合があります。(P.41)

内部クリーン運転

運転停止時



上記は冷房運転後の動作例です。
暖房・除湿切換(室温約16℃未満のとき)・ナノイーX送風運転後は、付着した油汚れとにおいの低減を行います。

- ★1: 27.7 m³(約6畳)の試験室で4日後の効果であり、実使用空間での実証結果ではありません。
- ★2: 内部クリーン運転の動作内容を「クリーン 送風 有」に変更したとき(P.27)は、カビの成長を抑制^{※2}する効果になります。

ナノイーX送風と暖房の運転で本体内部に付着したにおい成分とカビ菌を除去^{※1※2}、付着した油汚れを低減します。

- 付着したにおい成分やカビ菌をすべて除去する機能ではありません。
- お買い上げ時には、内部クリーン運転が自動で動作するように設定されています。
- ナノイーXは、リモコンで設定していなくても発生します。
- 運転中は上下風向ルーバーが開きます。

運転条件

冷房や暖房などを30分以上運転し、停止したとき。
(おやすみ切タイマーで停止したときを除く)

内部クリーン運転時間: 約80分～100分間、または約70分間

リモコン操作	停止		
本体の動作例	冷房 (30分以上)	内部クリーン (約80分～100分間)	停止
			↑ フィルターおそうじ運転を行うことがあります。

運転内容

- 冷房・除湿切換(室温約16℃以上のとき)運転後は、におい成分、カビ菌の除去と、付着した油汚れの低減を行います。
 - ・ナノイーX送風→暖房→ナノイーX送風の順に運転します。ナノイーX送風時は、ナノイーXを室内ユニット内部のすみずみまで行き渡らせます。
(運転時間: 約80分～100分間)
- 暖房・除湿切換(室温約16℃未満のとき)・ナノイーX送風運転後は、付着した油汚れとにおいの低減を行います。
 - ・ナノイーXを送風し、室内ユニット内部のすみずみまで行き渡らせます。
(運転時間: 約70分間)

■途中で止めたいとき

停止ボタンを押す。

- におい成分やカビ菌の除去、付着した油汚れを低減する効果がなくなるため、なるべく止めないでください。

■内部クリーン運転の動作内容を変更したいとき →P.27

お知らせ

- 冷房・除湿切換(室温約16℃以上のとき)運転後に内部クリーン運転したとき

- ・内部クリーン運転の時間は、本体内部の湿度が高く、弱い風量で冷房などを長時間運転しているときほど長くなります。
- ・温風で内部を乾燥させるため、室内の温度や湿度が上がることがあります。
- ・室内温度が低く、湿度が高いときに運転すると、壁や窓などに結露する場合があります。

- おやすみ切タイマーで毎回停止しているとき
内部クリーン運転を行いません。

エアコン内部を清潔に保つため、リモコンで毎日「手動おそうじ運転」(P.30)をするか、おそうじタイマー(P.29)の予約をおすすめします。

●長時間連続運転しているとき

内部クリーン運転を行いません。

エアコン内部を清潔に保つため、「クリーン24h 有」(P.27)にすることをおすすめします。冷房・除湿切換を連続で24時間運転した場合、運転を中断してフィルターおそうじ運転の後に内部クリーン運転を行います。

- ・毎日決まった時刻に動作させたいときは、おそうじタイマー(P.29)も予約してください。

※1: 27.7 m³(約6畳)、室温25℃、湿度70%の試験室にて、エアコン内部にカビ菌を滴下した試験片を設置。1日3時間の冷房運転後に内部クリーン運転ありとなしの条件において、4日後のカビ菌の数を比較。試験片のカビ菌(1種類)が99%除去されたことを確認。
(試験機関:(一財)北里環境科学センター)

※2: 27.7 m³(約6畳)、室温25℃、湿度70%の試験室にて、エアコン内部にカビセンサーを設置。1日3時間の冷房運転後に内部クリーン運転ありとなしの条件において、4日後のカビの菌糸長を比較。カビセンサー内のすべてのカビ(3種類)で、成長が抑制されることを確認。
(試験機関:(一社)カビ予報研究室)

風向・風量自動時の風の動き

操作方法は ▶ P.13


設定内容によって自動調節の内容が変わります。

冷 房	
自動(風向・風量)・しづか	
パワフル	
暖 房	
自動(風向・風量)・しづか	
パワフル	
冷房除湿	
自動(風向・風量)・しづか	
パワフル	
除湿	
自動(風向・風量)	
衣類乾燥	
自動(風向・風量)	
ナノイーX送風	
自動(風向・風量)・しづか	

上下風向ルーバーの可動範囲


●運転モードによって異なります。

冷房・除湿・冷房除湿・衣類乾燥・ナノイーX送風のときは、天井に向けることができます。



こんなときは

リモコンが使えないとき



リモコンは、お近くの販売店でお買い求めください。
品番：ACRA75C23250X
希望小売価格(税込)：5,500円
(2022年11月現在)

本体で応急運転ができます。

- ① 電源プラグの差し込みを確認する。
- ② 前面パネルを開けて、応急運転ボタンを押す。

■ 止めるとき → もう一度押す。

お知らせ

- 設定温度 25 °C の自動運転となり、温度や風量・風向は調節できません。
 - ・風量は「風量自動」になります。
 - ・風向はリモコンで設定していた風向になります。
- 電源プラグを抜き差しすると、風量と風向は自動になります。
- 応急運転ボタンを5秒間、長押しすると、強制冷房運転になります。(据付工事業者用ですので、ふだんは使用しないでください)

風向・風量自動時の風の動き

こんなときは


室内ユニットのランプを暗めにしたいとき

おやすみ時など、明るさが気になるときに暗めに設定できます。

決定 を5秒間、長押しする
(受信音“ピッ”)

■ 元に戻すとき

もう一度 **決定** を5秒間、長押しする



- お買い上げ時の明るさで、「AI快適エコナビ」を設定しているときは、明るさ自動調節機能が働きます。(P.38)

停電などで電源が切れたとき

- 運転は停止します。通電後、改めて運転してください。
通電時、上下風向ルーバーは閉じません。閉じたいときは、停止ボタンを押してください。
- タイマー予約は、取り消されます。通電後、予約し直してください。(P.17, 29)
- おはようチャージ設定時は、本体に記憶していた時刻情報が消去されるため、予熱運転が始まいません。
通電後、リモコンのメニューから「チャージ 有」を設定してください。(P.25) 時刻情報が本体に送信されます。
- 室温みはりは、本体に記憶していた設定が取り消されるため動作しません。
通電後、リモコンのメニューから「室温みはり 有」を設定してください。(P.15)

室外ユニットに背面金網を取り付けたいとき

- お買い上げの販売店へ取り付けをご依頼ください。(別売品)

よくあるお問い合わせ



タイマーランプ(オレンジ)が点滅する



異常をお知らせしています。
(P.52)



運転ランプ(緑)が点滅する



次のときに点滅します。
そのままお待ちください。

- 自動運転開始時。(運転モードを選んでいます)
- 暖房運転開始時。
(冷たい風を出さないよう、風を止めています)
- 暖房運転時、暖房を止めて霜取り運転しているとき。
(P.37)
- 入タイマー予約時の運転開始前。
(運転開始時刻を決めるため、室温を検知しています)
- おはようチャージ設定時。
(予熱運転をする・しないを決めるため、室温・外気温を検知しています)




室外ユニットから水や湯気が出る



暖房中は、室外ユニットで除湿した水が排水口から出ます。
また、室外ユニットに付いた霜が溶けて、水や湯気となって出ることがあります。(P.37)
冷房中は、室外ユニットの冷えた配管に水滴が付き、滴下する場合があります。

- 排水工事が必要なときは、
お買い上げの販売店へ
ご相談ください。



ボックスお手入れランプ(オレンジ)が点灯・点滅する



ダストボックスのお手入れ時期をお知らせしています。(P.32、33)

- お手入れをしないで使い続けると、ランプは点灯から点滅に変わります。(約120時間後)
点滅すると、フィルターおそうじ運転は自動で行われなくなるため、すぐにお手入れをしてください。



入タイマー時刻よりも早く運転を開始する



予約時刻に室温が設定温度近くになるように、早めに運転が始まります。(最長約50分前)



“ポコポコ”という音がする




ドレンホースから外気が流入し、発生する音です。

- 特に、高気密住宅など、気密性の高い部屋で、換気扇を回しているときや、屋外に強風が吹いているときに発生します。
- 部屋の吸気口を開けると解消される場合があります。
- 対応部材(別売品)の取り付けを、お買い上げの販売店へご相談ください。

おそうじ運転Q&A



停止したのに動いている



停止後、
フィルターや
本体内部のおそうじ
運転が始まります。(P.40、41)
フィルターおそうじ運転中は、上下風向
ルーバーを閉じますが、内部クリーン運転
中は少し開けて運転します。終了すると、
自動ですべての動きが止まります。

■ 自動で動くのを止めたいとき

フィルターおそうじ運転

止められませんが、お好みの時刻に変えることができます。(P.29「おそうじタイマー」)

内部クリーン運転

「クリーン 無」(P.27)にしてください。
その場合、リモコンで毎日「手動おそうじ運転」
(P.30)することをおすすめします。



冷房中などにおそうじ運転する



24時間を超える連続運転中にフィルターおそうじ運転をします。(P.40)

- 約12分間で自動終了し、元の運転に戻ります。
- おそうじタイマーを予約すると予約時刻に運転します。(P.29)



おそうじ運転を途中で止めてもいい?



停止ボタンで止められますが
内部クリーン運転は、なるべく
止めないでください。

(におい成分やカビ菌の除去、付着した油汚れを低減する効果がなくなるため)

- フィルターおそうじ運転を途中で止めたときは、次の暖房などの運転停止時に、再度運転します。
- 止めた後は、なるべく早く「手動おそうじ運転」(P.30)をするなど、汚れをためないのが、キレイに使うコツです。



おそうじ運転を止めて冷房などを運転したい



運転開始ボタンを押してください。



おやすみ時など、おそうじ運転の音が気になる



おやすみ切タイマーとおそうじタイマーのご使用をおすすめします。停止時、おそうじ運転を行いません。(P.16、29)

故障かな? ①

お問い合わせや修理を依頼される前に、まずご確認ください。

症 状	対処法と原因
おそうじ運転	●前回、フィルターおそうじ運転をしてから積算で約24時間以内の運転停止後は、おそうじ運転を行いません。 ●ボックスお手入れランプが点滅していませんか? ダストボックスから、ほこりがあふれ出るのを防ぐため、フィルターおそうじ運転は自動で行いません。 →ダストボックスとエアフィルターのお手入れをしてください。(P.32、33) ●「クリーン 無」にしていませんか?(P.27) ●「クリーン 2」(油汚れ低減動作なし)にしたとき、暖房やナノイーX送風後、内部クリーン運転は動作しません。(P.27) ●異常が発生していませんか?(タイマーランプ点滅) →異常の内容を確認してください。(P.52)
	●フィルターおそうじ運転をタイマー予約していませんか? 予約時刻になると冷房などの運転を中断し、エアフィルターなどを掃除します。
	●「おそうじ 念入」にしていませんか?(P.28) ●「クリーン 送風 有」にしていませんか?(P.27)
	●油汚れやタバコのヤニは、取りきれない場合があります。 →エアフィルターのお手入れをしてください。(P.35) ●ダストボックス、ゴムブレードが正しく取り付けられていますか?(P.32、33) ●汚れが気になるときは「おそうじ 念入」に変更できます。(P.28) ●フィルターおそうじ運転を途中で止めていませんか?
	●人が多く集まる場所など、ほこりがたまりやすい場合は、ボックスお手入れランプが点灯する前に、お手入れが必要です。 →ダストボックスお手入れ後、「間隔 短」に設定してください。 お手入れ時期を早めにお知らせします。(P.28)
本体	●ブレーカーが「切」になっていませんか? ●電源プラグがはずれていませんか? ●本体に付属のリモコン以外で遠隔操作をするときは、リモコンのメニュー設定を「遠隔 有」(P.28)にすると、運転できる場合があります。
	●「しずか」にしていませんか?(P.13) 室温や屋外温度によって、設定温度に到達するまでに時間がかかることがあります。 ●エアフィルターに汚れが残っていませんか? エアフィルターの掃除は自動で行いますが、ほこりや油汚れが多い環境などでご使用の場合、取りきれないことがあります。 →エアフィルターのお手入れをしてください。(P.35) ●屋外の熱を取り入れて暖房するため、屋外温度が0°C以下になると暖房能力は低下します。また、部屋の広さや外気温などの条件によっては、設定温度に到達しないことがあります。 →他の暖房器具との併用をおすすめします。

症 状	対処法と原因
よく 冷えない・暖まらない	<ul style="list-style-type: none"> ● 室内・室外ユニットの吹出口・吸入口をふさいでいませんか？(P.7) →周辺の障害物を取り除いてください。 →積雪時は室外ユニットの下や周辺の雪を取り除いてください。 積雪の多い地域では、防雪対策をおすすめします。 お買い上げの販売店へご相談ください。 ● 換気扇やガスコンロを使用していませんか？ ● 「セーブ 有」(P.24)またはエオリア アプリで「パワーセーブセレクト」を設定していませんか？ 最大電流値が低くなる分、冷えや暖まりが悪くなる場合があります。 ● 本体に付属のリモコン以外で遠隔操作(温度・風量・風向設定など)をされていませんか？ 遠隔操作で設定された内容は、リモコンに表示しません。 →リモコンで温度・風量・風向は変えられます。
暖まるまでに時間がかかる	<ul style="list-style-type: none"> ● 「セーブ 有」(P.24)または「室外音 Lo」(P.26)またはエオリア アプリで「パワーセーブセレクト」を設定していませんか？ 暖房能力が制限されるため、設定温度に到達するまで時間がかかります。
冷房・除湿切換時、 霧が出ている	<ul style="list-style-type: none"> ● 部屋の空気が、エアコンの冷たい風で冷やされて霧状になるためです。
本 体	<ul style="list-style-type: none"> ● 冷房時に、設定温度を20℃未満にしていませんか？ →20℃以上にしてください。 ● 内部クリーン運転を途中で停止した後、続けて冷房・除湿・冷房除湿運転をしたときは、本体内部や上下風向ルーバー、吹出口などに結露することがあります。 →時間を空けて、冷房・除湿・冷房除湿運転を行ってください。
	<ul style="list-style-type: none"> ● リモコンの現在時刻は合っていますか?(P.10) ● 室温みはりを設定していませんか?(P.15) 室温みはり運転中は、切タイマー予約時刻になっても停止しません。
室温みはり運転が 始まらない	<ul style="list-style-type: none"> ● 運転が止まった後、約30分間は温度・湿度の誤検知防止のため、室温みはりは動作しません。 ● 停電などにより、設定が取り消された可能性があります。 →リモコンのメニューから「室温みはり 有」を設定してください。(P.15)
おはようチャージを設定 したのに予熱運転が 始まらない	<ul style="list-style-type: none"> ● 前回の運転を暖房で停止していないときや室温・外気温が高いときは、予熱運転を行いません。(P.25) ● 「チャージ」表示中に停止ボタンを押すと、おはようチャージの設定が一時的に取り消され、予熱運転を行いません。(P.25) ● 停電などにより、本体の時刻情報が消去された可能性があります。 →リモコンのメニューから「チャージ 有」を設定してください。 時刻情報が本体に送信されます。(P.25)

故障かな? (2)

お問い合わせや修理を依頼される前に、まずご確認ください。

症 状	対処法と原因
本 体	運転中、上下風向ルーバー・左右風向ルーバーが勝手に動く
	●冷房や暖房の風向自動時、室温がリモコン設定温度に近づくと、自動的に上下風向ルーバーの向きが変わることがあります。 ●冷房・冷房除湿の運転中、結露を防ぐため、自動的に上下風向・左右風向ルーバーの向きが変わることがあります。
	停止後、上下風向ルーバーが閉じない
	●停止時、上下風向ルーバーは、すぐに閉じません。 確実に閉じるため、いったん大きく開いてから閉じます。 ●内部クリーン運転をしていませんか?(P.41、45) ●停止中に上下風向ルーバーを手で動かしていませんか? 手では完全に閉じることができません。 →リモコンの本体リセットボタンを押してから、停止ボタンを押してください。
	停電復帰後、運転しない・上下風向ルーバーが閉じない
	●復帰しても自動的に運転は開始せず、停止したままとなります。 このとき、上下風向ルーバーは閉じません。 →閉じたいときは、停止ボタンを押してください。
勝手に動き出す・止まる	●内部クリーン運転をしていませんか?(P.41) ●自動で動作する機能をリモコンで設定していませんか? •切タイマー／入タイマー (P.17) 予約は、取り消すまで毎日繰り返されます。 •カビみはり (P.31) •室温みはり (P.15) •おはようチャージ (P.25) 予熱中は、上下風向ルーバーが開きます。 ●本体に付属のリモコン以外で遠隔操作をされていませんか? ●「遠隔 有」を設定していませんか?(P.28) 通信できない状態が続くと、自動で停止することがあります。 ●HEMS(ホームエネルギー・マネジメントシステム)にエアコンをつないでいる場合は、エアコンが止まることがあります。 →遠隔操作をしない場合は、「遠隔 無」でお使いください。(P.28)
前面パネルが完全に閉まらない	●ダストボックスが正しく取り付けられていますか? →ダストボックスは、奥まで入れて、必ずロックしてください。(P.32、33) ●フィルター扉はロックされていますか?(P.33、35)
室内ユニット周辺の天井や壁が黒く汚れる	●空気中のちりやほこりがエアコンによる空気の循環や静電気で壁などに付着するためです。壁紙の種類によっては、汚れが付着しやすいものがあります。 →エアコン周辺の、こまめなお掃除をおすすめします。

症 状	対処法と原因
運転開始時、風がすぐ出ない	<ul style="list-style-type: none"> ●暖房時は、冷たい風が出るのを防ぐためです。暖かい風が出るまでに数分かかる場合があります。(風量手動のときは、吹き出しからしばらくの間、冷たい風が出ることがあります) ●においカット機能を設定していませんか?(P.26)
運転開始時の風が暖かくない・冷たくない	<ul style="list-style-type: none"> ●停止後すぐに再運転すると、約3分間、送風になります。(エアコン保護のため) ●おはようチャージで予熱中に暖房運転しても、本体が十分に暖まっていない場合は、温風がすぐ出ることがあります。(P.25)
風がにおう	<ul style="list-style-type: none"> ●じゅうたんや衣類などにしみこんでいる生活臭が、空気の循環によって出てくることがあります。 ●冷房から除湿・暖房に切り換えると、約5分間におうことがあります。 ●冷房・除湿・冷房除湿の運転開始時、室内ユニットに付着した生活臭が風とともにに出ることがあります。 →においカット機能(P.26)を設定すると、軽減する場合があります。 ●ドレンホースの先端が、においのたまる排水溝などに入っていますか?
風量が勝手に変わる	<ul style="list-style-type: none"> ●室内外の状況や設定温度、設定風量によって、風量が変わることがあります。
暖房の運転開始時や運転中に風が冷たく感じる	<ul style="list-style-type: none"> ●風量を  にしていませんか? 強い風で早く運転することを優先させるため、風が十分暖まる前に出ます。 →「パワフル」または「風量自動」をおすすめします。 ●リモコンで設定した温度に近づくと、室内温度が上がりすぎないように風の温度が少し下がります。このとき、風が冷たく感じないよう、風量が弱まりますが、風量手動のときは、弱くならないことがあります。
運転中に風が止まる	<p>〈除湿・冷房除湿時〉</p> <ul style="list-style-type: none"> ●運転開始時、約30秒間送風後、風を止めことがあります。 (室内温度が低いときに、冷たい風が出るのを防ぐため) ●室内温度が設定温度に近づくと、約5分間、運転が止まります。 <p>〈冷房・除湿・冷房除湿時〉</p> <ul style="list-style-type: none"> ●においカット機能を設定していませんか?(P.26) <p>〈暖房時〉</p> <ul style="list-style-type: none"> ●室外ユニットに付いた霜を溶かしている間、風が出ません。(霜取り運転) →しばらくお待ちください。(最長約12分間)(P.37)

故障かな? ③

お問い合わせや修理を依頼される前に、まずご確認ください。


症 状	対処法と原因
ラジオ	<ul style="list-style-type: none"> ●「AI快適エコナビ」を設定していませんか? 部屋が暗いと検知されると、少し暗めになり、明るいと検知されると元の明るさに戻ります。 ●暗めに設定していませんか? (P.43)
	<ul style="list-style-type: none"> ●ナノイーX/おそうじランプが運転中に消える →お買い上げの販売店へご相談ください。
	<ul style="list-style-type: none"> ●タイマー予約していないのにタイマーランプが点灯する・消灯しない ●本体に付属のリモコン以外で、遠隔操作をされていませんか?
	<ul style="list-style-type: none"> ●エアコンと無線LANルーターとが接続されていないときに点滅します。 エオリア アプリ(P.18)など、本体に付属のリモコン以外でエアコンを操作しないときは、リモコンの無線LANボタンを2秒間、長押しして消灯させてください。 ●エオリア アプリご利用時は、エアコンと無線LANルーターが接続されていないときに点滅します。下記の内容をご確認ください。 無線LANルーターと通信ができるようになると、点灯に変わります。 <ul style="list-style-type: none"> ・無線LANルーターの電源が切れていないか。 ・無線LANルーターの位置が室内ユニットから遠くないか。 ・初期設定の手順2~4 (P.19)を再度行い、接続を確認。
リモコン	<ul style="list-style-type: none"> ●乾電池が消耗していたり、使用推奨期限が近かつたりしませんか? →乾電池を交換してください。 ●リモコンを室内ユニットの受信部に向けていますか? (P.7) ●テレビやビデオのリモコンのボタンが、リモコンラックなどで押されていませんか? (混信して受信できない原因) ●インバーター照明がある部屋では信号を受け付けない場合があります。 →お買い上げの販売店へご相談ください。
	<ul style="list-style-type: none"> ●乾電池が消耗していませんか? →乾電池を交換してください。 ●+/-が逆になっていませんか? →+/-は正しく入れてください。
	<ul style="list-style-type: none"> ●時刻表示「12:00」が点滅していませんか? →現在時刻を合わせてください。 (P.10)
リモコンの設定どおりに運転しない	<ul style="list-style-type: none"> ●設置後、初めて運転したときは、リモコンの設定にかかわらず、上下風向ルーバーとフィルターおそうじ運転の動作チェック(試運転)が行われます。その後、リモコンの設定に応じた運転で動作チェック(試運転)が行われます。すべての試運転は約15分間で終了し、そのまま設定された運転が継続されます。

	症 状	対処法と原因
リモコン	暖房時、リモコンで風量調節ができない	●室内温度が設定温度に近づくと、自動的に風の温度と風量が少し下がります。 (室内温度が上がりすぎるとのを防ぐため)
	設定温度が勝手に変わる 「12:00」が点滅し、時刻合わせができない	●乾電池が消耗していませんか? 消耗すると、リモコンの表示が変わったり、設定ができなくなったりします。 →乾電池を交換してください。
	“ブシュツ”という音	●霜取り運転時や運転停止時に、エアコン内部の冷媒ガスの流れが切り替わる音です。
	“ピシツ”“パキッ”という音	●温度変化でエアコンの樹脂部分が伸び縮みする音です。
	水の流れるような“シャー” “ボコボコ”という音	●冷媒ガスがエアコン内部に流れている音です。
	“バサツ”“ギシツ”という音	●フィルターおそうじ運転中に発生している音です。 (エアフィルターやブラシが駆動しています) →寝室などでご使用時に音が気になるときは、「おそうじタイマー」の予約をおすすめします。(P.29)
	“シャー”“ジー”という音	●ナノイーメンが発生している音です。 →就寝時など音が気になるときは、ナノイーメンを取り消してください。(P.11)
	“ピッピッ”という受信音	●リモコンの設定温度が上限または下限になったことをお知らせしています。
音	何も操作していないのに “ピー”“ピーピー”“ピツ” “ピッピッ”などの受信音	●本体に付属のリモコン以外で遠隔操作をされていませんか?
	操作すると“ピーピーピー” “ピーピーピーピー” という受信音	●遠隔操作によりコントロールされている場合、本体に付属のリモコンで操作できることをお知らせしています。
	“ピピピピ”という音を繰り返す	●試運転時に、異常が発生したことをお知らせしています。(タイマーランプ点滅) →約3分間で音は止まります。お買い上げの販売店へご連絡ください。

故障かな?

タイマーランプが点滅するときは

室内または室外ユニットに異常が発生しています。以下の手順でご確認ください。



仕様

種類		冷房・暖房兼用セパレート形(インバーター)															
		室内品番	室外品番	室内品番	室外品番	室内品番	室外品番	室内品番	室外品番	室内品番	室外品番	室内品番	室外品番	室内品番	室外品番		
GXシリーズ		CS-GX223D	CU-GX223D	CS-GX253D	CU-GX253D	CS-GX283D	CU-GX283D	CS-GX363D	CU-GX363D	CS-GX403D2	CU-GX403D2	CS-GX563D2	CU-GX563D2	CS-GX633D2	CU-GX633D2		
DGEシリーズ		CS-223DGE	CU-223DGE	CS-253DGE	CU-253DGE	CS-283DGE	CU-283DGE	CS-363DGE	CU-363DGE	CS-403DG2E	CU-403DG2E	CS-563DG2E	CU-563DG2E	CS-633DG2E	CU-633DG2E		
DGXシリーズ		CS-223DGX	CU-223DGX	CS-253DGX	CU-253DGX	CS-283DGX	CU-283DGX	CS-363DGX	CU-363DGX	CS-403DGX2	CU-403DGX2	CS-563DGX2	CU-563DGX2	CS-633DGX2	CU-633DGX2		
電源		単相 100 V 50/60 Hz両用								単相 200 V 50/60 Hz両用							
電源プラグ形状		(II)	-	(II)	-	(II)	-	(II)	-	(II)	-	(II)	-	(II)	-		
冷房	定格能力(kW)	2.2 (0.5~3.0)		2.5 (0.5~3.2)		2.8 (0.5~3.2)		3.6 (0.6~3.8)		4.0 (0.6~4.3)		5.6 (0.7~5.7)		6.3 (0.7~6.4)			
	定格消費電力(W)	595 (135~770)		680 (135~830)		770 (135~830)		1,370 (155~1,420)		1,350 (155~1,600)		2,370 (160~2,390)		2,750 (160~2,780)			
	運転電流(A)	6.60		7.55		8.55		14.4		7.25		12.7		14.7			
	運転音 (dB : 音響パワーレベル)	58	57	60	58	60	59	64	62	61	61	65	66	68	69		
	冷房面積の 目安	鉄筋アパート 南向き洋室	15 m ² /9畳	17 m ² /10畳	19 m ² /12畳	25 m ² /15畳	28 m ² /17畳	39 m ² /23畳	43 m ² /26畳	木造 南向き和室	10 m ² /6畳	11 m ² /7畳	13 m ² /8畳	16 m ² /10畳	18 m ² /11畳	25 m ² /15畳	29 m ² /17畳
暖房	定格能力 (kW)	標準	2.2 (0.4~4.1)	2.8 (0.4~4.7)	3.6 (0.4~4.8)	4.2 (0.5~4.8)	5.0 (0.5~7.3)	6.7 (0.6~9.4)	7.1 (0.6~9.4)	低温	3.0	3.4	3.5	3.7	5.3	6.8	6.8
	定格消費電力 (W)	標準	465 (125~1,320)	630 (125~1,410)	870 (125~1,440)	1,200 (145~1,440)	1,430 (145~2,690)	1,940 (150~3,440)	2,420 (150~3,440)	低温	1,170	1,250	1,270	1,350	2,380	3,040	3,040
	運転電流(A)<最大>	5.15<15.0>		7.00<15.0>		9.65<15.0>		12.5<15.0>		7.25<15.0>		9.85<17.0>		12.3<17.0>			
	運転音 (dB : 音響パワーレベル)	60	58	61	58	62	58	64	64	64	62	67	65	67	69		
	暖房面積の 目安	鉄筋アパート 南向き洋室	10 m ² /6畳	13 m ² /8畳	16 m ² /10畳	19 m ² /12畳	23 m ² /14畳	30 m ² /18畳	32 m ² /20畳	木造 南向き和室	8 m ² /5畳	10 m ² /6畳	13 m ² /8畳	15 m ² /9畳	18 m ² /11畳	24 m ² /15畳	26 m ² /16畳
通年エネルギー消費効率			5.8		5.8		5.8		4.9		4.9		5.0		5.0		
JIS C 9612:2005			5.8		5.8		5.8		4.9		4.9		5.0		5.0		
区分名			A		A		A		C		C		F		F		
質量(kg)			10.5	17.5	10.5	20	10.5	21	10	22	10.5	26	11.5	36	11.5	36.5	
外形寸法 (高さ×幅×奥行) (mm)	室内ユニット	249×790×340															
	室外ユニット	539×675× 240		539×655×275						551×780× 289		630×799×299					

- この仕様値は、JIS C 9612:2013(日本産業規格)に基づいた数値です。
- 室外ユニットの幅の寸法には配管接続口部分を含んでいません。
- リモコンで「停止」のときの消費電力は電源が単相100 Vの場合0.8 W、単相200 Vの場合0.9 Wです。
(タイマー予約時、おはようチャージ、カビみはり設定時: 約1 W、室温みはり中: 約3 W)
- 無線LANランプ点灯中、「停止」のときの消費電力は約1 Wです。

●室外ユニットを、硫化ガス、機械油の多い所、悪臭や有毒ガスの発生する所、積雪の多い地域でご使用される場合は販売店へご相談ください。

■ 無線LAN部

無線LAN規格	IEEE802.11 b/g/n
周波数範囲	2.4 GHz帯
暗号化方式	WPA TM /WPA2 TM

著作権など①

- App StoreはApple Inc. のサービスマークです。
- iPhoneは、米国および他の国々で登録されたApple Inc. の商標です。iPhoneの商標は、アイホン株式会社のライセンスに基づき使用されています。
- AndroidおよびGoogle PlayはGoogle LLCの商標または登録商標です。
- “WPA™”および“WPA2™”は、“Wi-Fi Alliance®”の商標です。
- その他、本書に記載されている各種名称、会社名、商品名などは各社の商標または登録商標です。なお、本文中では™、®マークは一部記載していません。

■ ソフトウェアについて

本製品は、以下の種類のソフトウェアから構成されています。

- (1) パナソニック株式会社(以下パナソニック)により、
またはパナソニックのために開発されたソフトウェア
- (2) 第三者が保有しており、パナソニックにライセンスされたソフトウェア
- (3) GNU GENERAL PUBLIC LICENSE Version2.0
(GPL V2.0)に基づきライセンスされたソフトウェア
- (4) GPL V2.0 以外の条件に基づきライセンスされた
オープンソースソフトウェア

上記(3)(4)に分類されるソフトウェアは、これら単体で有用であることを期待して頒布されますが、「商品性」または「特定の目的についての適合性」についての默示の保証をしないことを含め、一切の保証はなされません。

パナソニックは、本製品の発売から少なくとも3年間、以下の問い合わせ窓口にご連絡いただいた方に対し、実費にて、GPL V2.0 またはソースコードの開示義務を課すその他の条件に基づきライセンスされたソフトウェアに対応する完全かつ機械読み取り可能なソースコードを、それぞれの著作権者の情報と併せて提供します。

問い合わせ窓口：

oss-cd-request@gg.jp.panasonic.com

また、これらソースコードおよび著作権者の情報は、以下のウェブサイトからも自由に無料で入手することができます。
<https://panasonic.net/cns/oss/ap/>

ソフトウェアに関する詳細および最新の情報は、サポート総合窓口(<https://panasonic.jp/support/>)の商品別サポートのページで、本製品のカテゴリと品番に対応する形で提供されている取扱説明書をご参照ください。

IwIP

IwIP is licenced under the BSD licence:

Copyright (c) 2001-2004 Swedish Institute of Computer Science.
All rights reserved.

Copyright (c) 2001-2003 Swedish Institute of Computer Science. All rights reserved.

Copyright (c) 2002 CITEL Technologies Ltd. All rights reserved.

Copyright (c) 2007 Dominik Spies <kontakt@dspies.de> All rights reserved.

Copyright (c) 2002-2003, Adam Dunkels. All rights reserved.

Copyright (c) 2001-2003 Swedish Institute of Computer Science.

Copyright (c) 2003-2004 Leon Woestenberg <leon.woestenberg@axon.tv>

Copyright (c) 2003-2004 Axon Digital Design B.V., The Netherlands.

All rights reserved.

Copyright (c) 2001-2004 Leon Woestenberg <leon.woestenberg@gmx.net>

Copyright (c) 2001-2004 Axon Digital Design B.V., The Netherlands.

All rights reserved.

MINIX3

Copyright (c) 2016 The MINIX 3 Project.
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

mbedTLS

Copyright (C) 2006-2015, ARM Limited, All Rights Reserved
Copyright (C) 2006-2016, ARM Limited, All Rights Reserved

Apache License
Version 2.0, January 2004
<http://www.apache.org/licenses/>

TERMS AND CONDITIONS FOR USE, REPRODUCTION,
AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.

3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted.

If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.

4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:

- (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
- (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
- (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
- (d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions.

Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.

6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.

7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.

8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any

character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.

9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

APPENDIX: How to apply the Apache License to your work.

To apply the Apache License to your work, attach the following boilerplate notice, with the fields enclosed by brackets "[]" replaced with your own identifying information. (Don't include the brackets!) The text should be enclosed in the appropriate comment syntax for the file format. We also recommend that a file or class name and description of purpose be included on the same "printed page" as the copyright notice for easier identification within third-party archives.

Copyright [yyyy] [name of copyright owner]

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License.
You may obtain a copy of the License at

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the License for the specific language governing permissions and limitations under the License.

WPA Suplicant

=====

Copyright (c) 2003-2016, Jouni Malinen <j@w1.fi> and
contributors All Rights Reserved.

This program is licensed under the BSD license (the one with advertisement clause removed).

If you are submitting changes to the project, please see CONTRIBUTIONS file for more instructions.

License

=====

This software may be distributed, used, and modified under the terms of BSD license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Free RTOS

The FreeRTOS source code is licensed by a *modified* GNU General Public License (GPL). The modification is provided in the form of an exception.

著作権など②

NOTE: The modification to the GPL is included to allow you to distribute a combined work that includes FreeRTOS without being obliged to provide the source code for proprietary components outside of the FreeRTOS kernel.

The FreeRTOS GPL Exception Text:

Any FreeRTOS source code, whether modified or in its original release form, or whether in whole or in part, can only be distributed by you under the terms of the GNU General Public License plus this exception. An independent module is a module which is not derived from or based on FreeRTOS.

Clause 1:

Linking FreeRTOS statically or dynamically with other modules is making a combined work based on FreeRTOS. Thus, the terms and conditions of the GNU General Public License cover the whole combination.

As a special exception, the copyright holder of FreeRTOS gives you permission to link FreeRTOS with independent modules that communicate with FreeRTOS solely through the FreeRTOS API interface, regardless of the license terms of these independent modules, and to copy and distribute the resulting combined work under terms of your choice, provided that

- + Every copy of the combined work is accompanied by a written statement that details to the recipient the version of FreeRTOS used and an offer by yourself to provide the FreeRTOS source code (including any modifications you may have made) should the recipient request it.
- + The combined work is not itself an RTOS, scheduler, kernel or related product.
- + The independent modules add significant and primary functionality to FreeRTOS and do not merely extend the existing functionality already present in FreeRTOS.

Clause 2:

FreeRTOS may not be used for any competitive or comparative purpose, including the publication of any form of run time or compile time metric, without the express permission of Real Time Engineers Ltd. (this is the norm within the industry and is intended to ensure information accuracy).

The standard GPL exception text:

GNU GENERAL PUBLIC LICENSE Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.
59 Temple Place, Suite 330, Boston, MA 02111-1307 USA
Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>
Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License** as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'. This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

著作権など③

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989
Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

newlib

The newlib subdirectory is a collection of software from several sources.

Each file may have its own copyright/license that is embedded in the source file. Unless otherwise noted in the body of the source file(s), the following copyright notices will apply to the contents of the newlib subdirectory:

(1) Red Hat Incorporated

Copyright (c) 1994-2009 Red Hat, Inc. All rights reserved.

This copyrighted material is made available to anyone wishing to use, modify, copy, or redistribute it subject to the terms and conditions of the BSD License. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY expressed or implied, including the implied warranties of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. A copy of this license is available at <http://www.opensource.org/licenses>. Any Red Hat trademarks that are incorporated in the source code or documentation are not subject to the BSD License and may only be used or replicated with the express permission of Red Hat, Inc.

(2) University of California, Berkeley

Copyright (c) 1981-2000 The Regents of the University of California.
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(3) David M. Gay (AT&T 1991, Lucent 1998)

The author of this software is David M. Gay.

Copyright (c) 1991 by AT&T.

Permission to use, copy, modify, and distribute this software for any purpose without fee is hereby granted, provided that this entire notice is included in all copies of any software which is or includes a copy or modification of this software and in all copies of the supporting documentation for such software.

THIS SOFTWARE IS BEING PROVIDED "AS IS", WITHOUT ANY EXPRESS OR IMPLIED WARRANTY. IN PARTICULAR, NEITHER THE AUTHOR NOR AT&T MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND

CONCERNING THE MERCHANTABILITY OF THIS SOFTWARE OR ITS FITNESS FOR ANY PARTICULAR PURPOSE.

The author of this software is David M. Gay.

Copyright (C) 1998-2001 by Lucent Technologies
All Rights Reserved

Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that the copyright notice and this permission notice and warranty disclaimer appear in supporting documentation, and that the name of Lucent or any of its entities not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

LUCENT DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS.

IN NO EVENT SHALL LUCENT OR ANY OF ITS ENTITIES BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

(4) Advanced Micro Devices

Copyright 1989, 1990 Advanced Micro Devices, Inc.

This software is the property of Advanced Micro Devices, Inc (AMD) which specifically grants the user the right to modify, use and distribute this software provided this notice is not removed or altered. All other rights are reserved by AMD.

AMD MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS SOFTWARE. IN NO EVENT SHALL AMD BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THE FURNISHING, PERFORMANCE, OR USE OF THIS SOFTWARE.

So that all may benefit from your experience, please report any problems or suggestions about this software to the 29K Technical Support Center at 800-29-29-AMD (800-292-9263) in the USA, or 0800-89-1131 in the UK, or 0031-11-1129 in Japan, toll free. The direct dial number is 512-462-4118.

Advanced Micro Devices, Inc.
29K Support Products
Mail Stop 573
5900 E. Ben White Blvd.
Austin, TX 78741
800-292-9263

(7) Sun Microsystems

Copyright (C) 1993 by Sun Microsystems, Inc. All rights reserved.

Developed at SunPro, a Sun Microsystems, Inc. business. Permission to use, copy, modify, and distribute this software is freely granted, provided that this notice is preserved.

(8) Hewlett Packard

(c) Copyright 1986 HEWLETT-PACKARD COMPANY

To anyone who acknowledges that this file is provided "AS IS" without any express or implied warranty:

permission to use, copy, modify, and distribute this file for any purpose is hereby granted without fee, provided that the above copyright notice and this notice appears in all copies, and that the name of Hewlett-Packard Company not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

Hewlett-Packard Company makes no representations about the suitability of this software for any purpose.

(9) Hans-Peter Nilsson

Copyright (C) 2001 Hans-Peter Nilsson

Permission to use, copy, modify, and distribute this software is freely granted, provided that the above copyright notice, this notice and the following disclaimer are preserved with no changes.

THIS SOFTWARE IS PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

(11) Christopher G. Demetriou

Copyright (c) 2001 Christopher G. Demetriou
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(12) SuperH, Inc.

Copyright 2002 SuperH, Inc. All rights reserved

This software is the property of SuperH, Inc (SuperH) which specifically grants the user the right to modify, use and distribute this software provided this notice is not removed or altered. All other rights are reserved by SuperH.

SUPERH MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS SOFTWARE. IN NO EVENT SHALL SUPERH BE LIABLE FOR INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THE FURNISHING, PERFORMANCE, OR USE OF THIS SOFTWARE.

So that all may benefit from your experience, please report any problems or suggestions about this software to the SuperH Support Center via e-mail at softwaresupport@superh.com .

SuperH, Inc.
405 River Oaks Parkway
San Jose
CA 95134
USA

(13) Royal Institute of Technology

Copyright (c) 1999 Kungliga Tekniska Högskolan
(Royal Institute of Technology, Stockholm, Sweden).
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of KTH nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY KTH AND ITS CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL KTH OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(14) Alexey Zelkin

Copyright (c) 2000, 2001 Alexey Zelkin <phantom@FreeBSD.org>
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(15) Andrey A. Chernov

Copyright (C) 1997 by Andrey A. Chernov, Moscow, Russia.
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(16) FreeBSD

Copyright (c) 1997-2002 FreeBSD Project.
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(17) S. L. Moshier

Author: S. L. Moshier.

Copyright (c) 1984,2000 S.L. Moshier

著作権など④

Permission to use, copy, modify, and distribute this software for any purpose without fee is hereby granted, provided that this entire notice is included in all copies of any software which is or includes a copy or modification of this software and in all copies of the supporting documentation for such software.

THIS SOFTWARE IS BEING PROVIDED "AS IS", WITHOUT ANY EXPRESS OR IMPLIED WARRANTY. IN PARTICULAR, THE AUTHOR MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND CONCERNING THE MERCHANTABILITY OF THIS SOFTWARE OR ITS FITNESS FOR ANY PARTICULAR PURPOSE.

(18) Citrus Project

Copyright (c)1999 Citrus Project,
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(19) Todd C. Miller

Copyright (c) 1998 Todd C. Miller <Todd.Miller@courtesan.com>
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(20) DJ Delorie (i386)

Copyright (C) 1991 DJ Delorie
All rights reserved.

Redistribution, modification, and use in source and binary forms is permitted provided that the above copyright notice and following paragraph are duplicated in all such forms.

This file is distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

(23) Intel (i960)

Copyright (c) 1993 Intel Corporation

Intel hereby grants you permission to copy, modify, and distribute this software and its documentation. Intel grants this permission provided that the above copyright notice appears in all copies and that both the copyright notice and this permission notice appear in supporting documentation. In addition, Intel grants this permission provided that you prominently mark as "not part of the original" any modifications made to this software or documentation, and that the name of Intel Corporation not be used in advertising or publicity pertaining

to distribution of the software or the documentation without specific, written prior permission.

Intel Corporation provides this AS IS, WITHOUT ANY WARRANTY, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Intel makes no guarantee or representations regarding the use of, or the results of the use of, the software and documentation in terms of correctness, accuracy, reliability, currentness, or otherwise; and you rely on the software, documentation and results solely at your own risk.

IN NO EVENT SHALL INTEL BE LIABLE FOR ANY LOSS OF USE, LOSS OF BUSINESS, LOSS OF PROFITS, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND. IN NO EVENT SHALL INTEL'S TOTAL LIABILITY EXCEED THE SUM PAID TO INTEL FOR THE PRODUCT LICENSED HEREUNDER.

(26) Mike Barcroft

Copyright (c) 2001 Mike Barcroft <mike@FreeBSD.org>
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(27) Konstantin Chuguev (--enable-newlib-iconv)

Copyright (c) 1999, 2000
Konstantin Chuguev. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

iconv (Charset Conversion Library) v2.0

(28) Artem Bityuckiy (--enable-newlib-iconv)

Copyright (c) 2003, Artem B. Bityuckiy, SoftMine Corporation.
Rights transferred to Franklin Electronic Publishers.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY

AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(30) - Alex Tatmanjants (targets using libc posix)

Copyright (c) 1995 Alex Tatmanjants <alex@elvisti.kiev.ua>
at Electronni Visti IA, Kiev, Ukraine.
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:
1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(31) - M. Warner Losh (targets using libc posix)

Copyright (c) 1998, M. Warner Losh <imp@freebsd.org>
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:
1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(32) - Andrey A. Chernov (targets using libc posix)

Copyright (C) 1996 by Andrey A. Chernov, Moscow, Russia.
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:
1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(33) - Daniel Eischen (targets using libc posix)

Copyright (c) 2001 Daniel Eischen <deischen@FreeBSD.org>
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:
1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(35) - ARM Ltd (arm and thumb variant targets only)

Copyright (c) 2009 ARM Ltd
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:
1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the company may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY ARM LTD "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL ARM LTD BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(41) Ed Schouten - Free BSD


Copyright (c) 2008 Ed Schouten <ed@FreeBSD.org>
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:
1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

長期使用製品安全表示制度に基づく本体表示について

経年劣化により、危害の発生が高まるおそれがあることを注意喚起するために、電気用品安全法で義務付けられた以下の表示を本体の銘板近傍に行っています。



※【設計上の標準使用期間】とは？

- 運転時間や温湿度など、以下の標準的な使用条件に基づく経年劣化に対して、製造した年から安全上支障なく使用することができる標準的な期間です。
- 設計上の標準使用期間は、無償保証期間とは異なります。
また、一般的な故障を保証するものではありません。

■標準使用条件…JIS C 9921-3 ルームエアコンディショナの設計上の標準使用期間を設定するための標準使用条件による

環境条件	電源電圧	製品の定格電圧による
	周波数	50 Hzまたは60 Hz
	冷房	室内温度 27 °C (乾球温度)
		室内湿度 47 % (湿球温度19 °C)
		屋外温度 35 °C (乾球温度)
		屋外湿度 40 % (湿球温度24 °C)
	暖房	室内温度 20 °C (乾球温度)
		室内湿度 59 % (湿球温度15 °C)
		屋外温度 7 °C (乾球温度)
		屋外湿度 87 % (湿球温度6 °C)
	設置条件	製品の据付工事説明書による標準設置
負荷条件	住宅	木造平屋、南向き和室、居間
	部屋の広さ	製品能力に見合った広さの部屋 (畳数)
想定時間	1年間の使用日数	東京モデル 冷房6月2日から9月21日までの112日間 暖房10月28日から4月14日までの169日間
	1日の使用時間	冷房：9時間／日 暖房：7時間／日
	1年間の使用時間	冷房：1,008時間／年 暖房：1,183時間／年

- 設置状況や環境、使用頻度が上記の条件と異なる場合、または、本来の使用目的以外でご使用された場合は、設計上の標準使用期間より短い期間で経年劣化による発火・けが等の事故に至るおそれがあります。

保証とアフターサービス

よくお読みください

使いかた・お手入れ・修理などは

■まず、お買い上げ先へご相談ください。
お買い上げの際に記入されると便利です

■転居や贈答品などでお困りの場合は、裏表紙の各ご相談窓口へご相談ください。

販売店名 お買い上げ日 年 月 日
電話 () -

修理を依頼されるときは

「よくあるお問い合わせ」(P.44、45)「故障かな?」(P.46~51)「タイマーランプが点滅するときは」(P.52)でご確認のあと、直らないときは、運転停止後、電源プラグを抜いて、お買い上げ日と右の内容をご連絡ください。

●製品名 ルームエアコン

品番 CS-〇〇〇〇



●異常の内容 できるだけ具体的に

●保証期間中は、保証書の規定にしたがって出張修理いたします。

保証期間：お買い上げ日から本体1年間（ただし、冷媒回路については5年間です）

●保証期間終了後は、診断をして修理できる場合はご要望により修理させていただきます。

※修理料金は次の内容で構成されています。

※補修用性能部品の保有期間 10年

当社は、このルームエアコンの補修用性能部品(製品の機能を維持するための部品)を、製造打ち切り後10年保有しています。


技術料 診断・修理・調整・占検などの費用

部品代 部品および補助材料代

出張料 技術者を派遣する費用

■「よく冷えない」症状で依頼される場合は

より早くご相談にお応えするため、事前に冷房チャック運転を行ってください。



● 滂房チェック運転やお知らせ音、運転ランプの点滅を途中で止めたいときは停止ボタンを押す。

室内ユニットのクリーニングをご要望される場合は

お買い上げの販売店、または修理で相談窓口(裏表紙)へご相談ください。

(ただし、室内ユニットの取りはずしができない等、設置状況によっては対応できることがあります)

ご相談窓口／商品登録

使いかた・お手入れ・修理などはまず、お買い上げ先へご相談ください。
転居や贈答品などでお困りの場合は、次の窓口にご相談ください。

サポート総合窓口 <https://panasonic.jp/support/>

 エアコン 使い方・お手入れなどのご相談窓口  フリーダイヤル 0120-878-692 受付時間 9:00~18:00 月曜日~土曜日 (祝日・正月三が日を除く) ■上記電話番号がご利用いただけない場合 06-6907-1187 ■FAX フリーダイヤル 0120-878-236 Help desk for foreign residents in Japan Tokyo (03) 3256-5444 Osaka (06) 6645-8787 Open : 9:00 - 17:30 (closed on Saturdays / Sundays / national holidays)	 修理に関するご相談窓口  フリーダイヤル 0120-878-554 受付時間 9:00~18:00 月曜日~土曜日 (祝日・正月三が日を除く) ■上記電話番号がご利用いただけない場合 03-6633-6700 https://panasonic.jp/support/repair.html
アプリの初期設定に関するお問い合わせ  フリーダイヤル 0120-878-832 受付時間 9:00~18:00 月曜日~土曜日 (祝日・正月三が日を除く)	

- 掲載サイトおよび動画の視聴は無料ですが、通信料金はお客様のご負担となります。(パケット定額サービスに未加入の場合、高額になる可能性があります)
- ご使用の回線(IP電話やひかり電話など)によっては、回線の混雑時に数分で切れる場合があります。
- 上記のURLはお使いの携帯電話等により、正しく表示されない場合があります。

【ご相談窓口におけるお客様の個人情報のお取り扱いについて】

パナソニック株式会社およびグループ関係会社は、お客様の個人情報をご相談対応や修理対応などに利用させていただき、ご相談内容は録音させていただきます。また、折り返し電話をさせていただくときのために発信番号を通知していただけます。なお、個人情報を適切に管理し、修理業務等を委託する場合や正当な理由がある場合を除き、第三者に開示・提供いたしません。個人情報に関するお問い合わせは、ご相談いただきました窓口にご連絡ください。

パナソニックの会員サイト「CLUB Panasonic」で「商品登録」をお願いします

特典	<ul style="list-style-type: none">●お持ちの家電商品、消耗品情報が一元管理できる!●登録商品に関するお知らせやサポート情報が入手できる!●登録者限定のキャンペーンに参加できる!	詳しくは こちら	
<p>●保証書用封筒に記載されているQRコードを読み取っていただくと、品番登録と製造番号を入力する必要がなく、簡単に登録していただけます</p>  			

・QRコードは、株式会社デンソーウェーブの登録商標です。

愛情点検	長年ご使用のルームエアコンの点検を!		
	こんな症状はありませんか	<ul style="list-style-type: none">●ブレーカーがたびたび切れる。●運転中にこげ臭いにおいがする。●室内ユニットから水が漏れる。●電源コードやプラグが異常に熱くなり、変色している。●室内や室外ユニットの取り付け部分が腐食したり、取り付けがゆるんでいる。●異常な音や振動がする。●その他の異常や故障がある。	 ご使用中止 事故防止のため電源プラグを抜いて、必ず販売店へ点検をご依頼ください。
	<p>家庭用エアコンにはGWP(地球温暖化係数)が675のフロン類(R32)が封入されています。地球温暖化防止のため、移設・修理・廃棄等にあたってはフロン類の回収が必要です。</p>		
廃棄時にご注意願います!	家電リサイクル法では、お客様がご使用済みのルームエアコンを廃棄される場合は、収集・運搬料金、再商品化等料金をお支払いいただき、対象商品を販売店等に適正に引き渡すことが求められています。		

パナソニック株式会社 空調冷熱ソリューションズ事業部

〒525-8520 滋賀県草津市野路東2丁目3番1-1号

© Panasonic Corporation 2022

ACXF55-34290
CS1122TO-W