5-axis Camera Position Control System Functions

Setting parameters

Setting parameters			
Function	Command Character	Input Range	
Report status	R	N/A	
Set microstepping mode	m	2, 4, 8, 16	
Pan degrees	р	float	
Tilt degrees	t	float	
Slider millimeters	Х	float	
Focus degrees	f	float	
Zoom degrees	у	float	
Set pan speed (deg/s)	S	float	
Set tilt speed (deg/s)	S	float	
Set slider speed (mm/s)	Х	float	
Pan acceleration increment delay (μs)	q	0 – 32676	
Tilt acceleration increment delay (μs)	Q	0 – 32676	
Slider acceleration increment delay (µs)	W	0 – 32676	
Scale the speed of all keyframed movements	W	float	
Invert pan direction	i	bool	
Invert tilt direction		bool	
Invert slider direction	j	bool	
Invert focus direction	F	bool	
Invert zoom direction	Υ	bool	
Enable stepper motors	e	N/A	
Set pan degrees offset	0	float	
Set tilt degrees offset	0	float	
Set homing mode (0: no homing, 1: Slider, 2: Pan & Tilt, 3: All axes)	Н	0-3	
Auto home all axes	А	N/A	
Save settings to FlashStorage	U	N/A	
Filming Functions			
Function	Command Character	Input Range	
Add keyframe position	#	N/A	

Function	Command Character	Input Range
Add keyframe position	#	N/A
Execute moves	;	1-32767
Move forward in keyframe array	>	N/A
Move backward in keyframe array	<	N/A
Jump to start of array]	N/A
Jump to end of array]	N/A
Edit current keyframe with current position	E	N/A
Add delay in keyframes (in ms)	d	0 – 32676
Edit delay at current position	D	0 - 32676
Clear all keyframe positions	С	N/A
Orbit point between 2 keyframes	@	0 – 32676
Calculate intercept of the first 2 keyframes	Т	N/A