#### EC4.404: Mechatronics System Design

#### Harikumar Kandath

Robotic Research Center, IIIT Hyderabad

harikumar.k@iiit.ac.in

Lecture 2, Jan 08, 2025.

#### General Information

Mechatronics: Study of the integration of mechanical hardware, electrical/electronic hardware with computer hardware and software. Named by Tetsuro Mori from Japan when working with Yaskawa Electric Coorporation. Applications: Robotics, Aerospace industry, automotive industry, process industry etc.

**Course Objective:** To introduce the design and development of a mechatronic system.

**Instructors**: Harikumar Kandath and Nagamanikandan Govindan.

#### Structure of Measurement System

#### Measurement system: Contains four basic modules.

- Sensing element.
- Signal conditioning element.
- Signal processing element.
- Data presentation element.




Figure: Structure of measurement system

# Static Characteristics of Measurement System

- Range
- Span
- Non-linearity
- Sensitivity
- Environmental effects
- Hysteresis
- Resolution
- Error

# Dynamic Characteristics of a Measurement System

When the input I changes suddenly, the output O will take some time to respond to it. For example, when a thermocouple is exposed to a sudden change in temperature from  $25^{\circ}\text{C}$  (e.g. room temperature) to  $100^{\circ}\text{C}$  (e.g. boiling water), the output will change from 1 mV to 4 mV after a while.

- Time response: time constant, damping ratio, natural frequency
- Frequency response: bandwidth
- Dynamic error

## Time response of first and second order system

• First order system:

$$\frac{d\Delta O(t)}{dt} + k_1 \Delta O(t) = k_2 \Delta I(t) \tag{1}$$

Example: For thermocouple  $\Delta I(t) = 100 - 25 = 75^{\circ}C$  and

 $\Delta O(t) = 4 - 1 = 3 \, mV.$ 

Time constant  $(\tau)$ ,

$$\tau = \frac{1}{k_1} \tag{2}$$



#### Step Response of first order system




Figure: Unit step input and response

For input  $\Delta I(t)$ ,  $0 \implies 25^{\circ}C$  and  $1 \implies 100^{\circ}C$  and for output  $\Delta O(t)$ ,  $0 \implies 1$  mV and  $1 \implies 4$  mV.

$$f_o(t) = \Delta O(t) = \frac{k_2}{k_1} (1 - e^{-k_1 t}) = \frac{k_2}{k_1} (1 - e^{-\frac{t}{\tau}})$$
 (3)

#### Response to Sinusoidal Input

$$\Delta I(t) = A \sin \omega t \tag{4}$$

$$\Delta O(t) = \frac{k_2}{k_1} \left( \frac{A\omega\tau}{1 + \tau^2\omega^2} e^{\frac{-t}{\tau}} + \frac{A}{\sqrt{1 + \tau^2\omega^2}} sin(\omega t + \phi_d) \right)$$
 (5)

$$\phi_d = -tan^{-1}(\omega \tau) \tag{6}$$



#### Transfer Function Approach

Definition: Ratio of the Laplace transform of the output to the Laplace transform of the input with all the initial conditions set to zero.

$$\mathcal{L}(f(t)) = F(s) = \int_0^\infty f(t)e^{-st}dt \tag{7}$$

Transfer function G(s)

$$G(s) = \frac{\Delta O(s)}{\Delta I(s)} = \frac{k_2}{s + k_1} = \frac{k_2/k_1}{\tau s + 1}$$
 (8)

For  $\Delta I(s) = \frac{1}{s}$ ,

$$\Delta O(s) = \frac{k_2}{k_1} (\frac{1}{s} - \frac{1}{s + 1/\tau}) \tag{9}$$

$$\Delta O(t) = \mathcal{L}^{-1} \Delta O(s) = \frac{k_2}{k_1} (1 - e^{\frac{-t}{\tau}})$$
 (10)

### Table of Laplace Transform

Function	Symbol	Graph	Transform
Tunction	Symbol	Отари	Hansioini
1st derivative	$\frac{\mathrm{d}}{\mathrm{d}t}f(t)$		sf(s) - f(0-)
2nd derivative	$\frac{\mathrm{d}^2}{\mathrm{d}t^2}f(t)$		$s^2 f(s) - s f(0-) - f(0-)$
Unit impulse	$\delta(t)$	$ \begin{array}{c c} 1 \\ a \\ 0 \end{array} \qquad \lim_{a \to 0} a \to 0 $	1
Unit step	$\mu(t)$	1	$\frac{1}{s}$
Exponential decay	$\exp(-\alpha t)$	1 0	$\frac{1}{s+\alpha}$
Exponential growth	$1 - \exp(-\alpha t)$	1	$\frac{\alpha}{s(s+\alpha)}$
Sine wave	sin ωt	0 1	$\frac{\omega}{s^2 + \omega^2}$
Phase-shifted sine wave	$\sin(\omega t + \phi)$		$\frac{\omega\cos\phi + s\sin\phi}{s^2 + \omega^2}$
Exponentially damped sine wave	$\exp(-\alpha t)\sin \omega t$	1	$\frac{\omega}{(s+\alpha)^2+\omega^2}$
Ramp with exponential decay	$t \exp(-\alpha t)$	0	$\frac{1}{(s+\alpha)^2}$



#### Frequency Response

Definition: Response to a sinusoidal input at the steady state (i.e.  $t \to \infty$ ).


$$\Delta O(ss) = \frac{k_2}{k_1} \left( \frac{A}{\sqrt{1 + \tau^2 \omega^2}} sin(\omega t + \phi_d) \right)$$
 (11)

Amplitude,  $|\Delta O(ss)| = \frac{k_2}{k_1} (\frac{A}{\sqrt{1+\tau^2\omega^2}})$  (input amplitude scaled by  $\frac{k_2/k_1}{\sqrt{1+\tau^2\omega^2}}$ ), Phase lag  $\phi_d = -tan^{-1}(\omega\tau)$ . Using transfer function approach,

$$|\Delta O(ss)| = |G(s = j\omega)|A = \frac{k_2/k_1}{\sqrt{1 + \tau^2 \omega^2}}A$$
 (12)

$$\phi_d = \phi(G(s = j\omega)) = \phi(\frac{k_2/k_1}{i\omega\tau + 1}) = -\tan^{-1}(\omega\tau)$$
 (13)

### Frequency Response Plots



#### Inference from Frequency Response

When  $|\tau\omega|<<1$ ,

$$|\Delta O(ss)| = \frac{k_2}{k_1} A, \ \phi_d = 0$$
 (14)

When  $|\tau\omega| >> 1$ ,

$$|\Delta O(ss)| = \frac{k_2}{k_1} \frac{A}{\tau \omega}, \ \phi_d = -tan^{-1}(\omega \tau)$$
 (15)

When  $|\tau\omega|=1$ ,

$$|\Delta O(ss)| = \frac{k_2}{k_1} \frac{A}{\sqrt{2}}, \ \phi_d = -tan^{-1}(1) = -\frac{\pi}{4}$$
 (16)

Bandwidth :  $\omega = \frac{1}{\tau}$  (30% or 3 dB reduction in amplitude).



#### Time response of second order system

Second order system:

$$\frac{d^2\Delta O(t)}{dt^2} + k_0 \frac{d\Delta O(t)}{dt} + k_1 \Delta O(t) = k_2 \Delta I(t)$$
 (17)

$$G(s) = \frac{\Delta O(s)}{\Delta I(s)} = \frac{k_2}{s^2 + k_0 s + k_1} = k \frac{\omega_n^2}{s^2 + 2\zeta \omega_n s + \omega_n^2}$$
(18)

$$\omega_n = \sqrt{k_1}$$
,  $\zeta = \frac{k_0}{2\sqrt{k_1}}$ ,  $k = \frac{k_2}{k_1}$ .

 $\omega_n$ = natural frequency (rad/s),  $\zeta$  = damping ratio.


Example:  $\Delta I(t)$  is force and  $\Delta O(t)$  is deflection.



#### Step Response

$$f_o(t)=\Delta O(t)=\mathcal{L}^{-1}(\Delta O(s))=\mathcal{L}^{-1}(G(s)\Delta I(s)).$$
 For input  $\Delta I(s)=rac{1/k}{s}$ ,

$$\Delta O(s) = \frac{k_2}{s^2 + k_0 s + k_1} \frac{1/k}{s} = \frac{\omega_n^2}{s(s^2 + 2\zeta\omega_n s + \omega_n^2)}$$
(19)





15 / 21

## Critical parameters to look for in step response

- Peak overshoot:  $e^{\frac{-\pi\zeta}{\sqrt{1-\zeta^2}}}$ .
- Settling time (response settles within 1% of the steady state value):  $\frac{5}{\zeta \omega_n}$ .
- Damped frequency:  $\omega_d = \omega_n \sqrt{1 \zeta^2}$  (only for  $\zeta \leq 1$ ).

#### Frequency Response

$$\Delta I(t) = A \sin \omega t$$

$$|\Delta O(ss)| = |G(s=j\omega)|A = k \frac{\omega_n^2}{\sqrt{(\omega_n^2 - \omega^2)^2 + 4\zeta^2 \omega_n^2 \omega^2}} A \qquad (20)$$

$$\phi_{d} = \phi(G(s = j\omega)) = \phi(\frac{k\omega_{n}^{2}}{(\omega_{n}^{2} - \omega^{2}) + j(2\zeta\omega_{n}\omega)}) = -tan^{-1}(\frac{2\zeta\omega_{n}\omega}{\omega_{n}^{2} - \omega^{2}})$$
(21)

when  $\omega = \omega_n$ ,


$$|\Delta O(ss)| = \frac{kA}{2\zeta}, \ \phi_d = -\frac{\pi}{2}$$
 (22)

when  $\omega = \omega_n \sqrt{1 - 2\zeta^2}$  (resonant frequency),

$$|\Delta O(ss)| = \frac{kA}{2\zeta\sqrt{1-\zeta^2}}, \ \phi_d = -\frac{\sqrt{1-\zeta^2}}{\zeta}$$
 (23)

◆□▶◆□▶◆臺▶◆臺▶ 臺 釣۹ペ

#### Frequency Response Plots



#### Analysis of Cascaded Systems




Figure: A Cascaded System

$$\frac{\Delta T_M(s)}{\Delta T_T(s)} = \frac{\Delta T_M(s)}{\Delta V(s)} \frac{\Delta V(s)}{\Delta E(s)} \frac{\Delta E(s)}{\Delta T_T(s)}$$
(24)

NB: Multiply the frequency response of individual systems to get the frequency response of the cascaded system.

$$\Delta T_M(t) = \mathcal{L}^{-1}(\Delta T_M(s)) = \mathcal{L}^{-1}(\left[\frac{\Delta T_M(s)}{\Delta V(s)}\frac{\Delta V(s)}{\Delta E(s)}\frac{\Delta E(s)}{\Delta T_T(s)}\right]\Delta T_T(s))$$

#### Response modification using compensators




Figure: Cascading with a Compensator

### THANK YOU