

The diagram shows the pin configuration for the ESP32-WROOM-32 module. The module is connected to a J2 header on the left and a J3 header on the right. The module's pins are numbered 1 through 38. The connections are as follows:

- Pin 1:** VDD
- Pin 2:** EN
- Pin 3:** SVP
- Pin 4:** SVN
- Pin 5:** I034
- Pin 6:** I035
- Pin 7:** I032
- Pin 8:** I033
- Pin 9:** I025
- Pin 10:** I026
- Pin 11:** I027
- Pin 12:** I014
- Pin 13:** I012
- Pin 14:** I013
- Pin 15:** GND
- Pin 16:** +5V
- Pin 17:** SHD/S02
- Pin 18:** SWP/S03
- Pin 19:** SC5/CMD
- Pin 20:** SCK/CLK
- Pin 21:** SDO/S00
- Pin 22:** SDI/S01
- Pin 23:** NC
- Pin 24:** GND
- Pin 25:** I015
- Pin 26:** I02
- Pin 27:** I016
- Pin 28:** I017
- Pin 29:** I018
- Pin 30:** I019
- Pin 31:** I020
- Pin 32:** I021
- Pin 33:** I022
- Pin 34:** TXD0/I01
- Pin 35:** RXD0/I03
- Pin 36:** TXD0/I04
- Pin 37:** RXD0/I05
- Pin 38:** TXD0/I06

The module is connected to a +3V3 supply through a 10uF capacitor (C4) and a 100nF capacitor (C3). The +5V supply is connected to pin 16. The GND is connected to pin 15. The module is labeled 'U1 ESP32-WROOM-32'.