OPERATION MANUAL

Revision 2

TORQUE SPEC 45 Nm

BOLT M6

SERVICE PROCEDURE

Step 1: remove bracket