



Radiance Hex Lights

Model 1.1 - Set of 7

1. Introduction

Thanks for purchasing Radiance Hex Lights Model 1. Kit of 7.

With your purchase you encourage further development of more awesome lightning models. We hope you enjoy using this product as much as we've enjoyed developing it. This set includes a standard LED strip controller that you can connect via Bluetooth. This manual outlines how to install and connect 7 hex lights, if you plan to add more lights or are adding to existing lights pay special attention to the "Safety Precautions" to avoid damaging yourself or the product. To operate the LED controller follow instructions on the attached sheet in the package.

2. Safety Precautions

When using Radiance Hex Lights consider the following warning, guidelines, and precautions:

- Please note that this is a decorative product, it is not designed for load or other mechanical purposes.
- This product is designed to operate with 5 volts any other voltage might damage the product.
- The provided power supply is rated for a max of 13 hexagons, do not add more hexagons without replacing the power supply. See our home page for recommendations.
- Do not disassemble the product. Operate in regular indoor temperatures, out of moisture. For better durability do not expose directly to sunlight for prolonged times.
- If needed, insert push pins with caution as they have sharp tips.

3. Tools and Materials Needed

Package comes with optional push pins for installations on drywalls or other soft surfaces; or velcro dots. If using push pins a flat instrument might be needed to apply extra pressure depending on the hardness of the material where it will be inserted.

To remove the backplate from the hexagon a wrapping wire was provided, a priming tool might also be handy such as a flat head screwdriver.


When installing a leveling or alignment tool is recommended to ensure the best results.

4. Package Contents

- | | |
|--------------------------|-----------------------|
| - Hexagons x7 | - Angled Connector x1 |
| - Hexagon Connectors x15 | - Connector Cable x7 |


- Long Connector x1
- Hex alignment tool x1
- Power Supply x1
- Controller x1
- Controller Box x1
- Controller Remote x1
- Controller Manual x1
- Push Pins x14
- Velcro Dots x35
- Stickers
- Thank You Card
- Beta Testers Card

5. Get to Know Your Hex




Hexagons are shipped with their backplate attached, take the backplate off by pulling the wrapping wire from both ends, optionally use a prying tool such as a flat head screwdriver or similar. Upon detaching the backplate you will find several connectors:

- LED output. The only cable connected, this sends the signal to LEDs on the hexagon. Uses 6-pin connection to achieve this
- Input connector. Receives power and signal for the hexagon, this is delivered via a 3-pin cable attached to a hexagon-connector supplied on the package. The connector cable has a handle with our logo, this handle has to be upwards.
- Output connector. Delivers power and signal to the next hexagon, this is delivered via a 3-pin cable attached to a hexagon-connector supplied on the package. The connector cable has a handle with our logo, this handle has to be upwards.
- Power Injection Port. When scaling the number of hexagons, power injection is used to provide extra power which is lost due to the distance between a hexagon and the power supply, mostly unused port except for large hexagon counts.




Backplate



Cable Handles (6-pin, 3-pin, 2-pin)


Backplate's features include triangles surrounding the connection box at the center. Those are used to place push pins to fix the backplate to the wall or to an appropriate soft surface (when not using the velcro dots). An arrow engraved on the backplate points at the orientation for the upper part to be inserted; the upper part can only be inserted as aligned on the engraved arrow. See image below for details of the upper portion.



Upper Assembly


Additionally there are posts in the inner area to help secure the cables when connecting and inserting. Make sure no cables are beyond this area otherwise it will be impossible to attach the upper part or the cables can be damaged.

Hexagons are connected with the help of interconnects. Those interconnects have a cable and can be opened if necessary by priming open the lid.




Hex Interconnectors

The LED controller is attached to its controller box and provides electrical transformation for connecting to the first hexagon. This box contains outputs to attach a hexagon interconnector in order to hide the cables, included with the package and if needed, there is an angled interconnector used to ease the connection into the first hexagon.



Controller Box



Angled Connector


6. Selecting a Layout



Sky's the limit here, use your creativity just remember that some layouts might complicate the wiring by not allowing a hex to connect to a neighbor. A long cable is provided to solve eventual connection gaps but should be used only when needed.

Consider the overall orientation of the hex layout, typically the original orientation sets the design for the rest of the hexagons, so it is important to plan ahead the desired layout.





The following samples provide feasible layouts using a 7-hex setup, it is important to consider the wiring for each setup as it has to be planned ahead see next section for details. Each setup outlines a suggested placement for the control box to allow for a linear wiring setup:

Simple Wiring Setup





Setup for Advanced Wiring (Requires long cable and/or reassembling connectors)




7. Overall Connection Guidelines

When planning to install hexagons consider the following:

- Hexagons are connected in series, one hexagon's output is the next hexagon's input.
- It is recommended that a surrounding hexagon is connected from its neighbor as the cable distance is limited.
- Tuck additional cable on the railing outlined in the inner part of the backplate to ensure proper assembly.


For the chosen layout visualize the electrical connection layout as well. Consider the following example, the red lines outline the electrical connection between different hexagons:



Hexagon Sample Wiring Diagram

8. Installation

Before installation, the area must be flat, clean and dry. Start by attaching the controller box using the provided velcro dots. Start placing the controller box and begin with the nearest hexagon. Use the alignment tool and any leveling tool as needed. Do not connect power until all the connections have been made.




Provided Alignment Tool

After placing the controller box, use a hexagon interconnector (or the angled interconnector) to connect to the first hexagon.

- Place the backplate next to the end of the hexagon interconnector coming from the previous hexagon or controller box. Fix the backplate using provided push pins x2 per hexagon to be inserted in the triangles of the backplate or the velcro dots on the surface facing the wall. Use the alignment tool or any leveling as desired.
- Connect to the *In* terminal (logo facing the top)
- If the 6-pin top cable is not connected to the backplate, connect it (logo facing the top)
- Use a 3-pin connector cable to connect to the *out* terminal (logo facing the top)
- Use the outlined railing to tuck the extra cable. Make sure all wires are in the interior part of the backplate, otherwise the top will not be able to assemble correctly to the backplate and the wires could be damaged.
- Insert the top. Ensure the top's salient aligns with the engraved arrow as that is the only position it can be placed in.
- Add any empty interconnector to fill the gap between two adjacent hexagon slots if you desire to make it look symmetric.

- Repeat all steps for the remaining hexagons.



Use of the alignment tool to place a backplate relative to others for proper spacing


9. Usage

Upon plugin the set you should see some lightning activity on the hexagons. Controlling the lightning effects is done through the remote provided or the app **BanlanX** (instructions are provided on the additional instruction sheet that comes with the remote). For further details refer to this app, however the basic effects are:

- Solid color
- A preconfigured effect
 - Can be set on a rotation of effects each with an amount of time or fixed
 - Speed of the effect can be set
- Noise based animation

Your controller can also be renamed for easier identification. This app allows you to control several devices.





BanlanX application is available on [Google Play Store](#) and the [Apple Store](#)

10. Maintenance and Care

- Clean only dust with a dry cloth.
- Keep the product away from the sun and in a dry environment.

11. FAQ and Advanced Usage

Using extended connection cable

This cable was provided for configurations where the next hexagon is not immediately positioned within a source hexagon. A hexagon interconnect (the plastic piece that houses the cable) might need to be opened in order to add the long connector cable and this needs to be done for any connectors needed where the cable has to cross. Use a prying tool such as a flat head screwdriver to pry open the lid on the connector. After placing the cable the lid can be reattached by pushing it against the base.

Can I detach a hexagon from its base once installed?

Yes, unplug your setup then pull the top carefully. If the backplate was installed using push pins, these might come partially with the base if the top fits too tight, make sure to re-attach the push pins once the top has been removed.

Can I reconfigure my setup?

Yes, unplug your setup, then remove the top of the hexagons carefully and remove input and output connectors to remove them from the circuit, then remove the push pins or pull the backplate to detach the velcro dots. Once all hexagons have been removed repeat the steps on the installation.

Can I order additional components?

You can order individual hexagons or sets of hexagons without the controller to make a bigger set. The provided power supply is rated for 15 hexagons. Other power supplies can be used as long as they provide 5 volts and enough power, additionally voltage injection might be needed in order to provide color accuracy for hexagons further away from the power source (this happens due to voltage drop as the distance increases).

Backplate has a special port to allow for additional power injection. Contact us for details on the power injection cable or for additional details on power supply with more capacity.

Hexagon connectors and most other pieces can also be ordered, contact us for more details.

If a cable was damaged during installation (by being clamped between the backplate and the top), you can order additional cables, contact us for details.

Not all hexagons turn on, how can I troubleshoot?

Most likely this is caused because a cable was damaged during installation, and got clamped between the backplate and the top, contact us to order additional cables.

Another likely cause is that connection was not made properly, if possible try swapping cables with another hexagon. Make sure the cables are connected with their handles facing you. Remember one port says input and another one says output, make sure the corresponding connections match.

12. Warranty

- 1 year warranty on production issues.
- Reach out to support on our website for instructions on warranty.

13. Contact Us

Radiance Home Page



Our Socials



Merchandise

