

TrailPeak Outdoor Co. — Product Care & Maintenance Guide

Proper care extends the life of TrailPeak gear and helps keep it within warranty-eligible condition. This guide covers flagship products.

Tents (Summit Pro 3-Season, BaseCamp 4-Person)

Always dry tents fully before storage to prevent mildew, which voids the seam-seal warranty. Store loosely rather than tightly rolled to preserve waterproof coating.

Footwear (AllTerrain Hiking Boots, RidgeRunner Trail Shoes, IronPeak Steel Toe Boots)

Clean mud and debris after each use and air dry away from direct heat. Direct heat exposure (e.g. campfires, heaters) is the leading cause of sole separation and is not covered by warranty.

Backpacks (TrailBlazer 65L, MicroPack 20L, CascadeDry Hydration Pack)

Hand wash with mild soap; avoid machine washing, which can damage frame stays. The TrailBlazer 65L's Lifetime Stitching Guarantee remains valid regardless of washing method.

Rain & Softshell Jackets (StormShield, AlpineFlex)

Re-treat with DWR (durable water repellent) spray every 20-30 wears to maintain waterproofing performance.