
<u>Instructions</u>


How to order the parts

Go to the website **Bricklink.com**




Go to "want" and then to "upload"







Use "Drag and Drop" or "Browse for file" to upload the .io-file




Scroll down and click on "Add to Wanted List"





Go to "View Default Wanted List"






Now you can set the condition of the parts. To do this, select all the parts and click on "Condition" to select the condition.





Before you select the stores, you can set some filters, such as the store location or the currency the store accepts.

To automatically select the stores that sell the parts at the lowest price, click on "Auto select".



Click on "Create carts" to complete the parts ordering process.

