

AIRGAPPED WALLET

MANUAL



CONTENTS

HIGHLIGHTS.....	3
HARDWARE FEATURES.....	3
SOFTWARE FEATURES.....	3
ARCHITECTURE.....	4
PIN ENTRY.....	5
MAIN SCREEN.....	5
TRANSACTION (SEND).....	5
INPUTS.....	6
TRANSACTION (RECEIVE).....	7
SETTINGS.....	8
SECURITY.....	8
RESET PIN.....	9
DISABLE PIN.....	9
NETWORK.....	10
ADD NETWORK.....	11
EDIT NETWORK.....	12
DELETE NETWORK.....	13
WALLET.....	14
WALLET ACTIVATE.....	14
RENAME WALLET.....	16
RESTORE WALLET.....	16
DELETE WALLET.....	18
KEYBOARD STYLE.....	18

HIGHLIGHTS


HARDWARE FEATURES

- 1) The hardware wallet boots up upon button press and runs automatically.
- 2) The wallet system turns off after 3 seconds of button press and powers off.

SOFTWARE FEATURES

- 1) Pin to set/reset option, enter with pin
- 2) Create wallet with proper seed phrase generation and verification
- 3) Rename wallet, Delete Wallet
- 4) Create multiple wallets, switch wallets from settings
- 5) Set new Network (provide name,symbol,type,chain id in consecutive screens)
- 6) Delete Network
- 7) Qr scan/generation for transaction
- 8) Transaction (Send,Receive)
- 9) Signed Tx generation
- 10) Manual input option other than Qr scan
- 11) User Interface theme changing (eg. Dark, Light)
- 12) User Interface layout changing (eg. Grid, Compact, List)
- 13) Invalid Input handling

ARCHITECTURE




PIN ENTRY



The PIN Entry screen is titled "Enter PIN". It features a text input field at the top containing four asterisks (****). Below the input field are two buttons: "X" and "OK". Below these buttons is a numeric keypad with buttons for digits 1 through 9, a decimal point (.), and a zero (0). A "BK" button is located at the bottom right of the keypad.

The device boots up and airgapped software starts running automatically. The first screen that comes is the pin entry screen. Press "X" to erase the screen all at once. To erase single characters one by one, press "BK". Press "OK" to enter the pin.

MAIN SCREEN




The Main Screen is titled "Wallet". It displays four large, rounded rectangular buttons stacked vertically: "Send", "Receive", "Settings", and "Exit". At the bottom of the screen, there are three smaller, rounded rectangular buttons: "Back", "Home", and "Opts".


After pin entry comes this screen. There are some navigation buttons. "Send" and "Receive" are transaction buttons. "Opts" and "Settings" buttons navigate to other important features. "Exit" closes the system.

TRANSACTION (SEND)

Upon pressing “Send”, “Network selection” screen is shown. Selection the network will take to a new screen where different options are shown to get the receiver’s data.




A vertical list of six buttons: "ETH · Ethereum (evm)", "BTC · Bitcoin (utxo)", "Q · q (evm)", "XDC · Xinfin (evm)", "XRP · XRP Ledger (xrp)", and "Back". At the bottom, there are three buttons: "Back", "Home", and "Opts".




The screen is titled "EVM receiver". It contains four buttons: "Scan QR (camera)", "Manual Input", "Use Default", and "Back". At the bottom, there are three buttons: "Back", "Home", and "Opts".

INPUTS

After selecting any one of the input methods, providing the address, amount and nonce need to be provided.



The screen is titled "Amount (ETH)". It features a large input field at the top. Below it are two buttons: "X" and "OK". At the bottom, there is a numeric keypad with buttons for digits 1-9, a decimal point ".", a zero "0", and a "BK" (backspace) button.



The screen is titled "Nonce". It features a large input field at the top. Below it are two buttons: "X" and "OK". At the bottom, there is a numeric keypad with buttons for digits 1-9, a decimal point ".", a zero "0", and a "BK" (backspace) button.

After providing them , the signed tx will be generated and it will be showed in screen as QR code.

Signed TX (QR)

Page 1/1



Prev

Next

Close


TRANSACTION (RECEIVE)

Upon pressing “Receive” from the wallet screen, the network selection screen will be shown. Upon selecting the network, the address will be shown on that respective network. Upon pressing “Show QR” Button, a QR code will be shown that represents the address.




SETTINGS

Pressing “Settings” will show a bunch of features related to Wallet , Network. Moreover it provides the option to change system button layout as well as theme of the system.



SECURITY

Pin can be made reset, or even disabled. This option lies in the settings screen.



RESET PIN

Takes seed word to verify the owner of the wallet is changing the password or not.

Seed word #4

q	w	e	r	t	y
u	i	o	p	a	s
d	f	g	h	j	k
l	z	x	c	v	b
n	m	.	,	Aa	BK
123	Space	CL	<	>	

See System Architecture for better understanding.


DISABLE PIN

First the current pin has to be provided to verify that the owner is operating the device.

Current PIN

1	2	3
4	5	6
7	8	9
CL	0	BK

From the next pin, in pin and security screen, the user will be asked for setting up a Pin.




PIN & Security

Set PIN

Back

Back Home Opts

This screen is titled "PIN & Security". It features a "Set PIN" button at the top, followed by a "Back" button. At the bottom, there are three buttons: "Back", "Home", and "Opts".



New PIN (4-10 digits)

X OK

1 2 3

4 5 6

7 8 9


CL 0 BK

This screen is titled "New PIN (4-10 digits)". It has a large input field for the PIN, followed by "X" and "OK" buttons. Below this is a numeric keypad with buttons for digits 1-9, 0, and function keys "CL" (clear) and "BK" (backspace).

See System Architecture for better understanding.

NETWORK

In the network screen under settings screen, existing networks are shown. Moreover, there is option to add a network as well as remove or edit existing networks.



Networks

ETH · Ethereum (evm)

BTC · Bitcoin (utxo)

Q · q (evm)

XDC · Xinfin (evm)

XRP · XRP Ledger (xrp)

IED · dd (evm)

Add Network

Edit Network

Delete Network

This screen is titled "Networks". It displays a list of existing networks, each in a button-like format: "ETH · Ethereum (evm)", "BTC · Bitcoin (utxo)", "Q · q (evm)", "XDC · Xinfin (evm)", "XRP · XRP Ledger (xrp)", and "IED · dd (evm)". Below the list are three buttons: "Add Network", "Edit Network", and "Delete Network".

ADD NETWORK

Provide key, name, type ,symbol and chain id of the network in the corresponding screens to make a network.

Key (A-Z0-9)

q	w	e	r	t	y
u	i	o	p	a	s
d	f	g	h	j	k
l	z	x	c	v	b
n	m	.	,	Aa	BK
123	Space	CL	<	>	

Name

q	w	e	r	t	y
u	i	o	p	a	s
d	f	g	h	j	k
l	z	x	c	v	b
n	m	.	,	Aa	BK
123	Space	CL	<	>	

Type (evm/utxo/xrp)

q	w	e	r	t	y
u	i	o	p	a	s
d	f	g	h	j	k
l	z	x	c	v	b
n	m	.	,	Aa	BK
123	Space	CL	<	>	

Symbol

q	w	e	r	t	y
u	i	o	p	a	s
d	f	g	h	j	k
l	z	x	c	v	b
n	m	.	,	Aa	BK
123	Space	CL	<	>	

chain_id

1	2	3
4	5	6
7	8	9
.	0	BK

EDIT NETWORK

The user will be asked about which network to be edited. The user can change the type, name, symbol, chain id etc of the network in the corresponding screens.

Edit which key?

ETH

BTC

XRP

XDC

WWW

Back

Back Home Opts

Type (evm/utxo/xrp)

q w e r t y

u i o p a s

d f g h j k

l z x c v b

n m . , Aa BK

123 Space CL < >

Name

q w e r t y

u i o p a s

d f g h j k

l z x c v b

n m . , Aa BK

123 Space CL < >

Symbol

q w e r t y

u i o p a s

d f g h j k

l z x c v b

n m . , Aa BK

123 Space CL < >

chain_id

1

X OK

1 2 3

4 5 6

7 8 9

. 0 BK

See System Architecture for better understanding.

DELETE NETWORK

Just select the network and it will be deleted.

Delete which key?

ETH

BTC

XRP

XDC

WWW

Back

Back

Home

Opts

See System Architecture for better understanding.

WALLET

In the wallet screen under settings screen, existing wallets are shown. Moreover, there is an option to add wallets as well as remove or edit existing wallets.

WALLET ACTIVATE

Press over a wallet name and it will be automatically activated.

Wallets
[Active] creative
ee
shakil
Add Wallet
Rename Wallet
Delete Wallet
Back

BackHomeOpts

Wallets
creative
ee
[Active] shakil
Add Wallet
Rename Wallet
Delete Wallet
Back

BackHomeOpts

WALLET CREATE

Wallets
creative
ee
[Active] shakil
Add Wallet
Rename Wallet
Delete Wallet
Back

BackHomeOpts

Add Wallet
Create
Restore
Back

BackHomeOpts

Words count
12 words
24 words
Back

BackHomeOpts

After selecting seed phrase length, you will be provided with a unique words combination that you will have to remember. For Example:


Write down	Write down
Page 1/2	Page 2/2
1. credit	7. hamster
2. between	8. never
3. predict	9. bonus
4. symptom	10. identify
5. orbit	11. zone
6. include	12. nest
PrevNext	PrevNext

Then you need to verify the words that you memorized or took snapshots of. After 3 to 4 verification, the wallet will be created.

Enter word #2					
q	w	e	r	t	y
u	i	o	p	a	s
d	f	g	h	j	k
l	z	x	c	v	b
n	m	.	,	Aa	BK
123	Space	CL	<	>	

RENAME WALLET

The user can rename any wallet. Pressing over the wallet name will take to another screen for renaming.



Rename which?

creative

ee

shakil

Back

Back Home Opts



New name for qqq

q w e r t y

u i o p a s

d f g h j k

l z x c v b


n m . , Aa BK

123 Space CL < >

See System Architecture for better understanding.

RESTORE WALLET

The user will be asked for wallet name that will be restored from the system.
The user will also be asked the seed phrase to verify the restoration process.



Wallet name

q w e r t y

u i o p a s

d f g h j k

l z x c v b

n m . , Aa BK

123 Space CL < >



Enter seed (12/24 words)

q w e r t y

u i o p a s

d f g h j k

l z x c v b


n m . , Aa BK

123 Space CL < >

See System Architecture for better understanding.

DELETE WALLET

User can delete any wallet from “Delete Wallet” screen. Pressing over the wallet name will remove that from the system. The system will want the pin as a way to verify the owner is using the device.



Delete which?


creative

ff

shakil

Back

Back Home Opts



Enter PIN to delete

X OK

1 2 3

4 5 6

7 8 9

. 0 BK

See System Architecture for better understanding.

KEYBOARD STYLE



Key (A-Z0-9)

qwe

q w e r t y

u i o p a s

d f g h j k

l z x c v b

n m . , Aa BK

123 Space CL < >

Fig: Semi Qwerty Keyboard



Key (A-Z0-9)

qwe99

1 2 3 4 5 6

7 8 9 0 - _

@ # \$ % & *

. , ? ! ' ;

/ () : Aa BK

ABC Space CL < >

Fig: Numeric Keyboard

