WIKIPEDIA

Printed circuit board

 $\label{eq:connects} \ \ \text{e} \ \underline{\text{e}} \ \underline{\text{e}} \ \underline{\text{components}} \ \underline{\text{or}} \ \underline{\text{e}} \ \underline{\text{e}} \ \underline{\text{components}} \ \underline{\text{or}} \ \underline{\text{e}} \ \underline{\text{e}} \ \underline{\text{components}} \ \underline{\text{e}} \ \underline{\text{$ conductive tracks, pads and other features etched from one or more sheet layers of copper laminated onto and/or between sheet layers of a non-conductive substrate. Components are generally soldered onto the PCB to both electrically connect and mechanically fasten them

Printed circuit boards are used in all but the simplest electronic products. They are also used in some electrical products, such as passive

 $Alternatives \ to \ PCBs \ include \ \underline{wire \ wrap} \ and \ \underline{point-to-point \ construction}, both \ once \ popular \ but \ now \ rarely \ used. \ PCBs \ require \ additional$ design effort to lay out the circuit, but manufacturing and assembly can be automated. Specialized CAD software is available to do much of the work of layout. Mass-producing circuits with PCBs is cheaper and faster than with other wiring methods, as components are mounted and wired in one operation. Large numbers of PCBs can be fabricated at the same time, and the layout only has to be done once. PCBs can also be made manually in small quantities, with reduced benefits.



Part of a 1983 Sinclair ZX Spectrum computer board, a PCB, showing the conductive traces, vias (the through-hole paths to the other surface), and some electronic components mounted using through-hole mounting.

PCBs can be single-sided (one copper layer), double-sided (two copper layers on both sides of one substrate layer), or multi-layer (outer and inner layers of copper, alternating with layers of substrate). Multi-layer PCBs allow for much higher component density, because circuit traces on the inner layers would otherwise take up surface space between components. The rise in popularity of multilayer PCBs with more than two, and especially with more than four, copper planes was concurrent with the adoption of surface mount technology. However, multilayer PCBs make repair, analysis, and field modification of circuits much more difficult and usually

The world market for bare PCBs exceeded \$60.2 billion in 2014. [1]

Contents

History

Overview

PCB characteristics

Through-hole technology Surface-mount technology Circuit properties of the PCB Materials

Key substrate parameters Common substrates Copper thickness

Safety certification (US)

Design

Manufacturing PCB CAM

Panelization Copper patterning

Large volume Small volume Hobbvist

Subtractive, additive and semi-additive processes

Chemical etching Lamination

Drillina

Plating and coating

Solder resist application

Leaend printing

Bare-board test

Assembly

Protection and packaging

Cordwood construction

Multiwire boards

See also

References

External links

History

Before the development of printed circuit boards electrical and electronic circuits were <u>wired point-to-point</u> on a chassis. Typically, the chassis was a sheet metal frame or pan, sometimes with a wooden bottom. Components were attached to the chassis, usually by insulators when the connecting point on the chassis was metal, and then their leads were connected directly or with jumper wires by soldering, or sometimes using crimp connectors, wire connector lugs on screw terminals, or other methods. Circuits were large, bulky, heavy, and relatively fragile (even discounting the breakable glass envelopes of the vacuum tubes that were often included in the circuits), and production was labor-intensive, so the products were expensive.

Development of the methods used in modern printed circuit boards started early in the 20th century. In 1903, a German inventor, Albert Hanson, described flat foil conductors laminated to an insulating board, in multiple layers. Thomas Edison experimented with chemical methods of plating conductors onto linen paper in 1904. Arthur Berry in 1913 patented a print-and-etch method in the UK, and in the United States Max Schoop obtained a patent^[2] to flame-spray metal onto a board through a patterned mask. Charles Ducas in 1927 patented a method of electroplating circuit patterns. [3]

The Austrian engineer Paul Eisler invented the printed circuit as part of a radio set while working in the UK around 1936. In 1941 a multi-layer printed circuit was used in German magnetic influence naval mines. Around 1943 the USA began to use the technology on a large scale to make proximity fuses for use in World War II. [3] After the war, in 1948, the USA released the invention for commercial use. Printed circuits did not become commonplace in consumer electronics until the mid-1950s, after the Auto-Sembly process was developed by the United States Army. At around the same time in the UK work along similar lines was carried out by Geoffrey Dummer, then at the RRDE.

Even as circuit boards became available, the point-to-point chassis construction method remained in common use in industry (such as TV and hi-fi sets) into at least the late 1960s. Printed circuit boards were introduced to reduce the size, weight, and cost of parts of the circuitry. In 1960, a small consumer radio receiver might be built with all its circuitry on one circuit board, but a TV set would probably contain one or more circuit boards.

Predating the printed circuit invention, and similar in spirit, was <u>John Sargrove</u>'s 1936–1947 Electronic Circuit Making Equipment (ECME) which sprayed metal onto a <u>Bakelite</u> plastic board. The ECME could produce three radio boards per minute.

During World War II, the development of the anti-aircraft proximity fuse required an electronic circuit that could withstand being fired from a gun, and could be produced in quantity. The Centralab Division of Globe Union submitted a proposal which met the requirements: a ceramic plate would be <u>screenprinted</u> with metallic paint for conductors and carbon material for <u>resistors</u>, with ceramic disc capacitors and subminiature vacuum tubes soldered in place. [4] The technique proved viable, and the resulting patent on the process, which was classified by the U.S. Army, was assigned to Globe Union. It was not until 1984 that the Institute of Electrical and Electronics Engineers (IEEE) awarded Mr. Harry W. Rubinstein the <u>Cledo Brunetti Award</u> for early key contributions to the development of printed components and conductors on a common insulating substrate. Mr. Rubinstein was honored in 1984 by his alma mater, the University of Wisconsin-Madison, for his innovations in the technology of printed electronic circuits and the fabrication of capacitors. [5] This invention also represents a step in the development of <u>integrated circuit</u> technology, as not only wiring but also passive components were fabricated on the ceramic substrate.

Originally, every electronic component had wire leads, and a PCB had holes drilled for each wire of each component. The component leads were then inserted through the holes and soldered to the copper PCB traces. This method of assembly is called through-hole construction. In 1949, Moe Abramson and Stanislaus F. Danko of the United States Army Signal Corps developed the Auto-Sembly process in which component leads were inserted into a copper foil interconnection pattern and dip soldered. The patent they obtained in 1956 was assigned to the U.S. Army. [6] With the development of board lamination and etching techniques, this concept evolved into the standard printed circuit board fabrication process in use today. Soldering could be done automatically by passing the board over a ripple, or wave, of molten solder in a wave-soldering machine. However, the wires and holes are inefficient since drilling holes is expensive and consumes drill bits and the protruding wires are cut off and discarded.

From the 1980s onward, small surface mount parts have been used increasingly instead of through-hole components; this has led to smaller boards for a given functionality and lower production costs, but with some additional difficulty in servicing faulty boards.

Manufacturers may not support component-level repair of printed circuit boards because of the relatively low cost to replace compared with the time and cost of troubleshooting to a component level. In board-level repair, the technician identifies the board (PCA) on which the fault resides and replaces it. This shift is economically efficient from a manufacturer's point of view but is also materially wasteful, as a circuit board with hundreds of good components may be discarded and replaced due to the failure of one minor and inexpensive part such as a resistor or capacitor. This practice is a significant contributor to the problem of <u>e-waste</u>.



An example of hand-drawn etched traces on a PCB



A PCB as a design on a computer (left) and realized as a board assembly populated with components (right). The board is double sided, with through-hole plating, green solder resist and a white legend. Both surface mount and through-hole components have been used.

Overview

A basic PCB consists of a flat sheet of insulating material and a layer of copper foil, laminated to the substrate. Chemical etching divides the copper into separate conducting lines called tracks or *circuit traces*, pads for connections, vias to pass connections between layers of copper, and features such as solid conductive areas for EM shielding or other purposes. The tracks function as wires fixed in place, and are insulated from each other by air and the board substrate material. The surface of a PCB may have a coating that protects the copper from corrosion and reduces the chances of solder shorts between traces or undesired electrical contact with stray bare wires. For its function in helping to prevent solder shorts, the coating is called solder resist.

A printed circuit board can have multiple copper layers. A two-layer board has copper on both sides; multi layer boards sandwich additional copper layers between layers of insulating material. Conductors on different layers are connected with vias, which are copper-plated holes that function as electrical tunnels through the insulating substrate. Through-hole component leads sometimes also effectively function as vias. After two-layer PCBs, the next step up is usually four-layer. Often two layers are dedicated as power supply and ground planes, and the other two are used for signal wiring between components.

"Through hole" components are mounted by their wire leads passing through the board and soldered to traces on the other side. "Surface mount" components are attached by their leads to copper traces on the same side of the board. A board may use both methods for mounting components. PCBs with only through-hole mounted components are now uncommon. Surface mounting is used for transistors, diodes, IC chips, resistors and capacitors. Through-hole mounting may be used for some large components such as electrolytic capacitors and connectors.

The pattern to be etched into each copper layer of a PCB is called the "artwork". The etching is usually done using <u>photoresist</u> which is coated onto the PCB, then exposed to light projected in the pattern of the artwork. The resist material protects the copper from dissolution into the etching solution. The etched board is then cleaned. A PCB design can be mass-reproduced in a way similar to the way photographs can be mass-duplicated from film negatives using a photographic printer.

In multi-layer boards, the layers of material are laminated together in an alternating sandwich: copper, substrate, copper, substrate, copper, etc.; each plane of copper is etched, and any internal vias (that will not extend to both outer surfaces of the finished multilayer board) are plated-through, before the layers are laminated together. Only the outer layers need be coated; the inner copper layers are protected by the adjacent substrate layers.

FR-4 glass epoxy is the most common insulating substrate. Another substrate material is cotton paper impregnated with phenolic resin, often tan or brown.

When a PCB has no components installed, it is less ambiguously called a *printed wiring board* (*PWB*) or *etched wiring board*. However, the term "printed wiring board" has fallen into disuse. A PCB populated with electronic components is called a *printed circuit assembly* (*PCA*), *printed circuit board assembly* or *PCB assembly* (*PCBA*). In informal usage, the term "printed circuit board" most commonly means "printed circuit assembly" (with components). The <u>IPC</u> preferred term for assembled boards is *circuit card assembly* (*CCA*), and for assembled backplanes it is *backplane assemblies*. "Card" is another widely used informal term for a "printed circuit assembly".

A PCB may be "silkscreen" printed with a legend identifying the components, test points, or identifying text. Originally, an actual silkscreen printing process was used for this purpose, but today other, finer quality printing methods are usually used instead. Normally the screen printing is not significant to the function of the PCBA.

A minimal PCB for a single component, used for prototyping, is called a breakout board. The purpose of a breakout board is to "break out" the leads of a component on separate terminals so that manual connections to them can be made easily. Breakout boards are especially used for surface-mount components or any components with fine lead pitch.


Advanced PCBs may contain components embedded in the substrate.

PCB characteristics

Through-hole technology

The first PCBs used through-hole technology, mounting electronic components by <u>leads</u> inserted through holes on one side of the board and soldered onto copper traces on the other side. Boards may be single-sided, with an unplated component side, or more compact double-sided boards, with components soldered on both sides. Horizontal installation of through-hole parts with two axial leads (such as resistors, capacitors, and diodes) is done by bending the leads 90 degrees in the same direction, inserting the part in the board (often bending leads located on the back of the board in opposite directions to improve the part's mechanical strength), soldering the leads, and trimming off the ends. Leads may be soldered either manually or by a wave soldering machine.^[9]

Through-hole manufacture adds to board cost by requiring many holes to be drilled accurately, and it limits the available routing area for signal traces on layers immediately below the top layer on multi-layer boards, since the holes must pass through all layers to the opposite side. Once surface-mounting came into use, small-sized SMD components were used where possible, with through-hole mounting only of components unsuitably large for surface-mounting due to power requirements or mechanical limitations, or subject to mechanical stress which might damage the PCB (e.g. by lifting the copper off the board surface).



Through-hole (leaded) resistors



Through-hole devices mounted on the circuit board of a mid-1980s home computer



A box of <u>drill bits</u> used for making holes in printed circuit boards. While tungsten-carbide bits are very hard, they eventually wear out or break. Drilling is a considerable part of the cost of a through-hole printed circuit board.

Surface-mount technology

Surface-mount technology emerged in the 1960s, gained momentum in the early 1980s and became widely used by the mid-1990s. Components were mechanically redesigned to have small metal tabs or end caps that could be soldered directly onto the PCB surface, instead of wire leads to pass through holes. Components became much smaller and component placement on both sides of the board became more common than with through-hole mounting, allowing much smaller PCB assemblies with much higher circuit densities. Surface mounting lends itself well to a high degree of automation, reducing labor costs and greatly increasing production rates. Components can be supplied mounted on carrier tapes. Surface mount components can be about one-quarter to one-tenth of the size and weight of through-hole components, and passive components much cheaper. However, prices of semiconductor <u>surface mount devices</u> (SMDs) are determined more by the chip itself than the package, with little price advantage over larger packages, and some wire-ended components, such as 1N4148 small-signal switch diodes, are actually significantly cheaper than SMD equivalents.



Surface mount components, including resistors, transistors and an integrated circuit

Circuit properties of the PCB

Each trace consists of a flat, narrow part of the <u>copper</u> foil that remains after etching. Its <u>resistance</u>, determined by its width, thickness, and length, must be sufficiently low for the current the conductor will carry. Power and ground traces may need to be wider than signal traces. In a multi-layer board one entire layer may be mostly solid copper to act as a <u>ground plane</u> for shielding and power return. For <u>microwave</u> circuits, <u>transmission lines</u> can be laid out in <u>a planar form</u> such as <u>stripline</u> or <u>microstrip</u> with carefully controlled dimensions to assure a consistent <u>impedance</u>. In radio-frequency and fast switching circuits the <u>inductance</u> and <u>capacitance</u> of the printed circuit board conductors become significant circuit elements, usually undesired; conversely, they can be used as a deliberate part of the circuit design, obviating the need for additional discrete components.



A PCB in a computer mouse: the component side (left) and the printed side (right)

Materials

Laminates

Laminates are manufactured by curing under pressure and temperature layers of cloth or paper with thermoset resin to form an integral final piece of uniform thickness. The size can be up to 4 by 8 feet (1.2 by 2.4 m) in width and length. Varying cloth weaves (threads per inch or cm), cloth thickness, and resin percentage are used to achieve the desired final thickness and dielectric characteristics. Available standard laminate thickness are listed in ANSI/IPC-D-275. [10]

The cloth or fiber material used, resin material, and the cloth to resin ratio determine the laminate's type designation (FR-4, CEM-1, G-10, etc.) and therefore the characteristics of the laminate produced. Important characteristics are the level to which the laminate is <u>fire retardant</u>, the <u>dielectric constant</u> (e_r), the <u>loss factor</u> (t\delta), the <u>tensile strength</u>, the <u>shear strength</u>, the <u>glass transition temperature</u> (T_g), and the Z-axis expansion coefficient (how much the thickness changes with temperature).

There are quite a few different dielectrics that can be chosen to provide different insulating values depending on the requirements of the circuit. Some of these dielectrics are polytetrafluoroethylene (Teflon), FR-4, FR-1, CEM-1 or CEM-3. Well known pre-preg materials used in the PCB industry are FR-2 (phenolic cotton paper), FR-3 (cotton paper and epoxy), FR-5 (woven glass and epoxy), FR-6 (matte glass and polyester), G-10 (woven glass and epoxy), CEM-1 (cotton paper and epoxy), CEM-2 (cotton paper and epoxy), CEM-3 (non-woven glass and epoxy), CEM-4 (woven glass and epoxy), CEM-5 (woven glass and polyester). Thermal expansion is an important consideration especially with ball grid array (BGA) and naked die technologies, and glass fiber offers the best dimensional stability.

FR-4 is by far the most common material used today. The board stock with unetched copper on it is called "copper-clad laminate".

With decreasing size of board features and increasing frequencies, small nonhomogeneities like uneven distribution of fiberglass or other filler, thickness variations, and bubbles in the resin matrix, and the associated local variations in the dielectric constant, are gaining importance.

Key substrate parameters

The circuitboard substrates are usually dielectric composite materials. The composites contain a matrix (usually an epoxy resin) and a reinforcement (usually a woven, sometimes nonwoven, glass fibers, sometimes even paper), and in some cases a filler is added to the resin (e.g. ceramics; titanate ceramics can be used to increase the dielectric constant).

The reinforcement type defines two major classes of materials: woven and non-woven. Woven reinforcements are cheaper, but the high dielectric constant of glass may not be favorable for many higher-frequency applications. The spatially nonhomogeneous structure also introduces local variations in electrical parameters, due to different resin/glass ratio at different areas of the weave pattern. Nonwoven reinforcements, or materials with low or no reinforcement, are more expensive but more suitable for some RF/analog applications.

The substrates are characterized by several key parameters, chiefly thermomechanical (glass transition temperature, tensile strength, shear strength, thermal expansion), electrical (dielectric constant, loss tangent, dielectric breakdown voltage, leakage current, tracking resistance...), and others (e.g. moisture absorption).

At the glass transition temperature the resin in the composite softens and significantly increases thermal expansion; exceeding T_g then exerts mechanical overload on the board components - e.g. the joints and the vias. Below T_g the thermal expansion of the resin roughly matches copper and glass, above it gets significantly higher. As the reinforcement and copper confine the board along the plane, virtually all volume expansion projects to the thickness and stresses the plated-through holes. Repeated soldering or other exposition to higher temperatures can cause failure of the plating, especially with thicker boards; thick boards therefore require a matrix with a high T_g .

The materials used determine the substrate's dielectric constant. This constant is also dependent on frequency, usually decreasing with frequency. As this constant determines the signal propagation speed, frequency dependence introduces phase distortion in wideband applications; as flat a dielectric constant vs frequency characteristics as is achievable is important here. The impedance of transmission lines decreases with frequency, therefore faster edges of signals reflect more than slower ones.

Dielectric breakdown voltage determines the maximum voltage gradient the material can be subjected to before suffering a breakdown (conduction, or arcing, through the dielectric).

 $Tracking\ resistance\ determines\ how\ the\ material\ resists\ high\ voltage\ electrical\ discharges\ creeping\ over\ the\ board\ surface.$

Loss tangent determines how much of the electromagnetic energy from the signals in the conductors is absorbed in the board material. This factor is important for high frequencies. Low-loss materials are more expensive. Choosing unnecessarily low-loss material is a common engineering error in high-frequency digital design; it increases the cost of the boards without a corresponding benefit. Signal degradation by loss tangent and dielectric constant can be easily assessed by an eye pattern.

Moisture absorption occurs when the material is exposed to high humidity or water. Both the resin and the reinforcement may absorb water; water also may be soaked by capillary forces through voids in the materials and along the reinforcement. Epoxies of the FR-4 materials aren't too susceptible, with absorption of only 0.15%. Teflon has very low absorption of 0.01%. Polyimides and cyanate esters, on the other side, suffer from high water absorption. Absorbed water can lead to significant degradation of key parameters; it impairs tracking resistance, breakdown voltage, and dielectric parameters. Relative dielectric constant of water is about 73, compared to about 4 for common circuit board materials. Absorbed moisture can also vaporize on heating, as during soldering, and cause cracking and delamination, [11] the same effect responsible for "popcorning" damage on wet packaging of electronic parts. Careful baking of the substrates may be required to dry them prior to soldering, [12]

Common substrates

Often encountered materials:

• <u>FR-2</u>, phenolic paper or phenolic cotton paper, paper impregnated with a <u>phenol formaldehyde resin.</u> Common in consumer electronics with single-sided boards. Electrical properties inferior to FR-4. Poor arc resistance. Generally rated to 105 °C.

- FR-4, a woven fiberglass cloth impregnated with an epoxy resin. Low water absorption (up to about 0.15%), good insulation properties, good arc resistance. Very common. Several grades with somewhat different properties are available. Typically rated to 130 °C.
- Aluminum, or metal core board or insulated metal substrate (IMS), clad with thermally conductive thin dielectric used for parts requiring significant cooling power switches, LEDs. Consists of usually single, sometimes double layer thin circuit board based on e.g. FR-4, laminated on aluminum sheet metal, commonly 0.8, 1, 1.5, 2 or 3 mm thick. The thicker laminates sometimes also come with thicker copper metalization.
- Flexible substrates can be a standalone copper-clad foil or can be laminated to a thin stiffener, e.g. 50-130 µm
 - Kapton or <u>UPILEX</u>, [13] a <u>polyimide</u> foil. Used for <u>flexible printed circuits</u>, in this form common in small form-factor consumer electronics or for flexible interconnects. Resistant to high temperatures.
 - Pyralux, a polyimide-fluoropolymer composite foil. [14] Copper layer can delaminate during soldering.

Less-often encountered materials:

- FR-1, like FR-2, typically specified to 105 °C, some grades rated to 130 °C. Room-temperature punchable. Similar to cardboard. Poor moisture resistance. Low arc resistance.
- FR-3, cotton paper impregnated with epoxy. Typically rated to 105 °C.
- FR-5, woven fiberglass and epoxy, high strength at higher temperatures, typically specified to 170 °C.
- FR-6, matte glass and polyester
- G-10, woven glass and epoxy high insulation resistance, low moisture absorption, very high bond strength. Typically rated to 130 °C.
- G-11, woven glass and epoxy high resistance to solvents, high flexural strength retention at high temperatures. [15] Typically rated to 170 °C.
- CEM-1, cotton paper and epoxy
- CEM-2, cotton paper and epoxy
- CEM-3, non-woven glass and epoxy
- CEM-4, woven glass and epoxy
- CEM-5, woven glass and polyester
- <u>PTFE</u>, ("Teflon") expensive, low dielectric loss, for high frequency applications, very low moisture absorption (0.01%), mechanically soft. Difficult to laminate, rarely used in multilayer applications.
- PTFE, ceramic filled expensive, low dielectric loss, for high frequency applications. Varying ceramics/PTFE ratio allows adjusting dielectric constant and thermal expansion.
- RF-35, fiberglass-reinforced ceramics-filled PTFE. Relatively less expensive, good mechanical properties, good high-frequency properties. [16][17]
- Alumina, a ceramic. Hard, brittle, very expensive, very high performance, good thermal conductivity.
- Polyimide, a high-temperature polymer. Expensive, high-performance. Higher water absorption (0.4%). Can be used from cryogenic temperatures to over 260 °C.

Copper thickness

Copper thickness of PCBs can be specified directly or as the weight of copper per area (in ounce per square foot) which is easier to measure. One <u>ounce</u> per <u>square foot</u> is 1.344 mils or 34 micrometers thickness. Heavy copper is a layer exceeding three ounces of copper per ft^2 , or approximately 0.0042 inches (4.2 mils, 105 μ m) thick. Heavy copper layers are used for high current or to help dissipate heat.

On the common FR-4 substrates, 1 \underline{oz} copper per ft^2 (35 μm) is the most common thickness; 2 oz (70 μm) and 0.5 oz (18 μm) thickness is often an option. Less common are 12 and 105 μm , 9 μm is sometimes available on some substrates. Flexible substrates typically have thinner metalization. Metal-core boards for high power devices commonly use thicker copper; 35 μm is usual but also 140 and 400 μm can be encountered.

Safety certification (US)

Safety Standard UL 796 covers component safety requirements for printed wiring boards for use as components in devices or appliances. Testing analyzes characteristics such as flammability, maximum operating temperature, electrical tracking, heat deflection, and direct support of live electrical parts.

Design

Initially PCBs were designed manually by creating a <u>photomask</u> on a clear <u>mylar</u> sheet, usually at two or four times the true size. Starting from the schematic diagram the component pin pads were laid out on the mylar and then traces were routed to connect the pads. Rub-on <u>dry transfers</u> of common component footprints increased efficiency. Traces were made with self-adhesive tape. Pre-printed non-reproducing grids on the mylar assisted in layout. The finished photomask was <u>photolithographically</u> reproduced onto a photoresist coating on the blank copper-clad boards.

Modern PCBs are designed with dedicated layout software, generally in the following steps:[18]

- 1. Schematic capture through an electronic design automation (EDA) tool.
- 2. Card dimensions and template are decided based on required circuitry and case of the PCB.
- 3. The positions of the components and heat sinks are determined.
- 4. Layer stack of the PCB is decided, with one to tens of layers depending on complexity. Ground and power planes are decided. A power plane is the counterpart to a ground plane and behaves as an <u>AC</u> signal ground while providing DC power to the circuits mounted on the PCB. Signal interconnections are traced on signal planes. Signal planes can be on the outer as well as inner layers. For optimal <u>EMI</u> performance high frequency signals are routed in internal layers between power or ground planes.^[19]
- <u>Line impedance</u> is determined using dielectric layer thickness, routing copper thickness and trace-width. Trace separation is also
 taken into account in case of differential signals. <u>Microstrip</u>, <u>stripline</u> or dual stripline can be used to route signals.
- 6. Components are placed. Thermal considerations and geometry are taken into account. Vias and lands are marked
- 7. Signal traces are routed. Electronic design automation tools usually create clearances and connections in power and ground planes automatically.
- 8. Gerber files are generated for manufacturing. [20][21][22][23]

Manufacturing

PCB manufacturing consists of many steps.

PCB CAM

Manufacturing starts from the fabrication data generated by computer aided design, and component information. [20] The fabrication data is read into the CAM (Computer Aided



A board designed in 1967; the sweeping curves in the traces are evidence of freehand design using adhesive tape

Manufacturing) software. CAM performs the following functions: [24]

- 1. Input of the fabrication data. [20][23]
- 2. Verification of the data
- 3. Compensation for deviations in the manufacturing processes (e.g. scaling to compensate for distortions during lamination)
- 4. Panelization
- 5. Output of the digital tools (copper patterns, drill files, inspection, and others) [20]

Panelization

Several small printed circuit boards (of the same or of different designs) can be grouped together for processing as a panel. The assemblers often mount components on panels rather than single PCBs because this is efficient. [25]

The panel is eventually broken into individual PCBs along perforations or grooves in the panel. [26] Today depaneling is often done by lasers which cut the board with no contact. Laser depaneling reduces stress on the fragile circuits, improving the yield of defect-free units.

Copper patterning

The first step is to replicate the pattern in the fabricator's CAM system on a protective mask on the copper foil PCB layers. Subsequent etching removes the unwanted copper. (Alternatively, a conductive ink can be ink-jetted on a blank (non-conductive) board. This technique is also used in the manufacture of hybrid circuits.)

- 1. Silk screen printing uses etch-resistant inks to create the protective mask.
- 2. Photoengraving uses a photomask and developer to selectively remove a UV-sensitive photoresist coating and thus create a photoresist mask. Direct imaging techniques are sometimes used for high-resolution requirements. Experiments were made with thermal resist.^[27]
- 3. PCB milling uses a two or three-axis mechanical milling system to mill away the copper foil from the substrate. A PCB milling machine (referred to as a 'PCB Prototyper') operates in a similar way to a plotter, receiving commands from the host software that control the position of the milling head in the x, y, and (if relevant) z axis.
- 4. Laser resist ablation Spray black paint onto copper clad laminate, place into CNC laser plotter. The laser raster-scans the PCB and ablates (vaporizes) the paint where no resist is wanted. (Note: laser copper ablation is rarely used and is considered experimental.)

The method chosen depends on the number of boards to be produced and the required resolution.

Large volume

- Silk screen printing Used for PCBs with bigger features
- Photoengraving Used when finer features are required

Small volume

- Print onto transparent film and use as photo mask along with photo-sensitized boards, then etch. (Alternatively, use a film photoplotter)
- Laser resist ablation
- PCB milling

Hobbyist

- Laser-printed resist: Laser-print onto toner transfer paper, heat-transfer with an iron or modified laminator onto bare laminate, soak in water bath, touch up with a marker, then
 etch.
- Vinyl film and resist, non-washable marker, some other methods. Labor-intensive, only suitable for single boards.

Subtractive, additive and semi-additive processes

Subtractive methods remove copper from an entirely copper-coated board to leave only the desired copper pattern. In additive methods the pattern is <u>electroplated</u> onto a bare substrate using a complex process. The advantage of the additive method is that less material is needed and less waste is produced. In the full additive process the bare laminate is covered with a photosensitive film which is imaged (exposed to light through a mask and then developed which removes the unexposed film). The exposed areas are sensitized in a chemical bath, usually containing palladium and similar to that used for through hole plating which makes the exposed area capable of bonding metal ions. The laminate is then plated with copper in the sensitized areas. When the mask is stripped, the PCB is finished.

Semi-additive is the most common process: The unpatterned board has a thin layer of copper already on it. A reverse mask is then applied. (Unlike a subtractive process mask, this mask exposes those parts of the substrate that will eventually become the traces.) Additional copper is then plated onto the board in the unmasked areas; copper may be plated to any desired weight. Tin-lead or other surface platings are then applied. The mask is stripped away and a brief etching step removes the now-exposed bare original copper laminate from the board, isolating the individual traces. Some single-sided boards which have plated-through holes are made in this way. General Electric made consumer radio sets in the late 1960s using additive boards.

The (semi-)additive process is commonly used for multi-layer boards as it facilitates the plating-through of the holes to produce conductive vias in the circuit board.

Chemical etching

Chemical etching is usually done with ammonium persulfate or ferric chloride. For PTH (plated-through holes), additional steps of electroless deposition are done after the holes are drilled, then copper is electroplated to build up the thickness, the boards are screened, and plated with tin/lead. The tin/lead becomes the resist leaving the bare copper to be etched away.^[28]



PCB copper electroplating line in the process of pattern plating copper




PCBs in process of having copper pattern plated (note the blue dry film resist)

The simplest method, used for small-scale production and often by hobbyists, is immersion etching, in which the board is submerged in etching solution such as ferric chloride. Compared with methods used for mass production, the etching time is long. Heat and agitation can be applied to the bath to speed the etching rate. In bubble etching, air is passed through the etchant bath to agitate the solution and speed up etching. Splash etching uses a motor-driven paddle to splash boards with etchant; the process has become commercially obsolete since it is not as fast as spray etching. In spray etching, the etchant solution is distributed over the boards by nozzles, and recirculated by pumps. Adjustment of the nozzle pattern, flow rate, temperature, and etchant composition gives predictable control of etching rates and high production rates.^[29]

As more copper is consumed from the boards, the etchant becomes saturated and less effective; different etchants have different capacities for copper, with some as high as 150 grams of copper per litre of solution. In commercial use, etchants can be regenerated to restore their activity, and the dissolved copper recovered and sold. Small-scale etching requires attention to disposal of used etchant, which is corrosive and toxic due to its metal content.^[30]

The etchant removes copper on all surfaces exposed by the resist. "Undercut" occurs when etchant attacks the thin edge of copper under the resist; this can reduce conductor widths and cause open-circuits. Careful control of etch time is required to prevent undercut. Where metallic plating is used as a resist, it can "overhang" which can cause short-circuits between adjacent traces when closely spaced. Overhang can be removed by wire-brushing the board after etching. [29]



The two processing methods used to produce a double-sided PWB with plated-through holes

Lamination

Multi-layer printed circuit boards have trace layers inside the board. This is achieved by laminating a stack of materials in a press by applying pressure and heat for a period of time. This results in an inseparable one piece product. For example, a four-layer PCB can be fabricated by starting from a two-sided copper-clad laminate, etch the circuitry on both sides, then laminate to the top and bottom prepreg and copper foil. It is then drilled, plated, and etched again to get traces on top and bottom layers.^[31]

The inner layers are given a complete machine inspection before lamination because afterwards mistakes cannot be corrected. The automatic optical inspection system compares an image of the board with the digital image generated from the original design data. [32]

Drilling

Holes through a PCB are typically drilled with <u>drill bits</u> made of solid coated <u>tungsten carbide</u>. Coated tungsten carbide is used because board materials are abrasive. High-speed-steel bits would dull quickly, tearing the copper and ruining the board. Drilling is done by computer-controlled drilling machines, using a *drill file* or Excellon file that describes the location and size of each drilled hole.

Holes may be made conductive, by electroplating or inserting hollow metal eyelets, to connect board layers. Some conductive holes are intended for the insertion of through-hole-component leads. Others used to connect board layers, are called <u>vias</u>.

When very small vias are required, drilling with mechanical bits is costly because of high rates of wear and breakage. In this case, the vias may be laser drilled—evaporated by lasers. [33] Laser-drilled vias typically have an inferior surface finish inside the hole. These holes are called *micro vias*. [34][35]

It is also possible with *controlled-depth* drilling, laser drilling, or by pre-drilling the individual sheets of the PCB before lamination, to produce holes that connect only some of the copper layers, rather than passing through the entire board. These holes are called *blind vias* when they connect an internal copper layer to an outer layer, or *buried vias* when they connect two or more internal copper layers and no outer layers.



Cut through a SDRAM-module, a multi-layer PCB. Note the via, visible as a bright copper-colored band running between the top and bottom layers of the board.



Eyelets (hollow)

The hole walls for boards with two or more layers can be made conductive and then electroplated with copper to form *plated-through holes*.^[36] These holes electrically connect the conducting layers of the PCB. For multi-layer boards, those with three layers or more, drilling typically produces a *smear* of the high temperature decomposition products of bonding agent in the laminate system. Before the holes can be plated through, this smear must be removed by a chemical *de-smear* process, or by *plasma-etch*. The de-smear process ensures that a good connection is made to the copper layers when the hole is plated through. On high reliability boards a process called etch-back is performed chemically with a potassium permanganate based etchant or plasma.^[37] The etch-back removes resin and the glass fibers so that the copper layers extend into the hole and as the hole is plated become integral with the deposited copper.

Plating and coating

PCBs are plated with solder, tin, or gold over nickel and a resist for $\underline{\text{etching}}$ away the unneeded underlying copper. [40][41]

After PCBs are etched and then rinsed with water, the solder mask is applied, and then any exposed copper is coated with solder, nickel/gold, or some other anti-corrosion coating. [42][43]

Matte solder is usually fused to provide a better bonding surface for bare copper. Treatments, such as <u>benzimidazolethiol</u>, prevent surface oxidation of bare copper. The places to which components will be mounted are typically plated, because untreated bare copper oxidizes quickly, and therefore is not readily solderable. Traditionally, any exposed copper was coated with solder by <u>hot air solder levelling</u> (HASL). The HASL finish prevents oxidation from the underlying copper, thereby guaranteeing a solderable surface. [44] This solder was a <u>tin-lead</u> alloy, however new solder compounds are now used to achieve compliance with the <u>RoHS</u> directive in the <u>EU</u>, which restricts the use of lead. One of these lead-free compounds is SN100CL, made up of 99.3% tin, 0.7% copper, 0.05% nickel, and a nominal of 60 ppm germanium.

It is important to use solder compatible with both the PCB and the parts used. An example is <u>ball grid array</u> (BGA) using tin-lead solder balls for connections losing their balls on bare copper traces or using lead-free solder paste.

Other platings used are OSP (organic surface protectant), immersion silver (\underline{IAg}), immersion tin, electroless nickel with immersion gold coating (\underline{ENIG}), electroless nickel electroless palladium immersion gold (\underline{ENEPIG}) and direct gold plating (over nickel). \underline{Edge} connectors, placed along one edge of some boards, are often nickel-plated then gold-plated. Another coating consideration is rapid diffusion of coating metal into tin solder. Tin forms intermetallics such as Cu_6Sn_5 and Ag_3Cu that dissolve into the Tin liquidus or solidus(@5oC), stripping surface coating or leaving voids.

Electrochemical migration (ECM) is the growth of conductive metal filaments on or in a printed circuit board (PCB) under the influence of a DC voltage bias. [45][46] Silver, zinc, and aluminum are known to grow whiskers under the influence of an electric field. Silver also grows conducting surface paths in the presence of halide and other ions, making it a poor choice for electronics use. Tin will grow "whiskers" due to tension in the plated surface. Tin-lead or solder plating also grows whiskers, only reduced by reducing the percentage of tin. Reflow to melt solder or tin plate to relieve surface stress lowers whisker incidence. Another coating issue is tin pest, the transformation of tin to a powdery allotrope at low temperature. [47]

Solder resist application

Areas that should not be soldered may be covered with solder resist (solder mask). One of the most common solder resists used today is called "LPI" (liquid photoimageable solder mask). (It is a photo-sensitive coating is applied to the surface of the PWB, then exposed to light through the solder mask image film, and finally developed where the unexposed areas are washed away. Dry film solder mask is similar to the dry film used to image the PWB for plating or etching. After being laminated to the PWB surface it is imaged and developed as LPI. Once but no longer commonly used, because of its low accuracy and resolution, is to screen print epoxy ink. In addition to repelling solder, solder resist also provides protection from the environment to the copper that would otherwise be exposed.

Legend printing

A legend is often printed on one or both sides of the PCB. It contains the component designators, switch settings, test points and other indications helpful in assembling, testing, servicing, and sometimes using the circuit board. [49][50]

There are three methods to print the legend.

- 1. Silk screen printing epoxy ink was the established method. It was so common that legend is often misnamed silk or silkscreen.
- 2. Liquid photo imaging is a more accurate method than screen printing.
- 3. Ink jet printing is new but increasingly used. Ink jet can print variable data, unique to each PWB unit, such as text or a bar code with a serial number.


Bare-board test

Boards with no components installed are usually bare-board tested for "shorts" and "opens". A short is a connection between two points that should not be connected. An open is a missing connection between points that should be connected. For high-volume production, a fixture or a rigid needle adapter makes contact with copper lands on the board. The fixture or adapter is a significant fixed cost and this method is only economical for high-volume or high-value production. For small or medium volume production flying probe testers are used where test probes are moved over the board by an XY drive to make contact with the copper lands. There is no need for a fixture and hence the fixed costs are much lower. [51] The CAM system instructs the electrical tester to apply a voltage to each contact point as required and to check that this voltage appears on the appropriate contact points and only on these.

Assembly

In assembly the bare board is populated (or "stuffed") with electronic components to form a functional *printed circuit assembly* (PCA), sometimes called a "printed circuit board assembly" (PCBA). [52][53] In through-hole technology, the component leads are inserted in holes surrounded by conductive *pads*, the holes keep the components in place. In <u>surface-mount technology</u> (SMT), the component is placed on the PCB so that the pins line up with the conductive *pads* or *lands* on the surfaces of the PCB; solder paste, which was previously applied to the pads, holds the components in place temporarily; if surface-mount components are applied to both sides of the board, the bottom-side components are glued to the board. In both through hole and surface mount, the components are then <u>soldered</u>; once cooled and solidified, the solder holds the components in place permanently and electrically connects them to the board.

There are a variety of soldering techniques used to attach components to a PCB. High volume production is usually done with a "Pick and place machine" or \underline{SMT} placement machine and bulk wave soldering or \underline{reflow} ovens, but skilled technicians are able to hand-solder very tiny parts (for instance 0201 packages which are 0.02 in. by 0.01 in.)^[54] under a $\underline{microscope}$, using tweezers and a fine-tip $\underline{soldering}$ iron,



PCB with test connection pads

for small volume prototypes. Some SMT parts cannot be soldered by hand, such as <u>BGA</u> packages. All through-hole components can be hand soldered, making them favored for prototyping where size, weight, and the use of the exact components that would be used in high volume production are not concerns.

Often, through-hole and surface-mount construction must be combined in a single assembly because some required components are available only in surface-mount packages, while others are available only in through-hole packages. Or, even if all components are available in through-hole packages, it might be desired to take advantage of the size, weight, and cost reductions obtainable by using some available surface-mount devices. Another reason to use both methods is that through-hole mounting can provide needed strength for components likely to endure physical stress (such as connectors that are frequently mated and demated or that connect to cables expected to impart substantial stress to the PCB-and-connector interface), while components that are expected to go untouched will take up less space using surface-mount techniques. For further comparison, see the SMT page.

After the board has been populated it may be tested in a variety of ways:

- While the power is off, visual inspection, automated optical inspection. <u>JEDEC</u> guidelines for PCB component placement, soldering, and inspection are commonly used to maintain <u>quality control</u> in this stage of PCB manufacturing.
- While the power is off, analog signature analysis, power-off testing.
- While the power is on, in-circuit test, where physical measurements (for example, voltage) can be done.
- While the power is on, functional test, just checking if the PCB does what it had been designed to do.

To facilitate these tests, PCBs may be designed with extra pads to make temporary connections. Sometimes these pads must be isolated with resistors. The in-circuit test may also exercise <u>boundary scan</u> test features of some components. In-circuit test systems may also be used to program nonvolatile memory components on the board.

In boundary scan testing, test circuits integrated into various ICs on the board form temporary connections between the PCB traces to test that the ICs are mounted correctly. Boundary scan testing requires that all the ICs to be tested use a standard test configuration procedure, the most common one being the Joint Test Action Group (JTAG) standard. The JTAG test architecture provides a means to test interconnects between integrated circuits on a board without using physical test probes, by using circuitry in the ICs to employ the IC pins themselves as test probes. JTAG tool vendors provide various types of stimuli and sophisticated algorithms, not only to detect the failing nets, but also to isolate the faults to specific nets, devices, and pins. [56]

When boards fail the test, technicians may desolder and replace failed components, a task known as rework.

Protection and packaging

PCBs intended for extreme environments often have a <u>conformal coating</u>, which is applied by dipping or spraying after the components have been soldered. The coat prevents corrosion and leakage currents or shorting due to condensation. The earliest conformal coats were <u>wax</u>; modern conformal coats are usually dips of dilute solutions of silicone rubber, polyurethane, acrylic, or epoxy. Another technique for applying a conformal coating is for plastic to be <u>sputtered</u> onto the PCB in a vacuum chamber. The chief disadvantage of conformal coatings is that servicing of the board is rendered extremely difficult.^[56]

Many assembled PCBs are static sensitive, and therefore they must be placed in antistatic bags during transport. When handling these boards, the user must be grounded (earthed). Improper handling techniques might transmit an accumulated static charge through the board, damaging or destroying components. The damage might not immediately affect function but might lead to early failure later on, cause intermittent operating faults, or cause a narrowing of the range of environmental and electrical conditions under which the board functions properly. Even bare boards are sometimes static sensitive: traces have become so fine that it's quite possible to blow an etch off the board (or change its characteristics) with a static charge. This is especially true on non-traditional PCBs such as MCMs and microwave PCBs.

Cordwood construction

Cordwood construction can save significant space and was often used with <u>wire-ended components</u> in applications where space was at a premium (such as <u>fuzes</u>, missile guidance, and telemetry systems) and in high-speed <u>computers</u>, where short traces were important. In cordwood construction, axial-leaded components were mounted between two parallel planes. The components were either soldered together with jumper wire, or they were connected to other components by thin nickel ribbon welded at right angles onto the component leads.^[57] To avoid shorting together different interconnection layers, thin insulating cards were placed between them. Perforations or holes in the cards allowed component leads to project through to the next interconnection layer. One disadvantage of this system was that special <u>nickel</u>-leaded components had to be used to allow the interconnecting welds to be made. Differential



A cordwood module


thermal expansion of the component could put pressure on the leads of the components and the PCB traces and cause mechanical damage (as was seen in several modules on the Apollo program). Additionally, components located in the interior are difficult to replace. Some versions of cordwood construction used soldered single-sided PCBs as the interconnection method (as pictured), allowing the use of normal-leaded components.

Before the advent of <u>integrated circuits</u>, this method allowed the highest possible component packing density; because of this, it was used by a number of computer vendors including <u>Control Data Corporation</u>. The cordwood method of construction was used only rarely once semiconductor electronics and PCBs became widespread.

Multiwire boards

Multiwire is a patented technique of interconnection which uses machine-routed insulated wires embedded in a non-conducting matrix (often plastic resin). It was used during the 1980s and 1990s. (Kollmorgen Technologies Corp, <u>U.S. Patent 4,175,816</u> (https://www.google.com/patents/US4175816) filed 1978) As of 2010, Multiwire was still available through Hitachi.

Since it was quite easy to stack interconnections (wires) inside the embedding matrix, the approach allowed designers to forget completely about the routing of wires (usually a time-consuming operation of PCB design): Anywhere the designer needs a connection, the machine will draw a wire in a straight line from one location/pin to another. This led to very short design times (no complex algorithms to use even for high density designs) as well as reduced crosstalk (which is worse when wires run parallel to each other—which almost never happens in Multiwire), though the cost is too high to compete with cheaper PCB technologies when large quantities are needed



Cordwood construction was used in proximity fuzes.

Corrections can be made to a Multiwire board more easily than to a PCB. $^{\mbox{\scriptsize [58]}}$

There are other competitive discrete wiring technologies that have been developed (Jumatech [1] (http://www.jumapcb.com/), layered sheets).

See also

- Breadboard
- <u>C.I.D.+</u>
- Design for manufacturability (PCB)
- Electronic packaging
- Electronic waste

- Multi-chip module
- Occam process another process for the manufacturing of PCBs
- Point-to-point construction
- Printed electronics creation of components by printing
- Printed circuit board milling
- Stripboard
- Veroboard
- Wire wrap

PCB materials

- Conductive ink
- Laminate materials:
 - BT-Epoxy
 - Composite epoxy material, CEM-1,5
 - Cyanate Ester
 - FR-2
 - FR-4, the most common PCB material
 - Polvimide
 - PTFE, Polytetrafluoroethylene (Teflon)

PCB layout software

- List of EDA companies
- Comparison of EDA software

References

- 1. "iconnect007 :: Article" (http://www.iconnect007.com/index.php/article/92973/worldpcb-production-in-2014-estimated-at-602b/92976/?skin=pcb). www.iconnect007.com. Retrieved 2016-04-12
- 2. US 1256599 (https://worldwide.espacenet.com/textdoc? DB=EPODOC&IDX=US1256599)
- 3. Charles A. Harper, Electronic materials and processes handbook, McGraw-Hill, 2003 ISBN 0-07-140214-4, pages 7.3 and 7.4
- 4. Brunetti, Cledo (22 November 1948). New Advances in Printed Circuits. Washington 20. Tavernier, Karel. "PCB Fabrication Data A DC: National Bureau of Standards.
- 5. Engineers' Day, 1984 Award Recipients (http://www.engr.wisc.edu/eday/eday1984.html), College of Engineering, University of Wisconsin-Madison
- 6. US 2756485 (https://worldwide.espacenet.com/textdoc? DB=EPODOC&IDX=US2756485) assigned to US Army. July 31, 1956.
- 8. "What is a Breakout Board for Arduino?" (https://programmingelectronics.com/whatis-a-breakout-board-for-arduino/). programmingelectronics.com
- 9. Electronic Packaging: Solder Mounting Technologies in K.H. Buschow et al (ed). Encyclopedia of Materials: Science and Technology (https://books.google.com/books?id=TyVVAAAAMAAJ), Elsevier, 2001 ISBN 0-08-043152-6, pages 2708-2709
- 10. "Design Standard for Rigid Printed Boards and Rigid Printed Board Assemblies". IPC. September 1991, IPC-4101.
- 11. Sood, B. and Pecht, M. 2011, Printed Circuit Board Laminates, Wiley Encyclopedia of Composites. 1-11.
- 12. By Lee W. Ritchey, Speeding Edge (November 1999). "A SURVEY AND TUTORIAL OF DIELECTRIC MATERIALS USED IN THE MANUFACTURE OF PRINTED $\underline{\textbf{CIRCUIT BOARDS" (http://speedingedge.com/PDF-Files/tutorial.pdf)}} \ (\texttt{PDF}).$ Circuitree magazine.
- 13. "Applications | UBE Heat Resistant Polyimide Materials" (http://www.upilex.jp/en/application.html). UBE, upilex.jp.

15. Carter, Bruce (19 March 2009). "Op Amps for

- 14. "Pyralux® Flexible Circuit Materials DuPont DuPont USA" (http://www.dupont.com/products-and-services/electronic-electricalmaterials/flexible-rigidflex-circuit-materials/brands/pyralux-flexible-circuit.html)
- Everyone" (https://books.google.cz/books? id=nnCNsjpicJIC&pg=PA475&lpg=PA475&dq=printed%20circuit%20board% 20materials%20%22fr-1% 22&source=bl&ots=uKXeq5pcNy&sig=6oufyctNShkLh5Po5EU6VZU84MA&hl=en&sa= 20circuit%20board%20materials%20%22fr-1%22&f=false). Newnes - via Google
- 16. "A High Performance, Economical RF/Microwave Substrate" (http://www.microwavejournal.com/articles/2426-a-high-performanceeconomical-rf-microwave-substrate). Microwavejournal.

- 17. "RF-35 datasheet" (http://www.multi-circuitboards.eu/fileadmin/user_upload/downloads/e_taconic_rf35-hf_www.multi-circuitboards.eu.pdf) (PDF). Taconic - via Multi-CB.
- 18. Printed Circuit Board Design Flow Methodology (http://www.cs.berkeley.edu/~prabal/teaching/cs194-05-s08/cs194-designflow.ppt)
- "See appendix D of IPC-2251" (http://www.lg-advice.ro/pdf/IPC-2251-cuprins.pdf) (PDF)
- Guide" (http://www.ucamco.com/downloads). Ucamco. Retrieved 8 January 2015.
- 21. Vermeire, Filip. "PCB Fabrication Data Example 1" (http://www.ucamco.com/downloads). Ucamco. Ucamco. Retrieved 7 January
- 22. Vermeire, Filip. "PCB Fabrication Data Example 2" (http://www.ucamco.com/downloads). Ucamco. Ucamco. Retrieved 7 January
- "The Gerber File Format Specification" (http://www.ucamco.com/downloads) Ucamco. Retrieved 8 January 2015
- 24. "Frontend data preparation" (http://www.eurocircuits.com/Frontend-datapreparation/). Eurocircuits. Retrieved 1 April 2017.
- "Making a PCB Educational movies" (http://www.eurocircuits.com/index.php/making-a-pcb-eductional-movies). Eurocircuits, Eurocircuits, Retrieved 20 January 2015
- 26. Kraig Mitzner, Complete PCB Design Using OrCad Capture and Layout (https://books.google.com/books?id=z7RCh8bK6_8C), pages 443-446, Newnes, 2011 ISBN 0080549209
- 27. Itshak Taff, Hai Benron. "Liquid Photoresists for Thermal Direct Imaging". The Board Authority, October 1999.
- 28. Riley, Frank; Production, Electronic Packaging and (2013-06-29). The Electronics Assembly Handbook (https://books.google.com/books?id=mFjuCAAAQBAJ). Springer Science & Business Media. p. 285. ISBN 9783662131619.
- 29. R. S. Khandpur, Printed circuit boards: design, fabrication, assembly and testing, Tata-McGraw Hill, 2005 ISBN 0-07-058814-7, pages 373-378
- 30. Bosshart (1983-01-01). Printed Circuit Boards: Design and Technology (https://books.google.com/books?id=6OwRb7N3j14C). Tata McGraw-Hill Education. p. 298. ISBN 9780074515495
- 31. Chenxi (1 January 2016). "32 Layer Printed Circuit Boards" (http://www.wellpcb.com/news/32-layer-printed-circuit-boards.html) www.wellpcb.com. Retrieved 2017-05-03
- "Inner layer inspection" (http://www.eurocircuits.com/index.php/making-a-pcbeductional-movies/39-register-punch-and-automatic-optical-inspection-aoi) Eurocircuits. Retrieved 31 Aug 2013.
- ${\tt 33.} \ \underline{\sf https://www.orbotech.com/products/categories/pcb/uv-laser-drilling}$
- 34. Julia, lia (20 November 2011). <u>"PCB assembly, PCB assembly quote, Printed Circuit</u> Board Assembly" (https://www.ourpcb.com/pcb-assembly). www.ourpcb.com/ OURPCB. Retrieved 29 December 2016.

- 35. http://www.magazines007.com/pdf/PCB-May2013.pdf%7Ctitle= Microvia Fabrication: When to drill, When to Blast
- "Making Holes Conductive" (http://www.omgi.com/product-elemakingholeconduct.html). Electronic Chemicals. Retrieved 5 Sep 2012.
- "Electro-Brite E-Prep
 Desmear/Etchback" (http://www.electrochemicals.com/ecframe.html). OM Group,
 Inc. Retrieved 5 Sep 2012.
- 38. https://www.dfrsolutions.com/hubfs/Resources/services/Selecting-a-PCB-Surface-Finish.pdf?t=1509023781105
- http://www.dfrsolutions.com/hubfs/DfR_Solutions_Website/Resources-Archived/Publications/2008-2010/2010_SMTAI_2010_Schueller.pdf
- Appendix F Sample Fabrication Sequence for a Standard Printed Circuit Board (http://books.nap.edu/openbook.php?record_id=11515&page=77), Linkages: Manufacturing Trends in Electronics Interconnection Technology, National Academy of Sciences
- 41. Production Methods and Materials 3.1 General
 (http://epa.gov/dfe/pubs/pwb/tech_rep/p2_report/p2_sec3.htm) Printed Wiring Board
 Project Report Table of Contents, Design for the Environment (DfE), US EPA
- 42. George Milad and Don Gudeczauskas. "Solder Joint Reliability of Gold Surface Finishes (ENIG, ENEPIG and DIG) for PWB Assembled with Lead Free SAC Alloy (http://www.uyemura.com/solder-joint-reliability-of-gold-surface-finishes-ENIG-ENEPIG-DIG.htm)."
- 43. "Nickel/Gold tab plating line" (http://renovare.com/Application%20_brief_2.pdf)
- 44. "Soldering 101 A Basic Overview" (http://www.indium.com/_dynamo/download.php?docid=27)
- IPC Publication IPC-TR-476A, "Electrochemical Migration: Electrically Induced Failures in Printed Wiring Assemblies," Northbrook, IL, May 1997.
- S.Zhan, M. H. Azarian and M. Pecht, "Reliability Issues of No-Clean Flux Technology with Lead-free Solder Alloy for High Density Printed Circuit Boards (https://www.calce.umd.edu/articles/abstracts/2005/density.htm)", 38th International Symposium on Microelectronics, pp. 367–375, Philadelphia, PA, September 25–29, 2005.

- Clyde F. Coombs *Printed Circuits Handbook* McGraw–Hill Professional, 2007 ISBN 0-07-146734-3, pages 45–19
- "liquid photoimageable solder masks" (http://www.coates.de/ccp/connections/liquid.pdf) (PDF). Coates Circuit Products. Retrieved 2 Sep 2012.
- "Silk-screen and cure" (http://www.eurocircuits.com/index.php/making-a-pcb-eductional-movies/49-silk-screen-and-cure). Eurocircuits. Retrieved 31 Aug 2013.
- 50. "Towards a more rational silkscreen" (http://xenoa.co.uk/2017/12/16/printed-circuitsmade-silk-screen-technique/). Optimum Design Associates. Retrieved 31 Aug 2013.
- "Electrical test" (http://www.eurocircuits.com/Electrical-test). Eurocircuits. Retrieved
 Apr 2015.
- Ayob, M.; Kendall, G. (2008). "A Survey of Surface Mount Device Placement Machine Optidmisation: Machine Classification". European Journal of Operational Research. 186 (3): 893–914. doi:10.1016/j.ejor.2007.03.042 (https://doi.org/10.1016%2Fj.ejor.2007.03.042).
- 53. Ayob, M.; Kendall, G. (2005). "A Triple Objective Function with a Chebychev Dynamic Pick-and-place Point Specification Approach to Optimise the Surface Mount Placement Machine" (http://www.cs.nott.ac.uk/~gxk/gxk1/../papers/mxaejor2005.pdf) (PDF). European Journal of Operational Research. 164 (3): 609–626. doi:10.1016/j.ejor.2003.09.034 (https://doi.org/10.1016%2Fj.ejor.2003.09.034).
- Borkes, Tom. "SMTA TechScan Compendium: 0201 Design, Assembly and <u>Process" (http://www.smta.org/files/smta_techscan_0201_overview.pdf)</u> (PDF). Surface Mount Technology Association. Retrieved 2010-01-11.
- 55. JTAG Tutorial (http://www.corelis.com/education/JTAG_Tutorial.htm#History)
- Shibu. Intro To Embedded Systems 1E. Tata McGraw-Hill. p. 293. <u>ISBN</u> <u>978-0-07-</u> 014589-4.
- 57. Wagner, G. Donald (1999). "History of Electronic Packaging at APL: From the VT Fuze to the NEAR

 Spacecraft" (http://www.jhuapl.edu/techdigest/TD/td2001/Wagner.pdf) (PDF). Johns Hopkins APL Technical Digest. 20 (1). Retrieved 2016-12-19.
- David E. Weisberg. "Chapter 14: Intergraph" (http://www.cadhistory.net/14% 20Intergraph.pdf). 2008. p. 14-8.

External links

- PCB Fabrication Data A Guide (http://www.ucamco.com/files/downloads/file/130/pcb_fabrication_a_guide_20150107.pdf)
- The Gerber Format Specification (http://www.ucamco.com/downloads/the_gerber_file_format_specification.pdf)

Retrieved from "https://en.wikipedia.org/w/index.php?title=Printed_circuit_board&oldid=826942095"

This page was last edited on 21 February 2018, at 21:24.

Text is available under the Creative Commons Attribution-ShareAlike License; additional terms may apply. By using this site, you agree to the Terms of Use and Privacy Policy. Wikipedia® is a registered trademark of the Wikimedia Foundation, Inc., a non-profit organization.