

API 4: Room Boundaries Python in Dynamo

Related videos








MAKING A CUSTOM PACKAGE



PYTHON FUNDAMENTALS



PYTHON IN DYNAMO (SERIES)



Dynamo and Python Room Boundaries (API 4)

This video

Navigate Revit API Docs

Unwrap Rooms

Obtaining area calc settings

Obtaining bounding curves, and returning as a prototype

```
R Python Script
9 import clr
10 clr.AddReference('DynamoRevitDS')
11 import Dynamo
12 from System import Environment
14 #Add document manager from Revit services
15 clr.AddReference('RevitServices')
16 import RevitServices
17 from RevitServices.Persistence import DocumentManager
20 DynamoCurrent = Dynamo.Applications.DynamoRevit()
21 ActiveScript = DynamoCurrent.RevitDynamoModel.CurrentWorkspace
22 DynamoVersion = DynamoCurrent.RevitDynamoModel.Version
24 # ensure version 2.X, get name
25 if DynamoVersion.StartsWith("2."):
      ScriptName = ActiveScript.Name + ".dyn"
27 else:
      ScriptName = "Version not supported"
30 # get system user name
31 UserName = Environment.UserName
```

Let's get into the example!

Rooms to Areas

3 part API based workflow

1. Room boundaries

2. Area lines from bounds

3. Areas from rooms

Room Boundaries

We need to obtain the

BoundarySegments of our rooms (which are spatial elements)

GetBoundarySegments Method

SpatialElement Class See Also

Returns the boundary segments.

Syntax

C#

Boundary Curves

We will need to obtain the boundary curves using

BoundarySegment class and GetCurve method

GetCurve Method

BoundarySegment Class

See Also

Get a copy of the curve that is formed along this boundary.

Syntax


C#


public Curve GetCurve()


Curves to Prototypes

We will need to convert our Revit curves back to Dynamo

Using the ToPrototype() method







We need to inspect the AreaVolumeSettings class

GetAreaVolumeSettings Method

AreaVolumeSettings Class

See Also

Get the area and volume settings of the project.

Syntax

C#

We need to obtain the

SpatialElementBoundaryOption setting (enumerated)

SpatialElementBoundaryLocation Property

SpatialElementBoundaryOptions Class

See Also

The boundary of spatial element for geometry calculation.

Syntax

C#

public SpatialElementBoundaryLocation SpatialElementBoundaryLocation { get; set; }

We need to obtain the

SpatialElementBoundaryLocation enumerated property value

Syntax

C#

public enum SpatialElementBoundaryLocation

	Member name	Description
	Finish	Spatial element finish face.
	Center	Spatial element centerline.
	CoreBoundary	Spatial element core boundary.
	CoreCenter	Spatial element core center.


Future Videos

Basic samples

Revit API

Advanced samples

And more!






Crumple is on github

https://github.com/aussieBIMguru





API 4: Room Boundaries Python in Dynamo