

	Function			
GPIO	F1	F2	F3	
0	SPI0 RX	UARTO TX	I2C0 SDA	
1	SPI0 CSn	UARTO RX	I2C0 SCL	
2	SPI0 SCK	UARTO CTS	I2C1 SDA	
3	SPI0 TX	UARTO RTS	I2C1 SCL	
4	SPI0 RX	UART1 TX	I2C0 SDA	
5	SPI0 CSn	UART1 RX	I2C0 SCL	
6	SPI0 SCK	UART1 CTS	I2C1 SDA	
7	SPI0 TX	UART1 RTS	I2C1 SCL	
8	SPI1 RX	UART1 TX	I2C0 SDA	
9	SPI1 CSn	UART1 RX	I2C0 SCL	
10	SPI1 SCK	UART1 CTS	I2C1 SDA	
11	SPI1 TX	UART1 RTS	I2C1 SCL	
12	SPI1 RX	UARTO TX	I2C0 SDA	
13	SPI1 CSn	UARTO RX	I2C0 SCL	
14	SPI1 SCK	UARTO CTS	I2C1 SDA	
15	SPI1 TX	UARTO RTS	I2C1 SCL	
16	SPI0 RX	UARTO TX	I2C0 SDA	
17	SPI0 CSn	UARTO RX	I2C0 SCL	
18	SPI0 SCK	UARTO CTS	I2C1 SDA	
19	SPI0 TX	UARTO RTS	I2C1 SCL	
20	SPI0 RX	UART1 TX	I2C0 SDA	
21	SPI0 CSn	UART1 RX	I2C0 SCL	

QSPI_CS 1 QSPI_SD1 2 QSPI_SD2 3	OCS# DO(IO1) IO2 GND	EP VCC 103 CLK D1(100)	9	CLK
Ŧ	IISON-8_L6.0-W5.0-F	P1.27-BL-EP		

v1.1 修复电池采集和开关电路 增加esd保护 移动排母位置 修改安装孔为1.6 v1.2_20240317 spi的引脚有误,已修正 sd卡座突出,后移一些 1.9寸307颠倒引脚顺序,已修正 2.13寸颠倒引脚顺序,已修正 修复开关丝印 beep使用GP8,扩展io为GP7 增加resst按钮













