

Rev. A Printed Parts Guide (Voron Trident Kit)

Refer to the **Part Printing Guidelines** section of the official [assembly manual](#) [↗](#) for general print settings. For the latest part files, visit the Voron [Github repository](#) [↗](#). If you do not have the means to print your own parts in ABS, the [Voron Print It Forward program](#) [↗](#) is a great option to obtain the parts at a very reasonable cost. If you do plan on printing the parts, refer to the following directions for LDO kit specific options:

Colour Coding

- ▶ Purple - These are not optional and must be printed for our kit to work.
- ▶ Blue - These are optional parts/changes that improve fit, appearance, or quality of life.

Part Guide

- ▶ **Nozzle Probe**- Our kit includes a Z endstop PCB for better modularity, use [this part](#) [↗](#) instead.
- ▶ **Clockwork2 Parts**- These parts from [here](#) [↗](#) is required so the toolhead PCB can mount the Clockwork2 extruder
- ▶ **Cable Chain Parts** - Our cable chain ends use the 2 hole configuration. When printing parts that interface with cable chains, always use the **2hole** version instead of **3hole** version (e.g. `xy_joint_cable_bridge_2hole` instead of `xy_joint_cable_bridge_3hole`)
- ▶ **Plug Panel**- Our kits ship with 1.2mm AC inlets with integrated switches. Use [this part](#) [↗](#) instead which is better adapted for 1.2mm inlets than the original `power_inlet_adamstech`.
- ▶ **Z Cable Anchor** - The LDO deck panel has a Z cable opening that is in a slightly different position than the original `z_cable_chain_mount_2hole`. Use [this part](#) [↗](#) to match up with the different hole position.
- ▶ **Deck Wire Cover** - The LDO deck panel has a larger rear right opening to fit larger connectors, use [this part](#) [↗](#) instead of the original `wire_cover_right` to cover the larger opening which should be attached after wiring is complete. Note that `wire_cover_left` is **unchanged**.
- ▶ **XY Endstop** - Our kit includes the [XY microswitch PCB](#) [↗](#), print [\[a\]_endstop_pod_D2F_switch.stl](#) [↗](#) instead of `[a]_endstop_pod_hall_effect`. Also, `[a]_y_endstop_housing` is not needed.
- ▶ **Breakout PCB Mount** - This [part](#) [↗](#) works with the toolhead breakout PCB. Use 4 M2x10 self-tapping screws to attach the PCB to the part. Also print a [DIN clip](#) [↗](#) to mount onto the DIN rail.
- ▶ **Controller Mount** - Our rev. A kits ship with the BigTreeTech Octopus V1.1 controllers, the corresponding pcb mount can be found in the [here](#) [↗](#), don't forget to also print two [DIN clips](#) [↗](#).
- ▶ **Beefy Raspberry Pi Mount** - [this](#) [↗](#) optional Raspberry Pi mount uses two DIN clips instead of one for an extra secure grip on the DIN rails. **Tip:** if you find it difficult to insert the USB/Ethernet cables due to a lack

of space, try rotating the RPi in relation to its mount.

- ▶ **Deck Support**- The LDO deck panel has a 4mm nominal thickness, use [deck_support_4mm](#) instead of its 3mm counterpart. 12 pieces are needed, if you follow our 250 wiring guide.
- ▶ **Heatbed Wiring Mount** - Print [this part](#) to mount the WAGO terminals and PCB, which are used to breakout the heatpad power and thermistor cables.
- ▶ **Touch Screen Mount** - For Trident Batch 1 users who received the Waveshare touchscreen, print this [mod](#) to install your touchscreen display. For all other users, you should have received the BigTreeTech touchscreen, print the mount from [here](#) . Do not print the *mini12864* parts under *STLs/Skirt*.
- ▶ **LED/Fan Splitter Spacer** - We include two 3x2 XH splicing PCBs. which are used to join two LED strips or two fans into a single cable. print two of [these](#) to mount the PCB to a 2020 extrusion.
- ▶ **LED Light Clip** - The included LED light strips can be mounted using these [bar clips](#) by eddie. In total, you will need 36 or 42 clips for Trident 250 and 300 respectively.
- ▶ **Handlebar Spacer** - This optional [part](#) offsets the top panel thickness and helps mount the included aluminum handlebar. Mount with M5x14 screws.
- ▶ **LDO Insert** - Show some LDO love and print this [optional insert](#) that can be installed into the skirts on your machine.

Mods

- ▶ **Klicky Probe** - We include parts for the optional Klicky probe mod by jlas1, check out more info on the mod [here](#) .
- ▶ **Nevermore Filter** - Our Rev.A kits include parts to build a [Nevermore Micro V5](#) by 0dsk4. print the version which uses 3x6 magnets. If you decide to build the Nevermore filter, print this [exhaust cover](#) with the stock [exhaust grill](#) to seal the back panel.
- ▶ **Purge Bucket** - Our kit includes a brass brush which you can convert into automated nozzle scrubber using this [mod](#) . Our build plate is slightly taller than standard so modified sheet stop files can be printed [here](#) .